



MAGNUM[®] TRUEAIRLESS[™]

Electric Airless Sprayer



OWNERS MANUAL

LTS 15, LTS 17, ProLTS 170, ProLTS 190

3A3529C

EN



WARNING

FIRE AND EXPLOSION HAZARD

LTS 15/LTS 17 Models:

- Use only non-flammable or water-based materials, or non-flammable paint thinners. Do not use materials having flash points lower than 100° F (38° C). This includes, but is not limited to, acetone, xylene, toluene, or naphtha. For more information about your material, request Safety Data Sheet (SDS) from the supplier.
- Spraying flammable or combustible materials in a factory or fixed location must comply with NFPA 33 and OSHA 1910.94(c) requirements in the USA and with all similar local regulations in other countries.

***Not approved for use in explosive atmospheres or hazardous locations.
For portable airless spraying of architectural paints and coatings.***



Important Safety Instructions

Read all warnings and instructions in this manual, related manuals, and on the unit. Be familiar with the controls and the proper usage of the equipment. Save these instructions.

Before You Spray

Before You Spray

Review Warnings for Important Safety Information

Important! Read carefully and practice good safety habits.

Review Manual & Watch Videos

Scan QR code for Operational Video or go to magnum.graco.com/magop/


Related Manuals

Gun: 312830 (SG)
ProXChange™ Pump: 3A3172 (ProLTS only)



Models

3000 psi (207 bar, 20.7 MPa) Maximum Working Pressure

	VAC	Model	Stand	Cart
 Intertek 110474 Certified to CAN/CSA C22.2 No. 68 Conforms to UL 1450	120 USA	LTS 15	17K955	
		LTS 17		17K960
		ProLTS 170	17H198	
		ProLTS 190		17H206

Contents

Before You Spray	2
Warnings	4
Know Your Sprayer	8
Setup	12
Start Up	13
Pressure Relief Procedure	13
How to Spray	19
Adjust Pressure Control	20
Spray Techniques	20
Clear Tip Clog	21
Cleanup	22
Storage	26
Reference	28
Spray Tip Selection	28
Cleaning Fluid Compatibility	29
Static Grounding Instructions (Oil-Based materials)	29
Maintenance	32
Troubleshooting	35
LTS 15: 17K955 Stand Sprayer Parts	40
LTS 17: 17K960 Cart Sprayer Parts	42
ProLTS 170: 17H198 Stand Sprayer Parts	44
ProLTS 190: 17H206 Cart Sprayer Parts	46
ProXChange Pump Parts (ProLTS only)	48
Wiring Diagram - 110/120V	50
Technical Specifications	51
Graco Standard Warranty	54
Graco Information	55

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual or on warning labels, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.


WARNING



GROUNDING

This product must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This product is equipped with a cord having a grounding wire with an appropriate grounding plug. The plug must be plugged into an outlet that is properly installed and grounded in accordance with all local codes and ordinances.

- Improper installation of the grounding plug is able to result in a risk of electric shock.
- When repair or replacement of the cord or plug is required, do not connect the grounding wire to either flat blade terminal.
- The wire with insulation having an outer surface that is green with or without yellow stripes is the grounding wire.
- Check with a qualified electrician or serviceman when the grounding instructions are not completely understood, or when in doubt as to whether the product is properly grounded.
- Do not modify the plug provided; if it does not fit the outlet, have the proper outlet installed by a qualified electrician.
- This product is for use on a nominal 120V circuit and has a grounding plug similar to the plugs illustrated below.



- Only connect the product to an outlet having the same configuration as the plug.
- Do not use an adapter with this product.

Extension Cords:

- Use only a 3-wire extension cord that has a grounding plug and a grounding receptacle that accepts the plug on the product.
- Make sure your extension cord is not damaged. If an extension cord is necessary use 12 AWG (2.5mm²) minimum to carry the current that the product draws.
- An undersized cord results in a drop in line voltage and loss of power and overheating.

Conductor Size		Length
AWG (American Wire Gauge)	Metric	Maximum
16	1.5 mm ²	25 ft. (8 m)
12	2.5 mm ²	50 ft. (15 m)

WARNING



FIRE AND EXPLOSION HAZARD

Flammable fumes, such as solvent and paint fumes, in work area can ignite or explode. To help prevent fire and explosion:



LTS 15/LTS 17 Models:

- Do not spray or clean with materials having flash points lower than 100°F (38° C). Use only non-flammable or water-based materials, or non-flammable paint thinners. For complete information about your material, request the Safety Data Sheet (SDS) from the material distributor or retailer.
- Do not spray combustible materials near an open flame or sources of ignition such as cigarettes, motors, and electrical equipment.
- Do not spray combustible liquids in a confined area.



ProLTS Models:

- Do not spray flammable or combustible materials near an open flame or sources of ignition such as cigarettes, motors, and electrical equipment.
- Do not spray flammable or combustible liquids in a confined area.

All Models:

- Paint or solvent flowing through the equipment is able to result in static electricity. Static electricity creates a risk of fire or explosion in the presence of paint or solvent fumes. All parts of the spray system, including the pump, hose assembly, spray gun, and objects in and around the spray area shall be properly grounded to protect against static discharge and sparks. Use Graco conductive or grounded high-pressure airless paint sprayer hoses.
- Verify that all containers and collection systems are grounded to prevent static discharge. Do not use pail liners unless they are anti-static or conductive.
- Connect to a grounded outlet and use grounded extensions cords. Do not use a 3-to-2 adapter.
- Do not use a paint or a solvent containing halogenated hydrocarbons.
- Keep spray area well-ventilated. Keep a good supply of fresh air moving through the area.
- Sprayer generates sparks. Keep pump assembly in a well ventilated area a least 20 feet (6.1 m) from the spray area when spraying, flushing, cleaning, or servicing. Do not spray pump assembly.
- Do not smoke in the spray area or spray where sparks or flame is present.
- Do not operate light switches, engines, or similar spark producing products in the spray area.
- Keep area clean and free of paint or solvent containers, rags, and other flammable materials.
- Know the contents of the paints and solvents being sprayed. Read all Safety Data Sheets (SDSs) and container labels provided with the paints and solvents. Follow the paint and solvents manufacturer's safety instructions.
- Fire extinguisher equipment shall be present and working.

WARNING



SKIN INJECTION HAZARD

High-pressure spray is able to inject toxins into the body and cause serious bodily injury. In the event that injection occurs, **get immediate surgical treatment**.



- Do not aim the gun at, or spray any person or animal.
- Keep hands and other body parts away from the discharge. For example, do not try to stop leaks with any part of the body.
- Always use the nozzle tip guard. Do not spray without nozzle tip guard in place.
- Use Graco nozzle tips.
- Use caution when cleaning and changing nozzle tips. In the case where the nozzle tip clogs while spraying, follow the **Pressure Relief Procedure** for turning off the unit and relieving the pressure before removing the nozzle tip to clean.
- Equipment maintains pressure after power is shut off. Do not leave the equipment energized or under pressure while unattended. Follow the **Pressure Relief Procedure** when the equipment is unattended or not in use, and before servicing, cleaning, or removing parts.
- Check hoses and parts for signs of damage. Replace any damaged hoses or parts.
- This system is capable of producing 3000 psi. Use Graco replacement parts or accessories that are rated a minimum of 3000 psi.
- Always engage the trigger lock when not spraying. Verify the trigger lock is functioning properly.
- Verify that all connections are secure before operating the unit.
- Know how to stop the unit and bleed pressure quickly. Be thoroughly familiar with the controls.



EQUIPMENT MISUSE HAZARD

Misuse can cause death or serious injury.

- Always wear appropriate gloves, eye protection, and a respirator or mask when painting.
- Do not operate or spray near children. Keep children away from equipment at all times.
- Do not overreach or stand on an unstable support. Keep effective footing and balance at all times.
- Stay alert and watch what you are doing.
- Do not operate the unit when fatigued or under the influence of drugs or alcohol.
- Do not kink or over-bend the hose.
- Do not expose the hose to temperatures or to pressures in excess of those specified by Graco.
- Do not use the hose as a strength member to pull or lift the equipment.
- Do not spray with a hose shorter than 25 feet.
- Do not alter or modify equipment. Alterations or modifications may void agency approvals and create safety hazards.
- Make sure all equipment is rated and approved for the environment in which you are using it.








ELECTRIC SHOCK HAZARD

This equipment must be grounded. Improper grounding, setup, or usage of the system can cause electric shock.

- Turn off and disconnect power cord before servicing equipment.
- Connect only to grounded electrical outlets.
- Use only 3-wire extension cords.
- Ensure ground prongs are intact on power and extension cords.
- Do not expose to rain. Store indoors.


WARNING

	<p>PRESSURIZED ALUMINUM PARTS HAZARD</p> <p>Use of fluids that are incompatible with aluminum in pressurized equipment can cause serious chemical reaction and equipment rupture. Failure to follow this warning can result in death, serious injury, or property damage.</p> <ul style="list-style-type: none"> • Do not use 1,1,1-trichloroethane, methylene chloride, other halogenated hydrocarbon solvents or fluids containing such solvents. • Do not use chlorine bleach. • Many other fluids may contain chemicals that can react with aluminum. Contact your material supplier for compatibility.
 	<p>MOVING PARTS HAZARD</p> <p>Moving parts can pinch, cut, or amputate fingers and other body parts.</p> <ul style="list-style-type: none"> • Keep clear of moving parts. • Do not operate equipment with protective guards or covers removed. • Pressurized equipment can start without warning. Before checking, moving, or servicing equipment, follow the Pressure Relief Procedure and disconnect all power sources.
	<p>TOXIC FLUID OR FUMES HAZARD</p> <p>Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.</p> <ul style="list-style-type: none"> • Read MSDSs to know the specific hazards of the fluids you are using. • Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.
	<p>PERSONAL PROTECTIVE EQUIPMENT</p> <p>Wear appropriate protective equipment when in the work area to help prevent serious injury, including eye injury, hearing loss, inhalation of toxic fumes, and burns. This protective equipment includes but is not limited to:</p> <ul style="list-style-type: none"> • Protective eyewear, and hearing protection. • Respirators, protective clothing, and gloves as recommended by the fluid and solvent manufacturer.
	<p>CALIFORNIA PROPOSITION 65</p> <p>This product contains a chemical known to the State of California to cause cancer, birth defects or other reproductive harm. Wash hands after handling.</p>

Know Your Sprayer

Know Your Sprayer

LTS 15 Stand Model




ti30912a

A	PushPrime™ Button
B	Prime/Spray Valve
C	Pressure Control Knob
D	ON/OFF Switch
E	Suction Tube
F	Drain Tube (with diffuser)
G	Airless Spray Gun
H	Reversible Spray Tip
J	Tip Guard
K	Gun Trigger Lock
L	Gun Fitting
M	Gun Filter (inside handle)

N	Pump
O	Inlet Valve
P	Outlet Valve (airless hose connection)
Q	Airless Hose
T	Inlet Strainer
U	Power Cord
W	Suction Tube Drip Cup
	Model/Serial Tag (Not shown, located on bottom of unit.)

See **Quick Reference**, page 31 for more information.

LTS 17 Cart Model




ti30913a

A	PushPrime™ Button
B	Prime/Spray Valve
C	Pressure Control Knob
D	ON/OFF Switch
E	Suction Tube
F	Drain Tube (with diffuser)
G	Airless Spray Gun
H	Reversible Spray Tip
J	Tip Guard
K	Gun Trigger Lock
L	Gun Fitting

M	Gun Filter (inside handle)
N	Pump
O	Inlet Valve
P	Outlet Valve (airless hose connection)
Q	Airless Hose
S	Pail Hanger
T	Inlet Strainer
U	Power Cord
	Model/Serial Tag (Not shown, located on bottom of unit.)
See Quick Reference , page 31 for more information.	

Know Your Sprayer

ProLTS 170 Stand Model




ti27116a

A	PushPrime™ Button
B	Prime/Spray Valve
C	Pressure Control Knob
D	ON/OFF Switch
E	Suction Tube
F	Drain Tube (with diffuser)
G	Airless Spray Gun
H	Reversible Spray Tip
J	Tip Guard
K	Gun Trigger Lock
L	Gun Fitting
M	Gun Filter (inside handle)
N	ProXChange™ Pump (behind Easy Access Door)
O	Inlet Valve

P	Airless Hose Connection
Q	Airless Hose
R	InstaClean™ Filter (inside fluid outlet)
T	Inlet Strainer
U	Power Cord
V	Easy Access Door
W	Suction Tube Drip Cup
X	Pump Removal Tool
Y	Outlet Valve
Z	Inlet Valve Removal Tool
	Model/Serial Tag (Not shown, located on bottom of unit.)

See **Quick Reference**, page 31 for more information.

ProLTS 190 Cart Model



ti27117a

A	PushPrime Button
B	Prime/Spray Valve
C	Pressure Control Knob
D	ON/OFF Switch
E	Suction Tube
F	Drain Tube (with diffuser)
G	Airless Spray Gun
H	Reversible Spray Tip
J	Tip Guard
K	Gun Trigger Lock
L	Gun Fitting
M	Gun Filter (inside handle)
N	ProXChange Pump (behind Easy Access Door)
O	Inlet Valve

P	Airless Hose Connection
Q	Airless Hose
R	InstaClean Filter (inside fluid outlet)
S	Pail Hanger
T	Inlet Strainer
U	Power Cord
V	Easy Access Door
X	Pump Removal Tool
Y	Outlet Valve
Z	Inlet Valve Removal Tool
	Model/Serial Tag (Not shown, located on bottom of unit.)
See Quick Reference , page 31 for more information.	


Setup

Setup


When unpacking sprayer for the first time or after long term storage perform setup procedure.

Assemble Your Sprayer


1. Connect Graco airless hose to outlet valve fitting. Use wrench to tighten securely.




2. Connect other end of hose to gun.




3. Use two wrenches to tighten securely. If hose is already connected, make sure connections are tight.
4. Engage trigger lock.



5. Remove tip guard. Be careful tip seal may fall out when tip guard is removed.



6. Turn pressure control knob all the way left (counter-clockwise) to lowest setting.




7. After long term storage check inlet strainer for clogs and debris.

Strain the Paint

Previously opened paint may contain dried paint or other debris. To avoid priming problems and spray tip clogs it is recommended to strain the paint before using. Paint strainers are available where paint is sold. Stretch a paint strainer over a clean pail and pour the paint through the strainer to capture any dried paint and debris before spraying.




Start Up



Pressure Relief Procedure




Follow the Pressure Relief Procedure whenever you see this symbol.




This equipment stays pressurized until pressure is manually relieved. To help prevent serious injury from pressurized fluid, such as skin injection or splashed fluid, follow the **Pressure Relief Procedure** whenever sprayer is stopped and before sprayer is cleaned or checked, and before equipment is serviced.


1. Turn ON/OFF switch to the **OFF** position.




2. Engage the trigger lock. Always engage the trigger lock when sprayer is stopped to prevent the gun from being triggered accidentally.




3. Turn pressure control knob to lowest setting.



4. Put drain tube into a waste pail and turn Prime/Spray valve in PRIME position (drain) to relieve pressure.



5. Hold the gun firmly to a pail. Point gun into pail. Disengage the trigger lock and trigger the gun to relieve pressure.



6. Engage the trigger lock.


Start Up

7. If you suspect the spray tip or hose is clogged or that pressure has not been fully relieved:
 - a. **VERY SLOWLY** loosen the tip guard retaining nut or the hose end coupling to relieve pressure gradually.
 - b. Loosen the nut or coupling completely.
 - c. Clear airless hose or spray tip obstruction. See **Clear Tip Clog**, page 21.


Flush Storage Fluid

This sprayer arrives from the factory with a small amount of test material in the system. **It is important that you flush this material from the sprayer before using it for the first time.** See **Cleaning Fluid Compatibility and Static Grounding Instructions (Oil-Based materials)**, page 29 for additional information when using oil-based materials.


1. Perform **Pressure Relief Procedure**, page 13.
2. Make certain ON/OFF switch is **OFF**.
3. Separate drain tube (smaller) from suction tube (larger).
4. Place drain tube in a waste pail.
5. Submerge suction tube in a pail partially filled with water or flushing fluid. If spraying oil-based materials, submerge the suction tube in mineral spirits, or compatible cleaning solvent. If spraying water-based materials, submerge the suction tube in water.




6. Turn Prime/Spray valve down to **PRIME** position.




7. Plug power supply cord into a properly grounded electrical outlet.
8. Press PushPrime button twice to loosen inlet valve ball.



9. Align setting indicator with Prime/Clean setting on pressure control knob.




10. Turn ON/OFF switch to **ON** position.




11. When sprayer starts pumping, flushing solvent and air bubbles will be purged from system. Allow fluid to flow out of drain tube, into waste pail, for 30 to 60 seconds.
12. Turn ON/OFF switch to **OFF** position.

If flushing fluid fails to come out of the drain tube, perform the steps below until flushing fluid flows up the suction tube and out the drain tube.

1. Some fluids prime faster if the ON/OFF switch is toggled on and off so the pump can slow and stop. Turn ON/OFF switch ON for three seconds, then OFF until motor stops, then ON again for three seconds, then OFF until motor stops. Continue until sprayer is primed. If flushing fluid does not flow up suction tube, see next step.




ProLTS:



Install suction tube and repeat **Flush Storage Fluid**, page 14.

2. Remove suction tube. Insert pointed end of a pencil into the inlet and push up to free inlet valve ball.



LTS15/LTS17:



Start Up

3. Remove outlet valve and clean. Make certain outlet ball moves free in the housing.

Install outlet valve and repeat **Flush Storage Fluid**, page 14.




4. Remove suction tube. Remove inlet valve and clean. Make certain the spring is facing up when the inlet ball and valve are installed.

Install inlet valve and suction tube and repeat **Flush Storage Fluid**, page 14.

ProLTS Inlet Valve Removal





An integrated tool is included in the frame to remove the inlet valve assembly from the pump. If you suspect that the inlet valve is clogged or stuck, remove the valve assembly and clean or replace. Insert pump inlet into frame and loosen the inlet valve. Remove inlet valve.



NOTICE

Do not lose the ball and spring inside the inlet valve assembly. It may fall out when the inlet valve is removed. Pump will not prime without the ball and spring.


5. Perform a power flush. See **Cleanup with Power Flush Adapter**, page 23.

				
High-pressure spray is able to inject toxins into the body and cause serious bodily injury. Do not stop leaks with hand or rag.				

Inspect for leaks. If leaks occur, perform **Pressure Relief Procedure**, page 13, then tighten all fittings and repeat **Start Up**. If there are no leaks continue with the next step.



Fill Pump (Prime Pump)

1. Move suction tube to paint pail and submerge suction tube in paint.



2. Turn ON/OFF switch to **ON** position.
3. Wait to see paint coming out of drain tube.
4. Turn ON/OFF switch to **OFF** position.


NOTE: If paint does NOT flow up the suction tube and out the drain tube, follow the **Flush Storage Fluid**, steps 1 - 5, on this page.




Start Up

Fill Gun and Hose

1. Hold gun against waste pail. Point gun into waste pail.
 - a. Disengage trigger lock.
 - b. Pull and hold gun trigger.
 - c. Turn Prime/Spray valve horizontal to SPRAY position.
 - d. Turn ON/OFF switch to **ON** position.




2. Trigger gun into waste pail until only paint comes out of the gun.
3. Release trigger. Engage trigger lock.
4. Transfer drain tube to paint pail and clip to suction tube.



NOTE: When motor stops, sprayer is ready to paint. If motor continues to run, sprayer is not properly primed. Repeat **Fill Pump (Prime Pump)** and **Fill Gun and Hose**.


How to Spray




Spray Tip Installation

To prevent spray tip leaks make certain spray tip and tip guard are installed properly.


1. Perform **Pressure Relief Procedure**, page 13.
2. Engage trigger lock.
3. Verify spray tip and tip guard parts are assembled in the order shown.




- a. Use spray tip to align gasket and seal in the tip guard.



- b. Spray tip must be pushed all the way into the tip guard. Turn spray tip to push down.




- c. Turn the arrow shaped handle on the spray tip forward to the spray position.
4. Screw spray tip and tip guard assembly onto the gun and tighten.



How to Spray

Adjust Pressure Control

The pressure control knob allows for infinite pressure adjustment. To reduce overspray, always start at the lowest pressure setting and increase pressure to the minimum setting that results in an acceptable spray pattern.



To select function, align symbol on pressure control knob with setting indicator on sprayer.

Tip and Pressure Selection

See table for recommended spray pressure for your material. Refer to paint (material) can for manufacturer's recommendations.

Maximum tip hole sizes supported by the sprayer:


- LTS 15: 0.015 in. (0.38 mm) – LTS 17: 0.017 in. (0.43 mm)
- ProLTS 170: 0.017 in. (0.43 mm) – ProLTS 190: 0.019 in. (0.48 mm)

	Coatings				
	Interior Stains/ Interior & Exterior Clears	Exterior Solid Stains	Primers	Interior Latex Paints	Exterior Latex Paints
Spray Pressure	Low Spray	High Spray	High spray	High Spray	High Spray
Tip hole Size					
0.011 in. (0.28 mm)	✓				
0.013 in. (0.33 mm)	✓		✓	✓	
0.015 in. (0.38 mm)		✓	✓	✓	✓
0.017 in. (0.43 mm)			✓	✓	✓
0.019 in. (0.48 mm)					✓

Spray Techniques


Use a piece of scrap cardboard to practice these basic spraying techniques before you begin spraying the surface.

- Hold gun 12 in. (30 cm) from surface and aim straight at surface. Tilting gun to direct spray angle causes an uneven finish.
- Flex wrist to keep gun pointed straight. Fanning gun to direct spray at angle causes uneven finish.




Triggering Gun

Pull trigger after starting stroke. Release trigger before end of stroke. Gun must be moving when trigger is pulled and released.



Aiming Gun


Aim center of spray of gun at bottom edge of previous stroke, overlapping each stroke by half.



Spray Pattern Quality

A good spray pattern is evenly distributed as it hits the surface.

- Spray should be atomized (evenly distributed, no gaps at edges).



If tails persist when spraying at the highest spray pressure:

- Spray tip may be worn. See **Tip and Pressure Selection**, page 20.

- A smaller spray tip may be needed.
- Material may need to be thinned. If material needs to be thinned follow manufacturer's recommendations.


Clear Tip Clog

In the event that particles or debris clog the spray tip, this sprayer is designed with a reversible spray tip that quickly and easily clears the particles without disassembling the sprayer.

See **Strain the Paint**, page 12 for additional information.

- Engage trigger lock. Rotate spray tip to unclog position. Disengage trigger lock. Trigger gun at waste area to clear clog.


UNCLOG



NOTE: If spray tip is difficult to rotate when turning to the unclog position perform, **Pressure Relief Procedure**, page 13, then turn Prime/Spray valve to spray position and repeat step 1.


- Engage trigger lock. Rotate spray tip back to spray position. Disengage trigger lock and continue spraying.

SPRAY



Cleanup


Cleaning the sprayer after each use results in a trouble free start up the next time the sprayer is used.




Cleaning from a Pail

- For short term shutdown periods (overnight to two days) refer to **Short Term Storage**, page 26.
- See **Cleaning Fluid Compatibility**, page 29 for information on flushing/cleaning fluids and **Static Grounding Instructions (Oil-Based materials)**, page 29.


- Perform **Pressure Relief Procedure**, page 13.
- Remove spray tip and tip guard assembly from gun and place in waste pail.




- Lift suction tube and drain tube from paint pail. Let paint drain into the pail.
- Separate drain tube (smaller) from suction tube (larger).




- Place empty waste and flushing fluid pails side by side.
- Place suction tube in flushing fluid. Use water for water based paint and mineral spirits or compatible oil-based flushing solvent for oil-based paint. Place drain tube in waste pail.



- Turn pressure control knob to the Prime/Clean setting.



- Turn Prime/Spray valve down to PRIME position.




- Turn ON/OFF switch to **ON** position.
- Flush until approximately 1/3 of the flushing fluid is emptied from the pail.


11. Turn ON/OFF switch to **OFF** position.

NOTE: Step 12 is for returning paint in hose to paint pail. One 50 ft (15 m) hose holds approximately 1 quart (1 liter) of paint.


12. To recover paint in hose, point gun into paint pail while holding gun firmly to the pail.
 - a. Disengage trigger lock.
 - b. Pull and hold gun trigger.
 - c. Turn Prime/Spray valve horizontal to **SPRAY** position.
 - d. Turn ON/OFF switch to **ON** position.
 - e. Continue to hold gun trigger until you see paint diluted with flushing fluid starting to come out of gun.



13. While continuing to trigger gun, quickly move gun to redirect spray into waste pail. Continue triggering gun into waste pail until flushing fluid dispensed from gun is relatively clear.



14. Turn pressure control knob to the lowest setting.
15. Stop triggering gun. Engage the trigger lock.



6. Turn pressure control knob to the Prime/Clean setting.


16. Turn Prime/Spray valve down to **PRIME** position.
17. Turn ON/OFF switch to **OFF** position.
18. Clean outlet filter. ProLTS only: See **Cleaning InstaClean™ Fluid Filter (ProLTS only)**, page 25.
19. Fill unit with Pump Armor™ fluid. See **Long Term Storage**, page 26.

Cleanup with Power Flush Adapter


(Water-based materials only)

Power flushing is a faster method of cleanup. It can only be used after spraying water-based coatings.


1. Perform **Pressure Relief Procedure**, page 13.
2. Remove spray tip and tip guard assembly from gun and place in waste pail.




3. Place empty waste and paint pails side by side.
4. Lift suction tube and drain tube from paint pail. Let paint drain into the pail.
5. Place suction and drain tube in waste pail.



Cleanup




7. Screw Power Flush attachment valve to garden hose. Close valve.



8. Turn on water. Open valve. Rinse paint off suction tube, drain tube and inlet strainer. Close valve.
9. Unscrew inlet strainer from suction tube. Place inlet strainer in waste pail.




10. Connect garden hose to suction tube with Power Flush attachment valve. Leave drain tube in waste pail.




11. Turn ON/OFF switch to **ON** position.
12. Open Power Flush attachment valve.
13. Circulate water through sprayer, into waste pail, for 20 seconds.
14. Turn ON/OFF switch to **OFF** position.

NOTE: Step 15 is for returning paint in hose to paint pail. One 50 ft (15 m) hose holds approximately 1 quart (1 liter) of paint.

15. To recover paint in hose, point gun into paint pail while holding gun firmly to the pail.
 - a. Disengage trigger lock.
 - b. Pull and hold gun trigger.
 - c. Turn Prime/Spray valve horizontal to **SPRAY** position.
 - d. Turn ON/OFF switch to **ON** position.
 - e. Continue to hold gun trigger until you see paint diluted with flushing fluid starting to come out of gun.




16. While continuing to trigger gun, quickly move gun to redirect spray into waste pail. Continue triggering gun into waste pail until flushing fluid dispensed from gun is relatively clear.




17. Turn pressure control knob to the low-est setting.

18. Stop triggering gun. Engage the trigger lock.



19. Turn Prime/Spray valve down to PRIME position.




20. Turn ON/OFF switch to OFF position.


Cleaning InstaClean™ Fluid Filter (ProLTS only)

The InstaClean Filter prevents particles from entering paint hose. After each use, remove and clean it to ensure peak performance.

1. Perform **Pressure Relief Procedure**, page 13.
2. Disconnect airless spray hose (A) from sprayer.
3. Unscrew outlet valve (B).
4. Remove InstaClean Filter (C).




5. Check InstaClean Filter (C) for debris. If needed, clean filter with water or flushing fluid and a soft brush.
 - a. Install closed (square) end of InstaClean Filter (C) in sprayer.
 - b. Screw outlet valve (B) into sprayer.
6. Tighten outlet valve and reconnect hose (A) to sprayer. Use two wrench to tighten securely.




Clean the Gun

1. Clean gun filter (A) with water or flushing fluid and a brush every time you flush the system. Replace gun filter if damaged.



2. Remove spray tip and tip guard and clean with water or flushing fluid and a brush.




3. Wipe paint off outside of gun using a soft cloth moistened with water or flushing fluid.

Storage

Storage


With proper storage, the sprayer will be ready to use the next time it is needed.




Short Term Storage

(up to 2 days)


1. Perform **Pressure Relief Procedure**, page 13.
2. Leave suction tube and drain tube in paint pail.



3. Cover paint and pail tightly with plastic wrap.



4. Engage trigger lock.




5. Leave gun attached to hose.
6. Remove tip and guard and clean with water or flushing fluid and a brush.
7. Wipe paint off outside of gun using a soft cloth moistened with water or flushing fluid.

Long Term Storage


(more than 2 days)

Pump Armor fluid protects the sprayer against freezing and corrosion.


- Before storing sprayer make sure all water is drained out of sprayer.
 - Do not allow water to freeze in sprayer.
 - Do not store sprayer under pressure.
 - Store sprayer indoors.
1. Perform **Pressure Relief Procedure**, page 13.
 2. Place suction tube in Pump Armor fluid bottle and drain tube in waste pail.




3. Turn Prime/Spray valve down to **PRIME** position.



4. Turn ON/OFF switch to **ON** position.
5. Turn pressure control knob clockwise until the pump turns on.
6. When storage fluid comes out of drain tube (5-10 seconds) turn ON/OFF switch to **OFF** position.
7. Turn Prime/Spray valve horizontal to **SPRAY** position to keep storage fluid in sprayer during storage.



8. Leave gun attached to hose.
9. Remove tip and guard and clean with water or flushing fluid and a brush.
10. Wipe paint off outside of gun using a soft cloth moistened with water or flushing fluid.



11. Secure a plastic bag around suction and drain tube to catch any drips.

Reference

Spray Tip Selection

Selecting Tip Size

Spray tips come in a variety of hole sizes for spraying a range of fluids. Your sprayer includes a tip for use in most paint spraying applications. Use the coatings table on page 20 to determine the range of recommended tip hole sizes for each fluid type. If you need a tip other than the one supplied, see the **Reversible Spray Tip Selection Chart**, page 28.

Hints:

- As you spray, the tip wears and enlarges. Starting with a tip hole size smaller than the maximum will allow you to spray within the rated flow capacity of the sprayer.
- Use larger tip hole sizes with thicker coatings and smaller tip hole sizes with thinner coatings.
- Tips wear with use and need periodic replacement.
- Tip hole size controls flow rate - the amount of paint that comes out of the gun.

Fan Width


Fan width is the size of the spray pattern, which determines the area covered with each stroke.

Hints:

- Select a fan width best suited to the surface being sprayed.
- Wider fans allow provide better coverage on broad, open surfaces.
- Narrower fans provide better control on small, confined surfaces.

Understanding Tip Number

The last three digits of tip number (i.e.: 221413) contain information about hole size and fan width on surface when gun is held 12 in. (30.5 cm) from surface being sprayed.



Reversible Spray Tip Selection Chart


Tip Part #	Fan Width *	Hole Size
221311	6 - 8 in. (152 - 203 mm)	0.011 in. (0.28 mm)
221411	8 - 10 in. (203 - 254 mm)	0.011 in. (0.28 mm)
221313	6 - 8 in. (152 - 203 mm)	0.013 in. (0.33 mm)
221413	8 - 10 in. (203 - 254 mm)	0.013 in. (0.33 mm)
221415	8 - 10 in. (203 - 254 mm)	0.015 in. (0.38 mm)
221515	10 - 12 in. (254 - 305 mm)	0.015 in. (0.38 mm)
221417	8 - 10 in. (203 - 254 mm)	0.017 in. (0.43 mm)
221517	10 - 12 in. (254 - 305 mm)	0.017 in. (0.43 mm)
221619	12 - 14 in. (305 - 356 mm)	0.019 in. (0.48 mm)
* - 12 in. (305 mm) from surface		

Example: For an 8 to 10 in. (203 to 254 mm) fan width and 0.013 (0.33 mm) hole size, order Part No. 221413.

Lacquer Conversion Kit

To spray lacquers with the ProLTS 170 or ProLTS 190, you must purchase a lacquer conversion kit, and follow **Static Grounding Instructions (Oil-Based materials)**, page 29, when using oil-based materials. See ProLTS 170 and ProLTS 190 parts list, page 41 or 47. The LTS 15 and LTS 17 must not be used with lacquers.

Cleaning Fluid Compatibility



Oil- or Water-Based Materials

- When spraying **water-based** materials, flush the system thoroughly with water.
- When spraying **oil-based** materials, flush the system thoroughly with mineral spirits or compatible, oil-based flushing solvent.
- To spray **water-based** materials **after** spraying **oil-based** materials, flush the system thoroughly with water first. The water flowing out of drain tube should be clear and solvent-free **before** you begin spraying the water-based material.
- To spray **oil-based** materials **after** spraying **water-based** materials, flush the system thoroughly with mineral spirits or a compatible oil-based flushing solvent first. The solvent flowing out of the drain tube should not contain any water. When flushing with solvents always follow **Static Grounding Instructions (Oil-Based materials)**, page 29.
- To avoid fluid splashing back on your skin or into your eyes, always aim gun at inside wall of pail.

Static Grounding Instructions (Oil-Based materials)



The equipment must be grounded to reduce the risk of static sparking and electric shock. An electric or static spark can cause fumes to ignite or explode. An improper ground can cause electric shock. A good ground provides an escape wire for the electric current.

Always use a metal pail for oil-based materials requiring flushing with compatible oil-based flushing solvents when sprayer is flushed or pressure is relieved.


Follow local code. Use only conductive metal pails, placed on a grounded surface such as concrete.

Do not place pail on a non-conductive surface such as paper or cardboard which interrupts grounding continuity.




Reference

Always ground a metal pail: connect a ground wire to the pail. Clamp one end to the pail and the other end to a true earth ground such as a water pipe.



To maintain ground continuity when sprayer is flushed or pressure is relieved: hold metal part of spray gun firmly to the side of a grounded metal pail, then trigger the gun.



Quick Reference

Page 10	Name	Description
A	Prime/Spray Valve	<ul style="list-style-type: none"> In PRIME position directs fluid to drain tube. In SPRAY position directs pressurized fluid to paint hose. Automatically relieves system pressure in overpressure situations.
B	PushPrime Button	Taps the inlet ball when pushed to loosen it.
C	Pressure Control Knob	Increases (clockwise) and decreases (counter-clockwise) fluid pressure in pump, hose, and spray gun. To select function, align symbol on pressure control knob with setting indicator, page 13.
D	ON/OFF Switch	Turns sprayer ON and OFF.
E	Suction Tube	Draws fluid from paint pail into pump.
F	Drain Tube	Drains fluid in system during priming and pressure relief.
G	Airless Spray Gun	Dispenses fluid.
H	Reversible Spray Tip	<ul style="list-style-type: none"> Atomizes fluid being sprayed, forms spray pattern and controls fluid flow according to hole size. Reverse position unclogs plugged tips without disassembly.
J	Tip Guard	Reduces risk of fluid injection injury.
K	Gun Trigger Lock	Prevents accidental triggering of spray gun.
L	Gun Fitting	Threaded connection for paint hose.
M	Gun Filter	Filters fluid entering spray gun to reduce tip clogs.
N	Pump	Pumps and pressurizes fluid and delivers it to paint hose.
O	Inlet Valve	Allows paint to flow from paint bucket into the sprayer.
P/Y	Airless Hose Connection/Outlet Valve	Threaded connection for airless hose. Allows paint to flow from the sprayer to the gun.
Q	Airless Hose	Transports high-pressure fluid from pump to spray gun.
R	InstaClean™ Filter (ProLTS only)	<ul style="list-style-type: none"> Filters fluid coming out of pump to reduce tip plugging and improve finish. Self cleans only during pressure relief.
S	Pail Hanger	For transporting pail by its handle.
T	Inlet Strainer	Prevents debris from entering pump.
U	Power Cord	Plugs into power source.
V	Easy Access Door (ProLTS only)	Easy Access Door permits quick access to the pump. Open pump door by pulling out on the tabs while sliding door up.
W	Suction Tube Drip Cup	Holds the suction tube during transport to catch drips.
X	Pump Removal Tool (ProLTS only)	Cut out in the frame provide the tools to quickly remove the pump packing without additional tools.
Z	Inlet Valve Removal Tool (ProLTS only)	Cut out in the frame provide the tools to quickly remove the inlet valve without additional tools.
	Power Flush Attachment	Connects garden hose to suction tube for power flushing water-based fluids.

Maintenance

Routine maintenance is important to ensure proper operation of your sprayer.



Activity	Interval
Inspect motor shroud openings for blockage.	Daily or each time you spray
Inspect/clean InstaClean filter (ProLTS only), fluid inlet strainer, and gun filter.	Daily or each time you spray

NOTICE

Protect the internal drive parts of this sprayer from water. Openings in shroud allow cooling of mechanical parts and electronics inside. If water gets into these openings, the sprayer could malfunction or be permanently damaged.

Airless Hoses

Check hose for damage every time you spray. Do not attempt to repair hose if hose jacket or fittings are damaged. Do not use hoses shorter than 25 ft (7.6 m). Wrench tighten, using two wrenches.

Spray Tips

- Always clean tips with compatible cleaning fluid and brush after spraying.
- Tips may require replacement after 15 gallons (57 liters) or they may last through 60 gallons (227 liters) depending on abrasiveness of paint.

Pump Repair (ProLTS only)

When pump packings wear, paint will begin to leak down outside of pump. Each time the pump kit is replaced, check pump inlet and outlet valves for wear or damage. Replace if worn or damaged. Always replace inlet and outlet valves every second time the pump kit is replaced.

- See **ProXChange Pump Parts (ProLTS only)**, page 48 or consult a Graco/MAGNUM authorized retailer, distributor, or service center.


- Purchase a pump repair kit and install according to instructions provided with kit, before your next job.

Pump Removal


Remove airless hose, suction tube, and drain tube.

Always perform **Pressure Relief Procedure**, page 13 before starting any pump repairs and unplug the sprayer.

- Unplug the sprayer from the power source.
- Pull tabs on sides of the easy access door towards you while pushing the entire door up.
- Now lift the door so that it swings out of the way.




4. Slide pump assembly off the mounting pins.



ProLTSCChange Removal Tool


An integrated tool is included in the frame to remove the ProLTSCChange packing assembly. See Pump repair manual for complete repair instructions.




Maintenance

Pump Installation


1. Slide pump assembly onto the mounting pins.



- a. Move pump rod up or down until cap is level with the opening in the yoke.




- b. Push on pump rod to slide pump assembly back on to mounting pins.
2. Swing easy access door closed while pushing the entire door down.



3. Install hose, suction tube, and drain tube.
4. Plug sprayer into power source.

NOTE: Door must be fully closed and latched before sprayer will operate.

Troubleshooting



1. Follow **Pressure Relief Procedure**, page 13, before checking or repairing.
2. Solutions at the beginning of each problem listed are the most common.

3. Check everything in this Troubleshooting Table before you bring the sprayer to an authorized service center.

Have a Question?

Call toll-free:

1-888-541-9788

Or visit us at:

www.magnum.graco.com/support

ti24021a

Problem	Cause	Solution
Motor does not run: (verify sprayer is plugged in, and ON/OFF switch is on)	ProLTS only: Easy access door not fully closed.	Verify that easy access door is closed and latched. See page 34.
	Pressure control is set at zero pressure.	Turn pressure control knob clockwise to increase pressure setting.
	Electric outlet is not providing power.	Test outlet with known working device. Reset circuit breaker or replace fuse. Find working outlet. Reset building circuit breaker or replace fuse.
	Extension cord is damaged.	Replace extension cord. See page 4.
	Sprayer electric cord is damaged.	Check for broken insulation or wires. Replace electric cord if damaged.
	Pump is seized (Paint has hardened in pump or Water is frozen in pump.)	Turn ON/OFF switch off and unplug sprayer from outlet. If frozen do NOT try to start sprayer until it is completely thawed or it may damage the motor, control board and/or drive train. Place sprayer in warm area for several hours. Check for free moving pump by removing shroud and spinning fan. If not frozen, check for hardened paint in pump. If paint has hardened in pump. See page 32. If motor does not turn with pump removed, consult a Graco/ Magnum authorized retailer, distributor, or service center.
	Motor or control is damaged.	Consult a Graco/ Magnum authorized retailer, distributor, or service center.

Troubleshooting

Problem	Cause	Solution
Sprayer runs, but pump does not prime or loses prime while in use. (Pump cycles but does not pump paint into suction tube or build pressure.)	Prime/Spray valve is in SPRAY position.	Turn Prime/Spray valve down to PRIME position until paint exits drain tube.
	Inlet strainer is clogged or suction tube is not immersed in paint.	Clean debris off inlet strainer and make sure suction tube is immersed in paint.
	Inlet valve ball is stuck or dirty.	Remove suction tube and place an allen wrench into the inlet section to dislodge the ball, see page 17. Clean inlet valve ball, see page 17. OR Power Flush sprayer, see page 23.
	Thick or "sticky" paint.	Some fluids may prime faster if the ON/OFF switch is momentarily turned off so the pump can slow and stop. Turn ON/OFF switch on and then off again, several times if necessary. See page 17.
	Suction tube is leaking.	Inspect suction tube connection for cracks or vacuum leaks.
	Outlet valve ball is stuck or dirty.	Unscrew outlet valve, remove, and clean assembly. See page 17.
	Debris in paint.	Strain the paint. See page 12.
	Prime/Spray valve is worn or obstructed with debris.	Take sprayer to Graco/MAGNUM authorized service center.

Problem	Cause	Solution
Pump is primed, but can not achieve good spray pattern.	Spray tip may be partially clogged.	Clear spray tip clog. See page 21.
	Reversible spray tip is in UNCLOG position.	Rotate arrow-shaped handle on spray tip so it points forward to SPRAY position. See page 21.
	Debris in paint.	Strain the paint. See page 29.
	Pressure is set too low.	Align pressure control knob setting indicator to desired spray setting. See page 20.
	ProLTS only: InstaClean fluid filter is clogged.	Clean or replace InstaClean fluid filter. See page 25.
	Spray gun fluid filter is clogged.	Clean or replace gun fluid filter. See page 25.
	Spray tip selected is too large for capability of sprayer.	Replace tip. See page 20.
	Spray tip is worn beyond the capability of sprayer.	Replace tip. See page 20.
	Spray tip gasket and seal worn or missing.	Replace gasket and seal. See page 19.
	Inlet strainer is clogged or suction tube is not immersed in paint.	Clean debris off inlet strainer and make sure suction tube is immersed in paint.
	Extension cord is too long or not heavy enough gauge.	Replace extension cord. See page 4.
	Inlet pump valve or outlet pump valve is worn or clogged with debris.	Check for worn or contaminated inlet valve or outlet valve. <ul style="list-style-type: none"> - Prime sprayer with paint - Trigger gun momentarily - When trigger is released, pump should cycle momentarily and stop - If pump continues to cycle, pump valves may be worn or contaminated with debris - Clean and reinstall valves. - ProLTS only: Replace valves with appropriate kits. See page 48.
	Material is too thick.	Thin material. Follow manufacturers recommendations.
	Airless hose is too long (if extra section was added).	Remove section of airless hose.
Spray gun stopped spraying while trigger is pulled.	Spray tip is clogged.	Clear spray tip clog. See page 21.
	Sprayer lost prime.	See troubleshooting section "Sprayer runs, but pump does not prime or loses prime while in use." on page 36.

Troubleshooting


Problem	Cause	Solution
When paint is sprayed, it runs down the wall or sags.	Material is going on too thick.	Move gun faster.
		Choose a spray tip with smaller hole size.
		Choose spray tip with wider fan.
		Make sure gun is far enough from surface.
When paint is sprayed, coverage is inadequate.	Material is going on too thin.	Move gun slower.
		Choose spray tip with larger hole size.
		Choose spray tip with narrower fan.
		Make sure gun is close enough to surface.
Fan pattern varies dramatically while spraying.	Pressure control switch is worn and causing excessive pressure variation.	Take sprayer to Graco/MAGNUM authorized service center.
Cannot trigger spray gun.	Spray gun trigger lock is engaged.	Rotate trigger lock to disengage trigger lock. See page 12.
Paint is coming out of pressure control switch.	Pressure control switch is worn.	Take sprayer to Graco/MAGNUM authorized service center.
Paint is leaking through drain tube.	Sprayer is over pressurizing.	Take sprayer to Graco/MAGNUM authorized service center.
Paint leaks down outside of pump.	Pump packings are worn.	Replace pump packings.
		ProLTS only: Replace pump packings with new ProXChange module. See page 32.
Motor is hot and runs intermittently. Motor automatically shuts off due to excessive heat. Damage can occur if cause is not corrected.	Vent holes in enclosure are plugged or sprayer is covered.	Keep vent holes clear of obstructions and overspray and keep sprayer open to air.
	Extension cord is too long or not a heavy enough gauge.	Replace extension cord. See page 4.
	Unregulated electrical generator being used has excessive voltage.	Use electrical generator with a proper voltage regulator.
	Motor needs to be replaced.	Take sprayer to Graco/Magnum authorized retailer, distributor, or service center.

Notes

[illegible]

LTS 15: 17K955 Stand Sprayer Parts

LTS 15: 17K955 Stand Sprayer Parts



ti28224a

Ref.	Torque
①	20-25 in-lb (2.3-2.8 N•m)
②	26-32 in-lb (2.9-3.6 N•m)
③	25-35 in-lb (2.8-4.0 N•m)
④	80-90 in-lb (9.0-10.0 N•m)
⑤	12-16 in-lb (1.4-1.8 N•m)
⑥	36-42 in-lb (4.0-4.7 N•m)

LTS 15: 17K955 Stand Sprayer Parts


17K955 Stand Sprayer Parts List

Ref.	Part	Description	Qty.	Ref.	Part	Description	Qty.
1	17L079	KIT, pump <i>includes 4, 8, 17, 29, 33, 48</i>	1	29b	103338	O-RING	1
2	16E835	DRIVE	1	29c	123849	SPRING, inlet	1
4	112689	SCREW, button, thd form	4	30	257002	KIT, strainer	1
5	17L282	KIT, motor	1	31	15Y296	COVER, wire	1
6	16D682	BRACKET, motor	1	32	115099	WASHER, hose	1
8	244267	KIT, pressure control <i>includes 8a, 8b</i>	1	33	235014	KIT, drain valve <i>includes 33a, 33b, 33c</i>	1
8a	15A464	LABEL, control	1	33a	24E578	BASE, valve	1
8b	15K530	LABEL, control	1	33b	187625	HANDLE, valve, drain	1
10	17K541	KIT, enclosure, LTS 15 <i>includes 10a, 10b, 16a</i>	1	33c	111600	PIN, grooved	1
10a	17K516	LABEL, A+ service	1	34	244035	DEFLECTOR, barbed	1
10b	115477	SCREW, mach, torx, pan hd	4	35	115489	CLAMP, drain tube	2
12	118899	SWITCH, rocker, spdt	1	36	195084	TUBE, drain	1
13	17L104	KIT, control board <i>includes 13a</i>	1	37	24V074	KIT, tube, suction <i>includes 30, 32, 34, 35, 36, 37a, 38, 39, 61</i>	1
13a	115477	SCREW, mach, torx	1	37a	197607	TUBE, suction <i>includes 32</i>	1
16	17L085	KIT, housing cover <i>includes 16a, 16b</i>	1	38	116295	CLAMP, tube	1
16a	120724	SCREW	4	39	195400	CLIP, spring	2
16b	17J967	LABEL, Magnum LTS 15, front	1	40	247339	HOSE, cpld, 1/4 in. x 25 ft	1
17	16E845	KIT, outlet valve, LTS 15 and LTS 17	1	41	234011	GUN, spray, SG2	
19	24K632	KIT, right leg, LTS 15 <i>includes 2 screws, 19a, 19b</i>	1	48	17L086	KIT, push prime	1
19a	125116	BOLT, carriage	4	51	16W319	COVER, gear	1
19b	102040	NUT, lock, hex	4	52	17H422	CUP, inlet drip	1
20	24K633	KIT, left leg, LTS 15 <i>includes 2 screws, 19a, 19b</i>	1	60	3A3526	GUIDE, Magnum quick guide, English (not shown)	1
22	16E842	KIT, power cord, LTS 15 <i>includes 22a, 22b</i>	1	60a	3A3528	GUIDE, Magnum quick guide, Spanish (not shown)	1
22a	115498	SCREW, grounding	1	61	115648	VALVE, power flush (not shown)	1
22b▲	17K627	LABEL, Magnum, warning (not shown)	1	62	244168	FLUID, pump armor, 8 oz (not shown)	1
29	16E844	KIT, pump, inlet valve <i>includes 29a, 29b, 29c</i>	1	63▲	222385	CARD, medical wallet (not shown)	1
29a	124249	BALL, intake	1	64	17K631	TAG, hang, tip (not shown)	1

▲Replacement Danger and Warning labels, tags, and cards are available at no cost.

LTS 17: 17K960 Cart Sprayer Parts

LTS 17: 17K960 Cart Sprayer Parts



Ref.	Torque
1	20-25 in-lb (2.3-2.8 N•m)
2	45-55 in-lb (5.0-6.2 N•m)
3	25-35 in-lb (2.8-4.0 N•m)
4	80-90 in-lb (9.0-10.0 N•m)
5	12-16 in-lb (1.4-1.8 N•m)
6	36-42 in-lb (4.0-4.7 N•m)

LTS 17: 17K960 Cart Sprayer Parts





17K960 Cart Sprayer Parts List


Ref.	Part	Description	Qty.	Ref.	Part	Description	Qty.
1	17L079	KIT, pump <i>includes 4, 8, 17, 29, 33, 48</i>	1	26a	16D951	TUBE, suction <i>includes 49</i>	1
2	16E835	KIT, drive	1	27	116295	CLAMP, tube	1
4	112689	SCREW, button, thd form	4	28	195400	CLIP, spring	2
5	17L282	KIT, motor	1	29	16E844	KIT, pump, inlet valve <i>(includes 29a, 29b, 29c)</i>	1
6	16D683	BRACKET, motor	1	29a	124249	BALL, intake	1
8	244267	KIT, pressure control <i>includes 8a, 8b</i>	1	29b	103338	O-RING	1
8a	15A464	LABEL, control	1	29c	123849	SPRING, inlet	1
8b	15K530	LABEL, control	1	30	257002	KIT, strainer	1
10	17K542	KIT, enclosure, LTS 17 <i>includes 10a, 10b, 10c, 10d, 16a</i>	1	31	15Y296	COVER, wire	1
10a	17K516	LABEL, A+ service	1	33	235014	KIT, drain valve <i>includes 33a, 33b, 33c</i>	1
10b	115477	SCREW, mach, torx, pan hd	4	33a	24E578	BASE, valve	1
10c	121481	NUT, U-type, tinnerman	1	33b	187625	HANDLE, valve, drain	1
10d	120093	SCREW, self drilling	1	33c	111600	PIN, grooved	1
12	118899	SWITCH, rocker, spdt	1	35	15R602	AXLE, cart	1
13	17L104	KIT, control board <i>includes 13a</i>	1	36	115095	WHEEL, 9 in.	2
13a	115477	SCREW, mach, torx	3	37	112612	CAP, hub	2
16	17L085	KIT, housing cover <i>includes 16a, 16b</i>	1	38	16H354	HANDLE, cart	1
16a	120724	SCREW	4	39	16H350	RACK, hose	1
16b	17J968	LABEL, Magnum LTS 17, front	1	40	120689	NUT, hex, acorn, 5/16-18 nickel	2
17	16E845	KIT, outlet valve	1	41	120788	SCREW, carriage	2
18	16W319	COVER, gear	1	42	115480	KNOB, t-handle	2
19	17L088	KIT, right leg, LTS 17 <i>includes 3 screws, 19a</i>	1	43	16D907	HANGER, pail	1
19a	260212	SCREW, hex washer	4	48	17L086	KIT, push prime	1
20	17L087	KIT, left leg, LTS 17 <i>includes 3 screws, 19a</i>	1	49	115099	WASHER, hose	1
22	16E843	KIT, power cord, LTS 17 <i>includes 22a, 22b</i>	1	51	247339	HOSE, cpld, 1/4 in. x 25 ft	1
22a	115498	SCREW, grounding	1	52	243011	GUN, spray, SG2	1
22b▲	17K627	LABEL, Magnum, warning (not shown)	1	60	3A3526	GUIDE, Magnum quick guide, English (not shown)	1
23	244035	DEFLECTOR, barbed	1	60a	3A3528	GUIDE, Magnum quick guide, Spanish (not shown)	1
24	115489	CLAMP, drain tube	2	61	115648	VALVE, power flush (not shown)	1
25	195108	TUBE, drain	1	62	244168	FLUID, pump armor, 8 oz (not shown)	1
26	24V073	KIT, suction tube <i>includes 23, 24, 25, 26a, 27, 28, 30, 49, 61</i>	1	63▲	222385	CARD, medical wallet (not shown)	1
				64	17K631	TAG, hang, tip (not shown)	1

▲Replacement Danger and Warning labels, tags, and cards are available at no cost.

ProLTS 170: 17H198 Stand Sprayer Parts

ProLTS 170: 17H198 Stand Sprayer Parts

Ref.	Torque
 1	140-160 in-lb (16 - 18 N•m)
 2	30-35 in-lb (3.5 - 4.0 N•m)
 3	110-120 in-lb (12 - 14 N•m)
 4	45-55 in-lb (5 - 6 N•m)



ti27198a

ProLTS 170: 17H198 Stand Sprayer Parts




17H198 Stand Sprayer Parts List


Ref. Part	Description	Qty.	Ref. Part	Description	Qty.
1	17K285 KIT, repair, motor, 120V <i>includes 1a</i>	1	27	17J032 LABEL, front	1
1a	287770 FAN	1	30	247340 HOSE, cpld, 1/4 in. x 50 ft	1
2	17J863 KIT, gear and yoke	1	31	243012 GUN, spray, SG3	1
3	17J173 CORD, power	1	32	115099 WASHER, hose	1
4	17J864 KIT, yoke	1	34	244035 DEFLECTOR, barbed	1
6	117493 SCREW, mach, hex, washer head	1	35	115489 CLAMP, drain tube	2
7	17J874 KIT, pump complete	1	36	195084 TUBE, drain	1
8	17J865 SHIELD, motor, blue <i>includes 9 and labels</i>	1	37	24V074 KIT, tube, suction <i>includes 32, 34, 35, 36, 37a, 38, 39, 40, 61</i>	1
9	118444 SCREW, mach, hwld 10-24 x 0.5 in.	3	37a	197607 TUBE, suction <i>includes 32</i>	1
10	17J866 COVER, front <i>includes 9, 10a, 10b, 12, 14</i>	1	38	116295 CLAMP, tube	1
10a	128551 CABLE, jumper, PC	1	39	195400 CLIP, spring	2
10b	17F262 COVER, wire	1	40	257002 KIT, strainer	1
12	115478 SCREW, mach, Torx, pan hd	4	45	17H422 CUP, suction/drain	1
13	15J803 SWITCH, bracket	1	56▲	17J027 LABEL, warning	1
14	17F233 COVER, pump, locking	1	57▲	222385 CARD, medical alert (not shown)	1
15	17J867 KIT, control board 120V <i>includes 15a, 16</i>	1	60	3A3526 GUIDE, Magnum quick guide, English (not shown)	1
15a	119276 FUSE, 12.5A slow blow	1	60a	3A3528 GUIDE, Magnum quick guide, Spanish (not shown)	1
16	117501 SCREW, plastite	1	61	115648 VALVE, power flush (not shown)	1
17	24Y329 KIT, switch, repair <i>includes 13</i>	1	62	244168 FLUID, pump armor, 8 oz (not shown)	1
18	115498 SCREW, mach, slot, hex whd	1	64	17K631 TAG, hang, tip (not shown)	1
19	17G328 PLATE, motor mount	1		17L305 KIT, conversion, lacquer (sold separate)	
20	16E836 KIT, right leg <i>includes 22, 23</i>	1			
21	16E837 KIT, left leg <i>includes 22, 23</i>	1			
22	260212 SCREW, hwh, thread forming	8			
23	15J699 CAP, tube	2			
24	276864 HANDLE, sprayer	1			
25	116139 GRIP, handle	1			

▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.

ProLTS 190: 17H206 Cart Sprayer Parts

ProLTS 190: 17H206 Cart Sprayer Parts

Ref.	Torque
 2	30-35 in-lb (3.5 - 4.0 N•m)
 3	110-120 in-lb (12 - 14 N•m)
 4	45-55 in-lb (5 - 6 N•m)








ProLTS 190: 17H206 Cart Sprayer Parts


17H206 Cart Sprayer Parts List

Ref.	Part	Description	Qty.	Ref.	Part	Description	Qty.
1	17F756	MOTOR, 120V	1	35	17K546	WHEEL <i>includes 34</i>	2
1a	287770	FAN	1	36	115480	KNOB, T-handle	2
2	17J863	KIT, gear and yoke	1	37	120689	NUT, hex, acorn, 5/16-18	2
3	17J173	CORD, power	1	38	15J790	HOOK, pail	1
4	17J864	KIT, yoke	1	39	16W362	AXLE, cart	1
7	17J874	KIT, pump complete	1	40	16H350	RACK, hose	1
8	17J865	SHIELD, motor, blue <i>includes 9 and labels</i>	1	41	16H353	HANDLE, cart	1
9	118444	SCREW, mach, hwhd 10-24 x 0.5 in.	3	42	120788	SCREW, carriage	2
10	17J866	COVER, front <i>includes 9, 10a, 10b, 12, 14</i>	1	43	115489	CLAMP, drain tube	1
10a	128551	CABLE, jumper, PC	1	44	195108	TUBE, drain	1
10b	17F262	COVER, wire	1	45	195400	CLIP, spring	1
12	115478	SCREW, mach, Torx, pan hd	1	46	244035	DEFLECTOR, barbed	1
13	15J803	SWITCH, bracket	1	47	257002	STRAINER, inlet	1
14	17F233	COVER, pump, locking	1	48	116295	CLAMP, tube	1
15	17J867	KIT, control board 120V <i>includes 15a, 16</i>	1	49	115099	WASHER, hose	1
15a	119276	FUSE, 12.5A slow blow	1	54	15J699	CAP, tube	2
16	117501	SCREW, plastite	1	55		CAP, tube	
17	24Y329	KIT, switch, repair <i>includes 13</i>	1		16W505	RIGHT, leg	1
18	115498	SCREW, mach, slot, hex whd	1		16W517	LEFT, leg	1
19	17G541	PLATE, motor, mount	1	56▲	17J027	LABEL, warning	1
20	17K185	LEG, right	1	57▲	222385	CARD, medical alert (not shown)	1
21	17K186	LEG, left	1	60	3A3526	GUIDE, Magnum quick guide, English (not shown)	1
22	260212	SCREW, hwh, thread forming	8	60a	3A3528	GUIDE, Magnum quick guide, Spanish (not shown)	1
26	24V073	TUBE, suction, assembly <i>includes 26a, 43, 44, 45, 46, 47, 48, 49, 61</i>	1	61	115648	VALVE, power flush (not shown)	1
26a	16H348	TUBE, suction <i>includes 49</i>	1	62	244168	FLUID, pump armor, 8 oz (not shown)	1
27	17J034	LABEL, front	1	64	17K631	TAG, hang, tip (not shown)	1
30	247340	HOSE, cpld, 1/4 in. x 50 ft	1		17J873	KIT, conversion, lacquer, (sold separate)	
31	243012	GUN, spray, SG3	1	▲Replacement Danger and Warning labels, tags, and cards are available at no cost.			
34	112612	CAP, hub	2				

ProXChange Pump Parts (ProLTS only)

ProXChange Pump Parts (ProLTS only)

Ref.	Torque
 1	140-160 in-lb (16 - 18 N•m)
 2	30-35 in-lb (3.4 - 4.0 N•m)
 3	30-35 ft-lb (40 - 48 N•m)
 4	220-250 in-lb (25 - 28 N•m)
 5	320-380 in-lb (36 - 43 N•m)



ti27261a

ProXChange Pump Parts (ProLTS only)


Pump Parts List

Ref.	Part	Description	Qty.	Ref.	Part	Description	Qty.
1	17G447	HOUSING, pump	1	13	120776	PACKING, O-ring	1
2	17D364	GUIDE, ball	1	14	24Y327	KIT, repair outlet <i>includes 12, 13</i>	1
3	128336	SPRING, compression	1	15	17J880	KIT, outlet valve repair <i>includes 42</i>	1
4	105445	BALL, 0.5 in.	1	16	128323	SPRING, valve	1
5	117501	SCREW, mach, slot	2	21	16D531	PACKING, O-ring	1
6		HWH		25	24Y472	KIT, repair, piston pump	1
		KIT, inlet housing		28	17J881	KIT, pressure control <i>includes 5, 28a, 28b, 28c, 29, 30</i>	1
	17J876	ProX17, ProX19	1	28a	15A464	LABEL, control	1
	17J877	ProX21	1	28b	15K530	LABEL, control	1
6a	124582	O-ring	1	28C	106555	O-ring	1
7	17J878	KIT, PushPrime <i>includes 7a, 7b</i>	1	29	17F227	BRACKET, electrical connector	1
7a	16P303	PACKING, O-ring	1	30	17F229	KIT, shield, wire	1
7b	17G540	LABEL, PushPrime	1	42	122486	PACKING, O-ring	1
8	235014	VALVE, drain, assy	1				
9	224807	BASE, valve	1				
10	187625	HANDLE, valve, drain	1				
11	111600	PIN, grooved	1				
12	257001	KIT, filter	1				


Wiring Diagram - 110/120V

Wiring Diagram - 110/120V

LTS 15/LTS 17:



ProLTS 170/ProLTS 190



Technical Specifications

	US	Metric
Sprayer		
Maximum fluid working pressure.	3000 psi	207 bar, 20.7 MPa
Maximum Delivery		
LTS 15	0.27 gpm	1.0 lpm
LTS 17	0.31 gpm	1.2 lpm
ProLTS 170	0.34 gpm	1.3 lpm
ProLTS 190	0.38 gpm	1.4 lpm
Maximum Tip Size		
LTS 15	0.015 in.	0.38 mm
LTS 17	0.017 in.	0.43 mm
ProLTS 170	0.017 in.	0.43 mm
ProLTS 190	0.019 in.	0.48 mm
Fluid Outlet npsm	1/4 in.	1/4 in.
Generator Minimum	2500 W	
Power Requirements		
LTS 15, LTS 17	110–120V, 9 A, 1Ø	
ProLTS 170, ProLTS 190	110–120V, 8 A, 1Ø	
Dimensions		
Height		
LTS 15	17.9 in.	45.5 cm
LTS 17	37.0 in.	94.0 cm
ProLTS 170	21.2 in.	53.9 cm
ProLTS 190	37.2 in.	94.5 cm
Length		
LTS 15	14.5 in.	36.8 cm
LTS 17	19.3 in.	49.0 cm
ProLTS 170	15.1 in.	38.4 cm
ProLTS 190	20.0 in.	50.1 cm
Width		
LTS 15	12.4 in.	31.5 cm
LTS 17	15.3 in.	38.9 cm
ProLTS 170	13.2 in.	33.5 cm
ProLTS 190	17.2 in.	43.7 cm
Weight		
LTS 15	16.5 lb.	7.5 kg
LTS 17	26.5 lb.	12.0 kg
ProLTS 170	27.3 lb.	12.4 kg

Technical Specifications

	US	Metric
ProLTS 190	37.5 lb.	17.0 kg
Storage temperature range ♦❖	−30° to 160°F	−35° to 71°C
Operating temperature range ✓	40° to 115°F	4° to 46°C
Materials of Construction		
Wetted materials on all models	stainless steel, brass, leather, ultra-high molecular weight polyethylene (UHMWPE), carbide, nylon, aluminum, PVC, polypropylene, fluoroelastomer, plated steel	
Notes		
* Startup pressures and displacement per cycle may vary based on suction condition, discharge head, air pressure, and fluid type.		

- ♦ **When pump is stored with non-freezing fluid. Pump damage will occur if water or latex paint freezes in pump.**
- ❖ Damage to plastic parts may result if impact occurs in low temperature conditions.
- ✓ Changes in paint viscosity at very low or very high temperatures can affect sprayer performance.

Graco Standard Warranty

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

For the latest information about Graco products, visit www.graco.com.

For patent information, see www.graco.com/patents.

TO PLACE AN ORDER, contact your Graco distributor or call 1-800-690-2894 to identify the nearest distributor.



**Every Graco purchase comes
with A+ Customer Service.**

**Call: (888) 541-9788 or go to
magnum.graco.com for videos
and product information.**

PROVEN QUALITY. LEADING TECHNOLOGY.

*All written and visual data contained in this document reflects the latest product information available at
the time of publication.*

Graco reserves the right to make changes at any time without notice.

Original instructions. This manual contains English. MM 3A3529

Graco Headquarters: Minneapolis
International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA

Copyright 2016, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com
Revision C, April 2017