


Pneumatic/Electric Lube Sentry Valve



PNEUMATIC LUBE SENTRY VALVE

OPERATION: Initiate lubricant flow from the lube pump serving the divider valve or pump to point system (until flow has been established, the electric or pneumatic circuit to the Lube Sentry must be bypassed). Lubricant passing through the hydraulic section of the valve (See Figure 1 or 2) from port (1) to port (2) moves to piston (3) in the direction of the arrow. The actuator rod (4) is attached to piston (3) and simultaneously moves in the same direction allowing the directional spool (5) in the air valve of the Pneumatic Lube Sentry (See Figure 1) to permit air to flow between port "A" and port "C" or tripping the microswitch(es). (See Figure 2 Note 2 on the Electric Lube Sentry.) The Lube Sentry is now in a flow position.

When lubricant flow stops, spring (6) returns piston (3) in the opposite direction, closing the porting to the lube outlet (7). The lubricant ahead of piston (3) is forced back through the adjustable needle valve (8) at a controlled rate. As piston (3) returns to the right, the attached actuator rod (4) moves the Pneumatic Lube Sentry directional spool (5) permitting air to now flow between port "A" and port "B" (See Figure 1), or changing the position of the microswitch(es) (See Figure 2 Note 2) on the Electric Lube Sentry. The Lube Sentry is now in a no-flow condition. Figure 1 shows a typical no-flow position.

Adjusting needle valve (8) clockwise increases shutdown time. A counterclockwise adjustment decreases the shutdown time.

Note 1: Pneumatic Valve Operation (During Lubricant Flow)





Figure 1. Pneumatic Lube Sentry Valve



ELECTRIC LUBE SENTRY VALVE




Figure 2. Electric Lube Sentry Valve

INSTALLATION

General Lube Line Connection

1. The Lube Sentry Valve should be located in the lube line downstream of pump, filters, and controls, but ahead of the master divider valve. (A high-pressure line filter placed after the pump is insurance against system plugging due to oil-born dirt.)
2. A pressure rupture assembly (Disk Relief Type) must be located in the main lube line between the pump and the line filter.
3. Always install Lube Sentry with "LUBE OUT" port up, to permit natural air purging of the device.

General Shutdown Reaction Adjustment


1. See graphs for minimum flow rates, with various viscosity oils, and shutdown time recommendations.
2. Start with the adjustment screw (Figures 1 & 2, Item 8) flush with end of housing. Turn on lube system with pump discharging oil at normal flow rate and pressure.
3. Slowly rotate adjustment screw clockwise until the electric switch/air valve changes mode (flow condition).
4. Stop oil flow and note time for electric switch air valve to change mode (no-flow condition).
5. Start normal flow of oil and note that the electric switch/air valve changes mode (flow condition) within two minutes and remains in this mode as long as normal oil flow continues.
6. For positive shutdown indication on the Electric Lube Sentry, an ohmmeter or continuity meter should be connected to wiring as follows: **No flow condition** – continuity between red and white wires. **Flow condition** – continuity between red and blue wires. **Caution** – In an explosive atmosphere, use only approved device for checking continuity
7. This is the minimum shutdown time attainable for the application. The shutdown time can be increased by continuing to turn the adjustment screw clockwise. **Caution** – Do not adjust shutdown time greater than shown on graphs or inconsistent shutdown time will result.

Pneumatic Lube Sentry Valve Installation


Pneumatic Connections

A. Series Type (in-line) Safety Control Pneumatic Circuits (See Figure 3)

1. Trace pneumatic safety circuits from the source of its take-off air supply through the various safety devices used on the engine and compressor to the entrance of the pilot air port (bonnet port) on the safety control valve or gas shut-off valve.
2. Select the most convenient location to break into the air circuit, either between two other safety devices or between the last safety device and the bonnet port of the safety control valve.



Graph 1. Minimum Flow Rate



Graph 2. Minimum Shutdown Time

3. Break the air circuit at the selected point and tube the Lube Sentry Valve into the circuit with air flow entering port "A" and leaving port "C" (See Figure 1). If gas is used as the control medium rather than air, tube the exhaust port "B" into a suitable vent line.

CAUTION – Never plug port in series type shutdown circuits.

4. To test device for operation, start engine to initiate flow in the divider valve system. Operation of the air valve within the Lube Sentry will be observed as the tripping out of the reset latch (manual override) lever on the safety control valve (see Figure 3), and the continued operation of the engine.

After a short interval of running during which the engine and compressor receive sufficient lubrication and all other safety devices move to the RUN position, dump the output of the pumps serving the divider valve systems by removing the pump blowout disc or a pipe plug from the pump manifold assembly. When the flow to the distribution system stops, the Lube Sentry should operate to dump the pressure in the pneumatic safety circuit, dropping out the safety control valve to stop the engine. (If shutdown action is sluggish, reduce the setting of the adjustable orifice through which air for the safety circuit passes.)

The Lube Sentry is provided with a 1/8" air valve. If the control orifice for the safety system is too large, air will be supplied to the Lube Sentry too quickly to permit it to dump properly.)

A pneumatic relay may be operated by the Lube Sentry (see Figure 4).

B. Parallel Type Safety Control Pneumatic Circuits (See Figure 5)

1. Parallel type safety circuits rely on their devices to dump the pilot control pressure on the safety control valve in case of trouble. This control pressure is supplied to the pilot (bonnet) port of the safety shutdown valve through an adjustable orifice which permits enough air to enter the circuit to maintain pressure on the port. When any safety device operates, the pilot pressure is dumped, with the control orifice preventing sufficient air to enter the system to maintain pressure.
2. The Lube Sentry should be teed in to the line serving the pilot port of the safety shutdown valve.
3. Connect port "B" into the safety circuit.
4. Plug port "C".
5. Port "A" (exhaust) may be connected to a vent line if necessary.
6. To test device for operation see item 4 under Series Type.

Electric Lube Sentry Valve Installation

Electric Switch Adjustment and Replacement

The electrical end of the Lube Sentry has been adjusted correctly at the factory. If the electric switch assembly is replaced, repairs required or adjustment necessary, proceed as follows:

Warning: Never remove the Lube Sentry Electric Switch Assembly from the Actuator Assembly or make any adjustments to the Electric Switch without first being sure there is **NO Electricity Present** at the Lube Sentry.

To Replace Electric Switch Assembly

1. After determining there is no electricity to the Lube Sentry, remove the switch assembly from the actuator assembly by removing the four-socket head screws holding the two assemblies together, being careful not to scratch the mating surfaces.
2. Be sure no corrosion or dirt is present. In a no-flow condition, the actuator rod should extend approx. 5/32 inches beyond the actuator rod housing.
3. Replace electric switch assembly. **Caution:** Do not reassemble if scratches, dirt, or corrosion are present on mating surfaces of switch and actuator assembly.

To Adjust Electric Switch Assembly

1. With no lubricant flowing, Lube Sentry should be in shutdown or warning position (switch actuated). You should show continuity between red and white wires, if not, the microswitch is misadjusted or broken.
2. If adjustment is required, remove the electrical connection

housing, consisting of conduit elbow and cap, nipple, and adaptor by loosening and removing the adaptor, (Figure 7, Item 31) from the switch housing.

3. Loosen setscrew (Item 26) located on bottom of switch body.
4. Actuating piston must be completely extended (Item 15).
5. Rotate switch enclosure screw (Item 23) clockwise until switch just actuates. (Continuity is obtained between red and white wires.) Rotate additional 1/4 turn after switch actuates.
6. Tighten setscrew (Item 26) to lock nylon ball (Item 25) against switch enclosure screw.
7. If microswitch is defective, replace.
8. Re-adjust switch.




Figure 3. Typical Series Installation of Pneumatic Engine Shutdown Circuit





Figure 4. Typical Installation with Pneumatic Indicating Relay



NOTE: Installation of the Pneumatic Lube Sentry as shown on the drawing provides automatic signalling of cylinder lubrication trouble. No flow caused by pump failure, broken line or low oil supply will cause the Lube Sentry to operate, removing air pressure from the fuel valve and stopping the engine.

Figure 5. Typical Parallel Gas Engine Installation of Lubriquip Pneumatic Lube Sentry with Fulton-Sylphon No. 530 Pneumatic Pilot Valve

Ordering Information		
Description	Part No.	Old Part No.
Pneumatic Lube Sentry, Complete	563506	527-100-190
Pneumatic Valve	563503	527-100-150
Actuator	563502	527-100-130
Electric Lube Sentry, Complete	563505	527-100-180
Switch Assembly	563504	527-100-170

For more information on the Pneumatic or Electric Lube Sentry Valve consult Literature L15831

Figure 6. Actuator Assembly

Item	Description	Part No.	Old Part No.	Qty.
1	Lube Sentry Actuator Assembly	563502	527-100-130	1
2	• Body (Matched Fit)	560999	527-100-000	1
3	• Piston (Matched Fit)	561000	527-100-010	1
4*	• Valve - Adjustment	561005	527-100-062	1
5*	• Housing Adjustment Screw	561004	527-100-052	1
6*	• O-Ring, Viton, 70 Duro	556560	422-041-140	2
7*	• O-Ring, Viton, 70 Duro	556551	422-040-060	1
8*	• Back-Up Ring	557719	527-000-760	2
9*	• O-Ring	556554	422-040-110	1
10*	• Setscrew, 1/4-20 x 1/4 Hex	555531	417-060-020	1
11*	• Ball, 3/16, Steel	556328	401-030-030	1
12*	• Spring-Piston Return	557753	527-100-110	1
13*	• O-Ring	556557	422-040-140	1
14*	• Spacer, O-Ring Retaining	561009	527-100-100	1
15*	• Piston-Switch Actuating	561002	527-100-030	1
16*	• Locking Screw, 3/8-24 x 3/16	556470	416-700-780	1
17*	• Back-Up Ring	556584	423-700-038	1
18*	• O-Ring	556553	422-040-080	1
19	• Screw - Piston Enclosure	561003	527-100-040	1
20	• Houseing - 5 W. Act. Piston	561001	527-100-020	1
-	Adjustment Screw & Housing Only	564405	527-100-370	1
*	Actuator Assembly Repair Kit	564436	560-001-130	1




Figure 7. Switch Assembly for Electric Lube Sentry

Item	Description	Part No.	Old Part No.	Qty.
22	Switch Assembly - Electric Lube Sentry	563504	527-100-170	1
23*	• Switch Enclosure Screw	557355	503-680-000	1
24*	• Microswitch Assembly	557757	527-100-210	1
25*	• Nylon Ball, 5/32 in.	555781	504-706-000	1
26*	• Setscrew, 10-32 x 3/8 in.	556476	417-450-040	1
27*	• Round Head Screw	555496	416-010-070	2
28*	• Int. Lockwasher	555631	421-070-010	2
29*	• Socket Head Srew, 1/4-20 x 1-3/4	556510	419-130-090	4
30	• Switch Housing	561008	527-100-090	1
31	• Adapter	557356	503-681-000	1
32	• Conduit Elbow w/Nipple	557384	507-912-000	1
*	Electric Switch Assembly Repair Kit	563908	560-001-120	1





Figure 8. Valve Assembly for Pneumatic Lube Sentry

Item	Description	Part No.	Old Part No.	Qty.
22	Valve Assembly - Pneumatic Lube Sentry	563503	527-100-150	1
23*	• O-Ring, 70 Duro	555690	422-041-200	1
24*	• O-Ring, 70 Duro	555685	422-040-220	1
25*	• Air Valve Spring	557353	503-658-000	1
26*	• Valve Cartridge	557354	503-659-000	1
27*	• Spring Guide	561011	527-100-320	1
28*	• Socket Head Screw, 1/4-20 x 1-3/4	556510	419-130-090	4
29	• Air Valve Housing	561006	527-100-070	1
30	• Air Valve Enclosure Screw	561007	527-100-080	1
*	Pneumatic Lube Sentry Repair Kit	563907	560-001-110	1



Specifications

Material	Steel
Max Pressure	6,000 psi (414 bar)
(1) Flow Rate (per day)	4 - 400 pints (1.89 - 189.2 liters)
Pressure Drop	250 psi (17 bar)
Seals	Viton
(1) Lubricant	Oil (450 - 2,000 SUS)
Net Weight	5 lb (2.265 kg)

Operating Temperature	-20°F to 180°F (-29°C to 82°C)
Max Air Pressure (Pneu.)	125 psi (8 bar)
Electrical Rating	1) 5 amps @ 125/250 VAC 2) A, B or C @ 28 VDC (A) Inductive - 3 amp (B) Resistive - 5 amp (C) Max Inrush - 15 amp

(1) Ref to Graph 1

All written and visual data contained in this document are based on the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice.

Contact us today!

To receive product information or talk with a Graco representative, call 800-533-9655 or visit us online at www.graco.com.

