



## Mix Manifold Kit

3A5079F  
EN


For near-the-gun mixing of 2 component materials when used with a ProMix® PD2K Proportioner.  
For professional use only.



### Important Safety Instructions

Read all warnings and instructions in this manual and in your PD2K proportioner manual. Save all instructions.

*See page 2 for model part numbers,  
maximum fluid working pressure, and  
approvals.*



ti29250a

# Models

## Mix Manifold Kits with Static Mixer and Mix-at-Belt Brackets

Part No.	Series	Description	Maximum Fluid Working Pressure
26A358	A	Low Pressure Mix Manifold	300 psi (2.1 MPa, 21 bar)
26A225	A	High Pressure Mix Manifold	1500 psi (10.5 MPa, 105 bar)
26A223	A	Low Pressure Mix Manifold, for acid-catalyzed materials	300 psi (2.1 MPa, 21 bar)
26A224	A	High Pressure Mix Manifold, for acid-catalyzed materials	1500 psi (10.5 MPa, 105 bar)

## Mix Manifold Assemblies

Part No.	Series	Description	Maximum Fluid Working Pressure
26A356	B	Low Pressure Mix Manifold	300 psi (2.1 MPa, 21 bar)
26A357	B	High Pressure Mix Manifold	1500 psi (10.5 MPa, 105 bar)
26A221	B	Low Pressure Mix Manifold, for acid-catalyzed materials	300 psi (2.1 MPa, 21 bar)
26A222	B	High Pressure Mix Manifold, for acid-catalyzed materials	1500 psi (10.5 MPa, 105 bar)





II 2 G Ex h IIA T6 Gb

## Related Manuals

Current manuals are available at [www.graco.com](http://www.graco.com).

Manual No.	Description
332457	ProMix PD2K Proportioner for Manual Spray Applications, Installation
332562	ProMix PD2K Proportioner for Manual Spray Applications, Operation
3A4186	ProMix PD2K Dual Fluid Panel Proportioner for Manual Spray Applications, Operation

# WARNING

	<p><b>FIRE AND EXPLOSION HAZARD</b></p> <p>Flammable fumes, such as solvent and paint fumes, in <b>work area</b> can ignite or explode. Paint or solvent flowing through the equipment can cause static sparking. To help prevent fire and explosion:</p> <ul style="list-style-type: none"> <li>• Use equipment only in well ventilated area.</li> <li>• Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static arc).</li> <li>• Ground all equipment in the work area. See <b>Grounding</b> instructions.</li> <li>• Never spray or flush solvent at high pressure.</li> <li>• Keep work area free of debris, including solvent, rags and gasoline.</li> <li>• Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present.</li> <li>• Use only grounded hoses.</li> <li>• Hold gun firmly to side of grounded pail when triggering into pail. Do not use pail liners unless they are antistatic or conductive.</li> <li>• <b>Stop operation immediately</b> if static sparking occurs or you feel a shock, Do not use equipment until you identify and correct the problem.</li> <li>• Keep a working fire extinguisher in the work area.</li> </ul>
	<p><b>SKIN INJECTION HAZARD</b></p> <p>High-pressure fluid from gun, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. <b>Get immediate surgical treatment.</b></p> <ul style="list-style-type: none"> <li>• Do not spray without tip guard and trigger guard installed.</li> <li>• Engage trigger lock when not spraying.</li> <li>• Do not point gun at anyone or at any part of the body.</li> <li>• Do not put your hand over the spray tip.</li> <li>• Do not stop or deflect leaks with your hand, body, glove, or rag.</li> <li>• Follow the <b>Pressure Relief Procedure</b> when you stop spraying/dispensing and before cleaning, checking, or servicing equipment.</li> <li>• Tighten all fluid connections before operating the equipment.</li> <li>• Check hoses and couplings daily. Replace worn or damaged parts immediately.</li> </ul>



# WARNING



## EQUIPMENT MISUSE HAZARD

Misuse can cause death or serious injury.



- Do not operate the unit when fatigued or under the influence of drugs or alcohol.
- Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See **Technical Specifications** in all equipment manuals.
- Use fluids and solvents that are compatible with equipment wetted parts. See **Technical Specifications** in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request Safety Data Sheets (SDSs) from distributor or retailer.
- Do not leave the work area while equipment is energized or under pressure.
- Turn off all equipment and follow the **Pressure Relief Procedure** when equipment is not in use.
- Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only.
- Do not alter or modify equipment. Alterations or modifications may void agency approvals and create safety hazards.
- Make sure all equipment is rated and approved for the environment in which you are using it.
- Use equipment only for its intended purpose. Call your distributor for information.
- Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces.
- Do not kink or over bend hoses or use hoses to pull equipment.
- Keep children and animals away from work area.
- Comply with all applicable safety regulations.



## TOXIC FLUID OR FUMES

Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.

- Read Safety Data Sheets (SDSs) to know the specific hazards of the fluids you are using.
- Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.




## PERSONAL PROTECTIVE EQUIPMENT

Wear appropriate protective equipment when in the work area to help prevent serious injury, including eye injury, hearing loss, inhalation of toxic fumes, and burns. This protective equipment includes but is not limited to:

- Protective eyewear, and hearing protection.
- Respirators, protective clothing, and gloves as recommended by the fluid and solvent manufacturer.

# Installation

1. Connect the component A supply to the A side fitting (11a) of the mix manifold.
2. Connect the component B supply to the B side fitting (11b) of the mix manifold.
3. Connect the solvent supply to the solvent fitting (30) of the mix manifold.
4. Connect the static mixer hose (106) to the manifold outlet and to the gun whip hose.



This equipment must be grounded to reduce the risk of static sparking. Static sparking can cause fumes to ignite or explode. Grounding provides an escape wire for the electric current.

5. Connect the ground wire (105) to the ground screw (41). Connect the other end of the ground wire to a true earth ground.





Figure 1 Mix Manifold (bottom view)

# Operation

## Pressure Relief Procedure




Follow the **Pressure Relief Procedure** whenever you see this symbol.




This equipment stays pressurized until pressure is manually relieved. To help prevent serious injury from pressurized fluid, such as skin injection, splashing fluid and moving parts, follow the **Pressure Relief Procedure** in your PD2K Operation manual (see [Related Manuals, page 2](#)) when you stop spraying and before cleaning, checking, or servicing the equipment.

## Gun Flush Procedure


1. Check that all hose connections are tight.
2. Press Standby  on the booth control. Trigger gun to relieve pressure.
3. Shut off the atomizing air.
4. If you are using a high pressure gun, engage the trigger lock. Remove the spray tip and clean it separately.
5. If using an electrostatic gun, shut off the electrostatics before flushing the gun.
6. Set the solvent supply pressure regulator at the lowest pressure possible, to avoid splashing or an injection injury. Generally a setting of 25–50 psi (0.18–0.35 MPa, 1.8–3.5 bar) is sufficient.


## Operation


- Turn off both A and B sides by rotating the main handle (26) down.




- Turn the solvent handle (SH) clockwise 90° to flush the A side.



- Press Purge  on the booth control to purge the A side. Trigger gun into a grounded waste container. When done purging, the system automatically switches to Standby mode, signalling the user to release the trigger.
- Turn the solvent handle (SH) counterclockwise 180° to flush the B side.



- Press Purge  on the booth control to purge the B side. Trigger gun into a grounded waste container. When done purging, the system automatically switches to Standby mode, signalling the user to release the trigger.


**NOTE:** The Purge Time value for the initial purge is based on the flush sequence defined in the loaded recipe. The Purge Time value for the second purge may be different and is based on the Recipe 0 flush sequence. See the Setup Mode screens in your PD2K Operation manual (see [Related Manuals, page 2](#)).

- Leave the mix manifold handles (SH and 26) in the positions shown in Step 10 when unit is in standby.

**NOTE:** If performing a color change, purge gun (as shown above) before selecting a new recipe. If only a new recipe is initiated, it will not purge both sides of the mix manifold.


## Spraying Procedure

- Check that all hose connections are tight before each use.
- Rotate solvent handle (SH) to the center spray position and rotate main handle (26) up.



- Follow spraying procedures in your PD2K Operation manual (see [Related Manuals, page 2](#)).

# Repair



## Disassembly

The following procedures describe the process of removing the handles (26 and SH) and disassembling the solvent housing (2), the integrator housing (3), and the main housing (1).

**NOTE:** Some parts, such as seals, seats, and o-rings, will need to be replaced after disassembly. Do not proceed unless you have replacement parts on hand. See [Kits and Accessories, page 17](#), for replacement kits.

### Remove Handles

1. Perform the [Gun Flush Procedure, page 5](#).
2. Perform the [Pressure Relief Procedure, page 5](#).
3. Relieve the pressure as described in the PD2K operation manual. Disconnect the hoses, taking note of which port (A or B) they are connected to.
4. Disconnect the mix manifold from the system.
5. Loosen the set screw (22) on each side of the main handle (26).




Figure 2 Remove handle assemblies

6. Remove the screw (28) and lock nut (37) on each side of the handle (26).

7. Slide the handle (26) away from the A-side (24) and B-side (25) handle supports. Remove the supports (24 and 25) away from stems (23) on each side of the main housing (1).
8. Loosen the set screw (22) and remove the lock nut (37) from the solvent handle assembly (SH).
9. Slide the solvent handle assembly (SH) away from the stem (20) on the solvent housing (2).

### Remove and Disassemble Solvent Housing

1. Remove the inlet fitting (30) from the solvent housing (2), and remove and discard the o-ring (12).




Figure 3 Remove and disassemble solvent housing

2. Remove the valve nut (18).

**IMPORTANT:** To prevent damage to the valve stem (20), the three throat valve seals (17) must be removed before pulling ball valve stem from solvent housing (2). The three seals are compressed together inside the housing. They are formed to the internal threads and will come out in the following step.

3. Press the tip of a pick into seal (17). Rotate the pick counter-clockwise to turn the seals up and out of the housing (2). Repeat as necessary to remove all three seals. If the third seal does not come out using this method, remove it along with the valve stem in the following step.

## Repair

4. Remove the valve stem (20) from the solvent housing (2) using locking pliers and a flat head screwdriver. Clamp the locking pliers on the rounded surface of the valve stem (20) close to the housing (2) with sufficient space to allow a screwdriver between the housing (2) and the pliers. Use the screwdriver to lever the valve stem (20) out of the housing (2). The valve seal (21) should come out with valve stem (20).




Figure 4 Use locking pliers and screwdriver to remove valve stem

5. Remove spacer (16) from the bottom of the valve bore in the housing (2). Discard the seal (21) and spacer (16).
6. Inspect the valve stem (20) for wear or damage, and clean or replace as necessary.
7. Inspect the inside of the solvent housing (2) for any pieces of worn or damaged seals.
8. Remove the screws (27) and pull the solvent housing (2) from the main housing (1), and remove and discard the o-rings (14 and 15).

## Remove and Disassemble Integrator Housing

1. Remove the screws (27) and pull the integrator housing (3) from the main housing (3), and remove and discard the o-rings (14 and 15).





Figure 5 Remove and disassemble integrator housing

2. Remove the check valve seats (4) using a 4mm (5/32 in.) hex key. Remove balls (6), retainers (7), and compression springs (8).
3. Inspect seats (4) and the integrated seat o-rings, balls (6), retainers (7), and compression springs (8) for wear or damage, and clean or replace as necessary.
4. Remove the outlet fitting (9) and integrator tube (10) from the integrator housing (3), and remove and discard the o-ring (13).
5. Inspect and clean the inside of integrator housing (3) of any pieces of worn or damaged seats, o-rings, retainers, or hardened material.



## Disassemble Main Housing

1. Remove the inlet fittings (11) from the main housing (1), and remove and discard the o-rings (12).



ti30866c


Figure 6 Disassemble main housing

2. Remove the valve nut (18).

**IMPORTANT:** To prevent damage to the valve stem (23), the three throat valve seals (17) must be removed before pulling valve stem (23) from the main housing (1). The three seals are compressed together inside the housing (1). They are formed to the internal threads and will come out in the following step.

3. Press the tip of a pick into the seal (17). Rotate the pick counter-clockwise to turn the seals up and out of the housing (1). Repeat as necessary to remove all three seals (17). If the third seal does not come out using this method, remove it along with the valve stem in the following step.

4. Remove the valve stem (23) from the main housing (1) using locking pliers and a flat head screwdriver. Clamp the locking pliers on the rounded surface of valve stem (23) close to the housing (1) with sufficient space to allow a screwdriver between the housing (1) and the pliers. Use the screwdriver to lever the valve stem (23) out of the housing (2). The valve seal (21) should come out with valve stem (23).



©33895a

Figure 7 Use locking pliers and screwdriver to remove valve stem

5. Remove the spacer (16) from the bottom of valve bore in the housing (1). Discard the seal (21) and spacer (16).
6. Repeat steps 2-5 to remove valve stem components from the opposite side of the main housing (1).
7. Inspect both valve stems (23) for wear or damage, and clean or replace as necessary.
8. Inspect the inside of the main housing (1) for any pieces of worn or damaged seals.
9. Remove the check valve seats (4) using a 4mm (5/32 in.) hex key. Remove balls (6), retainers (7), and compression springs (8).
10. Inspect seats (4) and the integrated seat o-rings, balls (6), retainers (7), and compression springs (8) for wear or damage, and clean or replace as necessary.

## Reassembly

The following procedures describe the process of reassembly and attaching the main housing (1), the integrator housing (3), the solvent housing (2), and the handles (26 and SH).


**NOTE:** Lubricate all o-rings when reassembling.

See [Kits and Accessories, page 17](#), for parts needed when reassembling.

### Reassemble Main Housing

The A and B side valve stems (23) have holes that pass directly through the stem. But the solvent valve stem (20) has a hole that enters from the end face of the stem and exits at 90 degrees out of the side of the stem. Be sure to use the correct valve stems (23) in the following steps.


1. Apply lubrication, such as a compatible lithium grease, to the valve stem (23), seal (21), and spacer (16).



ti30866c

Figure 8 Reassemble main housing


2. Install the spacer (16) into the housing (1) bore, aligning flats and pressing completely to the bottom of the bore.
3. Assemble the seal (21) on to the stem (23), and rotate the seal to align the holes.



ti32257b

Figure 9 Seal correctly aligned with the valve stem

4. Slide the stem assembly (21 and 23) into the installation tool body (43).
5. Slide the installation tool plunger (44) into the opposite end of the body (43). The plunger (44) should slide down easily and contact the seal (21). Ensure the holes on the stem (23) and seal (21) are still aligned.



ti32260b


Figure 10 Use installation tool to install stem assembly

6. Align the body (43) with the raised boss around the housing (1) bore. The seal (21) should slightly protrude into the bore. Using a press, vice, or by lightly tapping with a hammer, completely depress the plunger (44) to install the stem assembly (21 and 23) into the housing bore.
  7. Assemble the three throat valve seals (17) onto the valve stem (23), and press in with the plunger (44).
  8. Apply anti-seize lubricant (Loctite 51269, or equivalent) to the threads on the valve nut (18). Slide the valve nut (18) onto the stem (23) and into the housing (1). Use a torque wrench and tighten to **100 in-lbs (11.3 N·m)**.
- IMPORTANT:** Failure to tighten to the proper torque may result in improper sealing or damage to valve components.
9. Repeat steps 1–8 for the valve stem assembly on the opposite side of the main housing (1).

## Reassemble and Attach Integrator Housing

**NOTE:** Lubricate o-rings before installing into the main and integrator housings (1 and 3).

1. Place the o-rings (12) onto the inlet fittings (11), as shown in the figure. Apply Loctite Blue, or equivalent, to the upper threads on the inlet fittings (11) and screw the fittings into the bottom of the main housing (1).



ti30865a

Figure 11 Reassemble and attach integrator housing

2. Hold the integrator housing (3) with the two check valve holes facing up. Insert the compression springs (8), check valve retainers (7), and balls (6), as shown in the figure. Screw the check valve seats (4) into the housing (1) until flush with the surface.
3. Press the o-rings (14 and 15) into the indented circles in the top of the main housing (1).
4. Attach the integrator housing (3) to the top of the main housing (1) with four screws (27), as shown in the figure. Tighten to 25-30 in-lb (2.8-3.4 N·m).
5. Thread the integrator tube (10), narrow end up, into the top of the integrator housing (3). Slide the o-ring (13) onto the bottom end of the outlet fitting (9), and screw the fitting into the top of the housing (3).

## Reassemble and Attach Solvent Housing

The solvent valve stem (20) has a hole that enters from the end face of the stem and exits at 90 degrees out of the side of the stem. The A and B side valve stems (23) have holes that pass directly through the stem. Be sure to use the correct valve stem (20) in the following steps.

**NOTE:** Lubricate o-rings before installing into the solvent housing (2).

1. Apply lubrication, such as a compatible lithium grease, to the valve stem (20), seal (21), and spacer (16).




Figure 12 Reassemble and attach solvent housing

2. Hold the main housing (1) with the two check valve holes facing up. Insert the compression springs (8), check valve retainers (7), and balls (6), as shown in the figure. Screw the check valve seats (4) into the housing (1) until flush with the surface.
3. Press the o-rings (14 and 15) into the o-ring grooves in the side of the solvent housing (2).
4. Attach the solvent housing (2) to the side of the main housing (1) with four screws (27), as shown in the figure. Tighten to 25-30 in-lbs (2.8-3.4 N·m).
5. Install spacer (16) into housing (2) bore, aligning flats and pressing completely to the bottom of the bore.

6. Assemble seal (21) on to stem (20), and rotate the seal to align the holes.




Figure 13 Seal correctly aligned with the valve stem

7. Slide the stem assembly (20 and 21) into the installation tool body (43).
8. Slide installation tool plunger (44) into opposite end of the body (43). The plunger (44) should slide down easily and contact the seal (21).

**IMPORTANT:** To ensure proper A and B flushing operation, ensure the hole in the stem points toward the B side of the solvent housing (2). Failure to align the stem (20) in this direction may result in incomplete flushing of the manifold.




Figure 14 Stem valve hole pointing towards B side of solvent housing

9. Align the body (43) with the raised boss around the housing (2) bore. The seal (21) should slightly protrude into the bore. Using a press, vice, or by lightly tapping with a hammer, completely depress the plunger (44) to install the stem assembly (20 and 21) into the housing bore.
10. Assemble the three throat valve seals (17) onto the valve stem (20), and press in with the plunger (44).

- Apply anti-seize lubricant (Loctite 51269, or equivalent) to the threads on the valve nut (18). Slide the valve nut (18) onto the stem and into the housing (2). Use a torque wrench and tighten to **100 in-lbs (11.3 N·m)**.

**IMPORTANT:** Failure to tighten to the proper torque may result in improper sealing or damage to valve components.

## Reattach Handles

- Slide the solvent handle assembly (SH) onto the vertical stem (20).

The handle should be pointed toward the B side and slide onto the stem if the proper steps were followed in the previous section. If the ball stem was not installed with the opening pointed toward the B side, or if you suspect it may have rotated, remove the side npt plug (42) and turn the ball stem until you can visually see the side opening. Apply thread sealant and reinstall npt plug (42).

The threaded end of the stem (20) will extend beyond the top of the handle (SH) when the flats on the stem are properly aligned with the handle.

Torque the set screw (22) to 10 in-lb (1.1 N·m).

- Screw the lock nut (37) on to the threaded end of the valve stem (20), and torque to 18–23 in-lb (2.0–2.6 N·m). Verify that the handle moves smoothly between the A and B side positions.

- Place the o-ring (12) onto the inlet fitting (30), as shown in the figure. Apply Loctite Blue, or equivalent, to the upper threads on the inlet fitting (30) and screw the fitting into the bottom of the solvent housing (2).

- Slide the A-side (blue) handle support (24) onto the A-side stem (23). The threaded end of the stem (23) will extend beyond the support (24) when the flats on the stem are properly aligned with the support. Repeat for the B-side (red) handle support (25) on the B-side stem (23). Torque the set screws (22) to 10 in-lb (1.1 N·m).

- Slide the ends of the main handle (26) into the slots of the handle supports (24 and 25).

- Screw the lock nuts (37) on to the threaded ends of the valve stems (23), and torque to 18–23 in-lb (2.0–2.6 N·m). Screw the cap screws (28) into the handle supports (24 and 25), and torque to 40–45 in-lb (4.5–5.1 N·m). Verify the handle moves smoothly between the flush and spray positions.




Figure 15 Reattach handle assemblies

# Parts


## Mix Manifold Kits with Static Mixer and Mix-at-Belt Brackets

Part No. 26A358 Low Pressure Mix Manifold Kit

Part No. 26A225 High Pressure Mix Manifold Kit

Part No. 26A223 Low Pressure Mix Manifold Kit, for acid catalyzed materials

Part No. 26A224 High Pressure Mix Manifold Kit, for acid catalyzed materials




ti30803a

Ref. No.	Part No.	Description	Qty
101	16W557	BRACKET, belt	1
102	17M667	BRACKET, gun/belt	1
103	16W559	RETAINER, bracket	1
105	16W562	WIRE, ground; 25 ft (7.6 m)	1
106	16W563	HOSE, nylon, static mixer; high pressure; for 26A225 and 26A358; 3/8 npsm x 1/4 npsm (fbe); 8.0 in. (203 mm) long, Max WPR 3300 psi (228 bar)	1
	16W564	HOSE, nylon, static mixer; low pressure; alternate for 26A358; 3/8 npsm (fbe); 9.25 in. (235 mm) long; Max WPR 225 (15.5 bar) at 70°F (21°C), 100 psi (6.89 bar) and 200°F (93°C)	1
	26A079	HOSE, ptfе, static mixer, high pressure; for 26A223 and 26A224, 1/4 npsm(fbe), 12.38 in (314 mm) long; Max WPR 3000 psi (207 bar); (includes ref. 112 and 113)	1
107	26A356	MANIFOLD, mix; for 26A358	1
	26A357	MANIFOLD, mix, for 26A225	1
	26A221	MANIFOLD, mix; for 26A223	1
	26A222	MANIFOLD, mix; for 26A224	1
109	—	SCREW, cap, socket head; 1/4–20 x 0.5 in. (13 mm)	1
112	—	SWIVEL, union; for 26A223 and 26A224 only	1
113	—	FITTING, adapter	1
114	—	SCREW, button socket head; #6–32 x 0.375 in.	2

### Mix Manifold Assemblies

- Part No. 26A356 Low Pressure Manifold Assembly
- Part No. 26A357 High Pressure Manifold Assembly
- Part No. 26A221 Low Pressure Manifold Assembly, for acid catalyzed materials
- Part No. 26A222 High Pressure Manifold Assembly, for acid catalyzed materials



ti30802c

- 1 Torque to 100 in-lb (11.3 N•m).
- 2 Torque to 25 to 30 in-lb (2.8 to 3.4 N•m).
- 3 Torque to 18 to 23 in-lb (2.0 to 2.6 N•m).
- 4 Torque to 10 in-lb (1.1 N•m).
- 5 Torque to 40 to 45 in-lb (4.5 to 5.1 N•m).
- 6 Apply Loctite Blue or equivalent.
- 7 Apply Anti-Seize Loctite 51264 or equivalent.

Parts

Ref. No.	Part No.	Description	Qty
1	26A388	HOUSING, main; for models 26A221 and 26A222	1
	26A382	HOUSING, main; for models 26A356 and 26A357	1
2	26A390	HOUSING, solvent; for models 26A221 and 26A222; (includes ref. 27)	1
	26A384	HOUSING, solvent; for models 26A356 and 26A357; (includes ref. 27)	1
3	26A389	HOUSING, integrator; for models 26A221 and 26A222; (includes ref. 27)	1
	26A383	HOUSING, integrator; for models 26A356 and 26A357; (includes ref. 27)	1
4*‡	—	SEAT, check valve	4
6*‡	—	BALL, 316 sst	4
7*‡	—	RETAINER, check valve	4
8*‡	—	SPRING, compression	4
9	26A385	FITTING, outlet; (includes ref. 13)	1
10	16Y952	TUBE, integrator; for models 26A221 and 26A222	1
	16Y824	TUBE, integrator; for models 26A356 and 26A357	1
11	26A386	FITTING, inlet, 1/4 npsm; for models 26A221 and 26A356; (includes ref. 12)	2
		FITTING, inlet, 1/4 npsm; for models 26A222 and 26A357; replaces ref. 30 (includes ref. 12)	3
12‡^	—	PACKING, o-ring, ptfе; (included with ref. 11 and 30)	3
13‡^	—	PACKING, o-ring; (included with ref. 9)	1
14*‡^	—	PACKING, o-ring	4
15*‡^	—	PACKING, o-ring	4
16♦‡‡	—	SPACER	3
17♦‡‡	—	SEAL, valve, throat	9
18♦‡‡	—	NUT, valve, packing	3
19	26A393	HANDLE, solvent; silver; (includes ref. 22)	1

Ref. No.	Part No.	Description	Qty
20♦	—	STEM, valve, 3-way	1
21♦‡‡	—	SEAL, valve	3
22	—	SCREW, set, socket w/patch; (included with ref. 19, 24, and 25)	3
23†	—	STEM, valve, 17-4	2
24	26A391	HANDLE, resin, A side; blue; (includes ref. 22)	1
25	26A392	HANDLE, catalyst, B side; red; (includes ref. 22)	1
26	17M602	HANDLE, mix manifold	1
27‡	17S321	SCREW, socket head cap, as, .138 x .438	8
28♦‡‡	17R563	SCREW, hex head cap, 10-24 x .38	3
30	26A387	FITTING, inlet, 3/8 npsm; for models 26A221 and 26A356; (included with ref. 11)	1
		Not used for models 26A222 and 26A357	0
37♦‡‡	17S752	NUT, lock; 6-32, sst	3
38	17P503	EXTENSION, handle, solvent valve	1
41	112506	SCREW, ground	1
42	116134	PLUG, pipe, sst	1
43#	—	TOOL, seal, install, body (not shown)	1
44#	—	TOOL, seal, install, plunger (not shown)	1

\* These parts are included in Check Valve Kit 26A381. Each kit has parts for two check valves.

♦ These parts are included in Solvent Valve Kit 26A380.

† These parts are included in Resin/Catalyst Valve Kit 26A379. Each kit has parts for only one valve.

‡ These parts are included in Rebuild Kits 26A378 and 26C335.

^ These parts are included in O-Ring Kit 26A394.

# These parts are only available in Installation Tool Kit 26C334 and Mix Manifold Rebuild Kit with Installation Tools 26C335.

Parts labeled “—” are not available separately.



## Kits and Accessories

Part No.	Description
26C335	Mix Manifold Rebuild Kit with Installation Tools (includes ref. 4–8, 12–18, 21, 27, 28, 37, 43, and 44).
26A378	Mix Manifold Rebuild Kit (includes ref. 4–8, 12–18, 21, 27, 28, and 37).
26A379	Resin/Catalyst Valve Kit (includes ref. 16, 17, 18, 21, 23, 28, and 37). Each kit has parts for only one valve.
26A380	Solvent Valve Kit (includes ref. 16, 17, 18, 20, 21, 28, and 37).
26A381	Check Valve Kit (includes ref. 4–8, 14, and 15). Each kit has parts for two check valves.
26A394	Packing and O-Rings Kit (includes ref. 5, 12, 14, and 15).
24N641	1/8 in. (3 mm) ID Fluid Whip Hose; nylon; 1/4 npsm(f); 6 ft (1.8 m); for high and low pressure applications. 3200 psi (22 MPa, 220 bar) Maximum Fluid Working Pressure.
24N305	1/4 in. (6 mm) ID Fluid Whip Hose; nylon; 3/8 npsm(f); 6 ft (1.8 m); for low pressure applications only. 225 psi (1.6 MPa, 16 bar) Maximum Fluid Working Pressure.
24N348	1/4 in. (6 mm) ID Fluid Whip Hose; ptfе; 1/4 npsm(f); 6 ft (1.8 m); for high pressure applications only. 3000 psi (20.7 MPa, 207 bar) Maximum Fluid Working Pressure.
24U059	5/16 in. (8 mm) ID Grounded Air Whip Hose, for use with electrostatic guns; 1/4 npsm(f) x 1/4 npsm (f) left-hand thread; 6 ft (1.8 m). 100 psi (0.7 MPa, 7 bar) Maximum Air Working Pressure.
16F537	5/16 in. (8 mm) ID Air Whip Hose, for use with conventional air spray guns; 1/4 npsm(f); 6 ft (1.8 m). 200 psi (1.4 MPa, 14 bar) Maximum Air Working Pressure.
24S004	Air Line Quick Disconnect, for use with electrostatic guns.
26C334	Installation Tool Kit (includes ref. 43 and 44).

# Notes

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

# Technical Specifications

Mix Manifold	U.S.	Metric
Maximum Fluid Working Pressure:		
26A221, 26A223, 26A356, & 26A358 Low Pressure Mix Manifold	300 psi	2.1 MPa, 21 bar
26A222, 26A224, 26A225, & 26A357 High Pressure Mix Manifold	1500 psi	10.5 MPa, 105 bar
Mixing Ratio Range	0.1:1 — 50:1	
Manifold Fluid Inlet Size (A and B sides)	1/4–18 NPSM	
Manifold Fluid Inlet Size (Solvent):		
26A221, 26A223, 26A356, & 26A358 Low Pressure Mix Manifold	3/8–18 NPSM	
26A222, 26A224, 26A225, & 26A357 High Pressure Mix Manifold	1/4–18 NPSM	
Manifold Fluid Outlet Size	3/8 NPSM	
Operating Temperature Range	36 — 122°F	2 — 50°C
Weight (Approximate)	2.1 lb	0.95 kg
Wetted Parts:		
26A225, 26A356, 26A357, & 26A358 Mix Manifold	303, 316, 17–4PH, and 17–7PH SST; perfluoroelastomer; Reinforced PTFE	
26A221, 26A222, 26A223, & 26A224 Mix Manifold, for acid-catalyzed materials	316, 17–4PH, and 17–7PH SST; perfluoroelastomer; Reinforced PTFE	

# Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

**THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.**

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

**GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO.** These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

## FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

## Graco Information

For the latest information about Graco products, visit [www.graco.com](http://www.graco.com).

**To place an order**, contact your Graco Distributor or call to identify the nearest distributor.

**Phone:** 612-623-6921 **or Toll Free:** 1-800-328-0211 **Fax:** 612-378-3505

All written and visual data contained in this document reflects the latest product information available at the time of publication.

Graco reserves the right to make changes at any time without notice.

For patent information, see [www.graco.com/patents](http://www.graco.com/patents).

Original Instructions. This manual contains English. MM 3A5079

**Graco Headquarters:** Minneapolis

**International Offices:** Belgium, China, Japan, Korea

**GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA**

**Copyright 2017, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.**

[www.graco.com](http://www.graco.com)  
Revision F, June 2018