



KEEP FOR REFERENCE.
Read this and all related manuals for important warnings and instructions.

INSTRUCTIONS

First choice when quality counts.™

Airless Paint Sprayers

3000 psi (210 bar, 21 MPa) Maximum Working Pressure

ULTRA® MAX 1595

230 VAC

Model	Series	Description
232164	A	Hi-boy with RAC IV™ tip, gun and hose

120 VAC

Model	Series	Description
232160	A	Hi-Boy
232161	A	Hi-Boy with RAC IV tip, gun and hose
232162	A	CSA/UL Hi-Boy
232163	A	CSA/UL Hi-Boy with RAC IV tip, gun and hose

MARK V™

100 VAC

Model	Series	Description
232166	A	Hi-Boy


230 VAC

Model	Series	Description
232173	A	Hi-boy with RAC IV™ tip, gun and hose

120 VAC

Model	Series	Description
232171	A	Hi-Boy with RAC IV tip, gun and hose

All models are not available in all countries



Model 232164

Related Manuals

Operator	308855
Displacement Pump	308798
Spray Gun	308491
Spray Tip	308644

Table of Contents

Component Function and Identification	3	Drive Housing Replacement	15
Troubleshooting	5	Displacement Pump Repair	16
General Repair Information	4	Parts	18
Motor Brush Replacement	7	Accessories	23
Pressure Control	9	Technical Data	23
Pressure Control Repair	10	Dimensions	23
Pressure Control Wiring	12	Graco Phone Number	24
Motor Replacement	13	Graco Warranty	24
Bearing Housing & Connecting Rod Replacement .	14		

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441

©COPYRIGHT 1998, GRACO INC.

Graco Inc. is registered to I.S. EN ISO 9001

Warnings and Cautions

Warning Symbol




This symbol alerts you to the possibility of serious injury or death if you do not follow the instructions.

Caution Symbol



This symbol alerts you to the possibility of damage to or destruction of equipment if you do not follow the instructions.

 WARNING	
<p>Fire and explosion can occur when spraying or flushing flammable fluid in an area where air circulation is poor and flammable vapors can be ignited by an open flame or sparks.</p> <p>To help prevent a fire and explosion:</p> <ul style="list-style-type: none"> ● Use outdoors or in an extremely well ventilated area. ● Do not use 1,1,1-trichloroethane, methylene chloride, other halogenated hydrocarbon solvents or fluids containing such solvents in pressurized aluminum equipment. Such use could result in a chemical reaction, with the possibility of explosion. ● Remove, extinguish or unplug all ignition sources; tape wall switches. Do not smoke in spray area. ● Ground Sprayer, object being sprayed, paint and solvent pails. ● Hold gun firmly to side of a grounded pail when triggering into pail. ● Use a properly grounded outlet. ● Use only conductive airless paint hose. ● Do not modify this equipment. <p>Fluid injection is a serious injury! If high pressure fluid pierces your skin, the injury might look like “just a cut”. But it is a serious wound! Get immediate medical attention.</p> <p>To help prevent injection, always:</p> <ul style="list-style-type: none"> ● Engage trigger safety latch when not spraying. ● Point gun away from yourself or anyone else. <ul style="list-style-type: none"> ● Relieve pressure before checking or repairing any leak. ● Relieve pressure when you turn off the sprayer or stop spraying ● Keep drain hose outlet under fluid when opening drain valve. ● Relieve pressure through the gun when you turn off the sprayer or stop spraying. ● Do not use components rated less than system <i>Maximum Working Pressure</i> <p>Never allow children to use this unit. If you are injured using this equipment, get immediate medical treatment.</p>	       

Component Identification and Function




Fig. 1

A	Motor	DC motor, permanent magnet, totally enclosed, fan cooled
B	Drive Assembly	Transfers power from DC motor to the displacement pump
C	Pail Hanger	Container for fluid to be sprayed may be hung here
D	Displacement Pump	Transfers fluid to be sprayed from source through spray gun
E	Primary Fluid Outlet	Single spray gun operation is connected here
F	Secondary Fluid Outlet	Second spray gun operation is connected here
G	Pressure Drain Valve	Relieves fluid outlet pressure when open
H	Fluid Filter	Final filter of fluid between source and spray gun
J	Pressure Adjust Knob	Controls fluid outlet pressure
K	Pressure Control	Controls motor speed to maintain fluid outlet pressure at displacement pump outlet. Works with pressure adjusting knob.
L	ON/OFF Switch	Power switch that controls VAC main power to sprayer
M	3 ft (0.9 m) Hose	3/16 in. ID, grounded, nylon hose used between 50 ft hose and spray gun to allow more flexibility when spraying
N	50 ft (15 m) Main Hose	1/4 in. ID, (3/8 in. ID, MARK V) grounded, nylon hose, spring guards both ends
P	Spray Gun	High pressure spray gun with gun safety latch
R	RAC IV Switch Tip	Uses high pressure fluid to clear tip clogs without removing tip from spray gun
S	RAC IV Tip Guard	Reverse-A-Clean (RAC) tip guard reduces the risk of injection injury
T	Spray Gun Safety Latch	Gun safety latch inhibits accidental triggering of spray gun
U	Power Cord Rack	Holds wrapped power cord for storage
V	Spray Hose Rack	Holds wrapped spray hose for storage
W	10/12 Amp Switch	Allows Models 232164, 232173 to operate on 10A service with reduced performance
	15/20 Amp Switch	Allows Models 232160 through 232163, 232166, 232171 to operate on 15A service with reduced performance

General Repair Information

CAUTION

To reduce risk of pressure control malfunction:

- Use needle nose pliers to disconnect a wire. Never pull on wire, pull on connector.
- Mate wire connectors properly. Center flat blade of insulated male connector in female connector.
- Route wires carefully to avoid interference with other connections of pressure control. Do not pinch wires between cover and control box.

Tool List

Phillips screwdriver	1/4 in. hex key wrench
Small flat blade screwdriver	3/16 in. hex key wrench
Needle nose pliers	5/8 in. socket wrench
Plastic mallet or 20 oz (max) hammer	3/8 in. open end wrench
12 in. adjustable wrench	1/2 in. open end wrench
Adjustable, open-end wrench	3/4 in. open end wrench
Torque wrench	7/8 in. open end wrench
	High quality motor oil
	Bearing grease

1. **Keep all screws, nuts, washers, gaskets, and electrical fittings** removed during repair procedures. These parts are not normally provided with replacement assemblies.

WARNING



ELECTRIC SHOCK HAZARD

To reduce risk of serious injury, including electric shock, do not touch moving or electrical parts with fingers or tools while testing repair. Shut off and unplug sprayer when inspection is complete. Install all covers, gaskets, screws and washers before operating sprayer.

2. **Test repair** after problem is corrected.
3. **If sprayer does not operate properly**, review repair procedure to verify procedure was done correctly. If necessary, see Troubleshooting, page 5, for other possible solutions.

WARNING



EXPLOSION HAZARD

Motor and drive housing are very hot during operation and could burn skin if touched. Flammable materials spilled on hot, bare motor could cause fire or explosion. Have motor shield in place during operation to reduce risk of burns, fire or explosion.

CAUTION

Do not run sprayer dry for more than 30 seconds to avoid damaging pump packings.

4. **Install motor shield before operation** of sprayer and replace if damaged. Motor shield directs cooling air around motor to prevent overheating. It can also reduce risk of burns, fire or explosion; see preceding **WARNING**.

Pressure Relief Procedure

WARNING



INJECTION HAZARD

System pressure must be manually relieved to prevent system from starting or spraying accidentally. Fluid under high pressure can be injected through skin and cause serious injury. To reduce risk of injury from injection, splashing fluid, or moving parts, follow **Pressure Relief Procedure** whenever you:

- are instructed to relieve pressure,
- stop spraying,
- check or service any system equipment,
- or install or clean spray tip.

1. Lock gun safety latch.
2. Turn ON/OFF switch to OFF.
3. Unplug power supply cord.
4. Unlock gun safety latch. Hold metal part of gun firmly to grounded metal pail. Trigger gun to relieve pressure.
5. Lock gun safety latch.
6. Open pressure drain valve. Leave pressure drain valve open until ready to spray again.

If suspected that spray tip or hose is completely clogged, or that pressure has not been fully relieved after following steps above, VERY SLOWLY loosen tip guard retaining nut or hose end coupling to relieve pressure gradually, then loosen completely. Now clear tip or hose obstruction.

Troubleshooting

TYPE OF PROBLEM	WHAT TO CHECK <i>If check is OK, go to next check</i>	WHAT TO DO <i>When check is not OK refer to this column</i>
Motor runs and pump strokes, but output is low or there is no output.	Extension cord size and length.	Replace cord with a larger size, grounding type extension cord.
	Paint supply.	Refill and reprime pump.
	Clogged intake strainer.	Remove and clean strainer and reinstall. Mark V models 232171 and 232173 strainer is for use in paint only.
	Loose suction tube or loose fittings.	Tighten; use thread sealant or sealing tape on threads, if necessary.
	Worn spray tip.	Follow Pressure Relief Procedure Warning , then replace tip. See your separate gun or tip manual.
	Motor brushes, loose leads and terminals, minimum 13 mm brush length, broken or misaligned springs, or brushes binding in holders. See page 7.	Replace parts as needed. See page 7.
	Motor armature for shorts. Use an armature tester (growler).	Replace motor. See page 13.
	If pump continues to stroke when gun trigger is released. With pump on and primed, trigger gun momentarily, then release and engage safety latch. Relieve pressure, turn off and unplug sprayer.	Service pump. See manual 308798.
	If intake valve ball and piston ball are seating properly.	Remove intake valve and clean. Check balls and seats for nicks; replace if necessary. See manual 308798. Strain paint before using to remove particles that could clog the pump.
	Intake valve ball is packed with material.	Remove and clean intake valve. Do not leave Mark V models 232171 and 232173 sprayers under pressure for more than 5 minutes when pumping texture material and not actively spraying.
Leaking around throat packing nut which may indicate worn or damaged packings.	Replace packings. See manual 308798. Also check piston valve seat for hardened paint or nicks and replace if necessary. Tighten the packing nut/wetcup.	
Defective pressure control transducer.	Replace pressure control transducer. See page 10.	

(Continued on page 6)

Troubleshooting

Motor runs but pump does not stroke.	Displacement pump connecting rod pin (20). See page 16.	Replace pin, if missing. Be sure retainer spring (35) is fully in groove all around connecting rod. See page 16.
	Frozen or hardened paint in the pump (39).	Thaw. See NOTE 1. Plug in sprayer and turn on. Slowly increase pressure setting to see if motor starts.
	Be sure crank in drive housing rotates; plug in sprayer and turn on briefly to check. Turn off and unplug sprayer.	Check drive housing assembly for damage and replace if necessary. See page 17.
Motor is hot and runs intermittently.	Determine if sprayer was operated at high pressure with small tips, which causes low motor RPM and excessive heat build up.	Decrease pressure setting or increase tip size.
	Be sure ambient temperature where sprayer is located is no more than 90°F and sprayer is not located in direct sun.	Move sprayer to shaded, cooler area, if possible.
	Determine if sprayer was turned on, pressurized, but not operating for long periods of time.	Turn off sprayer whenever you stop spraying for a while and relieve fluid pressure.

NOTE 1: Thaw sprayer in a warm area if water or water-based paint has frozen in it. Do not start sprayer until it has thawed completely. If paint hardened (dried) in sprayer, replace pump packings. See manual 308798.


Grounding

Grounding

⚠ WARNING

Improper installation or alteration of the grounding plug will result in a risk of electric shock, fire or explosion that could cause serious injury or death.

1. Models 232160 through 233163, 232171 require a 120 Vac, 60 Hz, 10A circuit with a grounding receptacle. Models 232164, 232173 requires a 230 Vac, 50 Hz, 10A circuit with a grounding receptacle. Model 232166 requires a 100 Vac, 50 Hz, 15A circuit with a grounding receptacle. See Fig. 2.



Model 232164

9286A

Fig. 2

2. Do not alter ground prong or use adapter.
3. A 1.5 mm² by 90 m extension cord may be used with this equipment.

Motor Brush Replacement

NOTE: Replace brushes worn to less than 1/2 in. Brushes wear differently on each side of motor, check both sides. Brush Repair Kit 222157 is available for Models 232164, 232173 and Brush Repair Kit 220853 is available for Models 232160 through 232163, 232166, 232171. Spring clip, 110816, may be purchased separately.

Motor Brush Removal

1. Read **General Repair Information**; page 4.

2.  Relieve pressure; page 4.

3. Fig. 3. Remove motor shield (14). Remove inspection covers (B) and gaskets on each side of motor.

(Continued on page 8)




Fig. 3

7703B

4. Fig. 4. Push in 110816 spring clip (A) to release hooks (B) from brush holder (C). Pull out spring clip.
5. Fig. 4. Loosen terminal screw (D). Pull brush lead (E) away, leaving motor lead (F) in place. Remove brush (G) and spring (H).




Fig. 4

01227

6. Inspect commutator for excessive pitting, burning or gouging. A black color on commutator is normal. Have commutator resurfaced by a qualified motor repair shop if brushes wear too fast.

Motor Brush Replacement

Motor Brush Installation

⚠ CAUTION

When installing brushes, follow all steps carefully to avoid damaging parts.

7. Fig. 5. Install new brush (G) with lead in long slot (J) of brush holder (C).
8. Fig. 4. Slide brush lead (E) under washer of terminal screw (D) and tighten screw. Be sure motor lead (F) is connected at terminal screw.
9. Fig. 5. Place spring (H) on brush (G).
10. Fig. 5. Install spring clip (A). Push down to hook short slots (K) in brush holder (C).




Fig. 5

01227

11. Repeat for other side.
12. Test brushes.
 - a. Remove pump connecting rod pin.
 - b. With sprayer OFF, turn pressure control knob fully counterclockwise to minimum pressure. Plug in sprayer.
 - c. Turn sprayer ON. Slowly increase pressure until motor is at full speed.

⚠ CAUTION

Do not run sprayer dry for more than 30 seconds while checking brushes to avoid damaging displacement pump packings.

13. Install brush inspection covers and gaskets.
14. Break in brushes.
 - a. Operate sprayer 1 hour with no load.
 - b. Install connecting rod pin.

Pressure Control

⚠ CAUTION

Do not install the pressure control until motor is checked. A defective motor may damage the pressure control. Make sure to test the motor prior to pressure control installation.

⚠ WARNING



ELECTRIC SHOCK HAZARD

To reduce the risk of Electric Shock: wait 5 minutes after turning sprayer off before servicing to allow stored current to discharge.

Motor Test

With motor shield off and four motor leads disconnected:

1. Check continuity with multimeter from each black motor lead to ground (one at a time). Any reading less than infinite resistance – even very high resistance – means motor is shorted to ground. Replace motor.

⚠ CAUTION

A motor that is shorted to ground will damage the pressure control.

2. Remove fan cover from motor.
3. Remove pump pin (See page 16 for instructions to remove pin).
4. With black motor leads not connected, use motor fan to spin motor quickly. Motor should spin freely in both directions. If not, replace motor.
5. Connect black motor leads together.
6. Use motor fan to turn motor. It should be much harder to turn than in step 4. If there is uneven or no resistance to turning, check brushes and replace if necessary.
7. If there is still uneven or no resistance to turning, replace motor.

8. Install pump pin and fan cover.

Pressure Control Replacement

1.  Relieve pressure; page 4.
2. Remove two screws (19) holding filter assembly (A). See Fig. 7 and parts list, except as noted.
3. Remove filter assembly by unthreading swivel union (15) from hex nipple (102). Unthread nipple from pressure control (5)
4. Remove 8 screws (64) and motor shield (14).
5. Remove outlet cover (221) on pressure control wiring box. Disconnect motor leads. See Fig 6.
6. Loosen electrical tubing (22) from pressure control fitting and pull out wires
7. Remove hose (28) from rear of pressure control swivel union (15).
8. Support pressure control (5) and carefully remove motor mount screws (37). Remove pressure control.
9. Install new pressure control (5) with screws (37).
10. Continue to assemble sprayer.






Fig 6

Pressure Control



ULTRA® MAX 1595 shown

Fig 7 8184A

Pressure Control Repair

General Repair and Replacement



1. Relieve pressure; page 4.
2. Remove power cord (90) and plug retainer (89) by removing screws (230) and washers (229).
3. Remove screws (213) and lockwashers (214). Carefully remove control housing (202) from control motor board (201) so internal wiring is not damaged. Lay housing on side next to control motor board. See Fig. 8 and parts list.
4. Remove and replace only those components and wires necessary for repair. Make a diagram showing wire hook-ups for items removed to insure correct wiring when reinstalling. See Fig 9 for wiring information.
5. Install control housing (202) to motor control board (201) using screws (213) and lockwashers (214).

Pressure Control Transducer and O-Ring Replacement

WARNING




FIRE AND EXPLOSION HAZARD
Proper o-ring replacement is essential to reduce the risk of fire or explosion which can result in serious injury and property damage.

NOTE: Do not replace o-ring unless damaged or if leakage is seen around weep hole, o-ring or transducer.

1. See Fig. 8 and pressure control part list. Disassemble pressure control as in steps 1 through 4 on page 10 and remove old transducer (219) and, if necessary, old o-ring (220).

Pressure Control Repair



 Torque to 150 in-lb (17 N.m)

8185A

Fig 8

2. Carefully slide new o-ring (220) down bore (A) of motor control (201) into o-ring groove (B). Make sure o-ring is in groove around its entire circumference.
3. Carefully slide new transducer and plastic spacer (217) down bore. Loosely attach bracket (218), screws (213), and washers (214).
4. Seat transducer into o-ring by drawing down screws and washers until bracket is flush with motor control surface.
5. Carefully remove transducer and verify that o-ring is seated correctly and not pushed out of groove. If not seated correctly use new o-ring and repeat steps 2 through 5.
6. When o-ring is correctly installed, reinstall transducer and tighten screws to 150 in-lb (17 N.m). Install spacer (216) and C-clip (215). Connect electrical lead and assemble sprayer.
7. Perform Flush and Prime procedures in STARTUP of Operation Manual 308855 with compatible fluid.
8. Inspect weep hole (C) for any leakage.
9. If any leakage is present, replace o-ring repeating steps 1 through 9.

Pressure Control Wiring





Fig 9

Motor Replacement

⚠ WARNING



ELECTRIC SHOCK HAZARD

To reduce the risk of Electric Shock: wait 5 minutes after turning sprayer off before servicing to allow stored current to discharge.

NOTE: Refer to Fig. 10 and parts list, except as noted.


1.   Relieve pressure; page 4.
2. Remove motor shield (14). Remove front cover (31). Disconnect hose (28) at pump. Disconnect drain hose (79) from pump (39).
3. Remove outlet cover on pressure control wiring box. Disconnect four motor leads. See Fig 6.
4. Unscrew conduit connector (16) from motor and pull motor leads from tubing (22).
5. Remove screws (33) from recess of drive housing.
6. Remove screws (21 and 30) from motor bell (F).
7. Use a plastic mallet to tap displacement pump (39) from rear to loosen drive housing (18) from motor bell (F). Pull off drive housing.

⚠ CAUTION

DO NOT drop gear cluster (9) when removing drive housing (18). The gear cluster may stay engaged in the motor front end bell or the drive housing.

DO NOT lose thrust balls (10) located at each end of gear cluster (9) or drop them between gears. The balls, which are heavily covered with grease, usually stay in the shaft recesses, but could be dislodged. If caught between gears and not removed, the balls will seriously damage the drive housing. If the balls are not in place, the bearings will wear prematurely.

8. Lower pressure control (5) by unscrewing motor mounting screws (37).
9. Lift off motor (1).
10. Mount and center new motor on frame and attach pressure control (5) with motor mounting screws (37).
11. Insert motor leads through connector (16) and tubing (22) to pressure control. Screw connector (125) two or three threads into motor. Tighten locknut up to motor. Connect four motor leads. See Fig. 6.
12. Liberally grease gear cluster (9) and pinion gear (G) and pack all bearings in motor bell. Be sure thrust balls (10) are in place. (One ball is included with a replacement drive housing.)
13. Align gears and push drive housing (18) straight onto motor bell (F) and locating pins.
14. Continue to reassemble sprayer.



ULTRA[®] MAX 1595 shown

-  Seals (93) located inside conduit (22)
-  Apply 6 ounces bearing grease

7957A

Fig. 10

Bearing Housing and Connecting Rod Replacement

NOTE: Read **General Repair Information** on page 4 before doing this procedure. See Fig. 11.

NOTE: Stop sprayer at bottom of its stroke to get crank (E) in its lowest position. To lower crank manually, carefully rotate blades of fan with a screwdriver.



1. Relieve pressure; page 4.
2. Remove front cover (31). Unclip drain hose (79) from pump. Hold a wrench on pump intake valve (H) and unscrew pump suction tube (42). Disconnect pump hose (28).
3. Push up retaining spring (35). Push pin (20) out rear.
4. Loosen locknut (38). Unscrew displacement pump (39).
5. Remove four screws (33) and lockwashers (49).
6. Lightly tap lower rear of bearing housing (27) with a plastic mallet to loosen it from drive housing (18). Pull bearing housing and connecting rod assembly (29) straight off drive housing.
7. Remove pail bracket assembly (F) and install with locknuts (13) on new bearing housing.
8. Inspect crank (E) for excessive wear and replace parts as needed. Evenly lubricate inside of bronze bearing (B) with high quality motor oil. Liberally pack roller bearing (C) with bearing grease.
9. Assemble connecting rod (29) and bearing housing (27).
10. Clean mating surfaces of bearing (27) and drive (18) housings.
11. Align connecting rod (29) with crank (E) and drive housing locating pins (G) with bearing housing (27) holes. Push bearing housing onto drive housing or tap it into place with a plastic mallet.

⚠ CAUTION

DO NOT use the bearing housing screws (33) to try to align or seat the bearing housing; the bearing and drive housing will not align properly and will result in premature bearing wear.

12. Install screws (33) and lockwashers (49). Tighten screws evenly to 300 in-lb (34 N.m).

13. Install pump. See page 17.

14. Install remaining parts. See Fig. 11.




Fig. 11

7955A

Drive Housing Replacement

⚠ CAUTION


DO NOT drop gear cluster (9) when removing drive housing (18). Gear cluster may stay engaged in the motor front end bell or the drive housing.

DO NOT lose thrust balls (10) located at each end of gear cluster (9) or drop them between gears. The balls, which are heavily covered with grease, usually stay in the shaft recesses, but could be dislodged. If caught between gears and not removed, the balls will seriously damage drive housing. If the balls are not in place, the bearings will wear prematurely.

NOTE: Read **General Repair Information** on page 4 before doing this procedure. See Fig. 12.

1.  Relieve pressure; page 4.
2. Remove front cover (31) and motor shield (14). Unclip drain hose (79) from pump.
3. Remove four bearing housing screws (33) and lockwashers (49).

4. Lightly tap lower rear of bearing housing (27) with a plastic mallet to loosen it from drive housing (18). Pull assembled bearing housing and connecting rod straight off drive housing.
5. Remove two drive housing screws (51) and lockwashers (63).
6. Remove two lower screws (30) and lockwashers (63) and then two upper screws (21) and lockwashers (63) from front of motor (1).
7. Tap drive housing (18) with a plastic mallet to loosen it from front of motor (1), and then pull drive housing straight off.
8. Liberally apply approximately 4 ounces of bearing grease to gear cluster (9). Grease is supplied with drive housing replacement kit. Be sure thrust balls (10) are in place.
9. Align gears and push new drive housing straight onto front of motor and locating pins.
10. Continue reassembling sprayer.



- 1 ⚠ Torque to 300 in-lb (34 N.m)
- 2 ⚠ Torque to 90–100 in-lb (10.2–11.3 N.m)
- 3 ⚠ Liberally apply grease

ULTRA® MAX 1595 shown

Fig. 12

7956A

Displacement Pump Repair

Removing pump

1. Flush pump. Relieve pressure. Fig. 13. Cycle pump with piston rod (A) in its lowest position.
2. Fig. 13. Unscrew suction tube and hose from pump.




Fig. 13

 7672A

3. Fig. 14. Use screwdriver to push retaining spring (35) up and pin (20) out.




Fig. 14

 7674A

4. Fig. 15. Loosen locknut by hitting firmly with a 20 oz (maximum) hammer. Unscrew pump.




Fig. 15

 7673A

Repairing Pump

See manual 308798 for pump repair instructions.

Displacement Pump Repair

Installing pump

⚠ WARNING

If the pin works loose, it or other parts could break off due to the force of the pumping action. These parts could be projected through the air and result in serious bodily injury or property damage, including damage to the pump, connecting rod or bearing housing.

⚠ CAUTION

If the pump locknut loosens during operation, the threads of the bearing housing will be damaged.

1. Fig. 16. Pull piston rod out 1.5 in. Screw in pump until holes in bearing cross link and piston rod align.




Fig. 16

2. Fig. 17. Push pin (20) into holes.




Fig. 17

3. Fig. 18. Push retaining spring (35) into groove all the way around connecting rod.




Fig. 18

Fig. 19. Screw jam nut down onto pump until stops. Screw pump up into bearing housing until it is stopped by jam nut. Back off pump and jam nut to align pump outlet to back. Tighten jam nut by hand, then tap 1/8 to 1/4 turn with a 20 oz (maximum) hammer to approximately 75 ± 5 ft-lb (102 N-m).




Fig. 19

Fig. 20. Fill packing nut with Graco TSL, through one of the slits, until fluid flows onto the top of seal.





Fig. 20

Parts Drawing – Sprayer

Models 232160 through 232164, 232166, Series A



7951A

Parts List – Sprayer

Models 232160 through 232164, 232166, Series A

REF NO.	PART NO.	DESCRIPTION	QTY	REF NO.	PART NO.	DESCRIPTION	QTY
1		MOTOR, ELECTRIC	1	61	240136	HANDLE, cart	1
		<i>includes 41 and 73a</i>		62	192027	SLEEVE, cart	2
	235726*	Model 232164	1	63	105510	WASHER, lock, spring	6
	220854*	Models 232160 thru 232163	1	64	108865	SCREW, machine, pan hd	10
5		PRESSURE CONTROL	1	69	111482	RIVET, snap	1
		<i>see parts list on page 23</i>		71	171941	SPRING, compression	1
	239429	Model 232164	1	72	186075	SUPPORT, filter	1
	239750	Models 232160 thru 232163	1	73	192719	HANGER, pail	1
6	240143	FRAME, cart	1	74	100020	CONNECTOR, tube, female	2
8	107266	TERMINAL	2	75	187615	VALVE, seat	1
9	220637	GEAR REDUCER	1	77▲		LABEL, DANGER	1
10	100069	BALL	2		187791	English	1
11	104811	CAP, hub	2		189702	Japanese	1
13	112746	LOCKNUT, 5/16 –18	2	79	240144	HOSE, drain	1
14	240483	SHIELD, motor (includes label 77)	1	80	109032	SCREW, machine, pan hd	4
15	155494	UNION, swivel, 90°	2	81	185384	BRACKET	2
16	110138	CONNECTOR, conduct	1	82	110240	NUT, self-retaining	2
17	112827	BUTTON, snap	2	83	183350	WASHER	2
18	220879	DRIVE HOUSING	1	85	107447	SEAL, conduit	2
19	114402	SCREW, hex hd, flanged	4	86	192691	CLIP, spring	1
20	183210	PIN, straight, hdls	1	87▲	290447	LABEL, warning	3
21	100644	SCREW, cap	2			(on brush covers—not shown)	
22	065312	TUBING, electrical, flexible, 5.5 in.	1	88▲†	187784	LABEL, danger, French	1
24	107264	TERMINAL	2	89	192149	RETAINER, plug	1
25	161889	UNION, swivel	1	90		CORD SET	1
26	154636	WASHER	2		240539	European	1
27	240701	BEARING HOUSING	1		240540	Italy	1
28	240246	HOSE, coupled, 1/4in. by 20 in.	1		240541	Denmark	1
29	220640	ROD CONNECTING KIT	1		240542	Switzerland	1
30	100643	SCREW, cap	2		240543	Bare end, European	1
31	188423	COVER, housing	1		240247	Japan	1
32	108850	SCREW, mach, filh	4	92	235014	DRAIN VALVE ASSEMBLY	1
33	110141	SCREW, cap, sch	4	93	224807	CAM, drain valve	1
34	193081	BRACKET, manifold, filter	1	94	111600	PIN, grooved	1
35	183169	SPRING, retaining	1	95	187625	HANDLE, valve, drain	1
36	111699	GASKET, seat, valve	1	96	102814	GAUGE, pressure, fluid	1
37	110963	SCREW, flange, hex hd	4	97	100176	BUSHING, hex	1
38	193031	NUT, retaining	1	98	156849	NIPPLE, pipe	1
39	240291	KIT, pump, displacement	1	99	100483	TEE, pipe	1
		manual 308798		101	162485	NIPPLE, adapter	1
41	112538	ELBOW, 90°, street, reducing	1	102	193024	NIPPLE, hex	1
42	193097	TUBE, suction	1	103	240700	HOUSING KIT, filter (includes item 56)	1
43		PLUG, packless	1	104†	192839	LABEL, warning, French	1
	240131	Models 232160 thru 232164, 1/4 in.	1	105†	238361	HOSE, grounded, nylon, 1/4" ID,	1
	240987	Model 232166, 3/8 in.	1			cpld 1/4 npsm(f), 50 ft (15m)	
44	114271	STRAP, retaining	1			spring guards both ends	
47	206994	THROAT SEAL LIQUID, 8 OZ	1	106†	238358	HOSE, grounded, nylon, 3/16" ID,	1
48	240315	BOWL, filter	1			cpld 1/4 npsm(f), 3 ft (.9 m)	
49	106115	WASHER, lock, spring	4			spring guards both ends	
50	181072	STRAINER, inlet	1	107†	222667	GUN, contractor, basic	1
51	108849	SCREW, cap, sch	2			manual 307614	
52	110243	RING, retaining	2	108	221621	TIP, spray, cylinder (not shown)	1
53	108691	PLUG, tubing	2			manual 308644	
54	108460	CONNECTOR, conduit, 45°	1	109	237859	GUARD, rac (not shown)	1
55▲		LABEL, caution	1	110		LABEL, WARNING	1
	192839	English	1		187975	English	1
	193521	Japanese	1		193520	Japanese	1
56	104361	PACKING, o–ring	1				
57		ADAPTER					
	164672	Models 232160 thru 232164,	2				
		3/8 npt x 1/4 npsm					
	162485	Model 232166, 3/8 npt x 3/8 npsm	2				
58	101242	RING, retaining, ext.	2				
59	167025	STRAINER, 60 mesh	1				
60	179811	WHEEL, semi–pneumatic	2				

▲ *Extra Danger and Warning tags and labels available free.*
 **Motor Brush Repair Kit is available:*
Model 232164; order 222157
Models 232160 thru 232163, 232166; order 220853
 †*Models 232160 and 232162 have items 88 & 104, but not 105 thru 107. Model 232166 does not have any of these items.*

Parts List – Sprayer

Models 232171, 232173; Series A

REF NO.	PART NO.	DESCRIPTION	QTY	REF NO.	PART NO.	DESCRIPTION	QTY	
1		MOTOR, ELECTRIC <i>includes 41 and 73a</i>	1	64	108865	SCREW, machine, pan hd	10	
	235726*	Model 232173	1	69	111482	RIVET, snap	1	
	220854*	Model 232171	1	71	171941	SPRING, compression	1	
5		PRESSURE CONTROL <i>see parts list on page 23</i>	1	72	186075	SUPPORT, filter	1	
	239429	Model 232173	1	73	192719	HANGER, pail	1	
	239750	Model 232171	1	74	100020	WASHER, lock	2	
6	240143	FRAME, cart	1	75	193709	VALVE, seat	1	
8	107266	TERMINAL	2	77▲		LABEL, DANGER	1	
9	220637	GEAR REDUCER	1		187791	English	1	
10	100069	BALL	2		189702	Japanese	1	
11	104811	CAP, hub	2	79	194178	HOSE, drain	1	
13	112746	LOCKNUT, 5/16 –18	2	80	109032	SCREW, machine, pan hd	4	
14	240483	SHIELD, motor (includes label 77)	1	81	185384	BRACKET	2	
15	155494	UNION, swivel, 90°	2	82	110240	NUT, self-retaining	2	
16	110138	CONNECTOR, conduct	1	83	183350	WASHER	2	
17	112827	BUTTON, snap	2	85	107447	SEAL, conduit	2	
18	220879	DRIVE HOUSING	1	86	194525	CLIP, spring	1	
19	114402	SCREW, hex hd, flanged	4	87▲	290447	LABEL, warning (on brush covers—not shown)	3	
20	183210	PIN, straight, hdls	1	88▲†	187784	LABEL, danger, French	1	
21	100644	SCREW, cap	2	89	114426	RETAINER, plug	1	
22	065312	TUBING, electrical, flexible, 5.5 in.	1	90		CORD SET	1	
24	107264	TERMINAL	2		114514	USA Models 232160, 232161, 232171	1	
25	161889	UNION, swivel	1		114515	CSA Models 232162, 232163	1	
26	154636	WASHER	2		240539	European	1	
27	240701	BEARING HOUSING	1		240540	Italy	1	
28	240246	HOSE, coupled, 1/4in. by 20 in.	1		240541	Denmark	1	
29	220640	ROD CONNECTING KIT	1		240542	Switzerland	1	
30	100643	SCREW, cap	2		240543	Bare end, European	1	
31	188423	COVER, housing	1	92††	240914	DRAIN VALVE ASSEMBLY	1	
32	108850	SCREW, mach, filh	4	93	114708	SPRING	1	
33	110141	SCREW, cap, sch	4	94	114688	NUT, capped	1	
34	193081	BRACKET, manifold, filter	1	95	194102	HANDLE, valve, drain	1	
35	183169	SPRING, retaining	1	96	102814	GAUGE, pressure, fluid	1	
36	193710	SEAL, valve	1	97	114797	GASKET	1	
37	110963	SCREW, flange, hex hd	4	98	156849	NIPPLE, pipe	1	
38	193031	NUT, retaining	1	99	237475	SWIVEL, union	1	
39	240800	KIT, pump, displacement manual 308798	1	101	162485	NIPPLE, adapter	3	
41	100840	ELBOW, 90°	1	102	193024	NIPPLE, hex	1	
42	241717	DEFLECTOR	1	103	194497	HOUSING, filter	1	
43	240131	PLUG, packless	1	104†	192839	LABEL, warning, French	1	
44	114271	STRAP, retaining	1	105†	240797	HOSE, grounded, 3/8 in. x 50 ft (15m) spring guards both ends	1	
47	206994	THROAT SEAL LIQUID, 8 OZ	1	106†	241735	HOSE, grounded, 1/4 x 3 ft (.9 m) spring guards both ends	1	
48	240315	BOWL, filter, includes 71	1	107†	241338	GUN, texture; includes 105 and 106 manual 308491	1	
49	106115	WASHER, lock, spring	4	110		LABEL, WARNING	1	
50	189920	STRAINER, inlet	1		187975	English	1	
51	108849	SCREW, cap, sch	2		193520	Japanese	1	
52	110243	RING, retaining	2	111▲	195119	LABEL, warning (on drain hose—not shown)	1	
53	108691	PLUG, tubing	2		115	159841	ADAPTER, 1/4 npt(f) x 3/8 npt(m)	1
54	108460	CONNECTOR, conduit, 45°	1		119	224457	SWIVEL, straight	1
55▲		LABEL, caution	1		120	156971	NIPPLE	1
	192839	English	1		121	240987	PLUG, packless, 3/8	1
	193521	Japanese	1					
56	104361	PACKING, o-ring	1					
57	164672	ADAPTER	1					
58	101242	RING, retaining, ext.	2					
59	167025	STRAINER, 60 mesh	1					
60	179811	WHEEL, semi-pneumatic	2					
61	240136	HANDLE, cart	1					
62	192027	SLEEVE, cart	2					
63	105510	WASHER, lock, spring	6					

▲ Extra Danger and Warning tags and labels available free.

* Motor Brush Repair Kit is available:


Model, 232173; order 222157

Model 232171; order 220853

† Models 232171, 232173 have items, 105 thru 107.

†† Drain valve replacement kit 241276 is available

Pressure Control Drawing



- 1 Torque to 150 in-lb (17 N·m)
- 2 To housing ground, Fig. 9.
- 3 Located this point, inside housing
- 4 WARNING! See Pressure Control Transducer and O-Ring Replacement on page 10 for correct replacement procedure.

Fig 21

7202D

Pressure Control Parts List

Part Number 239750 or 239429

Ref No.	Part No.	Description	Qty	Ref No.	Part No.	Description	Qty
		PRESSURE CONTROL	1	218	192145	BRACKET, transducer	1
		<i>See Ref. No. 5 on page 21 for location</i>		219	236364	TRANSDUCER, pressure control	1
	239750	Models 232160 through 232163, 232166	1	220	104319	O-RING <i>See O-Ring Replacement page 10</i>	1
	239429	Model 232164	1	221	192050	ELECTRICAL ENCLOSURE KIT	1
201		MOTOR CONTROL BOARD	1	222	M71503	SCREW	2
	239283	Model 232164	1	224†	192142	PLUG	1
	239751	Models 232160 thru 232163, 166	1	225†	104836	SCREW	4
202		CONTROL HOUSING	1	226†	110637	SCREW	2
	238976	Model 232164	1	227†	192155	COVER	1
	239442	Models 232160 thru 232163, 166	1	228	113799	INLET, ac power	1
203	111930	. SWITCH, toggle (10/12 or 15/20)	1	229	114027	WASHER, flat	2
204	105658	. RING, locking	1	230	111714	SCREW, machine, phillips, pan hd	2
205	105659	. BOOT, toggle	1	231▲	189930	LABEL, caution	1
206	111961	. SWITCH, rocker (on/off)	1	232	157021	WASHER, lock, internal	1
207	236352	. POTENTIOMETER (pressure adjust)	1	233	111593	SCREW, grounding	1
208	112382	. NUT, shaft sealing	1	234	186620	LABEL, ground	1
209	114273	. KNOB, control	1	235†	111710	O-RING	1
210	193072	. LABEL, control knob	1	236†	111711	RING, backup	1
211	192226	. SPACER, switch	1	237	101754	PLUG, pipe	1
212	112788	. SCREW, cap hd	2	238	192212	PAD, foam	1
213	100644	SCREW, cap	5	323*	235009	SWITCH TRANSDUCER (not shown)	1
214	100016	WASHER, lock	5	324*	192150	BLOCK, transducer (not shown)	1
215	114031	CLIP, cee	1	325*	108850	SCREW, machine, fil hd (not shown)	4
216	192223	SPACER, transducer	1	326*	111704	SCREW, machine, fil hd (not shown)	2
217	192144	SPACER, transducer	1	327*	239530	SWITCH (not shown)	1

▲ Replacement Danger and Warning labels, tags and cards are available at no cost.

† These parts are included on all sprayers as shipped, but not on replacement pressure control 239576.

* These parts are included with replacement pressure control 239576, but are not on all sprayers as shipped.

Technical Data

Power Requirements

Models 232164 and 232173	230 VAC, 50 Hz, 1 phase, 12A min or 5000W generator
Models 232160 thru 163, 232171	120 VAC, 60 Hz, 1 phase, 15A min or 5000W generator
Model 232166	100 VAC, 50/60 Hz, 1 phase, 15A min or 5000W generator

Motor 1.6 HP
with latex at 138 bar (13.8 MPa, 2000 psi)

Working Pressure Range 0–210 bar (0–21 MPa, 0–3000 psi)

Cycles/Gallon (liter) 118 (31)

Maximum Delivery Rating 1.25 gpm (4.75 lpm)

Tip Size: one gun – 0.035; two guns – 0.025; three guns – 0.019
with latex at 138 bar (13.8 MPa, 2000 psi)

Power Cord

Model 232164, 232173 1.5 mm² by 4.5 m, 3 wire

Models 232160 – 163, 166, 171 . 2.0 mm² by 4.5 m, 3 wire

Inlet Paint Strainer 16 mesh (975 micron)
stainless steel screen, reusable

Outlet Paint Filter 60 mesh (238 micron)
stainless steel screen, reusable

Pump Inlet Size 3/4 npt(m)

Fluid Outlet Size

Filter 3/8 npt(f)

Filter with standard 3/8 npt(f) to 1/4 npsm adapter 1/4 npsm

Sound Data

Sound pressure level at one meter 85.3 db(A)

Sound power level 95.2 db(A)

Measured under maximum operating conditions per ISO-3744

Basic Sprayer Wetted Parts: zinc-plated carbon steel, polyurethane, polyethylene, stainless steel, PTFE, Delrin®, chrome plating, leather, V-Max™ UHMWPE, aluminum, stainless steel, tungsten carbide

NOTE: Delrin®

Dimensions

Weight (dry w/o packaging) 140 lb (63.5 kg)

Height 30.5 in. (775 mm)


Length 25.5 in. (648 mm)

Width 22.5 in. (572 mm)

Accessories

DANGER LABELS

An English language DANGER label is on your sprayer. If you have painters who do not read English, order one of the following labels to apply to your sprayer. Order labels from your Graco distributor.



Apply other language here

French	187784
Spanish	185962
German	186042
Greek	186046
Korean	186050

8183A

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale by an authorized Graco distributor to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

ADDITIONAL WARRANTY COVERAGE

Graco does provide extended warranty and wear warranty for products described in the "Graco Contractor Equipment Warranty Program".

Graco Phone Number

TO PLACE AN ORDER, contact your Graco distributor, or call this number to identify the distributor closest to you: **1-800-690-2894 Toll Free.**

All written and visual data contained in this document reflects the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice.

Sales Offices: Minneapolis, Detroit

Foreign Offices: Belgium, Korea, Hong Kong, Japan

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441

<http://www.graco.com>

PRINTED IN USA 308854 May 1998, Revised 04/2000