



ProMix® PD2K Proportioner for Automatic Spray Applications

332564L
EN


Electronic positive displacement proportioner for fast-setting two-component materials. Automatic system with Advanced Display Module. For professional use only.



Important Safety Instructions

Read all warnings and instructions in this manual and in your installation, repair, and associated component manuals. Save these instructions.

See page 3 for model part numbers and approvals information.



ti23768a

Contents

Related Manuals	3	Setup Mode Screens	69
Models	4	Password Screen	69
Warnings	7	System Screen 1	69
Important Isocyanate (ISO) Information	10	System Screen 2	70
Material Self-ignition	10	Solvent Push	71
General Information	12	System Screen 3	73
Advanced Display Module (ADM)	13	System Screen 4	73
ADM Display	13	System Screen 5	74
USB Download Procedure	13	Gateway Screen	75
USB Upload Procedure	14	Recipe Screen	76
ADM Keys and Indicators	15	Flush Screen	78
Soft Key Icons	16	Air/Solvent Chop	79
Navigating the Screens	17	Pump Screen 1	80
Screen Icons	17	Custom Valve Mapping	82
Pre-Operation Tasks	18	Pump Screen 2	86
Pre-operation Checklist	18	Pump Screen 3	87
Power On	18	Pressure Alarm and Deviation Limits	87
Initial System Setup	18	Pump Screen - Material Assignment	87
Flush Before Using Equipment	19	Calibration Screens	88
Valve Settings	19	Maintenance Screens	90
Pressure Relief Procedure	20	Advanced Screen 1	92
Without Color Change	20	Advanced Screen 2	93
With Color Change	20	Advanced Screen 3	93
Operation Using Advanced Display Module (ADM)	21	Advanced Screen 4	94
Prime and Fill the System	21	Diagnostic Screens	95
Pre-Fill the Pump	21	Calibration Checks	96
Spraying	21	Pump Pressure Check	96
Purging	22	Pump Volume Check	97
Shutdown	23	Solvent Meter Calibration	98
Operation Using a Programmable Logic Controller (PLC)	24	Color Change	99
Network Communications and Discrete I/O	24	Multiple Color Systems	99
Discrete I/O	24	System Errors	100
Communication Gateway Module (CGM) Details	26	On-Screen Help	100
Network Communication I/O Data Map	27	To Clear Error and Restart	101
Operation Flow Charts	38	Gun Trigger Input Function	101
Network Communication - Dynamic Command Structure (DCS)	47	Error Codes	102
PLC Diagnostic Screens	60	Maintenance	114
Flow Control System	61	Preventive Maintenance Schedule	114
Run Mode Screens	62	Flushing	114
Opening Screen	62	Cleaning the ADM	114
Home Screen	62	Appendix A: Integration with Allen Bradley PLC	115
Spray Screen	65	Appendix B: Multiple Guns	118
Fill Screen	66	Spray Screen	122
Usage Screen	67	Fill Screen	122
Jobs Screen	68	Potlife Screen	123
Errors Screen	68	Recipe 0	123
Events Screen	68	Maintenance Screen 5	124
		Operation With a PLC	124
		Technical Data	125
		California Proposition 65	125

Related Manuals


Current manuals are available at www.graco.com.

Manual No.	Description
332709	ProMix PD2K Proportioner for Automatic Spray Applications, Repair — Parts
332458	ProMix PD2K Proportioner for Automatic Spray Applications, Installation
332339	Dosing Pumps, Instructions — Parts
332454	Color/Catalyst Dispense Valves, Instructions — Parts
332455	Color Change Kits, Instructions — Parts

Manual No.	Description
333282	Color Change and Remote Mix Manifold Kits, Instructions — Parts
332456	Pump Expansion Kits, Instructions — Parts
334183	Modbus TCP Gateway Module, Instructions — Parts
334494	ProMix PD2K CGM Installation Kits, Instructions — Parts

Models

See Figs. 1–6 for component identification labels, including approval information and certification.

Part No.	Series	Maximum Air Working Pressure	Maximum Fluid Working Pressure	Location of PD2K and Electrical Control Box (ECB) Labels
AC0500	A	100 psi (0.7 MPa, 7.0 bar)	With low-pressure pumps: 300 psi (2.068 MPa, 20.68 bar)	 <p>i21937a</p>
			With high-pressure pumps: 1500 psi (10.34 MPa, 103.4 bar)	
AC1000	A	100 psi (0.7 MPa, 7.0 bar)	300 psi (2.068 MPa, 20.68 bar)	
AC2000	A	100 psi (0.7 MPa, 7.0 bar)	1500 psi (10.34 MPa, 103.4 bar)	



ProMix® PD Electronic Proportioner

CE 2575 **Ex II 2 G**
Ex ia IIA T3 Gb
FM13ATEX0026
FM21UKEX0122
IECEX FMG 13.0011

UK CA 0359

FM US APPROVED

FM16US0241
FM16CA0129
Intrinsically safe equipment for Class I, Div 1, Group D, T3
Ta = 2°C to 50°C

EAC

Intrinsically Safe (IS) System. Install per IS Control Drawing No. 16P577. Control Box IS Associated Apparatus for use in non hazardous location, with IS Connection to color change and booth control modules Apparatus for use in: Class I, Division 1, Group D T3 Hazardous Locations

Read Instruction Manual
Warning: Substitution of components may impair intrinsic safety.

MAX AIR WPR		
.7	7	100
MPa	bar	PSI
MAX FLUID WPR		
2.068	20.68	300
MPa	bar	PSI
MAX TEMP 50°C (122°F)		

Artwork No. 294021 Rev. L

PART NO.	SERIES	SERIAL

MFG. YR.

GRACO INC.
P.O. Box 1441
Minneapolis, MN
55440 U.S.A.
www.graco.com/patent

Figure 1 Model AC1000 Identification Label

ProMix® PD			POWER REQUIREMENTS	
PART NO.	SERIES NO.	MFG. YR.	VOLTS	AMPS
			90-250 ~	7 AMPS MAX 50/60 Hz

GRACO INC.
P.O. Box 1441
Minneapolis, MN
55440 U.S.A.

FM US APPROVED

FM16US0241
FM16CA0129
Intrinsically safe connections for Class I, Div 1, Group D
Ta = 2°C to 50°C
Install per 16P577

CE 2575 **Ex II (2) G**
[Ex ia Gb] IIA
FM13ATEX0026
FM21UKEX0122
IECEX FMG 13.0011

Um: 250 V
294024h

UK CA 0359

Figure 2 24M672 Control Box Identification Label




Figure 3 Model AC2000 Identification Label




Figure 4 Model AC0500 Identification Label




Figure 5 Non-Intrinsically Safe Color Change Control (Accessory) Identification Label




Figure 6 Intrinsically Safe Color Change Control (Accessory) Identification Label

ProMix® PD2K/PD1K				EXPANSION PUMP		
PART NO.	SERIES	SERIAL	MFG. YR.	MAX AIR WPR		
				.7	7	100
 GRACO INC. P.O. Box 1441 Minneapolis, MN 55440 U.S.A.				MPa bar PSI MAX FLUID WPR		
				MPa bar PSI		
 MAX TEMP 50°C (122°F)				10.34 103.4 1500		
				MPa bar PSI		
Artwork No. 294116 Rev. C						

Figure 7 Pump Expansion Kit (Accessory) Identification Label


PART NO.	DATE /SERIES	RECOGNIZED COMPONENT  C LISTED US
SERIAL NO.		
		Intertek 4003764 Conforms to UL STD 508 Certified to CAN/CSA STD C22.2 No. 14 Artwork No. 293656 Rev. D
12-30 VDC 4 AMP MAX Type 1 ENCL U.S. Patent Pending		

Figure 8 CGM Identification Label

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.

 <h2 style="margin: 0;">WARNING</h2>	
   	<p>FIRE AND EXPLOSION HAZARD</p> <p>Flammable fumes, such as solvent and paint fumes, in work area can ignite or explode. To help prevent fire and explosion:</p> <ul style="list-style-type: none"> • Use equipment only in well ventilated area. • Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static arc). • Keep work area free of debris, including solvent, rags and gasoline. • Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present. • Ground all equipment in the work area. See Grounding instructions. • Use only grounded hoses. • Hold gun firmly to side of grounded pail when triggering into pail. Do not use pail liners unless they are antistatic or conductive. • Stop operation immediately if static sparking occurs or you feel a shock, Do not use equipment until you identify and correct the problem. • Keep a working fire extinguisher in the work area.
 	<p>ELECTRIC SHOCK HAZARD</p> <p>This equipment must be grounded. Improper grounding, setup, or usage of the system can cause electric shock.</p> <ul style="list-style-type: none"> • Turn off and disconnect power at main switch before disconnecting any cables and before servicing or installing equipment. • Connect only to grounded power source. • All electrical wiring must be done by a qualified electrician and comply with all local codes and regulations.



WARNING

  	<p>INTRINSIC SAFETY</p> <p>Intrinsically safe equipment that is installed improperly or connected to non-intrinsically safe equipment will create a hazardous condition and can cause fire, explosion, or electric shock. Follow local regulations and the following safety requirements.</p> <ul style="list-style-type: none"> • Be sure your installation complies with national, state, and local codes for the installation of electrical apparatus in a Class I, Group D, Division 1 (North America) or Class I, Zones 1 and 2 (Europe) Hazardous Location, including all of the local safety fire codes (for example, NFPA 33, NEC 500 and 516, OSHA 1910.107, etc.). • To help prevent fire and explosion: <ul style="list-style-type: none"> • Do not install equipment approved only for a non-hazardous location in a hazardous location. See model ID label for the intrinsic safety rating of your model. • Do not substitute system components as this may impair intrinsic safety. • Equipment that comes in contact with the intrinsically safe terminals must be rated for Intrinsic Safety. This includes DC voltage meters, ohmmeters, cables, and connections. Remove the unit from the hazardous area when troubleshooting.
  	<p>SKIN INJECTION HAZARD</p> <p>High-pressure fluid from dispensing device, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. Get immediate surgical treatment.</p> <ul style="list-style-type: none"> • Do not point dispensing device at anyone or at any part of the body. • Do not put your hand over the fluid outlet. • Do not stop or deflect leaks with your hand, body, glove, or rag. • Follow the Pressure Relief Procedure when you stop dispensing and before cleaning, checking, or servicing equipment. • Tighten all fluid connections before operating the equipment. • Check hoses and couplings daily. Replace worn or damaged parts immediately.
 	<p>MOVING PARTS HAZARD</p> <p>Moving parts can pinch, cut or amputate fingers and other body parts.</p> <ul style="list-style-type: none"> • Keep clear of moving parts. • Do not operate equipment with protective guards or covers removed. • Pressurized equipment can start without warning. Before checking, moving, or servicing equipment, follow the Pressure Relief Procedure and disconnect all power sources.
 	<p>TOXIC FLUID OR FUMES</p> <p>Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.</p> <ul style="list-style-type: none"> • Read MSDSs to know the specific hazards of the fluids you are using. • Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines. • Always wear chemically impermeable gloves when spraying, dispensing, or cleaning equipment.



WARNING



PERSONAL PROTECTIVE EQUIPMENT

Wear appropriate protective equipment when in the work area to help prevent serious injury, including eye injury, hearing loss, inhalation of toxic fumes, and burns. This protective equipment includes but is not limited to:

- Protective eyewear, and hearing protection.
- Respirators, protective clothing, and gloves as recommended by the fluid and solvent manufacturer.



EQUIPMENT MISUSE HAZARD

Misuse can cause death or serious injury.



- Do not operate the unit when fatigued or under the influence of drugs or alcohol.
- Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See **Technical Data** in all equipment manuals.
- Use fluids and solvents that are compatible with equipment wetted parts. See **Technical Data** in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request MSDS from distributor or retailer.
- Do not leave the work area while equipment is energized or under pressure.
- Turn off all equipment and follow the **Pressure Relief Procedure** when equipment is not in use.
- Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only.
- Do not alter or modify equipment. Alterations or modifications may void agency approvals and create safety hazards.
- Make sure all equipment is rated and approved for the environment in which you are using it.
- Use equipment only for its intended purpose. Call your distributor for information.
- Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces.
- Do not kink or over bend hoses or use hoses to pull equipment.
- Keep children and animals away from work area.
- Comply with all applicable safety regulations.

Important Isocyanate (ISO) Information

Isocyanates (ISO) are catalysts used in two component materials.

Isocyanate Conditions

				
---	---	---	---	--

Spraying or dispensing fluids that contain isocyanates creates potentially harmful mists, vapors, and atomized particulates

- Read and understand the fluid manufacturer's warnings and Safety Data Sheet (SDS) to know specific hazards and precautions related to isocyanates.
- Use of isocyanates involves potentially hazardous procedures. Do not spray with the equipment unless you are trained, qualified, and have read and understood the information in this manual and in the fluid manufacturer's application instructions and SDS.
- Use of incorrectly maintained or mis-adjusted equipment may result in improperly cured material. Equipment must be carefully maintained and adjusted according to instructions in the manual.
- To prevent inhalation of isocyanate mists, vapors, and atomized particulates, everyone in the work area must wear appropriate respiratory protection. Always wear a properly fitting respirator, which may include a supplied-air respirator. Ventilate the work area according to instructions in the fluid manufacturer's SDS.
- Avoid all skin contact with isocyanates. Everyone in the work area must wear chemically impermeable gloves, protective clothing and foot coverings as recommended by the fluid manufacturer and local regulatory authority. Follow all fluid manufacturer recommendations, including those regarding handling of contaminated clothing. After spraying, wash hands and face before eating or drinking.

Material Self-ignition

				
---	---	--	--	--

Some materials may become self-igniting if applied too thick. Read material manufacturer's warnings and Safety Data Sheet (SDS).

Keep Components A and B Separate

				
---	--	---	--	--

Cross-contamination can result in cured material in fluid lines which could cause serious injury or damage equipment. To prevent cross-contamination:

- **Never** interchange component A and component B wetted parts.
- Never use solvent on one side if it has been contaminated from the other side.

Moisture Sensitivity of Isocyanates

Exposure to moisture (such as humidity) will cause ISO to partially cure; forming small, hard, abrasive crystals, which become suspended in the fluid. Eventually a film will form on the surface and the ISO will begin to gel, increasing in viscosity.

NOTICE

Partially cured ISO will reduce performance and the life of all wetted parts.

- Always use a sealed container with a desiccant dryer in the vent, or a nitrogen atmosphere. **Never** store ISO in an open container.
- Keep the ISO pump wet cup or reservoir (if installed) filled with appropriate lubricant. The lubricant creates a barrier between the ISO and the atmosphere.
- Use only moisture-proof hoses compatible with ISO.
- Never use reclaimed solvents, which may contain moisture. Always keep solvent containers closed when not in use.
- Always lubricate threaded parts with an appropriate lubricant when reassembling.

NOTE: The amount of film formation and rate of crystallization varies depending on the blend of ISO, the humidity, and the temperature.

Changing Materials

NOTICE

Changing the material types used in your equipment requires special attention to avoid equipment damage and downtime.

- When changing materials, flush the equipment multiple times to ensure it is thoroughly clean.
- Always clean the fluid inlet strainers after flushing.
- Check with your material manufacturer for chemical compatibility.
- When changing between epoxies and urethanes or polyureas, disassemble and clean all fluid components and change hoses. Epoxies often have amines on the B (hardener) side. Polyureas often have amines on the A (resin) side.

General Information

- Reference numbers and letters in parentheses in the text refer to numbers and letters in the illustrations.
- Be sure all accessories are adequately sized and pressure-rated to meet system requirements.
- To protect the screens from paints and solvents, clear-plastic protective shields (10 per pack) are available. Order Part No. 197902 for the Advanced Display Module. Clean the screens with a dry cloth if necessary.

Advanced Display Module (ADM)

ADM Display

The ADM display shows graphical and text information related to setup and spray operations.

For detail on the display and individual screens, see [Run Mode Screens, page 62](#), or [Setup Mode Screens, page 69](#).

Keys are used to input numerical data, enter setup screens, navigate within a screen, scroll through screens, and select setup values.

NOTICE

To prevent damage to the softkey buttons, do not press the buttons with sharp objects such as pens, plastic cards, or fingernails.




Figure 9 Advanced Display Module

USB Download Procedure

Use the USB port on the ADM to download or upload data.

1. Enable USB downloads. See [Advanced Screen 3, page 93](#).
2. Remove the cover from the USB port on the bottom of the ADM. Insert the USB drive.
3. During the download, USB BUSY appears on the screen.
4. When the download is complete, USB IDLE appears on the screen. The USB drive may then be removed.

NOTE: If the download operation takes longer than 60 seconds, the message disappears. To determine if the USB is busy or idle, check the Error Status bar on the screen. If idle, remove the USB.

5. Insert the USB flash drive into the USB port of the computer.
6. The USB flash drive window automatically opens. If it does not, open the USB flash drive from within Windows® Explorer.
7. Open Graco folder.
8. Open system folder. If downloading data from more than one system, there will be more than one folder. Each folder is labeled with the corresponding serial number of the ADM. (The serial number is on the back of the ADM.)
9. Open DOWNLOAD folder.
10. Open LOG FILES folder labeled with the highest number. The highest number indicates the most recent data download.
11. Open log file. Log files open in Microsoft® Excel® by default if the program is installed. They also can be opened in any text editor of Microsoft® Word.

NOTE: All USB logs are saved in Unicode (UTF-16) format. If opening the log file in Microsoft Word, select Unicode encoding.

12. Always reinstall the USB cover after removing the USB, to keep the drive free of dirt and dust.

USB Upload Procedure

Use this procedure to install a system configuration file and/or a custom language file.

1. If necessary, follow the **USB Download Procedure**, to automatically generate the proper folder structure on the USB flash drive.
2. Insert the USB flash drive into the USB port of the computer.
3. The USB flash drive window automatically opens. If it does not, open the USB flash drive from within Windows Explorer.
4. Open the Graco folder.
5. Open the system folder. If working with more than one system, there will be more than one folder within the Graco folder. Each folder is labeled with the corresponding serial number of the ADM. (The serial number is on the back of the module.)
6. If installing the system configuration settings file, place SETTINGS.TXT file into UPLOAD folder.
7. If installing the custom language file, place DISPTXT.TXT file into UPLOAD folder.
8. Remove the USB flash drive from the computer.
9. Install the USB flash drive into the USB port of the ProMix PD2K system USB port.
10. During the upload, USB BUSY displays on the screen.
11. Remove the USB flash drive from the USB port.

NOTE: If the custom language file was installed, users can now select the new language from the Language drop-down menu in the Advanced Setup Screen 1.

NOTE: If the system configuration settings file was installed, it is recommended to remove the file from the UPLOAD folder on the USB flash drive. This will prevent inadvertently overwriting any future setup changes.

ADM Keys and Indicators

NOTICE

To prevent damage to the softkey buttons, do not press the buttons with sharp objects such as pens, plastic cards, or fingernails.

Table 1 : ADM Keys and Indicators

Key	Function
 <p>Startup/Shutdown Key and Indicator</p>	<p>Press to startup or shutdown the pump/motor.</p> <ul style="list-style-type: none"> • Solid green indicates that power is applied to the motor. • Solid yellow indicates that power to the motor is off. • Blinking green or yellow indicates that the system is in Setup mode.
 <p>Stop</p>	<p>Press to immediately stop the system and remove motor power.</p>
 <p>Soft Keys</p>	<p>Press to select the specific screen or operation shown on the display directly next to each key. The top left soft key is the Edit key, which allows access to any settable fields on a screen.</p>
 <p>Navigation Keys</p>	<ul style="list-style-type: none"> • <i>Left/Right Arrows:</i> Use to move from screen to screen. • <i>Up/Down Arrows:</i> Use to move among fields on a screen, items on a dropdown menu, or multiple screens within a function.
<p>Numeric Keypad</p>	<p>Use to input values. See ADM Display, page 13.</p>
 <p>Cancel</p>	<p>Use to cancel a data entry field.</p>
 <p>Setup</p>	<p>Press to enter or exit Setup mode.</p>
 <p>Enter</p>	<p>Press to choose a field to update, to make a selection, to save a selection or value, to enter a screen, or to acknowledge an event.</p>

Soft Key Icons

The following icons appear in the ADM display, directly to the left or right of the soft key which activates that operation.

NOTICE

To prevent damage to the softkey buttons, do not press the buttons with sharp objects such as pens, plastic cards, or fingernails.

Table 2 : Soft Key Functions

Key	Function
 Enter Screen	Press to enter screen for editing. Highlights editable data on a screen. Use Up/Down arrows to move between data fields on the screen.
 Exit Screen	Press to exit screen after editing.
 Accept	Press to accept calibration value.
 Cancel	Press to cancel or reject calibration value.
 Prime Pump	Press to start a pump priming procedure.
 Line/Fill/Run	Press to start a line fill procedure.
 Mix	Press to start a spray procedure.
 Purge	Press to start a purge procedure.
 Solvent Purge	Press to engage solvent push sequence, when applicable.
 Pre-Fill Pump	Press to mark pump as filled. (Only for applicable pumps.)

Key	Function
 Standby	Press to stop all pumps and put system in Standby.
 Stop	
 Pressure Check	Press to start a pump pressure check.
 Volume Check	Press to start a pump volume check.
 Job Complete	Press to log the material usage and increment the job number.
 Counter Reset	Press to reset the current usage counter.
 Move Cursor to Left	Appears on the User ID Keyboard screen. Use to move cursor to the left.
 Move Cursor to Right	Appears on the User ID Keyboard screen. Use to move cursor to the right.
 Erase All	Appears on the User ID Keyboard screen. Use to erase all characters.
 Backspace	Appears on the User ID Keyboard screen. Use to erase one character at a time.
 Upper Case/Lower Case	Appears on the User ID Keyboard screen. Use to change case (upper/lower).
 Info	Press to get more information on active system error.

Key	Function
 Troubleshoot	Press to see troubleshooting information for system error.
 QR Code	Press to see QR Code for system error.

Navigating the Screens

There are two sets of screens:

- The Run screens control mixing operations and display system status and data.
- The Setup screens control system parameters and advanced features.

Press  on any Run screen to enter the Setup screens. If the system has a password lock, the Password screen displays. If the system is not locked (password is set to 0000), System Screen 1 displays.

Press  on any Setup screen to return to the Home screen.

Press the Enter soft key  to activate the editing function on any screen.

Press the Exit soft key  to exit any screen.

Use the other softkeys to select the function adjacent to them.

Screen Icons

As you move through the screens, you will notice that icons are used frequently to simplify global communication. The following descriptions explain what each icon represents.

Screen Icons	
 User ID	 Job Number
 Potlife	 1:1 Target Ratio
 Recipe Number	 Flow Rate
 Pressure	 Volume
 Material A	 Material B
 Material A+B	 Solvent
 Calendar	 Time
 Alarm/Advisory	 Deviation

Pre-Operation Tasks

Pre-operation Checklist

Go through the Pre-Operation Checklist daily, before each use.

✓	Checklist
	<p>System grounded</p> <p>Verify all grounding connections were made. See Grounding in the Installation manual.</p>
	<p>All connections tight and correct</p> <p>Verify all electrical, fluid, air, and system connections are tight and installed according to the Installation manual.</p>
	<p>Fluid supply containers filled</p> <p>Check component A and B and solvent supply containers.</p>
	<p>Dose valves set</p> <p>Check that dose valves are set 1-1/4 turns open. Start with the settings recommended in Valve Settings, page 19, then adjust as needed.</p>
	<p>Fluid supply valves open and pressure set</p> <p>The recommended component A and B fluid supply pressures are 1/2 to 2/3 of the target spray pressure.</p> <p>NOTE: Low pressure systems may be set within a range of ± 100 psi (0.7 MPa, 7 bar); high pressure systems may be set within a range of ± 300 psi (2.1 MPa, 21 bar). If the inlet pressure is higher than the outlet pressure, ratio accuracy may be affected.</p>
	<p>Solenoid pressure set</p> <p>85-100 psi inlet air supply (0.6-0.7 MPa, 6-7 bar).</p>

Power On

1. Turn the AC Power Switch (P) ON (I = ON, 0 = OFF).
2. The Graco logo will display while the system initializes, followed by the Home screen.
3. Press the Start key . The system status will change from "System Off" to "Startup." Once the pumps are powered and are in the Home position, the system status will change from "Startup" to "Standby."




Figure 10 Power Switch

Initial System Setup


1. Change optional setup selections to desired parameters, as described in [Setup Mode Screens, page 69](#).
2. Set recipe and flush information as described in [Recipe Screen, page 76](#) and [Flush Screen, page 78](#).

Flush Before Using Equipment

The pump fluid section was tested with lightweight oil, which is left in the fluid passages to protect parts. To avoid contaminating your fluid with oil, flush the equipment with a compatible solvent before using the equipment.

Valve Settings

Dose valves and purge valves are factory set with the hex nut (E) 1-1/4 turns out from fully closed.



ti21998a

Figure 11 Valve Adjustment

Pressure Relief Procedure



Follow the **Pressure Relief Procedure** whenever you see this symbol.

<p>This equipment stays pressurized until pressure is manually relieved. To help prevent serious injury from pressurized fluid, such as skin injection, splashing fluid and moving parts, follow the Pressure Relief Procedure when you stop spraying and before cleaning, checking, or servicing the equipment.</p>				

Without Color Change

NOTE: The following procedure relieves all fluid and air pressure in the system. Use your control interface to issue the necessary commands to your system.

1. Turn off the supply pumps. Open the drain valve on the supply line fluid filter to relieve pressure in the supply line.
2. Command the system to Standby. From Maintenance Screen 5 on the ADM, check the box in the field labeled Gun for the color or catalyst in the pump. Trigger the spray device to relieve pressure. Repeat for each pump in the system.
3. Flush the remote mix manifold and spray device. See [Flush Mixed Material, page 22](#).
4. Shut off the solvent supply pump. To relieve pressure, command the system to Purge and trigger the spray device. When the pressure is relieved, command the system to Standby to avoid getting a Purge Incomplete alarm.
5. If pressure remains in the solvent line between the solvent supply pump and the solvent valve:
 - VERY SLOWLY loosen a fitting to relieve pressure gradually.
 - Loosen the fitting completely.

With Color Change

NOTE: The following procedure relieves all fluid and air pressure in the system.

1. Turn off the supply pumps. Open the drain valve on the supply line fluid filter to relieve pressure in the supply lines. Do this for each color.

<p>If using an electrostatic gun, shut off the electrostatics before flushing the gun.</p>				


2. Trigger the gun to relieve pressure. From Maintenance Screen 5 on the ADM, check the box in the field labeled Gun for each color in the system, to manually open each color valve.
3. Set the system to Recipe 0 to flush the pumps and to purge to the spray device. Hold the gun trigger open after the solvent valve shuts off to relieve all pressure. When flushing is complete the system will go to Standby.
4. Shut off the solvent supply pump. Set the system to Recipe 0 to flush solvent from the pumps and to purge to the spray device. Command the system to Standby after just a couple of seconds, to avoid getting a Purge Incomplete alarm.
5. If pressure remains in the solvent line between the solvent supply pump and the solvent valve:
 - VERY SLOWLY loosen a fitting to relieve pressure gradually.
 - Loosen the fitting completely.
6. Verify on the ADM Home Screen that neither pump is showing any pressure.

Operation Using Advanced Display Module (ADM)

Prime and Fill the System

NOTE: See [Run Mode Screens, page 62](#), for further screen information, if needed.

NOTE: You must prime the input lines to the pumps or the inputs to the color change valves before priming the pump and filling the entire system.



1. If using an electrostatic gun, shut off the electrostatics before filling the lines.
2. Adjust the main air pressure. To ensure proper operation, set the main air pressure as close to 100 psi (0.7 MPa, 7.0 bar) as possible. Do not use less than 85 psi (0.6 MPa, 6.0 bar).
3. If this is the first time starting up the system, or if lines may contain air, purge as instructed under [Flush the System, page 22](#). The equipment was tested with lightweight oil, which should be flushed out to avoid contaminating your material.
4. **If the system is powered down**, press  on the ADM. Make sure that the system is in Standby mode.
5. Verify that the recipes and the flush sequences are programmed correctly by checking the [Recipe Screen, page 76](#) and the [Flush Screen, page 78](#).
6. Enable the manual override on System Screen 4.
7. Go to the [Fill Screen, page 66](#).
8. Select the desired color to load. Press the Prime Pump key . The color will load the pump through the color stack and out the outlet stack dump valve.

NOTE: In a single color system, step 8 can be skipped..

9. Press the Fill Line key  to run color out to the remote mix manifold. The pump will run until you press the Stop key  to stop the pump.
10. Trigger the gun into a grounded reservoir or purge receptacle until the line is full, then press the Stop key .
11. Repeat for all material lines.

Pre-Fill the Pump

NOTE: This option is only available for pumps that have color change valves and only a single material.

If a pump is filled with a material when the system is powered down, this will allow the user to change the pump's contents, without flushing the pump, the next time power is restored.

1. Enable the manual override on [System Screen 4, page 73](#).
2. Go to the [Fill Screen, page 66](#).
3. Press the Pre-Fill Pump key . The pump will change from material 61 to the proper color or catalyst.

Spraying

To spray in a multiple color system, also see [Multiple Color Systems, page 99](#).

NOTE: See [Run Mode Screens, page 62](#), for further screen information, if needed.



1. Command the system to Mix. The system will load the correct mixed material volume.

NOTE: The system will automatically run a Mix Fill if the recipe is not currently loaded into the system. The Mix Fill volume calculation includes the remote mix manifold volume and the mixed material hose volume. The mixed material hose volume is determined by the gun hose length and diameter entered in [System Screen 3, page 73](#), and the remote-to-mix hose length and diameter also entered in [System Screen 3, page 73](#).
2. Adjust the flow rate by changing the target pressure (in Pressure Mode) or the target flow rate (in Flow Mode) on the Spray Screen or through the PLC. The fluid flow rate shown on the Spray screen is the combined total of component A and B out of the spray device.
3. Turn on atomizing air to the spray device. Check the spray pattern as instructed in your spray device manual.


NOTICE

Do not allow a fluid supply tank to run empty. This can damage the pumps and lead to the proportioning of fluid and air that meets the ratio and tolerance settings of the equipment. This can further result in spraying uncatalyzed or poorly catalyzed material.

Purging


To purge one color and fill with a new color, see [Color Change, page 99](#).

Flush Mixed Material



There are times when you only want to purge the remote mix manifold and the spray device, such as:

- end of potlife
 - breaks in spraying that exceed the potlife
 - overnight shutdown or end of shift
 - before servicing the remote mix manifold, hose or gun.
1. Command the system to Standby.
 2. If you are using a high pressure spray device or an electrostatic gun, shut off the atomizing air.




3. Command the system to Purge A or Purge B. (See [Purge Mode Sequence, page 38](#).) Trigger the spray device into a grounded metal pail until the purge sequence is complete. When done purging, the system automatically switches to Standby mode, signalling the spray device to stop spraying.
4. If the system is not completely clean, repeat Step 5.

NOTE: For optimal efficiency, adjust purge sequence times so only one cycle is required.

NOTE: The remote mix manifold and gun remain full of solvent after purging.

Flush the System



Follow this procedure before:

- the first time material is loaded into the equipment
- servicing
- shutting down equipment for an extended period of time
- putting equipment into storage

Single Color System

1. Relieve the pressure. See [Pressure Relief Procedure, page 20](#).
2. Disconnect the color and catalyst supply lines from the pump inlet manifolds, and connect regulated solvent supply lines.
3. Set the solvent supply pressure regulator at the lowest pressure possible. Generally a setting of 25–50 psi (0.18–0.35 MPa, 1.8–3.5 bar) is sufficient.
4. Enable manual override on [System Screen 4, page 73](#).
5. On the ADM, go to the Fill screen. Set the Material to Color (A). Press . The system will pump solvent through pump A all the way to the gun.
6. Hold a metal part of the spray device firmly to a grounded metal pail. Trigger the spray device until clean solvent dispenses.
7. On the ADM, go to the Fill screen. Set the Material to Catalyst (B). Press . The system will pump solvent through pump B all the way to the gun.
8. Relieve the pressure. See [Pressure Relief Procedure, page 20](#)

Color Change System

1. Relieve the pressure. See [Pressure Relief Procedure, page 20](#).
2. Attach regulated solvent supply lines as follows:
 - **Multiple color/single catalyst system:** On the color side, do not disconnect the color supply line from the inlet manifold of Pump A. Instead, connect a regulated solvent supply line to the designated solvent valve on the color valve manifold. On the catalyst side, disconnect the catalyst supply line from the inlet manifold of Pump B, and connect a regulated solvent supply line.
 - **Multiple color/multiple catalyst system:** Connect regulated solvent supply lines to the designated solvent valves on the color and catalyst valve manifolds. Do not connect solvent supply lines directly to the inlet manifolds of the pumps.
3. Set the solvent supply pressure regulator at the lowest pressure possible. Generally a setting of 25–50 psi (0.18–0.35 MPa, 1.8–3.5 bar) is sufficient.
4. On the ADM, go to the Fill screen. Select Color (A). Enter the color number in the box to the right.
5. Select the Flush Line box.
6. If the solvent is not already loaded, press the Prime softkey . The system will prime solvent into the selected pump and out the outlet dump valve.
7. Press the Fill softkey . The system will flush the selected Color (A) line with the solvent until the user presses Stop .
8. Hold a metal part of the gun firmly to a grounded metal pail. Trigger the gun until clean solvent dispenses.
9. Repeat for each color line.
10. Relieve the pressure. See [Pressure Relief Procedure, page 20](#)

Shutdown

1. Flush out the mixed material to avoid potlife errors and fluid setup in the lines. See [Purging, page 22](#).
2. Follow the [Pressure Relief Procedure, page 20](#).
3. Close the main air shutoff valve on the air supply line and on the control box.
4. Press  on the Display Module to turn off power to the pumps.
5. Shut off system power (0 position).

Operation Using a Programmable Logic Controller (PLC)

Network Communications and Discrete I/O

The ProMix PD2K Automatic system does not use a Booth Control module. Instead, it uses Network Communications and has optional Discrete I/O features to drive the system remotely.

Some automation control elements of the ProMix PD2K can be driven by a discrete input *or* network communications. These options need to be configured at the ADM (see [System Screen 4, page 73](#)). The following features can be set to 'Discrete' or 'Network':

- **Flow Control** – Means of adjusting the control set point (see **Flow Control Set Point** below).
- **Gun Trigger** – Means of signaling the ProMix PD2K when the spray device is triggered.

NOTE: The Manual Override check box enables a user to operate the system before the automation (PLC) is available. Manual Override can be used to run all functions of the system if a proper gun trigger signal is provided. It is not intended to be the main mode of control. Graco recommends that Manual Override be disabled during normal operation to avoid driving the system in a way that conflicts with the automation sequence.

Discrete I/O

The ProMix PD2K does not supply power for Discrete I/O. A clear understanding of these inputs is necessary to properly integrate the ProMix PD2K with the PLC or networking device. Input and output connections are made at the Discrete I/O terminal strips on the Enhanced Fluid Control Module (EFCM) inside the control box.

Table 3 and Figure 12 show where discrete I/O connections are made on the ProMix PD2K.

Table 3 PD2K Discrete I/O Connections

I/O Description	EFCM Connector	Pins	Type
Gun Trigger Input	6	1,2	Normally Open Contact
Control Set Point	7	1,2	4-20 mA Input
Safety Interlock Input	7	11,12	Normally Open Contact

Digital Inputs

- **Safety Interlock:** This normally open contact works like a soft emergency stop button. If the ProMix PD2K reads the input as CLOSED it interrupts system operation and removes power from the pumps regardless of the current operating mode. If the input is read as OPEN, the system operates normally

NOTE: This digital input is always enabled.

Do not toggle this input to put the system into Standby mode.

- **Gun Trigger:** This normally open (maintained) contact provides a signal to the system to indicate whether or not a spray device is triggered. This input provides timing for alarm functions and also drives the flow control algorithm. If the input is OPEN the system operates as though the spray device is off. The input must be maintained CLOSED to signal that the spray device is triggered.

NOTE: The Gun Trigger discrete input must be enabled via System Screen 4 on the ADM. If it is set to 'Network' the discrete input is ignored and the spray device trigger signal is handled via the network communications.

If enabled, it is imperative that this signal be sent any time the spray device is triggered. Without the signal, the flow control features will not work.

Analog Inputs


Flow Control Set Point: When enabled, this 4-20mA signal input is used to set and adjust the operating flow control set point. The ProMix PD2K scales the set point linearly from 0 to the Max Set Point setting (see [System Screen 4, page 73](#)). *Examples,*

- **In Flow Control Mode:** If the Max Set Point is 500 cc/min, a 4mA signal is 0 cc/min and a 20mA signal is 500 cc/min.
- **In Pressure Control Mode:** If the Max Set Point is 500 psi, a 4mA signal is 0 psi and a 20mA signal is 500 psi.

NOTE: The Flow Control discrete input must be enabled via System Screen 4 on the ADM. If set to 'Network' the discrete input is ignored and set point adjustment is handled via the network communications.


4-20 mA Flow Control Set Point Input

Figure 12



Discrete I/O Connections on EFCM

Figure 13



KEY

- A1 Gun Trigger Input
- B1 Analog Set Point Input
- C1 Safety Interlock Input

Communication Gateway Module (CGM) Details

CGM Overview

The CGM provides a control link between the PD2K system and a selected fieldbus. This linkage provides the means for remote monitoring and control by external automation systems.

CGM Kits

The PD2K system does not come with a CGM. It must be purchased separately. The available CGM communication protocols are listed in the tables below.

NOTE: The CGM installation kit is also required for all protocols.

CGM Installation Kit Part No.	Field Bus	Manual
24W829	All	334494

CGM Part No.	Fieldbus	Manual
CGMDN0	DeviceNet	312864
CGMEP0	EtherNet/IP	312864
CGMPN0	PROFINET	312864
24W462	Modbus TCP	334183

Network Communication I/O Data Map

The PD2K has PLC Diagnostic Screens built into the software that assist in the system integration process. See [Setup Mode Screens, page 69](#).

ProMix PD2K Network Outputs

The ProMix PD2K Network Outputs are Read-Only and should be treated as inputs to a PLC or other networking device. These registers

provide various system and component status, measurement, and set point values. See [Network Output Data Map \(Read Only\), page 30](#).

OUTPUT REGISTER 00: Current System Mode

The Current System Mode register contains a number that indicates the current operation mode of the PD2K system.

Number	Operation Mode	Description
1	Pump Off	The pumps are currently powered down and the system is not in operation.
2	Recipe Change	The system is in the process of a color change sequence.
3	Recipe Change: Purge A	The system is purging material A as part of a recipe change.
4	Recipe Change: Purge B	The system is purging material B as part of a recipe change.
5	Recipe Change: Fill	The system is filling the hose from the remote valves to the mix manifold with material as part of a recipe change.
6	Mix Fill	The system is mixing material at ratio through the mix manifold and out the gun.
7	Mix	The system is currently mixing/spraying material.
8	Mix Idle	The system has paused mix operation due to the absence of a gun trigger signal.
9	Purge A	The system is purging material A while in Standby.
10	Purge B	The system is purging material B while in Standby.
11	Standby: Mix Ready	The system has a valid recipe loaded out to the gun.
12	Standby: Fill Ready	The system has a valid recipe loaded in the pumps, but not in the gun.
13	Standby: Mix Not Ready	The system requires that a recipe change operation be completed.
14	Standby: Alarm	The system has an active alarm.
15	Line Filling/Flushing	The system is filling/flushing a color change hose between the outlet valves and remote valves.
16	Pump Prime/Flush	The system is priming/flushing a pump.
17	Maintenance/Calibration	The system is currently performing a calibration or maintenance procedure.
18	Mix: Solvent Push	The system is currently mixing/spraying with solvent push engaged.

OUTPUT REGISTERS 01, 02, 03, and 04: Pump Status

The Pump Status registers contain a number that indicates the state of Pumps 1 — 4. This status can be used for general monitoring of the pump state, or as an indicator for driving independent pump operations. See [INPUT REGISTER 02: Flush/Prime Pump Command, page 33](#).

Table 4 Pump States for Output Registers 01–04

Number	Pump State	Description
0	Off	The pump is powered down or not enabled.
1	Standby	The pump is powered but not currently active.
2	Busy	The pump is currently in a recipe change or mixing operation.
3	Flushing	The pump is currently flushing with solvent
4	Priming	The pump is currently priming with material.

OUTPUT REGISTER 05: Actual Mix Flow

The Actual Mix Flow register reports back the instantaneous mixing flow rate in cc/min.

NOTE: This register is valid only during a mix operation.

OUTPUT REGISTER 06: Actual Mix Ratio

The Actual Mix Ratio register contains the instantaneous calculated mix ratio.

- The value reported is the ratio antecedent multiplied by 100. The ratio consequent is always 1.

Example: Value = 250 >> A mix ratio of 2.5:1 (Material A to Material B)

- If the current recipe ratio is 0:1 (1K recipe) this value will be 0.

This register is valid only during a mix operation.

OUTPUT REGISTER 07: Actual Mix Potlife Remaining

The Actual Potlife Remaining register contains the current amount of time remaining in the active recipe’s potlife in seconds.

NOTE: If potlife is disabled for the active recipe or at initial startup this value will be 0xFFFFFFFF.

OUTPUT REGISTER 08: Active Recipe Number

The Active Recipe Number register contains the number of the active recipe (1 – 60).

- This value is 0 if the system was flushed.
- This value is 61 if the system does not know the current loaded recipe, if the recipe is invalid, or at initial startup.

OUTPUT REGISTER 09: Active Recipe Material A

The Active Recipe Material A register contains the number of the Color (1 – 30) that is associated with the current recipe.

- This value is 0 if the system was flushed.
- This value is 61 if the current recipe is invalid or at initial startup.

OUTPUT REGISTER 10: Active Recipe Material B

The Active Recipe Material B data register contains the number of the Catalyst (31 – 34) that is associated with the current recipe.

- This value is 0 if the system was flushed.
- This value is 61 if the current recipe is invalid or at initial startup.
- This value is 0 if the current recipe ratio is 0:1 (1K recipe).

OUTPUT REGISTER 11: Active Recipe Material A Flush Sequence

The Active Recipe Material A Flush Sequence register contains the number of the Flush Sequence (1 – 5) that is associated with the Color pump of the current recipe.

If the current recipe is invalid this value reflects the Flush Sequence associated with Material A pump of recipe 0.

OUTPUT REGISTER 12: Active Recipe Material B Flush Sequence

The Active Recipe Material B Flush Sequence register contains the number of the Flush Sequence (1 – 5) that is associated with the Catalyst pump of the current recipe.

- If the current recipe is invalid this value reflects the Flush Sequence associated with Material B pump of recipe 0.
- This value is 0 if the current recipe ratio is 0:1 (1K recipe).

OUTPUT REGISTER 13: Active Recipe Ratio Set Point

The Active Recipe Ratio Set Point data register contains the ratio set point associated with the current recipe.

- The value reported is the ratio antecedent multiplied by 100. The ratio consequent is always 1.

Example: Value = 250 >> A mix ratio of 2.5:1 (Material A to Material B)

- This value is 0 if the current recipe ratio is 0:1 (1K recipe).

OUTPUT REGISTER 14: Active Recipe Potlife Timeout Set Point

The Active Recipe Potlife Timeout Set Point register contains the set point for the potlife time associated with the current recipe in minutes.

- This value is 0 if the potlife time is disabled for the current recipe.

OUTPUT REGISTER 15: Actual Pump 1 Flow Rate

OUTPUT REGISTER 16: Actual Pump 2 Flow Rate

OUTPUT REGISTER 17: Actual Pump 3 Flow Rate

OUTPUT REGISTER 18: Actual Pump 4 Flow Rate

These registers contain the instantaneous flow rate of Pumps 1–4 in cc/min.

This is **NOT** the mix flow rate. For mix flow rate see *Actual Mix Flow*.

OUTPUT REGISTER 19: Actual Pump 1 Fluid Pressure

OUTPUT REGISTER 20: Actual Pump 2 Fluid Pressure

OUTPUT REGISTER 21: Actual Pump 3 Fluid Pressure

OUTPUT REGISTER 22: Actual Pump 4 Fluid Pressure

These registers contain the instantaneous fluid pressure on the outlet of pumps 1–4 in PSI.

OUTPUT REGISTER 23: Gun 1 Trigger Input Status

The Gun 1 Trigger Input Status register contains the status of the Gun Trigger Discrete Input.

- The value is 0 if the input is OPEN (gun not triggered).
- The value is 1 if the input is CLOSED (gun triggered).

This data register is valid only for systems configured to use the discrete input for the Gun Trigger. See [Gun Trigger Signal, page 74](#).

OUTPUT REGISTER 24: Gun 2 Trigger Input Status

OUTPUT REGISTER 25: Gun 3 Trigger Input Status

OUTPUT REGISTER 26: Active Gun

These registers are only used with Multiple Guns enabled. See [Appendix B: Multiple Guns, page 118](#).

OUTPUT REGISTER 27: Safety Interlock Input Status

The Safety Interlock Input Status register contains the status of the Safety Interlock Discrete Input.

- The value will be 0 if the input is OPEN (Normal).
- The value will be 1 if the input is CLOSED (Safety Stop).

See [Safety Interlock in Digital Inputs, page 24](#).

OUTPUT REGISTERS 28 – 36: DCS Command Structure

See [Dynamic Command Description, page 47](#).

OUTPUT REGISTER 37: Time

The Time register contains a count of total seconds since the Unix Epoch (January 1, 1970).

- The actual value reported is not important. This register should be used for diagnosing status of communication between the ProMix PD2K and the networking device.

This register is NOT currently available with the Modbus Communications Gateway Module.

OUTPUT REGISTER 38 – 40: Software Version

The Software Version registers contain the “major,” “minor,” and “build” revisions of the ADM software.

These registers are NOT currently available with the Modbus Communications Gateway Module.

Network Output Data Map (Read Only)

Network Output ID	Modbus Register	Parameter Name	Data Type	Units	Range
00	40100	Current System Mode	uint32	NONE	1 = Pump Off 2 = Recipe Change 3 = Recipe Change: Purge A 4 = Recipe Change: Purge B 5 = Recipe Change: Fill 6 = Mix Fill 7 = Mix 8 = Mix Idle 9 = Purge A 10 = Purge B 11 = Standby: Mix Ready 12 = Standby: Fill Ready 13 = Standby: Mix Not Ready 14 = Standby: Alarm 15 = Line Filling/Flushing 16 = Pump Prime/Flush 17 = Maintenance/Calibration 18 = Mix: Solvent Push
01	40102	Pump 1 Status	uint32	NONE	0 = Off 1 = Standby 2 = Busy 3 = Flushing 4 = Priming
02	40104	Pump 2 Status	uint32	NONE	0 = Off 1 = Standby 2 = Busy 3 = Flushing 4 = Priming
03	40106	Pump 3 Status	uint32	NONE	0 = Off 1 = Standby 2 = Busy 3 = Flushing 4 = Priming
04	40108	Pump 4 Status	uint32	NONE	0 = Off 1 = Standby 2 = Busy 3 = Flushing 4 = Priming

Operation Using a Programmable Logic Controller (PLC)

Network Output ID	Modbus Register	Parameter Name	Data Type	Units	Range
05	40110	Actual Mix Flow	uint32	cc/min	1 - 1600
06	40112	Actual Mix Ratio	uint32	NONE	0 - 5000
07	40114	Actual Mix Potlife Remaining	uint32	sec	0 - 59940
08	40116	Active Recipe Number	uint32	NONE	0 - 61
09	40118	Active Recipe Material A	uint32	NONE	1 - 30, 61
10	40120	Active Recipe Material B	uint32	NONE	31 - 34, 61
11	40122	Active Recipe Material A Flush Sequence	uint32	NONE	1 - 5
12	40124	Active Recipe Material B Flush Sequence	uint32	NONE	1 - 5
13	40126	Active Recipe Ratio Set Point	uint32	NONE	0 - 5000
14	40128	Active Recipe Potlife Time Set Point	uint32	min	0 - 999
15	40130	Actual Pump 1 Flow Rate	uint32	cc/min	0 - 800
16	40132	Actual Pump 2 Flow Rate	uint32	cc/min	0 - 800
17	40134	Actual Pump 3 Flow Rate	uint32	cc/min	0 - 800
18	40136	Actual Pump 4 Flow Rate	uint32	cc/min	0 - 800
19	40138	Actual Pump 1 Fluid Pressure	uint32	PSI	0 - 1500
20	40140	Actual Pump 2 Fluid Pressure	uint32	PSI	0 - 1500
21	40142	Actual Pump 3 Fluid Pressure	uint32	PSI	0 - 1500
22	40144	Actual Pump 4 Fluid Pressure	uint32	PSI	0 - 1500
23	40146	Gun 1 Trigger Input Status	uint32	NONE	0 = Gun not triggered 1 = Gun triggered
24	40148	Gun 2 Trigger Input Status*	uint32	NONE	0 = Gun not triggered 1 = Gun triggered
25	40150	Gun 3 Trigger Input Status*	uint32	NONE	0 = Gun not triggered 1 = Gun triggered
26	40152	Active Gun*	uint32	NONE	1 - 3
27	40154	Safety Interlock Input Status	uint32	NONE	0 = Open 1 = Closed

Operation Using a Programmable Logic Controller (PLC)

Network Output ID	Modbus Register	Parameter Name	Data Type	Units	Range
28	40200	Command Acknowledge	uint32	NONE	0 := NOP 1 = BUSY 2 = ACK 3 = NAK 4 = ERR
29	40202	Command Return 0	uint32	N/A	N/A
30	40204	Command Return 1	uint32	N/A	N/A
31	40206	Command Return 2	uint32	N/A	N/A
32	40208	Command Return 3	uint32	N/A	N/A
33	40210	Command Return 4	uint32	N/A	N/A
34	40212	Command Return 5	uint32	N/A	N/A
35	40214	Command Return 6	uint32	N/A	N/A
36	40216	Command Return 7	uint32	N/A	N/A

* Only used when Multiple Guns is enabled.



DCS Register

ProMix PD2K Network Inputs

The ProMix PD2K Network Inputs are Write-Read capable, but should be treated as outputs from a PLC or other networking device. These registers allow the user to control system operation and configure system settings remotely. Invalid values (i.e. out of bounds or not consistent with system configuration) will be ignored by the ProMix PD2K. All values must be written as integers. Floating point numbers are not supported.

Do not rely on these registers for Read status, other than to confirm data that has been written and accepted.

NOTE: The PD2K system does not refresh the values for these registers. At power up all input registers initialize to invalid values.

INPUT REGISTER 00: System Mode Command

The System Mode Command register accepts a number that represents a command to the PD2K system to initiate a particular operation. Some operation modes may be initiated only under certain conditions (see Figures 5 – 9 for details).

Input Value	Operation Mode	Description
0	No OP	The system takes no action.
1	Power Pumps	The system powers on or powers off the pumps.
2	Remote Stop	The system stops all current operations and turns off power to the pumps.
3	Recipe Change	The system initiates a recipe change. (See also Register 7.)
4	Mix Fill	The system fills the mix manifold and gun with material at ratio for a valid recipe.
5	Mix	The system initiates a mix/spray cycle.
6	Purge A	The system purges only Material A out through the gun.
7	Purge B	The system purges only Material B out through the gun.
8	Standby	The system puts all active pumps into Standby mode.
9	Purge Recipe	The system automatically determines the purge sequence required based on the loaded recipe.
10	Purge (Inactive)	This command is only valid if Multiple Guns is enabled. The system will purge an inactive spray device. (See also Register 7.)
11	Solvent Push	The system initiates the solvent push sequence while mixing/spraying.

INPUT REGISTER 01: Pump Flush Sequence/Prime Material Selection

The Pump Flush Sequence/Prime Material Selection register is used in conjunction with the Flush/Prime Pump Command register (see INPUT REGISTER 02 below) to independently prime or flush an inactive pump.

- Write a value between 1 and 5 if flushing a pump.
- Write a value between 1 and 30 if priming a Color pump.
- Write a value between 31 and 34 if priming a Catalyst pump.
- Write a value of 41–43 (instead of 31) if your system has multiple guns and Catalyst 1 is common to more than one gun. See [Appendix B: Multiple Guns, page 118](#).
- Write a value of 51–53 (instead of 33) if your system has multiple guns and Catalyst 3 is common to more than one gun. See [Appendix B: Multiple Guns, page 118](#).

NOTE: It is important that the user know which material is assigned to each pump. An invalid selection will be ignored by the ProMix PD2K.

INPUT REGISTER 02: Flush/Prime Pump Command

The Flush/Prime Pump Command register is used in conjunction with the Pump Flush Sequence/Prime Material Selection register (see INPUT REGISTER 01) to independently prime or flush an inactive pump. The desired pump **MUST** be in Standby mode. Confirm by reading the corresponding Pump Status output register (see OUTPUT REGISTERS 01 – 04).

If an invalid Flush Sequence or invalid material number is written to the Pump Flush Sequence/Prime Material Selection register then the Flush/Prime command will be ignored. The user must know what material is assigned to each pump. (See Color Change Kits Instruction Manual 332455 for color/catalyst pump mapping.)

This register can also be used to fill or flush a specific material hose.

NOTE: If two pumps are currently mixing and an inactive pump is commanded to flush or prime it will continue its operation to completion without affecting the system mode status. When the mixing operation is complete, the system status will reflect Standby mode while the flushing/priming pump completes its operation.

Input Value	Operation Mode	Description
0	No OP	The system takes no action.
1	Flush Pump 1	Flush Pump 1 using selected sequence.
2	Prime Pump 1	Prime Pump 1 using selected material.
3	Flush Pump 2	Flush Pump 2 using selected sequence.
4	Prime Pump 2	Prime Pump 2 using selected material.
5	Flush Pump 3	Flush Pump 3 using selected sequence.
6	Prime Pump 3	Prime Pump 3 using selected material.
7	Flush Pump 4	Flush Pump 4 using selected sequence.
8	Prime Pump 4	Prime Pump 4 using selected material.
9	Fill Line	Run selected material from the pump and out the gun.
10	Flush Line	Run solvent through hoses for selected material from the pump and out the gun.
11	Stop Line Fill/Flush	Stop Line Fill/Flush command.

INPUT REGISTER 03: Mix (Pump 1) Control Set Point

The Mix Control Set Point register is used to set and adjust the mixing fluid control set point. It also is used as the fluid control set point for pump 1 when running a 1K recipe. It can be changed at any time, and the system will immediately adjust to the new set point.

- If the system is configured for Flow Control this value can be set between 5 and 1600 cc/min for a 2K recipe, and between 5 and 800 for a 1K recipe. See Fluid Control on [System Screen 4, page 73](#).
- If the system is configure for Pressure Control this value can be set between 0 and the maximum pump pressure in PSI. See Fluid Control on [System Screen 4, page 73](#).

NOTE: The Flow Control must be configured to 'Network' via System Screen 4 on the ADM. If set to 'Discrete' this register is ignored and set point adjustment is handled via the discrete input. See [Analog Inputs, page 24](#).

INPUT REGISTER 04: Pump 2 Control Set Point

INPUT REGISTER 05: Pump 3 Control Set Point

INPUT REGISTER 06: Pump 4 Control Set Point

These registers are not used.

INPUT REGISTER 07: Go to Recipe Number

The Go to Recipe Number register is used as a queue for the next recipe to be loaded when a recipe change is initiated. A number between 0 and 60 can be written to this register. However, a recipe must be enabled via the ADM before it can be loaded. See [Recipe Screen, page 76](#).

NOTE: Writing to this register does not trigger a recipe change. See [Color Change Sequence, page 43](#).

INPUT REGISTER 08: Clear Active Alarm

The Clear Active Alarm register is used to acknowledge an alarm remotely so that the system may resume operation. Be sure that the alarm condition has been alleviated. Write a 1 to this register to acknowledge the latest active alarm. If more than one alarm is currently active only the most recent alarm will be acknowledged. A repeated write should be performed to clear any remaining active alarms. See figure 9.

(See [System Errors, page 100](#) for more information on clearing alarms.)

NOTE: This register is not polled by the ProMix PD2K. An alarm is cleared only when a value of '1' is written to this register. It is recommended that the automation reset this register by writing a 0 to it at all other times to avoid inadvertently clearing an alarm.*

INPUT REGISTER 09: Job Complete

The Job Complete register is used to log the current job remotely. Write a '1' to the register to command the ProMix PD2K to flag a job complete.

(See [Usage Screen, page 67](#) for more information on Job Logs and Job Complete.)

NOTE: This register is not polled by the ProMix PD2K. A job is logged only when a value of '1' is written to this register. It is recommended the automation reset this register by writing a 0 to it at all other times to avoid inadvertently logging a job.*

* It is recommended to wait at least 500 msec for the PD2K to process before resetting to '0'.

INPUT REGISTER 10: Gun 1 Trigger

The Gun 1 Trigger register is used to signal the ProMix PD2K when the automatic spray device is triggered. This signal should be sent any time the spray device is triggered. The state of this register provides timing for alarm functions and also drives the flow control algorithm.

NOTE: If enabled, it is imperative that this signal be sent any time the spray device is triggered. Without it the flow control features will not work.

- Write a value of '1' to signal that the gun is triggered.
- Write a value of '0' to signal that the gun is NOT triggered.

NOTE: This register is used only if the Gun Trigger is set to 'Network' via System Screen 4 on the ADM. If it is set to 'Discrete' this register is ignored and gun trigger is handled via the discrete input. See [Digital Inputs, page 24](#). **NOTE: Because timing is so critical for flow control Graco recommends that users provide a discrete input to minimize latency effects.**




Figure 14 Gun Trigger Timing (Network and Discrete Signals Shown)

INPUT REGISTER 11: Gun 2 Trigger

INPUT REGISTER 12: Gun 3 Trigger

These registers are only used with Multiple Guns enabled. See [Appendix B: Multiple Guns, page 118](#).

INPUT REGISTER 13: Gun 4 Trigger

This register is not used.

INPUT REGISTERS 14 – 21: DCS Command Structure

See [Dynamic Command Description, page 47](#).

Network Input Data Map (Write/Read)

Network Input ID	Modbus Register	Parameter Name	Data Type	Units	Range
00	40156	System Mode Command	uint32	NONE	0 = No 1 = Power Pumps 2 = Remote Stop 3 = Recipe Change 4 = Mix Fill 5 = Mix 6 = Purge A 7 = Purge B 8 = Standby 9 = Recipe Purge 10 = Purge (Inactive) 11 = Solvent Push
01	40158	Pump Flush Sequence #/Prime Material #	uint32	NONE	1 - 5, 1 - 34, 41 - 43*, 51 - 53*
02	40160	Flush/Prime Pump Command	uint32	NONE	0 = No OP 1 = Flush Pump 1 2 = Prime Pump 1 3 = Flush Pump 2 4 = Prime Pump 2 5 = Flush Pump 3 6 = Prime Pump 3 7 = Flush Pump 4 8 = Prime Pump 4 9 = Fill Line 10 = Flush Line 11 = Stop Fill/Flush Line
03	40162	Mix (Pump 1) Control Set Point	uint32	cc/min or PSI	1 - 1600
04	40164	Pump 2 Control Set Point	uint32	cc/min or PSI	1 - 1600
05	40166	Pump 3 Control Set Point	uint32	cc/min or PSI	1 - 1600
06	40168	Pump 4 Control Set Point	uint32	cc/min or PSI	1 - 1600
07	40170	Go to Recipe Number	uint32	NONE	0, 1 - 60
08	40172	Clear Active Alarm	uint32	NONE	1 = Clear Active Alarm
09	40174	Job Complete	uint32	NONE	1 = Trigger job complete


Network Input ID	Modbus Register	Parameter Name	Data Type	Units	Range
10	40176	Gun 1 Trigger	uint32	NONE	0 = Gun not triggered 1 = Gun triggered
11	40178	Gun 2 Trigger*	uint32	NONE	0 = Gun not triggered 1 = Gun triggered
12	40180	Gun 3 Trigger*	uint32	NONE	0 = Gun not triggered 1 = Gun triggered
13	40182	Gun 4 Trigger	uint32	NONE	0 = Gun not triggered 1 = Gun triggered
14	40184	Command Argument 0	uint32	NONE	N/A
15	40186	Command Argument 1	uint32	NONE	N/A
16	40188	Command Argument 2	uint32	NONE	N/A
17	40190	Command Argument 3	uint32	NONE	N/A
18	40192	Command Argument 4	uint32	NONE	N/A
19	40194	Command Argument 5	uint32	NONE	N/A
20	40196	Command Argument 6	uint32	NONE	N/A
21	40198	DCS Command	uint32	NONE	See Command Table

These registers are not used.
 DCS Register


* Only used with Multiple Guns enabled.

Operation Flow Charts


Purge Mode Sequence




Purge Recipe Sequence




Purge (Inactive) Sequence



Inactive Pump Flush and Prime Sequences




Line Fill and Flush Sequences




Color Change Sequence

NOTE: If using Custom Mapping for color change valves, and the Inlet stack is set to Single, the Material Ready flag needs to be set prior to starting a recipe change. If the Material Ready flag is not set, the pump(s) will not fill with the designated material and the recipe change will not complete. See "Write Material Ready Flag DCS Command and Custom Valve Mapping" for more details.




Recipe Change Alarm Recovery Sequences



NOTE: System will automatically run through necessary recipe change steps based on it's current state. If **Goto Recipe Number** has not changed, it does not have to be rewritten here.


NOTE: System will automatically perform Mix Fill if it needs to be completed before transitioning directly into Mix mode.

Mixing Sequence



Alarm Clearing Sequence

NOTE: Some alarms put the system in Standby; more serious alarms shut the pumps down. If an alarm condition is active the System Mode will either be **Pump Off** or **Standby: Alarm**. (Output Register 00 = '1' or '14')



NOTE: If more than 1 active alarm exists a repeated write of '1' to Input Register 08 is required for each.

Network Communication - Dynamic Command Structure (DCS)


Dynamic Command Description

The Dynamic Command Structure (DCS) is used to 1) access data that requires some form of argument(s) or 2) consolidate data that requires multiple registers. The DCS uses a static set of network communication input and output registers (see [Network Input Data Map \(Write/Read\)](#), page 36 and [Network Output Data Map \(Read Only\)](#), page 30).

Use the following sequence for the DCS.

1. Write the appropriate command arguments to INPUT REGISTERS 14 – 20. These commands may be written sequentially or sent all at once.
2. Once all arguments have been passed, write the command ID to INPUT REGISTER 21.
3. The ProMix PD2K will respond to a valid command by writing a 2 (Acknowledge) to OUTPUT REGISTER 28.
4. The ProMix PD2K will write appropriate return values to OUTPUT REGISTERS 29 – 36.

ProMix PD2K Inputs (PLC Outputs)



ProMix PD2K Outputs (PLC Inputs)




Figure 15 Dynamic Command Structure Timing

List of DCS Commands

Table 5 Dynamic Commands with Command ID

ID	Command
0	No OP
1	Write User ID
2	Write Recipe
3	Write Flush Sequence
4	Write Fluid Control Mode
5	Write Mix Fill Set Point
6	Write Material Ready Flag
10	Read User ID
11	Read Recipe
12	Read Flush Sequence
13	Read Fluid Control Mode
14	Read Job Info
15	Read Alarm Info
16	Read Event Info
17	Read Recipe Potlife Time
19	Read Mix Fill Set Point
20	Read Pump Material
21	Read Gun Contents
22	Read Grand Totals

Write User ID

The Write User ID command allows users to assign a User ID to a Job Log. See [Usage Screen, page 67](#), for more details on Job Log and User ID. The User ID can be up to ten ASCII characters in length and is packaged as three little endian segments of ASCII characters. The return registers will echo the arguments received.

NOTE: The User ID character string must be terminated with a null character.

Example: Write a User ID of "John Doe" to the ProMix PD2K.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Write User ID	uint32	NONE	1	0 - 21
Argument 0	User ID characters [3:0] (ASCII)	uint32	NONE	0x6E686F4A = ['n', 'h', 'o', 'J']	N/A
Argument 1	User ID characters [7:4] (ASCII)	uint32	NONE	0x656F4420 = ['e', 'o', 'D', ' ']	N/A
Argument 2	User ID characters [9:8] (ASCII)	uint32	NONE	0x0 = [null]	N/A
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	User ID characters [3:0] (ASCII)	uint32	NONE	0x6E686F4A	N/A
Return 1	User ID characters [7:4] (ASCII)	uint32	NONE	0x656F4420	N/A
Return 2	User ID characters [9:8] (ASCII)	uint32	NONE	0x0	N/A

Write Recipe

The Write Recipe command allows users to configure an entire recipe remotely. See [Recipe Screen, page 76](#), for more details on recipes and recipe parameters. The return registers will echo the arguments received.

NOTE: The recipe must be enabled via the ADM before it can be loaded for mixing.

Example: Configure Recipe 6 for Color = 2, Catalyst = 1, Color Flush Sequence = 2, Catalyst Flush Sequence = 3, Mix Ratio Set Point = 1.50:1, and Potlife = 10 minutes.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Write Recipe	uint32	NONE	2	0 - 21
Argument 0	Recipe Number	uint32	NONE	6	0 - 60
Argument 1	Material A	uint32	NONE	2	0 - 30
Argument 2	Material B	uint32	NONE	31	0, 31 - 34
Argument 3	Material A Flush Sequence	uint32	NONE	2	1 - 5
Argument 4	Material B Flush Sequence	uint32	NONE	3	1 - 5
Argument 5	Mix Ratio Set Point	uint32	NONE	150 = 1.50:1	0 - 5000
Argument 6	Potlife Time Set Point	uint32	min	10	0 - 999
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Recipe Number	uint32	NONE	6	0 - 60
Return 1	Material A	uint32	NONE	2	0 - 30
Return 2	Material B	uint32	NONE	31	0, 31 - 34
Return 3	Material A Flush Sequence	uint32	NONE	2	1 - 5
Return 4	Material B Flush Sequence	uint32	NONE	3	1 - 5
Return 5	Mix Ratio Set Point	uint32	NONE	150	0 - 5000
Return 6	Potlife Time Set Point	uint32	min	10	0 - 999
Return 7	Recipe Gun Assignment*	uint32	NONE	1	1 - 3
* Only used when Multiple Guns is enabled.					

Write Flush Sequence

The Write Flush Sequence command allows users to configure an entire flush sequence remotely. See [Flush Screen, page 78](#), for more details of flush sequence parameters. The return registers will echo the arguments received.

Example: Configuring Flush Sequence 4 for Gun Purge Time = 10 sec, Initial Flush Volume = 125 cc, Final Flush Volume = 250 cc, Wash Cycles = 1, Strokes per Cycle = 2.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Write Flush Sequence	uint32	NONE	3	0 - 21
Argument 0	Flush Sequence #	uint32	NONE	4	1 - 5
Argument 1	Gun Purge Time	uint32	NONE	10	0 - 999
Argument 2	Initial Flush Volume	uint32	NONE	125	0 - 9999
Argument 3	Final Flush Volume	uint32	NONE	250	0 - 9999
Argument 4	# Wash Cycles	uint32	NONE	1	0 - 99
Argument 5	Strokes per Wash Cycle	uint32	NONE	2	0 - 99
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Flush Sequence #	uint32	NONE	4	1 - 5
Return 1	Gun Purge Time	uint32	sec	10	0 - 999
Return 2	Initial Flush Volume	uint32	cc	125	0 - 9999
Return 3	Final Flush Volume	uint32	cc	250	0 - 9999
Return 4	# Wash Cycles	uint32	NONE	1	0 - 99
Return 5	Strokes per Wash Cycle	uint32	NONE	2	0 - 99

Write Fluid Control Mode

The Write Fluid Control Mode command allows users to remotely change Fluid Control between 'Flow' and 'Pressure'. See [System Screen 4, page 73](#), for more details on Fluid Control mode. The return registers will echo the arguments received.

NOTE: The Fluid Control mode should be changed only when the system is in Standby or when the pumps are powered off. Do not change Fluid Control modes during a mix operation.

Example: Change to Flow Control mode.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Write Fluid Control Mode	uint32	NONE	4	0 - 21
Argument 0	Fluid Control Mode	uint32	NONE	0 = Flow Mode	0 = Flow 1 = Pressure
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Fluid Control Mode	uint32	NONE	0	0 = Flow 1 = Pressure

Write Mix Fill Set Point

The Write Mix Fill Set Point command allows for setting an alternate control set point to decrease the time it takes to fill the line with mixed material. See [System Screen 4, page 73](#), for more details on Mix Fill Set Point. The return registers will echo the arguments received.

NOTE: The Mix Fill Set Point units depend on the selected Fluid Control Mode of the system. If the Fluid Control Mode is 'Flow', the units will be cc/min. If the Fluid Control Mode is 'Pressure', the units will be PSI. If the value is zero, this set point will be ignored.

Example: Configuring a flow control system to a Mix Fill Set Point of 300 cc/min.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Write Mix Fill Set Point	uint32	NONE	5	0 - 21
Argument 0	Mix Fill Set Point	uint32	cc/min or PSI	300	1 - 1600 (cc/min) 1 - 1500 (PSI) 0 := Disabled
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Mix Fill Set Point	uint32	cc/min or PSI	300	1 - 1600 (cc/min) 1 - 1500 (PSI) 0 := Disabled

Write Material Ready Flag

The Write Material Ready Flag command is used to signal to the PD2K that the upstream material management has the appropriate color/catalyst loaded at the inlet valve stack(s) of the pump(s) prior to a recipe change. This flag is only used when multiple materials for a pump are fed to the PD2K via a single valve at the inlet valve stack (i.e. a piggyback system). See [Custom Valve Mapping, page 82](#) for more info on Single inlet valve stacks.

NOTE: This flag should be cleared prior to or during a material change operation upstream of the inlet valve stack to avoid having the wrong material being fed into the pump during a recipe change.

Example: Setting the Material Ready Flag.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Write Material Ready Flag	uint32	NONE	6	0 - 21
Argument 0	Material Ready Status	uint32	NONE	1	0 := Not Ready/No OP 1 := Material Ready
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Mix Fill Set Point	uint32	NONE	1	0 := Not Ready/No OP 1 := Material Ready

Read User ID

The Read User ID command reads back the current User ID. See [Usage Screen, page 67](#), for more details on Job Log and User ID. The User ID can be up to ten ASCII characters in length and is packaged as three little endian segments of ASCII characters. No arguments are required.

Example: Read User ID that is currently "John Doe".

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Read User ID	uint32	NONE	10	0 - 21
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	User ID characters [3:0] (ASCII)	uint32	NONE	0x6E686F4A = ['n', 'h', 'o', 'J']	N/A
Return 1	User ID characters [7:4] (ASCII)	uint32	NONE	0x656F4420 = ['e', 'o', 'D', ' ']	N/A
Return 2	User ID characters [9:8] (ASCII)	uint32	NONE	0x0 = [null]	N/A

Read Recipe

The Read Recipe command returns all configured recipe parameters for a desired recipe number. The number of the recipe to be read is the only argument.

Example: Read Recipe 5 data as it is currently configured with Color = 3, Catalyst = 2 (32), Color Flush Sequence = 1, Catalyst Flush Sequence = 4, Mix Ratio Set Point = 3.25:1, and Potlife = 35 min.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Read Recipe	uint32	NONE	11	0 - 21
Argument 0	Recipe #	uint32	NONE	5	0 - 60
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Recipe #	uint32	NONE	5	0 - 60
Return 1	Material A	uint32	NONE	3	0 - 30, 61
Return 2	Material B	uint32	NONE	32	0, 31 - 34, 61
Return 3	Material A Flush Sequence	uint32	NONE	1	1 - 5
Return 4	Material B Flush Sequence	uint32	NONE	4	1 - 5
Return 5	Mix Ratio Set Point	uint32	NONE	325	0 - 5000
Return 6	Potlife Time Set Point	uint32	min	35	0 - 999

Read Flush Sequence

The Read Flush Sequence command returns all configured parameters for a desired flush sequence. The number of the flush sequence to be read is the only argument.

Example: Read Flush Sequence 1 as it is currently configured with Gun Purge Time = 20 sec, Initial Flush Volume = 0 cc, Final Flush Volume = 500 cc, Wash Cycles = 2, and Strokes per Cycle = 1.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Read Flush Sequence	uint32	NONE	12	0 - 21
Argument 0	Flush Sequence #	uint32	NONE	1	1 - 5
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Flush Sequence #	uint32	NONE	1	1 - 5
Return 1	Gun Purge Time	uint32	sec	20	0 - 999
Return 2	Initial Flush Volume	uint32	cc	0	0 - 9999
Return 3	Final Flush Volume	uint32	cc	500	0 - 9999
Return 4	# Wash Cycles	uint32	NONE	2	0 - 99
Return 5	Strokes per Wash Cycle	uint32	NONE	1	0 - 99

Read Fluid Control Mode

The Read Fluid Control Mode command is used to read the current Fluid Control mode of the system is currently operating under. No arguments are required.

Example: Read Fluid Control as currently set to Pressure mode.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Read Fluid Control Mode	uint32	NONE	13	0 - 21
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Fluid Control Mode	uint32	NONE	1 = Pressure	0 = Flow 1 = Pressure

Read Job Info

The Read Job Info command is used to access data from any of the most recent 200 job logs. The argument is the *chronological index* of the job log, where 0 is the most recent job log and 199 is the 200th most recent.

The date is returned as four-byte packet with each byte holding a two-digit value for (from MSB to LSB) year, month, day, and day of the week (Monday = 01).

The time is returned as a three-byte packet with each byte holding a two-digit value. Starting from the MSB, the first byte can be ignored, then hour, minute, and second.

NOTE: The argument is an index not a job number. The actual job number will, however, be one of the returned parameters. These records will match what is reported on the Jobs screen of the ADM.

(See [Usage Screen, page 67](#), for more details on Job Log)

Example: Read back the most recent job log, job 25, which ran recipe 2 for a total of 1234 cc's of material under User ID "John Doe". The job was logged on Thursday May 29, 2014 at 11:22:14 AM.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Read Job Info	uint32	NONE	14	0 - 21
Argument 0	Job Index	uint32	NONE	0	0 - 199
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Job Date	uint32	[YY:MM:DD-:DW]	0x0E051D04 = [14:05:29:04]	N/A
Return 1	Job Time	uint32	[xx:HH:MM-:SS]	0x0B160E = [11:22:14]	N/A
Return 2	Job Number	uint32	NONE	25	0 - 9999
Return 3	Recipe #	uint32	NONE	2	0 - 60
Return 4	A+B Volume	uint32	cc	1234	N/A
Return 5	User ID [3:0] (ASCII)	uint32	NONE	0x6E686F4A = ['n', 'h', 'o', 'J']	N/A
Return 6	User ID [7:4] (ASCII)	uint32	NONE	0x656F4420 = ['e', 'o', 'D', ' ']	N/A
Return 7	User ID [9:8] (ASCII)	uint32	NONE	0	N/A

Read Alarm Info

The Read Alarm Info command allows remote access to any of the last 200 alarms logged by the ProMix PD2K. The argument is the *chronological index* of the alarm log, where 0 is the most recent alarm and 199 is the 200th most recent.

The date is returned as a four-byte packet with each byte holding a two-digit value for (from MSB to LSB) year, month, day, and day of the week (Monday = 01).

The time is returned as a three-byte packet with each byte holding a two-digit value. Starting from the MSB, the first byte can be ignored, then hour, minute, and second.

The alarm code is a four-character little endian ASCII string

See [System Errors, page 100](#), for more details on these Event Types.

An example decoding algorithm is provided below.

Example: Read back the second most recent alarm, which was a Position Pump 1 (DK01) recorded on Tuesday June 3, 2014 at 8:11 AM.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Read Alarm Info	uint32	NONE	15	0 - 21
Argument 0	Alarm Index	uint32	NONE	1	0 - 199
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Alarm Date	uint32	[YY:MM:DD:DW]	0x0E060302 = [14:06:03:02]	N/A
Return 1	Alarm Time	uint32	[xx:HH:MM:SS]	0x080B0B = [08:11:11]	N/A
Return 2	Alarm Code Char[3:0]	uint32	NONE	0x31304B44 = ['1', '0', 'K', 'D']	N/A

Example ASCII Character String Decode Algorithm:

```

character_str[0] = Return_2 & 0xFF;
character_str[1] = (Return_2 >> 8) & 0xFF;
character_str[2] = (Return_2 >> 16) & 0xFF;
character_str[3] = (Return_2 >> 24) & 0xFF;
character_str[4] = '\0';
    
```

Read Event Info

The Read Event Info command allows remote access to any of the last 200 events logged by the ProMix PD2K. The argument is the *chronological index* of the events log, where 0 is the most recent event and 199 is the 200th most recent.

The date is returned as a four-byte packet with each byte holding a two-digit value for (from MSB to LSB) year, month, day, and day of the week (Monday = 01).

The time is returned as a three-byte packet with each byte holding a two-digit value. Starting from the MSB, the first byte can be ignored, then hour, minute, and second.

The event code is a four-character little endian ASCII string.

The example decoding algorithm provided above for the Alarm Code may be used for Events equivalently.

Example: Read back the fifth most recent event, which was a Setup Value(s) Changed (EC00) recorded on Tuesday June 3, 2014 at 8:11 AM.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Read Event Info	uint32	NONE	16	0 - 21
Argument 0	Event Number	uint32	NONE	4	0 - 199
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Event Date	uint32	[YY:MM:DD-:DW]	0x0E060302 = [14:06:03:02]	N/A
Return 1	Event Time	uint32	[xx:HH:MM:SS]	0x080B0B = [08:11:11]	N/A
Return 2	Event Code Char[3:0]	uint32	NONE	0x30304345 = ['0', '0', 'C', 'E']	N/A

Read Recipe Potlife Time

The Read Recipe Potlife Time command returns the remaining potlife time, in minutes, for a selected recipe if it is currently loaded and mixed. This command is particularly useful if Multiple Guns is enabled. See [Appendix B: Multiple Guns, page 118](#).

NOTE: This command will return 0xFFFFFFFF if there is no potlife time associated with the recipe or the timer has not started.

Example: Read recipe 1 potlife time remaining that is currently "12 minutes".

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Read Recipe Potlife Time	uint32	NONE	17	0 - 21
Argument 0	Recipe Number	uint32	NONE	1	1 - 60
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Recipe Number	uint32	NONE	1	1 - 60
Return 1	Potlife Time Remaining	uint32	min	12	0 - 999

Read Mix Fill Set Point

The Read Mix Fill Set Point command is used to read the current Mix Fill Set Point. See [System Screen 4, page 73](#), for more details on Mix Fill Set Point. No arguments are required.

NOTE: The Mix Fill Set Point units depend on the selected Fluid Control Mode of the system. If the Fluid Control Mode is 'Flow', the units will be cc/min. If the Fluid Control Mode is 'Pressure', the units will be PSI. If the value is zero, this set point will be ignored.

Example: Read the Mix Fill Set Point, currently set to 350 cc/min.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Read Mix Fill Set Point	uint32	NONE	19	0 - 21
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Mix Fill Set Point	uint32	cc/min or PSI	350	1 - 1600 (cc/min) 1 - 1500 (PSI) 0 := Disabled

Read Pump Material

The Read Pump Material command returns the material number of the color or catalyst that is currently loaded in a user-specified pump.

NOTE: This command will return '0' if the pump is filled with solvent, or '61' if the material is unknown.

Example: Read what material is loaded in pump 1, which is currently color 2.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Read Pump Material	uint32	NONE	20	0 - 21
Argument 0	Pump Number	uint32	NONE	1	1 - 4
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Pump Number	uint32	NONE	1	1 - 4
Return 1	Material Number	uint32	NONE	2	0 - 34, 61

Read Gun Contents

The Read Gun Contents command returns the recipe number of the mixed material that is currently loaded in a user-specified gun. This command is used if Multiple Guns are enabled. See [Appendix B: Multiple Guns, page 118](#) .

NOTE: This command will return '0' if the gun is filled with solvent, or '61' if the material is unknown.

Example: Read what material is loaded in gun 1, which is currently recipe 2.

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Read Gun Contents	uint32	NONE	21	0 - 21
Argument 0	Gun Number	uint32	NONE	1	1 - 3
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Gun Number	uint32	NONE	1	1 - 3
Return 1	Recipe Number	uint32	NONE	2	0 - 61

Read Grand Totals

The Read Grand Totals command allows remote access to the material grand total volume data. No arguments are necessary for this command.

Example: Read current Grand Total usage data. A = 132 gal, B = 128 gal, A+B = 260 gal, Solvent = 11 gal

DCS Register	Parameter Description	Data Type	Units	Value	Range
DCS Command	Read Grand Totals	uint32	NONE	22	0 - 22
Acknowledge	Command Acknowledged	uint32	NONE	2 = ACK	0 - 4
Return 0	Grand Total A Material	uint32	Gallons	132	0 - 4,294,967,295
Return 1	Grand Total BMaterial	uint32	Gallons	128	0 - 4,294,967,295
Return 2	Grand Total A+B	uint32	Gallons	260	0 - 4,294,967,295
Return 2	Grand Total Solvent	uint32	Gallons	11	0 - 4,294,967,295

PLC Diagnostic Screens

These screens may be used to verify PLC communications by providing a real-time status of all Network Inputs and Outputs.

PLC Diagnostic Screens 1–4

These screens show all PD2K Network Outputs with their associated register ID, Modbus TCP address, current value, and any relevant state information.

09/23/15 11:38 ← PLC Diagnostic Advanced →			
Standby		No Active Errors	
Network Outputs			
ID	Address	Value	
0	40100	11	Standby: Mix Ready
1	40102	1	Standby
2	40104	1	Standby
3	40106	1	Standby
4	40108	1	Standby
5	40110	0	-
6	40112	0	-
7	40114	3247	-

Figure 16 PLC Diagnostic Screen 1

PLC Diagnostic Screens 7

This screen encapsulates all the registers used in the Dynamic Command Structure. Arguments and Command registers are shown on the left. Acknowledge and Return registers are shown on the right. When a valid DCS command is sent, the Return registers will display the appropriate data on the right side of the screen. This can be used to test and verify DCS commands with the PLC.

09/23/15 11:51 ← PLC Diagnostic Advanced →					
Standby		No Active Errors			
DCS					
ID	Address	Value	ID	Address	Value
14	40184	0	28	40200	2
15	40186	0	29	40202	1
16	40188	0	30	40204	1
17	40190	0	31	40206	31
18	40192	0	32	40208	1
19	40194	0	33	40210	1
20	40196	0	34	40212	100
21	40198	11	35	40214	55
			36	40216	1

Figure 18 PLC Diagnostic Screen 7

PLC Diagnostic Screens 5–6

These screens show all PD2K Network Inputs with their associated register ID, Modbus TCP address, last value written, and any relevant state information.

NOTE: If a Network Input has not been written, it will show a value of 4294967295 (0xFFFFFFFF) and state as invalid.

09/23/15 11:48 ← PLC Diagnostic Advanced →			
Standby		No Active Errors	
Network Inputs			
ID	Address	Value	
0	40156	1	Power Pumps
1	40158	17	-
2	40160	6	Prime Pump
3	40162	250	-
4	40164	4294967295	Invalid
5	40166	4294967295	Invalid
6	40168	4294967295	Invalid
7	40170	1	-

Figure 17 PLC Diagnostic Screen 5

Flow Control System

Overview

Flow control is an optional feature that precisely regulates the flow of material to an automatic spray device, to help ensure adequate coverage and avoid sags or runs in the finish coat. The ProMix PD2K system can control fluid flow by directly controlling the proportioning pumps. The pumps accurately dispense a fixed volume of fluid during each stroke. For this reason, the flow rate of a given pump is directly proportional to the velocity of the pump. As long as the gun is open and the system is stable, flow control is the most effective method for controlling flow rate.

The flow control system relies on two main inputs for controlling flow rate: Gun Trigger and Control Set Point. **NOTE: These inputs are timing critical. Graco recommends that users wire them discretely to the controller.** Alternatively these two inputs can be driven by the network communications, but latency could be an issue for systems requiring precise timing.

See [System Screen 4, page 73](#), for more details on configuring these options for 'Discrete' or 'Network'.

NOTE: Flow control cannot be selected with a manual gun system.

Normal Flow Control

The ProMix PD2K will directly control the speed of the pump(s) to the programmed flow control set point to maintain accurate flow rate and ratio. The flow control set point is set by Network Communications or the Discrete Input.

The system is considered to be stable when the pressure readings do not fluctuate and the flow rate is maintained. While the system is considered stable it will store ("learn") the associated pump pressures to a table that is used if the gun trigger signal is lost or removed.

Pressure Control

When the gun trigger signal is removed the system automatically switches to pressure control mode to avoid over pressurizing the fluid lines and to allow smooth transition to flow control if the gun trigger signal returns. It also works to maintain a consistent flow rate even though it has transitioned to pressure control mode if the gun trigger signal is inadvertently lost.

Gun On/Off Prediction

The pressure table also is used to predict if the gun has been turned on or off (without a change to the gun trigger input). The flow control system continually monitors the desired outlet pressure compared to the actual outlet pressure. If the actual pressure remains 50% higher than the desired pressure for longer than 10msec, then the system predicts that the gun trigger has been released. If the actual pressure drops below the desired pressure longer than 10msec, then the system predicts that the gun has been triggered.

The gun on/off prediction is used in the flow control algorithm to prevent the fluid pressure from becoming too high or too low due to a system disturbance. For example, if a gun off prediction occurs while the gun trigger input is high, the system will begin to control to the pressure value last stored in the pressure table for the current flow set point.

System Startup and Defaults

The pressure table is stored in volatile memory, so the table values will be lost after a power cycle of the ProMix PD2K controller. This issue is not significant because the system generally is able to recalculate new pressure table values within a few seconds (depending on the stability of the fluid system).

Run Mode Screens

NOTE: Selection fields and buttons that are grayed-out on the screens are not currently active.



Figure 19 Opening Screen


Opening Screen

At power up, the Graco logo will display for approximately 5 seconds, followed by the Home screen.

Home Screen

The Home screen displays the current status of the system. The following table details the information shown.

To view pump flow rates and pressures (as shown), select "Diagnostic Mode" on [System Screen 1, page 69](#).








ti23367a

Figure 20 Home Screen, in Mix Mode with Diagnostics On

Home Screen Key

Key	Description	Details
A	Date and Time	See Advanced Screen 1, page 92 , to set.
B	Menu Bar	Run Screens. Use left and right arrow keys to scroll through the different Run screens: <ul style="list-style-type: none"> • Home (shown in Diagnostic Mode) • Spray (see Spray Screen, page 65) • Fill (see Fill Screen, page 66), available only if manual override is enabled on System Screen 4, page 73. • Usage (see Usage Screen, page 67) • Jobs (see Jobs Screen, page 68) • Errors (see Errors Screen, page 68) • Events (see Events Screen, page 68)
C	Status Bar	System Status: Displays the current mode of operation:
		<ul style="list-style-type: none"> • Pump Off • Standby • Startup • Mix (Dispense in 1K Mode) • Fill • Purge • Shutdown • Change Recipe • Idle • Prime Pump • Calibrate • Stall Test • Maintenance Test
D	Error Status	Displays any active error code.
E	Pump Animation and Diagnostic Information	
F	Pump Number (1–4)	
G	Material (A or B)	
H	Available Colors	
J	Pump Inlet Color	
L	Pump Flow Rate	
M	Pump Outlet Color	
N	Pump Outlet Pressure	
P	Pump Indicator Light <ul style="list-style-type: none"> • Clear = power off • Yellow = standby • Green = active 	
S	Solvent Flow Rate	

Run Mode Screens

Key	Description	Details
T	Spray Device Animation	Shows mixed material in the spray device and displays active recipe at the spray device. Gun animation changes to show: <ul style="list-style-type: none"> •  0 (Mix Fill) •  1 (Mix With Gun Triggered) •  1 (Recipe Standby) •  1 (Purge) •  0 (Solvent Standby) •  1 (Mix With Gun Not Triggered)
U	Active Recipe (📄)	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>V U</p>  <p>ti22008a W</p> </div> <div style="text-align: center;"> <p>Y Z</p>  <p>X</p> </div> </div>
V	Current Ratio (1:1) (Not shown in 1K Mode)	
W	Potlife Time Remaining (🕒)	
X	Total Volume for the Current Job (📄)	
Y	Current Flow Rate (⚙️)	
Z	Current Pressure (🌀)	

Spray Screen

NOTE: In normal operating mode, controlled by a PLC, the Spray Screen is display only. No changes can be made. This section provides information about the Spray Screen if manual override is enabled on [System Screen 4, page 73](#). The screens show a system in manual override mode.

The Spray screen includes the following information:

- Active Recipe (can be changed on this screen)
- Target Ratio (not shown in 1K Mode)
- Actual Ratio (not shown in 1K Mode)
- Target Pressure (if Pressure Mode is selected on System Screen 4) or Target Flow (if Flow Mode is selected). Target pressure or flow can be changed on this screen).
- Actual Pressure
- Actual Flow
- Potlife Remaining
- Gun Animation

In addition, the Spray screen includes three soft keys:



Press to put the system in Standby.



Press to spray mixed material.



Press to purge the gun.

When the system is configured for solvent push, the purge soft key changes to the solvent push soft key while in Mix mode.



Press to initiate solvent push.




Figure 21 Spray Screen, in Standby Mode




Figure 22 Spray Screen, in Mix Mode



Figure 23 Spray Screen, in Idle Mode




Figure 24 Spray Screen, in Mix Mode, Solvent Push Enabled

Fill Screen

NOTE: This screen is visible only if manual override is enabled on [System Screen 4, page 73](#).

The Fill screen displays the following information for the pump assigned to the current color:

- Material. Select Color (A), Catalyst (B), or Solvent. The pump animation at the top of the screen will show the selected material.
- Flush Line (only for systems with color change). Select this box if you want to flush the specified material line. The system uses flush sequence 1.

To prime the pumps and fill the lines, first read [Prime and Fill the System, page 21](#).

1. Press the Edit softkey  to open the screen for editing.
2. Select Color (A).
3. If the selected material is not already loaded, press the Prime softkey . The system will prime Color (A) into the selected pump through the selected color valve and out the outlet dump valve.
4. Press the Fill softkey . The system will attempt to fill the Color (A) lines until the user presses Stop . Trigger the gun into a waste container.
5. Repeat for Catalyst (B).

Pre-Fill Pump

The pump pre-fill option is available for pumps that have color change, but only a single material (color or catalyst). The pre-fill option may be used for pumps that remain filled with material when the system was powered down.

Press the Pre-Fill softkey  to “prime” the pump without flushing or expelling any material unnecessarily.




Figure 25 Fill Screen, Color (A) Selected




Figure 26 Fill Screen, Solvent Selected




Figure 27 Fill Screen, Pre-Fill Pump Option

Usage Screen

The first Usage screen displays the current job usage and grand total usage of component A, B, A+B, and solvent (S). Edits may be made only if manual override is enabled on [System Screen 4, page 73](#). The second Usage screen displays the total volume pumped for all available materials.

NOTE: In 1K Mode, the B and A+B components are not shown.

1. Press the Edit softkey  to open the screen for editing.
2. To enter or change the User ID (*), select the field to open the User ID Keyboard screen, and enter the desired name (10 characters maximum).
3. To log the current job, press the Job Complete softkey . This will clear the current usage fields and increment to the next job number. The Grand Totals cannot be cleared. See the [Jobs Screen, page 68](#), to review past jobs.
4. Press the Edit softkey  to close the screen.




Figure 28 Usage Screen




Figure 29 Usage Screen, 1K Mode




Figure 30 User ID Keyboard Screen




Figure 31 Usage Log

Jobs Screen

The Jobs screen displays the 200 most recent job numbers, recipes, and A+B volumes in a log, with date, time, and User ID.

09/25/13 00:24							←	Fill	Usage	Jobs	Errors	Events	→	
Mix									No Active Errors					
09/25/13	00:23	John Doe12	0022	1	55	cc								
09/25/13	00:23	John Doe12	0021	1	168	cc							3	
09/25/13	00:23	John Doe12	0020	1	7	cc								
09/25/13	00:23	John Doe12	0019	1	11	cc								
09/25/13	00:23	John Doe12	0018	1	10	cc							1	
09/25/13	00:23	John Doe12	0017	1	8	cc								
09/25/13	00:23	John Doe12	0016	1	32	cc								
09/25/13	00:23	John Doe12	0015	1	184	cc							2	
09/25/13	00:23	John Doe12	0014	1	173	cc								
09/25/13	00:23	John Doe12	0013	1	219	cc								

Figure 32 Jobs Screen

Errors Screen

The Errors screen displays the 200 most recent Error Codes in a log, with date, time, and description.

08/10/13 23:17							←	Jobs	Errors	Events	Home	→	
Idle									No Active Errors				
08/10/13	22:44	DK04-A	Position Pump 4										18
08/10/13	22:44	DK03-A	Position Pump 3										19
08/10/13	22:44	DK02-A	Position Pump 2										20
08/10/13	22:44	DK01-A	Position Pump 1										
08/10/13	22:44	CA0X-A	Comm. Error ADM										1
08/10/13	22:44	P6D4-A	Press. Sens. Removed Outlet 4										2
08/10/13	22:44	P6D3-A	Press. Sens. Removed Outlet 3										3
08/10/13	22:44	P6D2-A	Press. Sens. Removed Outlet 2										4
08/10/13	22:44	P6D1-A	Press. Sens. Removed Outlet 1										
08/10/13	22:44	DK04-A	Position Pump 4										

Figure 33 Errors Screen

Additional information is available for system errors to assist with troubleshooting. To access this

information for a system error that has occurred, first

press  to enter edit mode; the first error will be highlighted. Using the Up and Down arrow keys,

navigate to the desired error code, press  again (see [System Errors](#), page 100, for more information on the troubleshooting information screens).

11/15/17 11:14				Jobs	Errors	Events	Home
Pump Off						EMIX: Pump Off	
10/26/17	12:37	SPD1-A	Gun Purge Incomplete				
10/26/17	12:37	SPD1-A	Gun Purge Incomplete				1
10/26/17	12:36	SND1-A	Mix Fill Incomplete				
10/26/17	12:35	F1S2-A	Flow Low Purge Pump 2				
10/26/17	12:33	F8D1-A	Flow Not Detected				2
10/25/17	16:16	F7S1-A	Flow Detected Solvent Gun				
10/25/17	16:16	F7P1-A	Flow Detected Air Gun				
10/25/17	16:16	F7S1-A	Flow Detected Solvent Gun				3
10/25/17	14:30	SND1-A	Mix Fill Incomplete				
10/25/17	14:20	P6D4-A	Press. Sens. Removed Outlet 4				

Figure 34 Errors Screen, Edit Mode

Events Screen

The Events screen displays the 200 most recent Event Codes in a log, with date, time, and description.

08/10/13 23:17							←	Jobs	Errors	Events	Home	Spray	→
Idle									No Active Errors				
08/10/13	22:52	EC00-R	Setup Value(s) Changed										18
08/10/13	22:51	EVUX-V	USB Disabled										19
08/10/13	22:49	EBUX-R	USB Drive Removed										20
08/10/13	22:48	EVUX-V	USB Disabled										
08/10/13	22:46	EBUX-R	USB Drive Removed										1
08/10/13	22:46	EC00-R	Setup Value(s) Changed										2
08/10/13	22:45	EQU0-V	USB Idle										3
08/10/13	22:45	EQU1-R	Sys. Settings Downloaded										4
08/10/13	22:45	EQU3-R	Custom Lang. Downloaded										
08/10/13	22:45	EQU5-R	Logs Downloaded										

Figure 35 Events Screen

Setup Mode Screens

Press  on any Run screen to enter the Setup screens.

NOTE: Selection fields and buttons that are grayed-out on the screens are not currently active.

If the system has a password lock, the Password screen displays. See [Password Screen, page 69](#).

Password Screen




Figure 36 Password Screen

Enter the 4 digit password, then press . System screen 1 will open, allowing access to the other Setup screens.

Entering an incorrect password clears the field. Reenter the correct password.

To assign a password, see [Advanced Screen 1, page 92](#).

System Screen 1

System screen 1 includes the following fields which define your system.




Figure 37 System Screen 1, During Standby

Diagnostic Mode

Select this box to display flow rate and pressure for each pump on the [Home Screen, page 62](#).

Color Pumps

Enter the number of color pumps in your system.

Catalyst Pumps

Enter the number of catalyst pumps in your system.

NOTE: Changing the number of catalyst pumps to "0" will put the system into 1K Mode.

Non-Mix Pressure (Fill Pressure - 1K Mode)

Enter a lower pressure for use when not mixing and spraying (for example during fill or flushing).

NOTE: Low pressure systems may be set 100 psi (0.7 MPa, 7 bar) lower than target pressure; high pressure systems may be set 300 psi (2.1 MPa, 21 bar) lower than target pressure.

Solvent Meter

Select this box if your system uses a solvent meter. The Solvent K-Factor field will then become active.

Solvent K-Factor

Enter the solvent meter K-Factor.

System Screen 2

System screen 2 sets the following system operating parameters.




Figure 38 System Screen 2, in Standby Mode

Mix Idle Timeout (Idle Timeout - 1K Mode)

The Gun Trigger Input signals that the device is triggered. If you are not using a gun trigger signal, the system does not know if the spray device is spraying. If a pump failed you could spray pure resin or catalyst without knowing. This should be caught by the Mix No Flow Timeout; the default is 5 seconds. The Mix Idle Timeout will trigger Idle mode, which will run a pump stall test to check for leaks, then put the pumps in Standby (holding their current position) after the designated period of time. Enter the desired Mix Idle Timeout in this field.

See [Digital Inputs, page 24](#).

Mix No Flow Timeout (No Flow Timeout - 1K Mode)

The Gun Trigger Input signals that the gun is triggered. If the Gun Trigger Input indicates that the gun is triggered, but there is no fluid flow through a pump, you could spray pure resin or catalyst without knowing. The Mix No Flow Timeout will cause the system to shutdown after the designated period of time. The default is 5 seconds. Enter the desired shutdown time in this field.

See [Digital Inputs, page 24](#).

Auto Park Pumps

Parking the pumps will help prevent material from hardening on the pump rods. The Auto Park Pumps timer will automatically park all pumps and turn off pump power. The default value of 0 minutes turns off this feature.

NOTE: The timer only runs while the system is in Standby and all guns are purged to prevent volumes from going off ratio.

Mix Balance Interval (Not used in 1K Mode)

When transitioning from Standby mode to Mix mode, fluid viscosities and high ratios may affect how quickly fluid dynamics balance, which may result in nuisance Exceed Max Flow or Differential Pressure mixing alarms.

The Mix Balance Interval set point may be used to enable a brief period at the start of a mix cycle for fluids to balance before generating any mixing alarms.

NOTE: The Mix Balance Interval timer only runs while the gun is triggered. Setting this time to zero turns the timer off.

Mix Fill Set Point

Set a higher flow rate or pressure for use while mix filling to decrease the time needed to fill the hose and spray device. Once the spray device is filled, the system will use the target set point as set by the PLC.

The default value is '0'. When set to '0', the system ignores the Mix Fill Set Point and instead uses the target set point as set by the PLC.

The value will be a flow rate if Fluid Control is set to 'Flow', or a pressure if Fluid control is set to 'Pressure'.

Max Flow Rate

The Max Flow Rate setting allows you to limit the total flow rate while in Mix mode. Normally, while controlling to the target pressure set point, flow rates may fluctuate slightly due to a number of variations, including ambient conditions or user adjustment of the applicator tip. The Max Flow Rate may be used to ensure a more consistent application of material, and could result in material savings.

The default setting is 0. When set to 0, the system does not limit the flow rate beyond what the pumps are capable of delivering.

NOTE: The Max Flow Rate is a global set point that applies to all recipes in the same way.

Solvent Push Enable

Enable the Solvent Push option for the end of a mix/spray cycle. When enabled, the system may be commanded to end a mix/spray cycle with solvent push using the soft key on the ADM Spray Screen or using a PLC command. For more details, see [Solvent Push, page 71](#).

NOTE: The solvent push feature is only available for Flow Mode fluid control systems with single outlet color change valve configurations (see [Custom Valve Mapping, page 82](#)). The checkbox is only visible if the system is configured in this way.

Solvent Push

Certain fluid stream configurations can benefit from switching from resin to solvent before concluding a mixing/spray cycle. The solvent is dispensed directly behind the resin material and is used to push the resin material (and, as a result, the mixed material) down the fluid path and to the spray device. The dispensed solvent comes at a cost savings over the resin material and also provides a head start on the flushing of the pump and fluid lines before the next color change.

The solvent push feature is available as an option for certain system configurations. See [Custom Valve Mapping](#), page 82.

- The **Fluid Control** must be set to **Flow Mode** (see [System Screen 5](#), page 74).
- The resin pump must use the **Custom Valve Mapping** option of **Single Outlet Color Change**.
- This configuration usually does not use a remote color change stack, so the **Remote Color Change** must be set to **Disabled**.

The following figure shows a typical MISO (multiple color in, single color out) configuration.




Figure 39 MISO Fluid Stream Configuration (for Solvent Push)

Mix Volume Percent

Solvent may be pushed past the mix manifold and into the mix hose, if needed. To prevent atomizing solvent, it may only be dispensed to a percent of the mix hose volume. The default value is 0%, which will not dispense solvent beyond the mix manifold. The mix hose volume is set by the Gun Hose Length and Gun Hose Diameter (see [System Screen 4, page 73](#)).

				
If using an electrostatic gun, to reduce the risk of fire and explosion, confirm the mix hose parameters are accurately represented in the settings.				

The displayed volume shows the total amount of solvent to be dispensed during the solvent push sequence. This volume includes, at minimum, the total fluid stream volume from the inlet color stack to the mix manifold. Additionally, this volume will include a percentage of the mix hose volume, if set to greater than 0%.

The solvent push sequence is initiated using a soft key on the Spray Screen (see [Spray Screen, page 65](#)) or a PLC command (see [ProMix PD2K Network Inputs, page 33](#)).

Timing is critical to avoid having the solvent push sequence end before the last part has been finished. The system will go into Standby and must complete a recipe change before it can mix again.

System Screen 3

System screen 3 sets the following system operating parameters.

03/01/19 16:43 ← Advanced System Gateway →

Standby No Active Errors

Stall Test Pressure: psi

Pump Stall Test: seconds

Max Leak Rate: cc/min

Figure 40 System Screen 3

Stall Test Pressure

Set the minimum stall test pressure. The setting should be approximately 50 psi (0.35 MPa, 3.5 bar) higher than the highest inlet pressure.

NOTE: If the material supply pressure at the pump inlet is greater than 90% of the Stall Test Pressure, the system will generate an alarm and will not complete the stall test. See [Calibrate Screen 1, page 88](#).

Pump Stall Test

Set the duration for the pump stall test. See [Calibrate Screen 1, page 88](#).

Maximum Leak Rate

Enter the maximum allowable leak rate for a pump stall test.

System Screen 4

System screen 4 sets the following system operating parameters.

03/01/19 17:12 ← Advanced System Gateway →

Pump Off EMLX: Pump Off

Multiple Guns:

Gun Hose Length: ft

Gun Hose Diameter: in

Mix At Wall:

Hose Length A: ft

Hose Diameter A: in

Hose Length B: ft

Hose Diameter B: in

Figure 41 System Screen 4

Multiple Guns

Check this box to enable the option to use more than a single spray device (with a maximum of three). See [Appendix B: Multiple Guns, page 118](#).

Gun Hose Length

Enter the length of the hose from the remote mix manifold to the spray device.

Gun Hose Diameter

Enter the diameter of the hose from the remote mix manifold to the spray device. The minimum diameter is 1/8 in. (3 mm).

Mix At Wall

This field should always be enabled unless not using a remote mix module.

Hose Length and Diameter

Enter the length and diameter of the hose from the remote color stack to the remote mix manifold, for both A and B hoses.

Mix at Belt Circ.

This option is for systems that have fluid circulation and using mix-at-the-belt manifolds. This should not be used with automatic systems.

System Screen 5

System screen 5 sets the following system operating parameters.




Figure 42 System Screen 5

Fluid Control

Select the desired operating mode (pressure or flow), using the pull-down menu.

- In **Pressure Mode**, the motor will adjust the pump speed to maintain the fluid pressure set by an external control device.
- In **Flow Mode**, the motor will maintain a constant speed to maintain the target flow rate set by an external control device.

Manual Override

Check this box to give users system control at the ADM. Leave the box unchecked if all system settings are controlled through a PC, PLC, or other networked device.

Gun Trigger Signal

Select the format of the signal indicating whether the spray device is triggered.

- Discrete — the signal is sent via a direct, hard-wired connection
- Network — the signal is sent via a PC, PLC, or other networked device.

Flow Control (Setpoint Signal)

Select the format of the signal that indicates system flow rate or pressure.

- Discrete — the signal is sent via a direct, hard-wired connection. This selection will make the Max Rate field active.
- Network — the signal is sent via a PC, PLC, or other networked device.
- Recipe — flow rate or pressure is set according to user-entered value on each recipe screen.

Low Flow Tolerance

This field is active if Fluid Control is set to 'Flow'. The system will detect if the flow rate falls below a designated percentage of the target flow rate. Set that percentage in this field. For example, you might want the system to time out if it detects a flow rate that is 10 percent of the target, rather than waiting until a no flow timeout occurs.

Low Flow Timeout

The low flow timeout causes the system to shut down after the designated period of time if the flow rate continues to be at or below the low flow tolerance set in the previous section. The default is 5 seconds. Enter the desired shutdown time in this field.

Gateway Screen

System screen 4 sets the following system operating parameters.

01/25/17 18:27 System Gateway Recipe Flush

Pump Off EMIX: Pump Off

Gateway: Modbus TCP - 0

Enable:

DHCP:

IP: 192 168 1 7

Subnet: 255 255 255 0

Gateway: 0 0 0 0

DNS1: 0 0 0 0

DNS2: 0 0 0 0

Figure 43 Gateway Screen

Gateway ID

Select the desired Gateway ID from the dropdown menu.

Enable

Uncheck Enable while setting the IP Address, Subnet mask, Gateway, DNS1 or DNS2. When the settings are loaded, check the Enable box to write the new settings to the selected Gateway.

Check this box to enable the selected Gateway so that the PLC can communicate with it.

DHCP

Select this box if your system has a Dynamic Host Configuration Protocol (DHCP). This protocol assigns unique IP addresses to devices, then releases and renews these addresses as devices leave and rejoin the network. If selected, the IP Address, Subnet, and Gateway fields will not be editable and will display the addresses supplied by the DHCP.

TCP/IP

Use the remaining fields to set the IP address, subnet mask, Gateway, DNS1, and DNS2.

Recipe Screen

Figure 44 Valid Recipe Screen

Recipe

Enter the desired recipe number (1-60).

Recipe 0

Use Recipe 0 to flush the system.

- **If a recipe (1–60) is loaded:** Select Recipe 0 to flush the previously active pumps and purge the gun.
- **If Recipe 0 or 61 is loaded:** Select Recipe 0 to flush all pumps and purge the gun.

Enabled

Selecting “Enabled” makes the selected recipe accessible from the Spray screen on the ADM or to the PLC.

Note: Recipe 0 is always enabled.

Color (A) Valve

Enter the desired color valve number (1-30).

NOTE: If you enter a number which is not valid in your system configuration, the field will be highlighted and the recipe becomes invalid. For example, if your configuration has 8 color valves and you enter 30, the field will appear as shown in the Invalid Recipe Screen example.

Catalyst (B) Valve (Disabled in 1K Mode)

Enter the desired catalyst valve number (1-4).

NOTE: If you enter a number which is not valid in your system configuration, the field will be highlighted and the recipe is invalid. For example, if your configuration has 1 catalyst valve and you enter 4, the field will be highlighted and the recipe is invalid.

Figure 45 Invalid Recipe Screen

Flush Sequence

Enter the desired flush sequence (1-5) for the color (A) valve and the catalyst (B) valve. The gun purge time for each material depends on the flush sequence assigned to each. See [Flush Screen, page 78](#). If materials A and B require different purge times, assign separate flush sequences. Set the necessary gun purge time for each. For hard to flush colors, select a longer sequence. 1 is the default, and should be designated for the longest, most thorough flush duration.

Mix Ratio (Disabled in 1K Mode)

Enter the desired mix ratio (0 to 50.0):1.

Potlife Time

Enter the potlife time (0 to 999 minutes). Entering 0 disables this function.

Mix Pressure Tolerance (Disabled in 1K Mode)

The pressure of one component must be within a percentage (\pm) of the pressure of the other component during spray or mix. Set the desired Mix Pressure Tolerance in this field. The default is 25%.

Differential Pressure and the Mix Pressure Tolerance Set Point

A primary means of maintaining ratio assurance for the ProMix PD2K system is through monitoring of the differential pressure between the A-pump and B-pump outlets. Ideally, these two pressures would be identical, but factors such as line sizing, viscosity, and mix ratio lead to some variation. Understanding where your system typically operates is imperative when setting up an effective differential pressure check that notifies the user of potential mix ratio inaccuracies while avoiding nuisance alarms.

It is recommended that, once the system is fully installed and ready to use, the user load a recipe and then spray the mixed material. While spraying, note the outlet pressures of both the A and B pumps (per the ADM's main screen or the PLC) and spray long enough to ensure the pressures have stabilized to a nominal value. The difference between the outlet pressures of the A and B pumps is an established baseline for the Mix Pressure Tolerance set point.

The Mix Pressure Tolerance set point allows the B-side pump outlet pressure to vary a specified percentage away from the A-side pump outlet (spray) pressure. For example: In the following figure, if the spray pressure (A-side pump outlet pressure) is 100 psi, and the Mix Pressure Tolerance is set to 25%, the B-side outlet pressure is allowed to float between 75 and 125 psi (100 psi ± 25%) without generating an alarm.




Figure 46 The acceptable B-side pump outlet pressure range for a system with a target spray pressure (A) of 100 psi and a Mix Pressure Tolerance of 25%.

It is recommended that you keep the Mix Pressure Tolerance set point as low as possible to alert the user of anything affecting the mix ratio accuracy. However, if your system is generating several differential pressure alarms, or will be mixing a wide variety of materials at different mix ratios, you may need to increase the Mix Pressure Tolerance.

Dual Solvent




Figure 47 Dual Solvent Recipe Screen

Selecting 'Dual Solvent' enables the sequencing of flushing mixed material for a system using two types of solvent (i.e., water and solvent based) that should not be mixed together.


Purge 1, 2, and 3

Select the sequence for purging the mixed material from the mix hose and spray device. Each stage of the sequence can be set to either 'A' or 'B'. The solvent corresponding to each material will be dispensed out the spray device for the Gun Purge Time of the Flush sequence assigned to that material for each stage. See Table 6 for a progression of the successive stages of the purge sequence.

Fill

Select the sequence for dispensing material into the mix hose and spray device. The choices are: 'A then B', 'B then A', and 'Parallel', if no fill sequencing is necessary. The fill sequence is typically dictated by the last material used in the purge sequence. See Table 6 for a progression of the fill sequence following the last stage of the purge sequence.

Table 6 The Progression of Purge Sequence and Fill Sequence in a Dual Solvent System



Flush Screen



Figure 48 Flush Screen

Flush Number

Enter the desired flush sequence (1-5). For hard to flush colors, select a longer sequence. 1 is the default, and should be designated for the longest, most thorough flush duration.

Air/Solvent Chop

Enable an air and solvent chop for flushing the gun rather than just a solvent purge. See [Air/Solvent Chop, page 79](#).

Air and solvent chop may also be enabled for flushing out a pump. See [Custom Valve Mapping, page 82](#), for more information.

NOTE: Air/solvent chop requires additional hardware for the air purge valve. See manual 333282 for kit numbers and installation details.

Initial Flush

Enter the initial flush volume (0 to 9999 cc).

Wash Cycles

A Wash Cycle activates the pump with the valves closed, to use pumping motion to thoroughly clean the pump. Enter the desired number of wash cycles (0 to 99). Entering a number will make the Strokes per Cycle field active.

Strokes per Wash Cycle

Enter the desired pump strokes per wash cycle (0 to 99). Default is 1.

Final Flush

Enter the final flush volume (0 to 9999 cc).

Gun Purge Time

Enter the spray device purge time (0 to 999 seconds).

Pump Screen 1

NOTE: Your system may include 2, 3, or 4 pumps. Information for each pump is accessible under a separate tab in the menu bar at the top of the screen. Select the tab for the desired pump. Each pump has three screens. Only the screens for Pump 1 are shown here, but the same fields appear on all.

Pump screen 1 includes the following fields which define the pump.




Figure 51 Pump Screen 1 Color




Figure 52 Pump Screen 1 Catalyst

Pump Size

Select 35cc or 70cc, as appropriate.

Inlet Pressure

Select one of the following:

- Disabled
- Monitor, to track inlet pressure (requires inlet pressure transducer)

Select Color Change

Select this box if your system uses color change.

Materials

Enter the number of materials used in your system. Each color change module controls 8 colors.

Hose Length

Compute the length of the hoses from the supply stack to the pump and from the pump to the outlet stack. Enter the total length.

Hose Diameter

Enter the diameter of the supply and output hoses.

Available Colors

The module displays the number of colors available in your system. This field is not editable.

Color Change Valve Mapping

Valve Mapping

Select whether to use Standard, static valve mapping, or fully configurable Custom valve mapping. The color change valve mapping is the assignment of the location of the solenoids in the color change control modules. A static, pre-determined map layout makes for an easily predictable and hands-free option. However, an application and user may benefit from laying out the valve mapping on their own for consolidation of equipment, reduced hardware complexity, or simply to lay out valves according to what makes most sense.

See [Custom Valve Mapping, page 82](#), for more detailed information.

Remote Valve Map

Select an alternate static valve map for the IS color change modules. This is useful for a system that

has more than one color pump but relatively few color change materials. The alternate maps allow for consolidating 2 color pumps (Alternate 1) or 3 color pumps (Alternate 2) onto a single IS color change module. See the Color Change and Remote Mix Manifold Kits manual (333282) for valve maps.

NOTE: This selection is only available on Pump Screen 1 for color pumps.

Catalyst Valve Map

Select an alternate static valve map for a system with two catalyst pumps that requires one pump to change among three catalysts and only a single catalyst on the other pump. See the Color Change and Remote Mix Manifold manual (333282) for more valve maps.

NOTE: This selection is only available on Pump Screen 1 for catalyst pumps with color change enabled.

Custom Valve Mapping

For a PD2K system that has color change, the user has an option for how the control solenoids are mapped on the control modules. Selecting Standard (default) will use the traditional, static valve mapping. The static maps are laid out logically and established for retro-fitting. If Standard is selected no additional set up for the color change valves is required at the ADM. For more information or to see the static map layouts, refer to manuals 332455 and 333282.

By selecting Custom, every color change solenoid may be assigned to any unique, valid control module location. This option offers the ultimate customization as well as the benefit of consolidation of equipment. Additionally, custom valve mapping enables some advanced color change valve features.

NOTE: This option applies to all pumps, so changing it for one will change it for all.

NOTE: When going from Standard to Custom, the PD2K will automatically pull in the static map assignments for all valves as a starting point. When going from Custom to Standard, the PD2K will clear all custom valve assignments and revert to the static mappings.

Pump Screen - Advanced Configuration




Figure 53 Pump Screen, Advanced Configuration

Inlet Color Change

Select Multiple if each individual material has its own valve on the inlet color stack for a particular pump. Select Single if there is more than one material using a single valve on the inlet color stack (i.e., a piggable system). This option is only available for pumps that have more than one color change material.

NOTE: For systems that select Single, it is expected the user knows when a particular material is plumbed and filled to the inlet stack before performing a color change. The PD2K system does not know what material is connected up stream of the inlet valve stack.

Pump Air Purge

Select Enable to add an air purge valve to the pump inlet stack to allow for an air/solvent chop flush of the pump out the dump valve. Select Disable if no air purge valve will be used for the pump. This option is only available for color pumps. See Pump Air/Solvent Chop on [Pump Screen - Valve Assignment, page 84](#), for further detail.

Outlet Color Change

Select Multiple if each individual material has its own valve on the outlet color stack for a particular pump. Select Single if there is more than one material using a single hose connected to the outlet color stack. This option is only available for pumps that have more than one color change material.

NOTE: If Single is selected, the hose connected to the outlet stack will need to be purged before completing a color change.

Remote Color Change

Select Multiple if each individual material has its own valve on the remote color stack for a particular pump. Select Single if there is more than one material using a single hose connected to the remote color stack. Select Disable if there are no remote color change valves (only solvent and air purge) for the pump. The Disable option is only available if Mix-at-Wall is enabled, and Single is only available for pumps that have more than one color change material.


NOTE: Unless Disabled is selected, this must match the selection for Outlet Color Change unless.

NOTE: If Single is selected, the hose connected between the outlet stack and remote stack will need to be purged before completing a color change.

Auxiliary

Select Enable to add an auxiliary valve downstream of the remote valve stack for the pump. The Auxiliary valve is only opened when that particular pump is dispensing (either mixing or purging). This option is only available if Mix-at-Wall is enabled, and also Multiple Guns is not enabled.

The following figure illustrates an example application of the auxiliary valve. Pumps 1 and 3 both dispense color, but one is solvent based and one is water based. (Pump 2 dispenses a catalyst.) With the auxiliary valves in place for both pumps, only one will flow through the A-side of the remote mix manifold, and the other is completely isolated by the auxiliary valve.



t133090a

Figure 54 Example Application of the Auxiliary Valve

Clear Valve Map

Check this box to clear all valve assignments. The user will be prompted to confirm the choice. This will erase any valve assignments permanently, including

any that were automatically set based on the static mapping.

Pump Screen - Valve Assignment

11/06/17 17:49		←	Flush	Pump 1	Pump 2	→
Standby		No Active Errors				
	Valve			Location		↑
	Inlet Solvent	1	01			3
	Inlet Color 1	1	02			
	Inlet Color 2	0	00			4
	Outlet Dump	1	10			
	Outlet Color 1	1	11			5
	Outlet Color 2	0	00			
	Remote Solvent Gun 1	0	00			1
	Remote Color 1	0	00			2
	Remote Color 2	0	00			
						↓

Figure 55 Pump Screen, Valve Assignment

This screen allows the user to assign each individual color change valve solenoid in the system to a unique

location. The list of valves will automatically populate based on the settings that apply to the pump. A description of the valve includes what stack it belongs to, the material identification, and a specific gun or pump designator, if that applies.

NOTE: Some remote stack valves may be shared by more than one pump. They will show up on the valve list for all pumps to which they apply.

All color change valves require a valid location be assigned for the system to be able to operate properly. There are two columns that determine the solenoid location. The left column is the color change module number. This number must be between 1 and 8 and should reflect the dip switch settings on one of the color change boards (see manual 332455 for more details on dip switch settings). The second column is the solenoid location, and this number must be between 1 and 18. The following figure shows the solenoid location enumeration.




Figure 56 Solenoid Location Enumeration

If more than one valve is assigned a valid solenoid location, all instances of that location will be highlighted in red, and are considered invalid.




Figure 57 Pump Screen, Valve Assignment with duplicates

A value of 0 for the control module, or 00 for the solenoid, indicates no previous location assignment and both are also invalid assignments.

If a valve location is considered invalid, any operation that uses that valve will be prevented from running. This is easily identified on the Recipe screens. If any of the material's valves are considered invalid, that material will be highlighted red. If any of the valves used in the flush procedure are considered invalid, the flush sequence will be highlighted red.




Figure 58 Recipe Screen with invalid valve location

Pump Air/Solvent Chop

Enabling an air purge valve on the inlet stack of a color pump allows for an air/solvent chop during the pump flush process. The air/solvent chop will replace the wash cycles in a pump flush. Instead, the pump will run at a steady speed for the set number of strokes (full length travel in one direction) while alternating between air and solvent for the desired duty cycles. One pump stroke takes approximately 2 seconds during this phase.

NOTE: Air/solvent chop requires additional hardware for the air purge valve. See manual 333282 for kit numbers and installation details.




Figure 59 Flush Screen with pump air/solvent chop




Figure 60 Flush Screen with both air/solvent chops

To enable air/solvent chop for a pump flush, check the Air/Solvent Chop box on the Flush screen. Because air/solvent chop may also be used for purging the gun, if Mix-at-Wall is enabled, the Air/Solvent Chop option becomes a pull-down selection where the user may choose None, Pump, Gun, or Both. If air/solvent chop is enabled for the gun purge, all gun purge parameters will appear on the right side, and pump flush parameters are on the left side. The following parameters apply to the pump flush. For details on air/solvent chop for the gun, see [Flush Screen, page 78](#).

Air Chop

Set the air chop duty cycle for the chop phase of the pump flush.

Solvent Chop

Set the solvent chop duty cycle for the chop phase of the pump flush.

Pump Screen 2

Pump screen 2 sets the pressure transducer settings for the pump.




Figure 61 Pump Screen 2, Default Settings Enabled




Figure 62 Pump Screen 2, Default Settings Disabled

Default Settings Selected

When the “Use Default Settings” box is selected, default settings are used for the calibration values, and the fields are grayed out.

Default Settings Not Selected

When the “Use Default Settings” box is not selected, the following calibration values must be entered. Invalid values will be over-ridden and the system will automatically select the default settings.

- **Inlet Offset Factor:** This field is only used if **Inlet Pressure** in [Pump Screen 1, page 80](#), is set to **Monitor**; it is grayed out if set to **Disabled**. The valid range is -01.20 to +01.20 mV/V.
- **Inlet Sensitivity Factor:** This field is only used if **Inlet Pressure** in [Pump Screen 1, page 80](#), is set to **Monitor**; it is grayed out if set to **Disabled**. The valid range is 18.80 to 21.20 mV/V.
- **Outlet Offset Factor:** The valid range is -01.20 to +01.20 mV/V.
- **Outlet Sensitivity Factor:** The valid range is 18.80 to 21.20 mV/V.

Pump Screen 3

Pump screen 3 sets the pressure alarm limits for the pump.

When **Inlet Pressure** in [Pump Screen 1, page 80](#), is set to Disabled, the inlet limit fields are grayed out and only the outlet limit fields are active. See [Pressure Alarm and Deviation Limits, page 87](#).




Figure 63 Pump Screen 3, Pressure Monitoring Disabled

When **Inlet Pressure** in [Pump Screen 1, page 80](#), is set to Monitor, all fields are active. See [Pressure Alarm and Deviation Limits, page 87](#).




Figure 64 Pump Screen 3, Pressure Monitoring Enabled

Pressure Alarm and Deviation Limits

Inlet fields are only active if **Inlet Pressure** in [Pump Screen 1, page 80](#), is set to Monitor; they are grayed out if set to Disabled. Outlet fields are active at all times.

- Alarm and Deviation ranges are 0-300 psi for low pressure systems, and 0-1500 psi for high pressure systems.
- Setting to 0 will disable the alarm. The Inlet Alarm High and Outlet Alarm High **cannot** be disabled.
- Alarms and Deviations will display when the inlet or outlet pressure drops below the low limit or exceeds the high limit.

NOTE: Outlet Alarm Low is only enabled for systems using Flow Control.

Pump Screen - Material Assignment

For systems using Multiple Guns and Mix-at-Wall, see [Appendix B: Multiple Guns, page 118](#), for more detail.

Calibration Screens

Calibrate Screen 1

Calibrate Screen 1 initiates a pump pressure check (stall test) for the selected pump. During the test, the Stall Test screen will appear.

The pump and lines must be primed with color or catalyst before doing the stall test. See [System Screen 2, page 70](#), to set test parameters. See [Pump Pressure Check, page 96](#), for complete test instructions.

To initiate the test, press the Pressure Check  button for the desired pump. The system will first check the inlet pressure due to the material supply pressure. If this pressure is greater than 90% of the Stall Test Pressure, the system will generate an alarm and halt the stall test. The pump will build pressure in the line to a minimum of the Stall Test Pressure. The pump will then move to the center stroke position and stall test the upstroke, followed by the downstroke.

NOTE: The Last Passed log can only be reset by successfully completing the test.

The screen displays the number of days since the last stall test was passed for each pump.



Figure 65 Calibrate Screen 1




Figure 66 Stall Test Screen

Calibrate Screen 2

Calibrate Screen 2 initiates a volume test for the selected pump. During the test, the Volume Check screen will appear.

The pump and lines must be primed with color or catalyst before doing the Volume Check. See [Pump Volume Check, page 97](#), for complete test instructions.

To initiate the test, press the Volume Check  button for the desired pump.

The screen displays the volume dispensed. Press  to end the test.

Press and hold the Reset button  for 1-2 seconds to reset the volume counter.



Figure 67 Calibrate Screen 2




Figure 68 Volume Check Screen

Calibrate Screen 3

Calibrate Screen 3 initiates a calibration of an accessory solvent meter. During the test, the Volume Verification screen will appear.

The meter and lines must be primed with solvent before doing the calibration. See [Solvent Meter Calibration, page 98](#), for complete instructions.

To initiate the calibration, press the Volume Check  button.

The screen displays the volume dispensed. Enter the amount of solvent dispensed in the Measured

Volume field, or press  to end the test.

After the Measured Volume is entered, the Accept

Calibration window will appear. Press  to accept

the calibration. Press  to cancel the calibration and retain the previous K-factor.

Press and hold the Reset button  for 1-2 seconds to reset the volume counter.




Figure 69 Calibrate Screen 3




Figure 70 Enter Measured Volume of Solvent




Figure 71 Accept Calibration

Maintenance Screens

Maintenance Screen 1

Use this screen to set maintenance intervals. Set to 0 to disable the alarm.

NOTE: The Pump Stall Test cannot be disabled. You must enter a value other than 0.




Figure 72 Maintenance Screen 1, Interval Settings

Maintenance Screen 2

Maintenance screen 2 shows the current interval status of the solvent meter, fluid filter, and air filter.

Press and hold the Reset button  for 1-2 seconds to clear the alarm and reset the counter.




Figure 73 Maintenance Screen 2, Current Status

Maintenance Screen 3

Maintenance screen 3 shows the current interval status of the pump maintenance tests.

Press and hold the Reset button  for 1-2 seconds to clear the alarm and reset the counter.

NOTE: The Pump Stall Test can only be reset by successfully completing the test.




Figure 74 Maintenance Screen 3, Current Pump Status

Maintenance Screen 4

Maintenance screen 4 is used to manually relieve pump outlet pressure, or to configure automatic pressure relief.

NOTE: Pump outlet pressure relief is only available for pumps that have a dump valve (color change outlet valves).

To manually relieve pump outlet pressure, change the number to the desired pump and press the Relief

softkey .

To set the system to automatically relieve pump outlet pressure, check the Autodump box and set the Pressure Limit. All applicable pumps, while in Standby, will briefly open the dump valves to relieve outlet pressure when the reading climbs above the set Pressure Limit. The system will attempt up to three times if the pressure does not drop below the set limit.




Figure 75 Maintenance Screen 4, Manual Pump Relief

Maintenance Screen 5

Maintenance screen 5 displays cycle counts for a selected color, catalyst, or solvent valve.

Press and hold the Reset button  for 1-2 seconds to reset the counter.

If the system is in Standby, valves can be opened or closed by selecting or deselecting the box for the corresponding valve. Leaving this screen will close all manually-driven valves.




Figure 76 Maintenance Screen 5, Color Valve Resets




Figure 77 Maintenance Screen 5, Solvent Valve Resets

NOTE: The number to the right of “Solvent” is the pump number, not the material number.

Advanced Screen 1

Advanced screen 1 sets the following display parameters.




Figure 78 Advanced Screen 1

Language

Defines the language of the screen text. Select:

- English (default)
- Spanish
- French
- German
- Japanese
- Chinese
- Korean
- Dutch
- Italian
- Portuguese
- Swedish
- Russian

Date Format

Select mm/dd/yy, dd/mm/yy, or yy/mm/dd.

Date

Enter the date, using the format selected. Use two digits for the month, day, and year.

Time

Enter current time in hours (24 hour clock) and minutes. Seconds are not adjustable.

Password

The password is only used to enter Setup mode. The default is 0000, which means no password is required to enter Setup. If a password is desired, enter a number from 0001 to 9999.

NOTE: Be sure to write down the password and keep it in a secure location.

Screen Saver

Select the desired screen timeout in minutes (00-99). 5 is the default. Select zero (0) to disable the screen saver.

Silent Mode

Select Silent Mode to disable the alarm buzzer and audible feedback.

Advanced Screen 2

Advanced screen 2 sets display units (US or metric).

The screenshot shows the 'Advanced' screen with a navigation bar at the top containing '08/10/13 23:21', 'Maint.', 'Advanced', 'System', and 'Recipe'. Below the navigation bar, there are two status indicators: 'Standby' and 'No Active Errors'. The main content area is titled 'Units' and contains three dropdown menus: 'Grand Total: gal', 'Pressure: psi', and 'Length: ft'. A vertical navigation bar on the right side of the screen has buttons labeled 1, 2, 3, 4, and a down arrow.

Figure 79 Advanced Screen 2

Display Units

Select the desired display units:

- Grand Total Volume (US gallon or liter)
- Pressure (psi, bar, or MPa)
- Length (ft or m)

Advanced Screen 3

Advanced screen 3 enables USB downloads and uploads.

The screenshot shows the 'Advanced' screen with a navigation bar at the top containing '08/10/13 23:21', 'Maint.', 'Advanced', 'System', and 'Recipe'. Below the navigation bar, there are two status indicators: 'Standby' and 'No Active Errors'. The main content area contains three settings: 'Enable USB Downloads/Uploads: ', 'Download Depth: Last days', and 'Log 90% Full Advisory Enabled: '. A vertical navigation bar on the right side of the screen has buttons labeled 1, 2, 3, 4, 1, and a down arrow.

Figure 80 Advanced Screen 3

Enable USB Downloads/Uploads

Select this box to enable USB downloads and uploads. Enabling USB activates the Download Depth field.

Download Depth


Enter the number of days for which you want to retrieve data. For example, to retrieve data for the previous week, enter 7.

Log 90% Full Advisory Enabled

This selection is enabled by default. When enabled, the system will issue an advisory if the memory log has reached 90% of capacity. Perform a download to avoid loss of data.

Advanced Screen 4

Advanced screen 4 displays the software part numbers and versions for the system components. This is not an editable screen.



The screenshot shows a control panel interface. At the top, there is a status bar with the date and time '12/18/01 18:47', a left arrow, 'Pump 2', 'Advanced', 'Recipe', 'Flush', and a right arrow. Below this is a 'Standby' indicator and 'No Active Errors'. The main area is a table with three columns: 'Module', 'Software Part #', and 'Software Version'. To the right of the table is a vertical navigation bar with an up arrow, a '3' button, a '4' button (highlighted), a '1' button, a '2' button, and a down arrow.

Module	Software Part #	Software Version
Advanced Display	16K567	0.07.013
USB Configuration	16K464	0.03.002
Fluid Plate	16K460	0.08.001
Booth Control	16N913	0.02.003
Color Change - 1	16N914	0.01.009
Color Change - 2	16N914	0.01.007
Color Change - 5	16N914	0.01.009

Figure 81 Advanced Screen 4

Diagnostic Screens

Diagnostic Screen 1




Figure 82 Diagnostic Screen 1

Use this screen to test and verify proper wiring for all inputs to the EFCM. (See installation manual for details.) The screen shows all available inputs to the EFCM, but only highlights those that are relevant to the system configuration. All inputs are normally open. When the input sees a switch closure the status indicator on the screen will turn green.

Diagnostic Screen 2




Figure 83 Diagnostic Screen 2

This screen can be used to determine whether any of the EFCM outputs are currently on or off. The screen shows all available outputs from the EFCM, but only highlights those that are relevant to the system configuration. The status indicator next to each output indicates the output is ON when it is green.

Diagnostic Screens 3–10




Figure 84 Diagnostic Screen 1

Diagnostic screens 3–10 are only available for color change modules that are currently connected to the PD2K system. These screens provide real time status of the color change valve outputs by changing the status indicator from white to green when the system energizes that solenoid. The user may scroll through the boards with the up and down arrows, or jump directly to a specific color change module by selecting it from the drop-down box.

Calibration Checks

Pump Pressure Check

NOTE: Enter the transducer calibration data before doing the pressure check.



Perform the pressure check:

- The first time the system is operated.
- Whenever new materials are used in the system, especially if the materials have viscosities that differ significantly.
- At least once per month as part of regular maintenance.
- Whenever a pump is serviced or replaced.

During each pressure test, the dose valve will close during an up stroke and a down stroke (in either order). This test is to verify that the valves are seating properly and not leaking. If leaking occurs, the system will alarm after the test for that particular pump direction.

NOTE: Do not trigger the spray device during the pressure check.

1. The pump and lines must be primed with color or catalyst before doing the Pressure Check. See [Prime and Fill the System, page 21](#).
2. If the display is on a Run Mode screen, press  to access setup screens.
3. Scroll to Calibrate to display [Calibrate Screen 1, page 88](#).
4. Press the Pressure Check  button for the desired pump. The pump will build pressure in the line to a minimum of the Stall Test Pressure. The pump will then move to the center stroke position and stall test the upstroke, followed by the downstroke.
5. The pressure and flow that the unit measured are displayed on the screen. Compare with the maximum leak rate entered on [System Screen 2, page 70](#). If the values are substantially different, repeat the test.

NOTE: The stall test pressure set point is a minimum. The system may stall at a higher pressure depending on hose lengths and fluid composition.

Pump Volume Check



1. The pump and lines must be primed with color or catalyst before doing the Volume Check. See [Prime and Fill the System, page 21](#).
2. If the display is on a Run Mode screen, press  to access setup screens.
3. Scroll to Calibrate in the menu bar.
4. Scroll to [Calibrate Screen 2, page 88](#).
5. Press the soft key  for the pump you want to check.

NOTE: For maximum accuracy, use a gravimetric (mass) method to determine the actual volumes dispensed. Verify that the fluid line is filled and at the proper pressure before checking. Air in the line or pressure that is too high may cause incorrect values.

6. Press the Reset key . The volume counter will reset to 0.
7. Trigger the gun into a graduated cylinder. Dispense a minimum of 500cc of material.
8. The volume that the unit measured displays on the screen.
9. Compare the amount on the screen to the amount in the graduated cylinder.

NOTE: If the value is substantially different, repeat the test. If the dispensed volume and measured volume still do not match, check that the A and B pump positions are not reversed.

NOTE: Stop triggering the gun and press  to cancel the test.

Solvent Meter Calibration



1. The meter and lines must be primed with solvent before doing the calibration. See [Prime and Fill the System, page 21](#).
2. If the display is on a Run Mode screen, press  to access setup screens.
3. Scroll to Calibrate in the menu bar.
4. Scroll to [Calibrate Screen 3, page 89](#).
5. Press the soft key  to initiate the calibration.


NOTE: For maximum accuracy, use a gravimetric (mass) method to determine the actual volumes dispensed.

NOTE: Verify that the fluid line is filled and at the proper pressure before calibrating. Air in the line or pressure that is too high may cause incorrect calibration values.

6. Trigger the gun into a graduated cylinder. Dispense a minimum of 500cc of material.
7. The volume that the unit measured displays on the screen.
8. Compare the amount on the screen to the amount in the graduated cylinder.

NOTE: If the value is substantially different, repeat the calibration process.
9. Enter the amount of solvent dispensed in the Measured Volume field on the screen.
10. After the measured volume is entered, the controller calculates the new solvent meter K-factor and displays it on the screen. The standard meter K-factor is 0.021 cc/pulse.
11. Press  to accept the calibration. Press  to cancel the calibration and retain the previous K-factor.

Color Change



Color Change Module Kits are available as an accessory. See manual 333282 for complete information.

Multiple Color Systems

1. Command the system to Standby.
2. Enable manual override on [System Screen 4, page 73](#).
3. Select the new recipe on the [Spray Screen, page 65](#). This will change colors in the pump and initiate a gun purge.
4. The system will purge material B then material A out of the gun. Each material will purge for the amount of time designated by the Flush Sequence selected for each material on the [Recipe Screen, page 76](#).
5. Wait for the color change to complete. The system automatically goes from Color Change to Mix Fill and the remote mix manifold automatically selects the correct color.
6. Trigger the gun to complete the Mix Fill.

NOTE: There is a 10 second delay without flow before the system will fault.
7. Wait for the system to complete the Mix Fill operation. Command the system to Mix and begin spraying..

System Errors

System errors alert you of a problem and help prevent off-ratio spraying. There are three types: Advisory, Deviation, and Alarm.

An **Advisory** records an event in the system, and will clear itself after 60 seconds. The four-digit error code will be followed by '-V'.

A **Deviation** records an error in the system but does not shut down the equipment. The deviation must be acknowledged by the user. The four-digit error code will be followed by '-D'.

If an **Alarm** occurs, operation stops. The four-digit error code will be followed by '-A'.

If any of the system error types occur:

- Alarm buzzer sounds (unless in silent mode).
- Alarm popup screen shows the active alarm code (see [Error Codes, page 102](#)).
- Status bar on the Advanced Display Module shows the active alarm code.
- Alarm is saved in the date/time stamped log.

A **Record** saves relevant system events in the background. These are informational only and can be reviewed on the Events screen, which displays the 200 most recent events, with date, time, and description.

On-Screen Help

When a system alarm occurs, a help screen is available to provide timely and relevant troubleshooting information for the user. On the

alarm popup screen, press  to access the help screens. The help screens may also be accessed at any time by going to the Errors Screen and selecting an alarm in the log (see [Errors Screen, page 68](#)).




Figure 85 Alarm Popup Screen

All alarms have a QR code screen. A mobile device with internet access and a QR reader may use the QR code to access additional information on a webpage hosted by help.graco.com.



Figure 86 Error QR Code Screen

A number of the alarms that are most likely to be encountered during typical operation have detailed troubleshooting information screens. The troubleshooting screens will replace the QR code screen, though the QR code may still be accessed by

pressing .




Figure 87 Error Troubleshooting Screen

To Clear Error and Restart

NOTE: When a deviation or alarm occurs, be sure to determine the error code before resetting it. If you forget which code occurred, go to the [Errors Screen, page 68](#), to view the last 200 errors, with date and time stamps.

If an alarm has occurred, correct the cause before resuming operation.

To acknowledge a deviation or clear an alarm, press



on the Advanced Display Module. Users also may acknowledge and clear errors via a network device. [INPUT REGISTER 08: Clear Active Alarm in ProMix PD2K Network Inputs, page 33](#).

Gun Trigger Input Function

The Gun Trigger Input signals the controller when the gun is triggered. The gun icon on the Advanced Display Module shows spray when the Gun Trigger Input is activated.

If a pump fails, pure resin or catalyst could spray indefinitely if the unit does not detect the condition and intervene, which is why the Gun Trigger Input is so important.

If the unit detects through the Gun Trigger Input signal that the gun is triggered, yet one or both of the pumps are not running, a Flow Not Detected Alarm (F8D1) occurs after 10 seconds (default) and the system goes into Standby.

Error Codes

NOTE: When an error occurs be sure to determine the code before resetting it. If you forget which code occurred, use the [Errors Screen, page 68](#), to view the last 200 errors, with date, time, and description.

Purge Errors

Code	Type	Description	Problem	Cause	Solution
ETE0	Record	Purge Not Complete	The system was unable to complete a purge sequence.	An indication that the system either could not complete or was interrupted before completing a gun purge.	No action required.
SPD1	Alarm	Gun Purge Incomplete	The system timed out without reaching the user-specified volume of solvent for a purge.	Solvent flow switch not working.	Replace switch.
				Solvent flow is too low to actuate the solvent switch.	Increase solvent pressure to drive a high purge flow rate
				Gun is not triggered.	Operator must continue flushing for configured time, until the booth control indicates purge is completed.
				Mix manifold was not set to flush position, blocking solvent flow to the spray gun.	Set manifold to flush position.

Mix Errors

Code	Type	Description	Problem	Cause	Solution
F7S1	Alarm	Flow Detected Solvent Gun	The solvent flow switch is indicating unexpected solvent flow.	Solvent flow switch is stuck in flow position.	Clean or replace switch.
				There is a leak through the solvent cutoff valve.	Check for leaks and repair valve.
F7S2	Alarm	Flow Detected Solvent Mix	The solvent flow switches indicate that both are flowing solvent at the same time.	One or both solvent flow switches are stuck in flow position.	Clean or replace the switch(es).
				There is a leak through one or both of the solvent cutoff valves.	Check for leaks and repair valve(s).
QPD1	Alarm, then Deviation	Potlife Expired	Potlife time has expired before the system has moved the required amount of material (potlife volume) through the mixed material line.	Purge process was not completed.	Make sure purge process is completed.
				Solvent supply shut off or empty.	Verify solvent supply is available and on, supply valves are open.
QP##	Deviation	Potlife Expired Recipe ##	Potlife time has expired before the system has moved the required amount of material (potlife volume) through the mixed material line in an inactive gun loaded with recipe ##. *This only applies to systems with multiple guns.	An inactive gun has mixed material for recipe ## loaded and has not dispensed enough material in the required amount of time.	Purge the inactive gun.
SND1	Alarm	Mix Fill Incomplete	The system timed out before the mix fill cycle loaded the gun with mixed material.	Mix manifold not set to spray position.	Set manifold to spray.
				Spray gun was not triggered.	Allow flow through gun during fill process until the fill complete LED stops flashing.
				Restrictions in mixer, manifold, or spray gun.	Fix restrictions.

Pumping Errors

NOTE: In some error codes listed below, a # symbol is shown as the last digit. This symbol represents the applicable component number, which can vary. The unit's display will show the applicable number as the last digit in the code. For example, the F1S# code listed in this table will be displayed as F1S1 if the affected component is pump 1, F1S2 for pump 2, and so on.

Code	Type	Description	Problem	Cause	Solution
DA0#	Alarm	Exceeded Maximum Flow Pump #	Pump was driven to its maximum allowed speed.	System has a leak or open valve that is allowing unrestricted flow.	Inspect system for leaks.
				Pump is cavitating, cycling without restriction.	Verify that the pump is being supplied with material.
				Viscosity of material is too thin for nozzle size.	Reduce nozzle size to create more restriction. Reduce paint pressure to lower the flow rate.
				System pressure or Flow Setpoint is too high (causing the pump to work too hard).	Reduce the pressure or the Flow Setpoint.
DE0#	Alarm	Leak Detected Pump #	This is a manual stall test failure when the pump cannot build pressure to the target "Stall Test Pressure." Will fault after 30 seconds.	No material in the pump or line.	Make sure the pump and down stream color line are loaded with material.
				Leak in the system.	Determine if leak is external or internal by visually inspecting the system for fluid leakage. Fix all loose or worn hoses, fittings, and seals. Inspect all valve seats and needles for wear, and replace worn piston or throat seals.
DF0#	Alarm	No Stall Up Pump #	Pump failed the stall test; did not stall on the upstroke.	Valve failure, seal failure, worn rod or cylinder.	Replace inlet and outlet valve and seal for up stroke. Replace piston and throat seals. Replace rod and cylinder as necessary.
DG0#	Alarm	No Stall Down Pump #	Pump failed the stall test; did not stall on the downstroke.	Valve failure, seal failure, worn rod or cylinder.	Replace inlet and outlet valve and seal for down stroke. Replace piston and throat seals. Replace rod and cylinder as necessary.
DH0#	Alarm	No Stall Pump #	Pump failed the stall test; did not stall on either the upstroke or the downstroke.	Valve failure, seal failure, worn rod or cylinder.	Replace inlet and outlet valve and seal for up and down strokes. Replace piston and throat seals. Replace rod and cylinder as necessary.

Code	Type	Description	Problem	Cause	Solution
DKD#	Alarm	Position Failed Pump #	Pump was unable to reach its drive position.	Not enough air is supplied to the dosing valves.	Ensure that at least 85 PSI is being supplied to the dosing valves.
				The pressure at the pump outlet is too high.	Check for an obstruction downstream of the pump that would increase pressure. Ensure the feed pressure is within 1/2 - 1/3 of the target pressure.
DKF#	Alarm	Position Overspeed Pump #	Pump moved beyond its drive position.	The pump was knocked out of position.	There is not fluid pressure at the outlet of the pump. Run the pump at a lower pressure to fill the lines. Check that the feed pressure is not more than 1/2 – 1/3 greater than the target pressure.
EBH#	Record	Home Complete Pump #	Record of pump homing is complete.	An indication on the display that the pump completed the home function	No action required.
EF0#	Alarm	Timeout Startup Pump #	Pump tried but was not able to move to the home position within a specified amount of time.	Pump dose valves did not actuate.	Verify air pressure to solenoid valves. Verify the valves are actuating.
				Motor could not drive pumps and linear actuator.	Verify motor is driving the pump.
				Pump stroke length is shortened by mechanical system tolerance.	Verify correct assembly of linear actuator and pump piston rods. See pump manual.
EF1#	Alarm	Timeout Shutdown Pump #	Pump tried but was not able to move to the park position within a specified amount of time.	Pump dose valves did not actuate.	Visually inspect valves to ensure they are operating properly; verify they have air pressure above 85 psi (0.6 MPa, 6.0 bar).
				Pump is filled with thick paint and could not drive piston to end of stroke. Motor or drive is worn or damaged.	Observe motor and drive assembly to verify that the motor is generating force.
EP0X	Record	Auto Park Complete	Record of pumps auto park complete.	An indication on the display that the system parked the pump automatically.	No action required.
ETD#	Record	Autodump Pump # Complete	Record of pump # pressure automatic pressure relief complete.	An indication on the display that the system automatically opened the dump valve to relieve pressure.	No action required.
F1A#	Alarm	Flow Low Dispense Pump #	The pump was unable to maintain its target flow rate.	There is a restriction in the hose or gun that is preventing the pump from dispensing at its target rate.	Check that the gun is triggered and for restrictions in the hose.

System Errors

Code	Type	Description	Problem	Cause	Solution
F1D#	Alarm	Flow Low Mix Pump #	The pump was unable to maintain it's target flow rate.	There is a restriction in the hose or gun that is preventing the pump from dispensing at it's target rate.	Check that the gun is triggered and for restrictions in the hose.
F1F#	Alarm	Flow Low Fill Pump #	There has been no flow or low flow during a pump fill operation.	There is a restriction on the outlet side of the pump or color stack.	Make sure there are no restrictions in the color stack and that the dump valve is actuating.
				Thick viscosity paint requires more pressure to pump.	Increase non-mix pressure if necessary to create flow during the fill function.
				The pumps do not have to move for the system to build enough pressure to meet the setpoint.	Increase non-mix pressure if necessary to create flow during the fill function.
F1S#	Alarm	Flow Low Purge Pump #	There has been no flow or low flow during a pump purge operation.	Restriction in the outlet side of the pump or color stack resulting in the solvent flow being too low.	Make sure there are no restrictions in the system. Increase non-mix pressure if necessary to create flow during the purge function.
F7D#	Alarm	Flow Detected Pump #	The pump flow exceeded 20 cc/min flow coming into Idle mode.	There is a leak in the system or the gun was open when the system went into Idle mode.	Verify there are no leaks in the system. Make sure the air flow switch is actuating properly. Do not trigger the gun without atomizing air.
F8D1	Alarm	Flow Not Detected	No flow while mixing.	Restriction in the outlet side of the pump or color stack.	Make sure there are no restrictions in the system.
F9D#	Alarm	Flow Unstable Pump #	The pump flow rate did not stabilize while entering Idle mode.	Potential leak in the system.	Check the system for leaks and run manual stall test.

Pressure Errors

NOTE: In some error codes listed below, a # symbol is shown as the last digit. This symbol represents the applicable component number, which can vary. The unit's display will show the applicable number as the last digit in the code. For example, the P6F# code listed in this table will be displayed as P6F1 if the affected component is pump 1, P6F2 for pump 2, and so on.

Code	Type	Description	Problem	Cause	Solution
P1D#	Alarm	Pressure Low Outlet Pump #	The outlet pressure on pump # is less than the user-entered alarm limit. *This alarm is only enabled with Flow Control.	There is no fluid pressure or pump is cavitating.	Check supply for pump #, increase supply pressure.
P1F#	Alarm	Pressure Low Inlet Pump #	The inlet pressure on pump # is less than the user-entered alarm limit.		Increase inlet pressure.
P2F#	Deviation	Pressure Low Inlet Pump #	The inlet pressure on pump # is less than the user-entered deviation limit.		Increase inlet pressure.
P3D#	Deviation	Pressure High Outlet Pump #	The outlet pressure on pump # is greater than the user entered deviation limit.		Relieve system pressure.
P3F#	Deviation	Pressure High Inlet Pump #	The inlet pressure on pump # is greater than the user-entered deviation limit.		Decrease inlet pressure.
P4D#	Alarm	Pressure High Outlet Pump #	The outlet pressure on pump # is greater than the user entered alarm limit.		Relieve system pressure.
P4F#	Alarm	Pressure High Inlet Pump #	The inlet pressure on pump # is greater than the user-entered alarm limit.		Decrease inlet pressure.
P4P#	Alarm	Pressure High Supply Pump #	The supply pump fluid pressure for pump # is greater than 90% of the user-entered Stall Test Pressure.	The supply pump pressure is too high.	Check supply for pump #, decrease supply pressure.
P6D#	Alarm	Press. Sens. Removed Outlet #	No outlet pressure transducer is detected when the system is expecting one.	Disconnected transducer.	Verify transducer is connected properly. Replace if reconnecting does not eliminate the alarm.
P6F#	Alarm	Press. Sens. Removed Inlet #	No inlet pressure transducer is detected when the system is expecting one.	Disconnected transducer.	Verify transducer is connected properly. Replace if reconnecting does not eliminate the alarm.
P9D#	Alarm	Press. Sens. Failed Outlet #	Outlet pressure transducer has failed.	Outlet pressure transducer has failed or the pressure is above the readable range.	Relieve system pressure. Verify connections, or replace if reconnecting does not eliminate the alarm.
P9F#	Alarm	Press. Sens. Failed Inlet #	Inlet pressure transducer has failed.	Inlet pressure transducer has failed or the pressure is above the readable range.	Relieve system pressure. Verify connections, or replace if reconnecting does not eliminate the alarm.

System Errors

Code	Type	Description	Problem	Cause	Solution
QADX	Alarm	Differential Pressure A Over B	Low differential pressure. This alarm is active only during Mix mode.	There is a leak on the B side.	Check the system for internal and external leaks on all catalyst manifolds and plumbing.
				The B side pump is cavitating.	Check paint supply on the B side, increase paint supply pressure.
QBDX	Alarm	Differential Pressure B Over A	High differential pressure. This alarm is active only during Mix mode.	There is a leak on the A side.	Check the system for internal and external leaks on all color manifolds and plumbing.
				The A side pump is cavitating.	Check paint supply on the A side, increase paint supply pressure.

System Errors

Code	Type	Description	Problem	Cause	Solution
EB00	Record	Stop Button Pressed	Record of a stop button press.	Indicates system stop key on ADM was pressed.	n/a
EBIX	Record	Pumps Off Button Pressed	Record of a pump power off button press.	Indicates pump power key o ADM pressed to power down pumps.	n/a
EBCX	Record	Pumps Off PLC Command	Record of a pump power off PLC command.	Indicates a system command to power off pumps was sent by the PLC.	n/a
EC00	Record	Setup Value(s) Changed	Record of changing setup variables.	Indicates date and time when setup values were changed.	n/a
EL00	Record	System Power On	Record of power cycle (ON).	Indicates date and time when system was started.	n/a
EM00	Record	System Power Off	Record of power cycle (OFF).	Indicates date and time when system was turned off.	n/a
EMIX	Advisory	Pump Off	The pumps are not powered and are unable to move.	Pump power was turned off or an error occurred.	Start pumps by pressing pump start key on Advanced Display module.
ES00	Advisory	Factory Defaults	Record of defaults being loaded.		n/a
WSN1	Alarm	Config Error Color	A color defined for the system is not assigned to any gun. *This only applies to systems with multiple guns.	One or more colors is missing a valid gun assignment.	Ensure all colors for all color pumps have a gun assigned to them on Pump Screen 4.
WSN2	Alarm	Config Error Catalyst	A catalyst defined for the system has an invalid gun assignment. *This only applies to systems with multiple guns.	One or more catalyst is missing a valid gun assignment.	Ensure all catalysts for all catalyst pumps have a gun assigned to them on Pump Screen 4.
				Too many catalyst gun assignments exist.	The total number of catalyst gun assignments for the system may not exceed four.

Communication Errors

NOTE: In some error codes listed below, a # symbol is shown as the last digit. This symbol represents the applicable component number, which can vary. The unit's display will show the applicable number as the last digit in the code. For example, the CAC# code listed in this table will be displayed as CAC1 if the affected component is color change board 1, CAC2 for board 2, and so on.

Code	Type	Description	Problem	Cause	Solution
CA0X	Alarm	Comm. Error ADM	System does not detect the Advanced Display Module (ADM).	This communication error indicates that the Network has lost communication with the Advanced Display Module.	Check CAN cable connecting ADM to the EFCM.
CAC#	Alarm	Comm. Error Color Change #	System does not detect the Color Change Module #.	This communication error indicates that the network has lost communication with the Color Change Module #.	Check CAN cable connections to the Color Change Module # and any interconnected modules.
CADX	Alarm	Comm. Error Fluid Module	System does not see the Enhanced Fluid Control Module (EFCM).	This communication error indicates that the Network has lost communication with the EFCM.	Check CAN cables connecting ADM to the EFCM. Replace Cable or EFCM as necessary.
CAGX	Alarm	Comm. Error Gateway	System does not detect a CGM that was registered as being connected at power up.		
CAG#	Alarm	Comm. Error Modbus Gateway	System does not detect a Modbus CGM that was registered as being connected at power up.	The Modbus CGM address dial was changed while the system was powered up.	Unplug the Modbus CGM from the CAN network and re-plug it back in so that it re-registers with the new address.
				The Modbus CGM is not connected/failed.	Check that the Modbus CGM is properly connected to the CAN network and it's LEDs indicate it is powered.
CDC#	Alarm	Duplicate Color Change #	System detects two or more identical Color Change Modules.	More than one Color Change Module with the same address is connected in the system .	Check the system and remove the extra color change module.
CDDX	Alarm	Duplicate Fluid Module	System sees two or more identical Enhanced Fluid Control Modules (EFCM).	More than one EFCM is connected in the system.	Check the system and remove the extra EFCM.

USB Errors

Code	Type	Description	Problem	Cause	Solution
EAUX	Advisory	USB Busy	USB drive is inserted, download is in progress.	Indicates USB port is uploading or downloading data.	Wait for USB Idle.
EBUX	Record	USB Drive Removed	USB drive was removed while downloading or uploading.	Downloading/uploading data on USB was interrupted by the USB device being removed.	Replace the USB device and begin process again.
EQU0	Advisory	USB Idle	USB download completed, drive may be removed.	Data transfer is completed to the USB device.	Remove USB device from ADM.
EQU1	Record	USB Sys. Settings Downloaded	Settings were downloaded to USB drive.	User installed USB device in ADM USB port.	n/a
EQU2	Record	USB Sys. Settings Uploaded	Settings were uploaded from USB drive.	User installed USB device in ADM USB port.	n/a
EQU3	Record	USB Custom Lang. Downloaded	Custom language was downloaded to USB drive.	User installed USB device in ADM USB port.	n/a
EQU4	Record	USB Custom Lang. Uploaded	Custom language was uploaded from USB drive.	User installed USB device in ADM USB port.	n/a
EQU5	Record	USB Logs Downloaded	Data logs were downloaded to USB drive.	User installed USB device in ADM USB port.	n/a
EVUX	Advisory	USB Disabled	USB drive has been inserted, downloading is disabled.	Configuration of system is blocking data transfer.	Change configuration to enable USB download function.
MMUX	Advisory	Maint. USB Logs Full	USB memory is more than 90% full.	Configuration parameter on system is enabled to generate this advisory.	Complete download to ensure no data is lost.
WSUX	Advisory	USB Config. Err.	USB configuration file does not match expected; checked on startup.	A software update was not completed successfully.	Reinstall software.
WXUD	Advisory	USB Download Err.	An error occurred while downloading to the USB drive.	User installed incompatible USB device in ADM USB port.	Repeat process with compatible USB device.
WXUU	Advisory	USB Upload Err.	An error occurred while uploading from the USB drive.	User installed incompatible USB device in ADM USB port.	Repeat process with compatible USB device.

Miscellaneous Errors

NOTE: In some error codes listed below, a # symbol is shown as the last digit. This symbol represents the applicable component number, which can vary. The unit's display will show the applicable number as the last digit in the code. For example, the B9D# code listed in this table will be displayed as B9D1 if the affected component is pump 1, B9D2 for pump 2, and so on.

Code	Type	Description	Problem	Cause	Solution
B9A0	Advisory	Volume Rollover A Current	Batch counter for material A rolled over.	The totalizer has reached maximum capable value and started over at zero.	n/a
B9AX	Advisory	Volume Rollover A Lifetime	Grand total counter for material A rolled over.	The totalizer has reached maximum capable value and started over at zero.	n/a
B9B0	Advisory	Volume Rollover B Current	Batch counter for material B rolled over.	The totalizer has reached maximum capable value and started over at zero.	n/a
B9BX	Advisory	Volume Rollover B Lifetime	Grand total counter for material B rolled over.	The totalizer has reached maximum capable value and started over at zero.	n/a
B9D#	Advisory	Volume Rollover Pump #	Grand total counter for pump # rolled over.	The totalizer has reached maximum capable value and started over at zero.	n/a
B9S0	Advisory	Volume Rollover Solvent Current	Batch counter for solvent rolled over.	The totalizer has reached maximum capable value and started over at zero.	n/a
B9SX	Advisory	Volume Rollover Solvent Lifetime	Grand total counter for solvent rolled over.	The totalizer has reached maximum capable value and started over at zero.	n/a
WX00	Alarm	Software Errors	An unexpected software error has occurred.		Call Graco technical support.

Calibration Errors

NOTE: In some error codes listed below, a # symbol is shown as the last digit. This symbol represents the applicable component number, which can vary. The unit's display will show the applicable number as the last digit in the code. For example, the ENT# code listed in this table will be displayed as ENT1 if the affected component is pump 1, ENT2 for pump 2, and so on.

Code	Type	Name	Description
END#	Record	Calibration Pump #	A calibration test was run on the pump.
ENS0	Record	Calibration Solvent Meter	A calibration test was run on the solvent meter.
ENT#	Record	Calibration Stall Test Pump #	A stall test was completed successfully on pump #.

Maintenance Errors

NOTE: In some error codes listed below, a # symbol is shown as the last digit. This symbol represents the applicable component number, which can vary. For example, the MAD# code listed in this table will be displayed as MAD1 if the affected component is pump 1, MAD2 for pump 2, and so on.

Because some components are assigned a 2-digit number, the last digit of the code is displayed as an alphanumeric character. The second table below correlates the alphanumeric digit to its component number. For example, code MEDZ represents outlet valve 30.

Code	Type	Name	Description
MAD#	Advisory	Maint. Outlet Pump #	Maintenance is due on pump.
MAT#	Advisory	Maint. Stall Test Pump #	Maintenance stall test is due on pump.
MEB#	Advisory	Maint. Valve Catalyst (B) #	Maintenance is due on catalyst valve.
MED#	Advisory	Maint. Valve Outlet #	Maintenance is due on outlet valve.
MEF#	Advisory	Maint. Valve Inlet #	Maintenance is due on inlet valve.
MEG#	Advisory	Maint. Valve Gun #	Maintenance is due on gun valve.
MEN#	Advisory	Maint. Valve Auxiliary	Maintenance is due on auxiliary valve.
MES#	Advisory	Maint. Valve Solvent #	Maintenance is due on solvent valve.
MFF#	Advisory	Maint. Meter Flow #	Maintenance is due on flow meter.
MFS0	Advisory	Maint. Meter Solvent	Maintenance stall test is due on solvent meter.
MGH0	Advisory	Maint. Filter Fluid	Maintenance is due on fluid filter.
MGP0	Advisory	Maint. Filter Air	Maintenance is due on air filter.
MJP#	Advisory	Maint. Valve Air	Maintenance is due on air valve.

Alphanumeric Last Digits

Alphanumeric Digit	Component Number
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
A	10
B	11
C	12
D	13
E	14
F	15

Alphanumeric Digit	Component Number
G	16
H	17
J	18
K	19
L	20
M	21
N	22
P	23
R	24
T	25
U	26
V	27
W	28
Y	29
Z	30

Maintenance

Preventive Maintenance Schedule

The operating conditions of your particular system determine how often maintenance is required. Establish a preventive maintenance schedule by recording when and what kind of maintenance is needed, and then determine a regular schedule for checking your system.

Flushing

- Flush before changing fluids, before fluid can dry in the equipment, at the end of the day, before storing, and before repairing equipment.
- Flush at the lowest pressure possible. Check connectors for leaks and tighten as necessary.
- Flush with a fluid that is compatible with the fluid being dispensed and the equipment wetted parts.

Cleaning the ADM

Use any alcohol-based household cleaner, such as glass cleaner, to clean the ADM.


Appendix A: Integration with Allen Bradley PLC

This appendix outlines how to integrate a ProMix PD2K with an Allen Bradley Studio 5000 Programmable Logic Controller (PLC).


To integrate, the ProMix PD2K must have the Ethernet/IP protocol for PLC CGM (Graco Part number CGMEPO) installed prior to performing this procedure.

In the PLC software, perform the following steps:

1. Add the new Ethernet module.




2. The **Select Module Type** screen opens.



- a. In the search field, type "generic" .
- b. Select ETHERNET-MODULE Generic Ethernet Module.
NOTE: Do not select the Close on Create checkbox.
- c. Click the Create button.

3. The **New Module** screen opens.




Configure the module by defining the fields as follows:

NOTE: The Open Module Properties checkbox must remain selected so that the configuration can be completed after completing this screen.

- a. Name (required): Enter a name for the module (select a name that will have meaning for you when viewed on the Ethernet directory shown by the figure in step 1).
- b. Description (optional): Use any description desired.
- c. IP Address (required): Enter the static IP address of the Graco EtherNet/IP CGM installed in the ProMix PD2K.
- d. Input: Assembly Instance (required): Enter “100”, which is a device-specific parameter for the Graco EtherNet/IP CGM.
- e. Input: Size (required): Enter “41”, which is the number of 32-bit registers that are allocated for input variables in the Graco EtherNet/IP CGM.
- f. Output: Assembly Instance (required): Enter “150”, which is the device-specific parameter for the Graco EtherNet/IP CGM.
- g. Output: Size (required): Enter “22”, which is the number of 32-bit registers that are allocated for output variables in the Graco EtherNet/IP CGM.
- h. Configuration: Assembly Instance (required): Enter “1”.
- i. Configuration: Size (required): Enter “0”.
- j. Click the OK button. The **Module Properties Report** window will be displayed.

4. On the Connection tab:



NOTE: An asterisk appears after the tab heading if unsaved changes are present. Click the Apply button to save changes without exiting this screen.

- a. Enter a Requested Packet Interval (RPI) value.
NOTE: Graco recommends a value of 30 ms or greater.
- b. If desired, select the available checkboxes.
- c. Click the OK button to save all changes and exit this screen.

Table 7 Potential Configuration Problems

Error	Description
Connection Request Error — Invalid Input Application Path	This error, which also triggers an I/O Fault on the PLC, is caused by an invalid number being entered for the Input: Assembly Instance parameter. The correct value for this parameter is “100”.
Connection Request Error — Invalid Output Application Path	This error, which also triggers an I/O Fault on the PLC, is caused by an invalid number being entered for the Output: Assembly Instance parameter. The correct value for this parameter is “150”.
Connection Request Error — Invalid Input Size	This error, which also triggers an I/O Fault on the PLC, is caused by an invalid number being entered for the Input: Size parameter. The correct value for this parameter is “41”.
Connection Request Error — Invalid Output Size	This error, which also triggers an I/O Fault on the PLC, is caused by an invalid number being entered for the Output: Size parameter. The correct value for this parameter is “22”.
Module Configuration Rejected — Format Error	This error, which also triggers an I/O Fault on the PLC, is caused by an invalid number being entered for the Configuration: Size parameter. Because there are no configuration registers associated with the module, the correct value for this parameter is “0”.

Appendix B: Multiple Guns

A ProMix PD2K Automatic system normally operates with a single remote mix manifold and spray device (see Fig 69), but may be configured to used multiple (up to three maximum) remote mix manifolds and spray devices (see Fig 70). Having multiple spray

devices has the advantage of very fast color changes; the system could have a recipe loaded in each spray device and could then switch between them almost instantly. The PD2K will also track potlife time for multiple mixed recipes.




Figure 88 Fluid lines for a typical PD2K Automatic system.




Figure 89 Fluid lines for a PD2K Automatic system with multiple guns.

Appendix B: Multiple Guns

The Multiple Guns operation mode may be enabled on System Screen 3 by checking the box and then subsequently entering the number of spray devices for the system in the **Number** field.




Figure 90 System Screen 3 Multiple Guns

Each color in the system must be assigned to a single spray device. Assignment of the color to a spray device is done on the Pump Screen 4 by entering the spray device number next to the color number.




Figure 91 Pump Screen 4 Color

Catalysts may be assigned to a single spray device, shared among multiple spray devices (common), or a mix of both. Only one catalyst per pump may be configured as Common, and because each assignment requires a remote valve, the total number (including each common assignment) cannot exceed four. To configure a catalyst as common to multiple spray devices, check the **Common** box and select all appropriate spray devices.




Figure 92 Pump Screen 4 Catalyst




Figure 93 Pump Screen 4 Catalyst Common

Recipes can only be set up to use a color and catalyst that are assigned to the same spray device. If the color and catalyst spray device assignments do not match, the recipe will be invalidated and disabled. See [Recipe Screen, page 76](#) for more information on invalid recipes.

When common catalysts are used, the system will automatically allocate each spray device assignment to a unique remote catalyst valve (1–4), shown in the following table.

On the left, locate the row that has;

1. the number of catalyst pumps,
2. the catalyst valve map selection (see [Pump Screen 1, page 80](#)), and
3. the appropriate common catalyst configuration for your system.

Follow along the resulting row to the right to find the system's remote catalyst valve allocation.

Table 8 Remote Catalyst Valve allocation for system using Common catalyst

Catalyst Pumps	Valve Map Selection	Pump 2: Common Catalyst	Pump 4: Common Catalyst	Remote Catalyst Valve 1	Remote Catalyst Valve 2	Remote Catalyst Valve 3	Remote Catalyst Valve 4
1	Standard	None	N/A	Catalyst 1	Catalyst 2	Catalyst 3	Catalyst 4
1	Standard	Common to Guns 1 & 2	N/A	Catalyst 1 (Gun 1)	Catalyst 1 (Gun 2)	Catalyst 2	Catalyst 3
1	Standard	Common to Guns 1 & 3	N/A	Catalyst 1 (Gun 1)	Catalyst 1 (Gun 3)	Catalyst 2	Catalyst 3
1	Standard	Common to Guns 2 & 3	N/A	Catalyst 1 (Gun 2)	Catalyst 1 (Gun 3)	Catalyst 2	Catalyst 3
1	Standard	Common to Guns 1–3	N/A	Catalyst 1 (Gun 1)	Catalyst 1 (Gun 2)	Catalyst1 (Gun3)	Catalyst 2
2	Standard	None	-	Catalyst 1	Catalyst 2	-	-
2	Standard	Common to Guns 1 & 2	-	Catalyst 1 (Gun 1)	Catalyst 1 (Gun 2)	-	-
2	Standard	Common to Guns 1 & 3	-	Catalyst 1 (Gun 1)	Catalyst 1 (Gun 3)	-	-
2	Standard	Common to Guns 2 & 3	-	Catalyst 1 (Gun 2)	Catalyst 1 (Gun 3)	-	-
2	Standard	-	None	-	-	Catalyst 3	Catalyst 4
2	Standard	-	Common to Guns 1 & 2	-	-	Catalyst 3 (Gun 1)	Catalyst 3 (Gun 2)
2	Standard	-	Common to Guns 1 & 3	-	-	Catalyst 3 (Gun 1)	Catalyst 3 (Gun 3)
2	Standard	-	Common to Guns 2 & 3	-	-	Catalyst 3 (Gun 2)	Catalyst 3 (Gun 3)
2	Alternate	None	N/A	Catalyst 1	Catalyst 2	Catalyst 3	Catalyst 4
2	Alternate	Common to Guns 1 & 2	N/A	Catalyst 1 (Gun 1)	Catalyst 1 (Gun 2)	Catalyst 2	Catalyst 4
2	Alternate	Common to Guns 1 & 3	N/A	Catalyst 1 (Gun 1)	Catalyst 1 (Gun 3)	Catalyst 2	Catalyst 4
2	Alternate	Common to Guns 2 & 3	N/A	Catalyst 1 (Gun 2)	Catalyst 1 (Gun 3)	Catalyst 2	Catalyst 4
2	Alternate	Common to Guns 1–3	N/A	Catalyst 1 (Gun 1)	Catalyst 1 (Gun 2)	Catalyst 1 (Gun 3)	Catalyst 4

With Multiple Guns enabled, the system requires two additional remote solvent valves for each spray device. Because of this, the total number of colors is reduced to 26 and the valve map for the IS color change modules are configured differently. Refer to Color Change and Remote Mix Kit manual (333282) for more detail.

Spray Screen

The Spray screen provides the same information and operating capabilities as with a single spray device (see [Spray Screen, page 65](#)). In addition, the Spray screen shows the contents of each spray device, and allows the user to purge a spray device that is not currently active. (The active spray device is that which is, or was, most recently spraying or loading mixed material, and is highlighted on the left side of the screen.) If manual override is enabled, and the system is in Standby, the user may select **Purge** and enter the recipe number to be flushed from an inactive gun. This provides the ability to purge a spray device that is currently inactive but loaded with mixed material that has an expired potlife.



Figure 94 Spray Screen Purge

NOTE: Only a recipe that is loaded in one of the spray devices may be selected to be purged. This prevents inadvertent purging of a desired loaded recipe.

Fill Screen

The Fill screen operates the same as with a single spray device (see [Fill Screen, page 66](#)).

NOTE: When filling a line, it is important to know and trigger the appropriate spray device to which the material is assigned to avoid over-pressuring the system.

When filling a line with a catalyst that is common, the user will also need to select one of the spray devices. The system will open the appropriate valves and fill material out the selected spray device.




Figure 95 Fill Screen Common Catalyst

Potlife Screen

With Multiple Guns enabled, an additional Run Mode screen is now accessible. This screen will show all recipes that are currently loaded in a spray device that have a non-zero potlife, and the amount of time remaining in the potlife.

09/23/15 10:24					
← Spray Fill Potlife Usage Jobs →					
Standby		No Active Errors			
#	⌚	#	⌚	#	⌚
1	51 min	11		21	
2	119 min	12		22	
3		13		23	1
4		14		24	
5		15		25	
6		16		26	
7		17		27	2
8		18		28	
9		19		29	
10		20		30	

Figure 96 Potlife Screen

Recipe 0

If a user wishes to always skip purging the B-side of a particular spray device, or to avoid nuisance purging alarms when no catalyst solvent is plumbed to a particular spray device manifold, it may be disabled on Recipe Screen 0. Select the **1K** option for the appropriate Gun number to indicate only single-component recipes are run through that manifold. (Default value is 2K).

NOTE: 1K should only be selected for manifolds that do not have a B-side solvent plumbed to the manifold. If a combination of one-component and two-component recipes are run through a manifold, the system will automatically determine whether the B-side needs to be purged or can be skipped.

03/01/16 13:01					
← System Recipe Flush Pump 1 →					
Standby		No Active Errors			
	Recipe: 0	Ratio: :1			
	Enabled:	Potlife: min			
	Color (A):	Gun 1: 2K			
	Flush: 1	Gun 2: 2K			
	Catalyst (B):	Gun 3: 2K			
	Flush: 1				
	Dual Solvent: <input type="checkbox"/>				
Mix Pressure Tolerance:					

Figure 97 Recipe 0 Multiple Guns

Maintenance Screen 5

Color change valves may be manually overridden from Maintenance Screen 5 the same as with a single spray device (see [Maintenance Screen 5, page 91](#)).

For a catalyst configured as common, the user will have to identify which remote valve to cycle by selecting the appropriate gun.




Figure 98 Maintenance Screen 5 Common Catalyst

Because each spray device has its own unique remote solvent valves, when overriding a remote solvent valve the user will similarly have to identify the appropriated spray device.

NOTE: For remote solvent valves, the pump number only identifies whether the valve is for the color solvent valve (color pump number) or for the catalyst solvent valve (catalyst pump number).




Figure 99 Maintenance Screen 5 Solvent

Operation With a PLC

All spray devices defined for the system are required to have provided for them a unique gun trigger signal. The following table shows where discrete I/O connections are made for the three available gun trigger inputs on the EFCM.

I/O Description	EFCM Connector	Pins	Type
Gun Trigger Input 1	6	1, 2	Normally Open Contact
Gun Trigger Input 2	6	3, 4	Normally Open Contact
Gun Trigger Input 3	6	5, 6	Normally Open Contact

If the Gun Trigger is configured to 'Network', Input Registers 10, 11, and 12 are used. Review [Discrete I/O, page 24](#) and [ProMix PD2K Network Inputs, page 33](#).

Output Register 26 is used to indicate which gun is currently the 'active' spray device.

When command a line fill/flush for a common catalyst from the PLC using Input Registers 01 and 02, the appropriate spray device must be identified and triggered to avoid over-pressurizing the system. To accomplish this, the common catalysts have a special material number designation. If filling with a common catalyst on pump 2, instead of using material 31 the user will enter 41, 42, and 43 for spray device 1, 2, and 3, respectively. See [ProMix PD2K Network Inputs, page 33](#), and [Line Fill and Flush Sequences, page 42](#), for details.

If one of the inactive spray devices is loaded with material and the potlife expires, it may be desired to purge the material immediately, but not change over materials in the pumps. The Purge (Inactive) system command will allow the user to momentarily cease spraying the active gun and purge and inactive gun, then immediately return to spraying with the previously active gun. The user must enter the recip of the inactive gun in Output Register 07 first and then command the system with Output Register 10 (see [Purge \(Inactive\) Sequence, page 40](#)).

Technical Data

Positive Displacement Proportioner	U.S.	Metric
Maximum fluid working pressure:		
AC1000 Air Spray Systems	300 psi	2.1 MPa, 21 bar
AC2000 Air-Assisted Spray Systems	1500 psi	10.5 MPa, 105 bar
Maximum working air pressure:	100 psi	0.7 MPa, 7.0 bar
Air supply:	85–100 psi	0.6–0.7 MPa, 6.0–7.0 bar)
Air filter inlet size:	3/8 npt(f)	
Air filtration for air logic (user-supplied):	5 micron (minimum) filtration required; clean and dry air	
Air filtration for atomizing air (user-supplied):	30 micron (minimum) filtration required; clean and dry air	
Mixing ratio range:	0.1:1 — 50:1, ±1%	
Fluids handled:	one or two component: <ul style="list-style-type: none"> • solvent and waterborne paints • polyurethanes • epoxies • moisture sensitive isocyanates 	
Viscosity range of fluid:	20–5000 centipoise	
Fluid filtration (user-supplied):	100 mesh minimum	
Maximum fluid flow:	800 cc/minute (depending on material viscosity)	
Fluid outlet size:	1/4 npt(m)	
External power supply requirements:	90 - 250 Vac, 50/60 Hz, 7 amps maximum draw 15 amp maximum circuit breaker required 8 to 14 AWG power supply wire gauge	
Operating temperature range:	36 to 122°F	2 to 50°C
Storage temperature range:	–4 to 158°F	–20 to 70°C
Weight (approximate):	195 lb	88 kg
Sound data:	Less than 75 dB(A)	
Wetted parts:	17–4PH, 303, 304 SST, Tungsten carbide (with nickel binder), perfluoroelastomer; PTFE, PPS, UHMWPE	

California Proposition 65

CALIFORNIA RESIDENTS

 **WARNING:** Cancer and reproductive harm — www.P65warnings.ca.gov.

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

For the latest information about Graco products, visit www.graco.com.

To place an order, contact your Graco Distributor or call to identify the nearest distributor.

Phone: 612-623-6921 **or Toll Free:** 1-800-328-0211 **Fax:** 612-378-3505

All written and visual data contained in this document reflects the latest product information available at the time of publication.

Graco reserves the right to make changes at any time without notice.

For patent information, see www.graco.com/patents.

Original Instructions. This manual contains English. MM 332564

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA

Copyright 2014, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com

Revision L, September 2022