




SLOW STROKER II

AIRLESS PAINT SPRAYER



OPERATION MANUAL AND PARTS LIST FOR MODEL AIRLESSCO 3600SL, 4100SL AND 5300SL

WARNING: Before operating, doing any service or maintenance procedures, learn and follow the Pressure Relief Procedure on page 6. Read and understand all warnings on pages 4,5,6 and 7.

**ALL SERVICE PROCEDURES MUST BE PERFORMED
BY AUTHORIZED AIRLESSCO SERVICE CENTER.**

TABLE OF CONTENTS

Introduction	1
Flushing, How to Flush	1, 2
Setting Up	3
Setting Up and Starting	3, 4
Warnings.....	4, 5, 6, 7
Spray Gun Introduction	8
Spray Technique	9, 10
Airless Spray Gun Operation	11
007X /007XL Spray Guns	12, 13
007 Hi Build Mastic Gun	14
Spray Tip Selection	15
Regular Maintenance	16
Oil and Lubrication Instructions	16
Electric Motor Maintenance	16
Troubleshooting	17
Troubleshooting - Machine does not start	18
Pressure Control Unit	19
Electrical System	20
Replacement of Potentiometer	21
Replacement of Thermal Circuit Breaker	21
Replacement of Pressure Control Unit	21
Replacement of Sensor	21
Servicing Fluid Pump	22
Servicing Upper & Lower Check Valves	23
V-Packing Replacement	24
Fluid Pump Parts List	25
Replacement of Belt/Belt Adjustment	26
Suction Assemblies	26
Maxi-Filter Assembly	27
Paint System	27
Complete Sprayer	28, 29

INTRODUCTION

AIRLESSCO'S SLOW STROKING DC POWERED PUMPS MODELS 3600SL, 4100SL & 5300SL

The AIRLESSCO SL SERIES of airless paint sprayers are a culmination of years of development work resulting in a new class of airless sprayers. Incorporated into the design is Airlessco's proven Slow Stroking Paint Pump, a new low speed, quiet gear system and a DC Motor that stays cool even when you run long extension cords. The SL Series pumps are severe duty pumps designed to meet the needs of professional painting contractors.

SPECIFICATIONS

MODEL 3600SL		MODEL 4100SL		MODEL 5300SL	
Pressure	3000 PSI	Pressure	3000 PSI	Pressure	3000 PSI
Output	0.7 GPM	Output	0.8 GPM	Output	1 GPM
Tip Size	1 GUN UP TO 0.023	Tip Size	1 GUN UP TO 0.027 2 GUNS UP TO 0.017	Tip Size	1 GUN UP TO 0.031 2 GUNS UP TO 0.019

WARNING

Prior to starting, read, understand and observe all safety precautions & warnings on page 4, 5, 6 & 7 and all labels and tags on the machine.

FLUSHING - Read prior to using your sprayer

1. New Sprayer

Your new Airlessco unit was factory tested in an Anti-freeze solution, which was left in the pump. **Before using oil-base paint** flush with mineral spirits only.

Before using water-base paint, flush with mineral spirits, followed by soapy water, then a clean water flush.

2. Changing Colors

Flush with a compatible solvent such as mineral spirits or water.

3. Changing From Water-base to Oil-base

Flush with soapy water, then mineral spirits.

4. Changing From Oil-base to Water-base

Flush with mineral spirits, followed by soapy water, then a clean water flush.

5. Storage

Always relieve pressure (See pressure relief procedure on page 6) prior to storage or when machine is unattended.

Oil-base Paint: Flush with mineral spirits. Ensure that there is no pressure in the unit, then close the prime/pressure relief valve.

Water-base Paint: Flush with water, then mineral spirits. For longer term storage use a 50/50 mixture of mineral spirits and motor oil. Always ensure that there is no pressure in the unit, and close the prime/pressure relief valve for storage.

WARNING: NEVER LEAVE PUMP UNATTENDED WHILE UNDER PRESSURE !

6. Start Up After Storage


Before using **water-base paint**, flush with soapy water and then a clean water flush.

When using **oil-base paint**, flush out the mineral spirits with the material to be sprayed.

HOW TO FLUSH


FIG. 1

REMOVE
SPRAY
TIP




ENGAGE GUN
SAFETY LATCH
(LOCK GUN) as
per gun instruc-
tion manual.

FIG. 3



metal pail

FIG. 2




Pressure Control Knob: used to adjust pressure only. Turn clockwise to increase pressure and counterclockwise to decrease pressure.

**On/Off Switch
Thermal Overload Switch**

Prime/Pressure Relief Valve (Prime/PR Valve)
Used to relieve pressure from gun, hose & tip and to prime the unit when in OPEN position. (It is in open position when there is a wider gap between valve handle and cam body)

When in CLOSED position, there is only a very slight gap between handle & body
When closed the system is pressurized. Handle as a loaded firearm!



1. Be sure the gun safety latch is engaged and there is no spray tip in the gun. Refer to your separate instruction manual provided with your gun on its safety features and how to engage safety latch. Refer to Fig. 1

2. Pour enough clean, compatible solvent into a large, empty metal pail to fill the pump and hoses.

3. Place the suction tube into the pail or place the pail under the pump.

4. Turn the pressure control knob to low pressure. Refer to Fig. 2.

5. Open the prime valve to the open-priming position. This will allow an easy start. Refer to Fig. 2.

6. Turn the motor ON/OFF switch to ON.

7. Point the gun into the metal pail and hold a metal part of the gun firmly against the pail. Refer to Fig. 3.

WARNING: To reduce the risk of static sparking, which can cause fire or explosion, always hold a metal part of the gun firmly against the metal pail when flushing. This also reduces splashing. Refer to Fig. 3.

8. Disengage the gun safety latch and squeeze the gun trigger. At the same time, slowly turn the pressure control knob clockwise, just enough to start the pump. Refer to Fig. 2.

9. Allow the pump to operate until clean solvent comes from the gun.

10. Release the trigger and engage the gun safety latch.

11. If you are going to start spraying, place the suction tube into the supply container. Release the gun safety latch and trigger the gun into another empty metal container, holding a metal part of the gun firmly against the metal pail, and force the solvent from the pump and hose. Engage the gun safety latch until you are ready to prime the pump.

12. If you are going to store the sprayer, remove the suction tube from the solvent pail, holding a metal part of the gun firmly against the metal pail, force the solvent from the pump and hose, Engage the gun safety latch. Refer to "Storage" procedure on page 1.

13. Whenever you shut off the sprayer follow the Pressure Relief Procedure Warning on Page 6.

SETTING UP

1. Connect the Hose and Gun

- Remove the plastic cap plug from the outlet connector and screw a conductive or grounded 3000 psi spray hose onto fluid outlet.
- Connect an airless spray gun to the other end of the hose.

- ## 2. Fill the Packing Nut/Wet Cup 1/3 full with Throat Seal Oil (TSO) supplied. (Fig. 4)




FIG. 4

3. Check the Electrical Service

Be sure the electrical service is 120 V, 60 HZ AC 15 amp minimum and that the outlet you use is properly grounded.

4. Grounding


WARNING: To reduce the risk of static sparking, fire or explosion which can result in serious bodily injury and property damage, always ground the sprayer and system components and the object being sprayed as instructed on page 6.

- ## 5. Flush the sprayer
- as per "Flushing" - New Sprayer on page 1 and "How to Flush" on page 2.

SETTING UP AND STARTING -

Read Safety Warnings on page 4, 5, 6 and 7 before starting.

1. Learn the Controls



When you turn the valve handle and the gap between the valve handle and the cam body becomes wider - this means the valve is in the open position. It is in the closed position when the gap becomes very small.

FIG. 5

Pressure Control Knob

-used to adjust pressure only. Turn clockwise to increase pressure and counterclockwise to decrease pressure.

On/Off Switch

Thermal Overload Switch

Prime/Pressure Relief Valve- used to **relieve pressure** from gun, hose & tip AND to Prime machine when in open position (a wider gap shows between valve handle and cam body) When in closed position (very slight gap) the system is pressurized and ready to spray. Learn and follow **Pressure Relief Procedure** on page 6 of this manual.

- ## 2. Prepare the Material
- according to the material manufacturer's recommendations.

- ## 3. Place the suction tube
- into the material container.

4. Starting the Sprayer

 (See Fig. 5 above)

- Prime Valve must be open - priming position.
- Pressure control knob must be in Low Pressure position.
- Turn the motor ON/OFF switch to ON.

WARNING: To stop the unit in an emergency, turn motor off. Then relieve the fluid pressure in the pump and hose as instructed in the Pressure Relief Procedure on Page 6.

CAUTION: Do not turn motor on without fluid pump having enough fluid so that it can be primed. Running fluid pump dry will decrease life of pumps packings.

5. Prime the pump.

- Be sure gun safety latch is engaged.
- After the pump is primed, close the prime valve by turning it all the way to "closed" position.
- Turn the pressure control knob to desired spray pressure.
- Disengage the gun safety lock and you are ready to start spraying.

WARNING: If you spray into the paint bucket, always use lowest spray pressure and maintain firm metal to metal contact between gun and container. See Fig.3. page 2.

CONTINUED NEXT PAGE

SETTING UP AND STARTING

6. Adjusting the Pressure

- Turn the pressure control knob clockwise to increase and counterclockwise to decrease pressure.
- Always use the lowest pressure necessary to completely atomize the material.

CAUTION: Operating the sprayer at higher pressure than needed wastes material, causes early tip wear and shortens sprayer life.

- If more coverage is needed use a larger tip rather than increasing the pressure.
- Check the spray pattern. The tip size and angle determines the pattern width and flow rate.

7. Cleaning a Clogged Tip

WARNING: To reduce the risk of injection, never hold your hand, body, fingers or hand in a rag, in front of the spray tip when cleaning or checking for cleared tip. Always point the gun toward the ground or into a waste container when checking to see if the tip is cleared or when using a self-cleaning tip.

- Follow the Pressure Relief Procedure on page 6.
- Clean the front of the tip frequently (with toothbrush only) during the day to keep material from building up and clogging the tip.
- To clean and clear a tip if it clogs, refer to the separate instruction manual received with your gun or nozzle.

There is an easy way to keep the outside of the tip clean from material build-up:

Everytime you stop spraying for even a minute, lock the gun and submerge the gun into a small bucket of thinner compatible with the material sprayed. Thinner will dissolve the build up of paint on the outside of tip, tip guard and gun much more effectively if the paint did not have time to dry out completely

WARNING: Clogged standard (flat) tip - clean only after the tip is removed from the gun. Follow the Pressure Relief Procedure on Page 6.

8. When shutting off the sprayer

- Whenever you stop spraying, even for a short break, follow the Pressure Relief Procedure Warning on page 6.
- Clean the tip and gun as recommended by your separate gun instruction manual.
- Flush the sprayer at the end of each work day if the material you are spraying is waterbased, or if it could harden in the sprayer overnight. See "Flushing" page 1 & 2. Use a compatible solvent to flush, then fill the pump and hoses with an oil-based solvent such as mineral spirits.

WARNING: Be sure to relieve pressure in the pump after filling with mineral spirits.

- For long term shutdown or storage, refer to page 1.

WARNINGS

HIGH PRESSURE SPRAY CAN CAUSE EXTREMELY SERIOUS INJURY. Handle as you would a loaded firearm. Learn and follow the PRESSURE RELIEF PROCEDURE ON PAGE 6. Observe all warnings. This sprayer is for professional use only.

DO NOT USE halogenated solvents in this sytem. The prime valve, 2 gun manifold and most airless guns have aluminum parts and may explode. Cleaning agents, coatings, paints or adhesives may contain halogenated hydrocarbon solvents. DON'T TAKE CHANCES! Consult your material suppliers to be sure. Some of the most common of these solvents are: Carbontetrachloride, Chlorobenzene, Dichloroethane, Dichloroethyl Ether, Ethylbromide, Ethylchloride, Tethrachoethane. Alternate valves and guns are available if you need to use these solvents.

Important: United States Government safety standards have been adopted under the Occupational Safety & Health Act. These standards, particularly the General Standards, Part 1910 & and Construction Standards, Part 1926 should be consulted.

WARNINGS CONTINUED ON NEXT PAGE.....

WARNINGS

MEDICAL ALERT - Airless Spray Wounds

If any fluid appears to penetrate your skin, get **EMERGENCY MEDICAL CARE AT ONCE. DO NOT TREAT AS A SIMPLE CUT.** Tell the doctor exactly what fluid was injected.

NOTE TO PHYSICIAN: Injection in the skin is a traumatic injury. **It is important to treat the injury surgically as soon as possible. DO NOT DELAY treatment to research toxicity.** Toxicity is a concern with some exotic coatings injected directly into the blood stream. Consultation with a plastic surgeon or reconstructive hand surgeon may be advisable.

INJECTION HAZARD

Fluids under high pressure from spray or leaks can penetrate the skin and cause extremely serious injury including the need for amputation.

NEVER point the spray gun at anyone or any part of the body.

NEVER put hand or fingers over the spray tip. Do not use rag or other materials over your fingers. Paint will penetrate through material and into the hand.

NEVER try to stop or deflect leaks with your hand or body.

ALWAYS have gun tip guard in place when spraying.

ALWAYS lock gun trigger when you stop spraying.

ALWAYS remove tip from the gun to clean it.

NEVER try to "blow back" paint, this is not an air spray sprayer.

ALWAYS follow the **PRESSURE RELIEF PROCEDURE**, as shown on page 6, before cleaning or removing the spray tip or servicing any system equipment.

Be sure equipment safety devices are operating properly before each use.

Tighten all fluid connections before each use.

MEDICAL TREATMENT

If any fluid appears to penetrate your skin, get **EMERGENCY CARE AT ONCE. DO NOT TREAT AS A SIMPLE CUT.**

* Go to an emergency room immediately

* Tell the doctor you suspect an injection injury

* Tell him what kind of material you were spraying with and have him read **NOTE TO PHYSICIAN** above.

GENERAL PRECAUTIONS

NEVER alter equipment in any manner

NEVER smoke while in spraying area.

NEVER spray highly flammable materials.

NEVER use around children.

NEVER allow another person to use sprayer unless he is thoroughly instructed on its' safe use and given this operators manual to read.

ALWAYS wear a spray mask, gloves and protective eye wear while spraying.

ALWAYS ensure fire extinguishing equipment is readily available and properly maintained.

NEVER LEAVE SPRAYER UNATTENDED WITH PRESSURE IN THE SYSTEM. FOLLOW PRESSURE RELIEF PROCEDURES ON PAGE 6.

ALWAYS INSPECT SPRAYING AREA

Keep spraying area free from obstructions.

Make sure area has good ventilation to safely remove vapors and mists.

NEVER keep flammable material in spraying area.

NEVER spray in vicinity of open flame or other sources of ignition.

Spraying area must be at least 20 ft. away from spray unit.

SPRAY GUN SAFETY

ALWAYS set safety lock on the gun in "LOCKED" position when not in use and before servicing or cleaning.

DO NOT remove or modify any part of gun.

ALWAYS REMOVE SPRAY TIP when cleaning. Flush unit with **LOWEST POSSIBLE PRESSURE.**

CHECK operation of all gun safety devices before each use.

Be very careful when removing the spray tip or hose from gun. A plugged line contains fluid under pressure. If the tip or line is plugged, follow the **PRESSURE RELIEF PROCEDURE** as outlined on page 6.

TIP GUARD

ALWAYS have the tip guard in place on the spray gun while spraying. The tip guard alerts you to the injection hazard and helps prevent accidentally placing your fingers or any part of your body close to the spray tip.

SPRAY TIP SAFETY

Use extreme caution when cleaning or changing spray tips. If the spray tip clogs while spraying, engage the gun safety latch immediately **ALWAYS** follow the **PRESSURE RELIEF PROCEDURE** and then remove the spray tip to clean it.

NEVER wipe off build up around the spray tip.

ALWAYS remove tip & tip guard to clean **AFTER** pump is turned off and the pressure is relieved by following the **PRESSURE RELIEF PROCEDURE.**

Hazardous fluid or toxic fumes can cause serious injury or death if splashed in eyes or on skin, inhaled or swallowed. Know the hazards of the fluid you are using. Store & dispose of hazardous fluids according to manufacturer, local, state & national guidelines.

ALWAYS wear protective eyewear gloves, clothing and respirator as recommended by fluid manufacturer **WARNINGS CONTINUED ON NEXT PAGE.....**

WARNINGS

PRESSURE RELIEF PROCEDURE

To avoid possible serious bodily injury including injection, always follow this procedure whenever the sprayer is shut off, when checking or servicing it, when installing, changing or cleaning tips and whenever you stop spraying or when you are instructed to relieve the pressure.

1. Engage gun safety latch. Refer to separate instruction manual provided with your gun on its safety features and how to engage safety latch.

2. Turn unit off and unplug from electrical outlet.

3. Disengage gun safety latch and trigger gun to relieve residual fluid pressure. *Hold metal part of the gun in contact with grounded metal pail.*





4. Turn Prime/pressure relief valve (PR Valve) to the open (priming) position to relieve residual fluid pressure.

There will be a wider gap between valve handle and cam body when in open position

Note: When in closed position there is only a very slight gap.

Note: The valve handle can move both CCW & CW and can face different directions.



5. Re-engage gun safety latch.

*For overnight or long term storage close prime/pressure relief valve.



IF THE SPRAY TIP OR HOSE IS CLOGGED, follow Step 1 through 5 above. Expect paint splashing into the bucket while relieving pressure during Step 4. If you suspect that pressure hasn't been relieved due to damaged prime/pressure relief valve or other reason, VERY SLOWLY loosen the tip guard retaining nut or hose end couplings to relieve pressure gradually, then loosen completely. Now clear the tip, gun or hose obstruction.

HOSES

Tighten all fluid connections securely before each use. High pressure fluid can dislodge a loose coupling or allow high pressure spray to be emitted from the coupling and result in an injection injury or serious bodily injury.

Use only hose having a spring guard. The spring guard helps protect the hose from kinks or other damage which could result in hose rupture and cause an injection injury.

NEVER use a damaged hose, which can result in hose failure or rupture and cause an injection injury or other serious bodily injury or property damage. Before each use, check entire hose for cuts, leaks abrasion or bulging of cover, or damage or movement of couplings. If any of these conditions exist, replace the hose immediately. Never use tape or any device to try to mend the hose as it cannot contain the high pressure fluid. NEVER ATTEMPT TO RECOUPLE THE HOSE. High pressure hose is not recoupleable.

Help prevent damage to the hose by handling and routing carefully. Do not move the sprayer by pulling it with the hose.

GROUNDING

Ground the sprayer & other components in the system to reduce the risk of static sparking, fire or explosion which can result in serious bodily injury and property damage. For detailed instructions on how to ground, check your local electrical code. ALWAYS ensure switch is in OFF position before plugging unit in.

Always ground all of these components.

1. Sprayer: plug the power supply cord, or extension cord, each equipped with an undamaged three-prong plug, into a properly grounded outlet. DO NOT USE AN ADAPTER.

Use only a 3 wire extension cord that has a 3 blade grounding plug, and a 3 slot receptacle that will accept the plug on the product. Make sure your extension cord is in good condition. When using an extension cord, be sure to use one heavy enough to carry the current your product will draw. (Note: The table on the top of the next page shows the correct size to use depending on cord length and name plate ampere rating. If in doubt, use the next heavier gauge. The smaller the gauge number the heavier the cord.

2. Air Hoses; use only grounded hoses.

3. Fluid hose: use only grounded hoses.

4. Spray gun or dispensing valve; grounding is obtained through connection to a properly grounded fluid hose and pump.

5. Object being sprayed; according to your local code.

6. All solvent pails used when flushing.

Once each week, check electrical resistance of hose (when using multiple hose assemblies, check overall resistance.) Overall (end to end) resistance of unpressurized hose must not exceed 29 megohms (max.) for any coupled length or combination of hose lengths. If hose exceeds these limits, replace it immediately.

Never exceed 500 ft. (150 m) overall combined hose length to assure electrical continuity

WARNINGS

UL RECOMMENDATION FOR MINIMUM GAUGE EXTENSION CORD

AMPERAGE RATING RANGE	VOLTAGE									
		25	50	100	150	200	250	300	400	500
5 - 6	120	18	16	12	12	10	10	8	8	6
6 - 8	120	18	16	12	10	10	8	6	6	6
8 - 10	120	18	14	12	10	8	8	6	6	4
10 - 12	120	16	14	10	8	8	6	6	4	4

Always follow recommended pressure and operating instructions.

KEEP CLEAR OF MOVING PARTS

Keep clear of moving parts when starting or operating the sprayer. Do not put your fingers into any openings to avoid amputation by moving parts or burns on hot parts. Precaution is the best insurance against an accident. When starting the motor, maintain a safe distance from moving parts of the equipment. Before adjusting or servicing any mechanical part of the sprayer, follow the PRESSURE RELIEF PROCEDURE on page 6.

AVOID COMPONENT RUPTURE

This sprayer operates at 3000 psi (205 bar). Always be sure that all components and accessories have a maximum working pressure of at least 3000 psi to avoid rupture which can result in serious bodily injury including injection and property damage.

NEVER leave a pressurized sprayer unattended to avoid accidental operation of it which could result in serious bodily injury.

ALWAYS follow the PRESSURE RELIEF PROCEDURE whenever you stop spraying and before adjusting, removing or repairing any part of the sprayer.

NEVER alter or modify any part of the equipment to avoid possible component rupture which could result in serious bodily injury and property damage.

NEVER use weak or damaged or non-conductive paint hose. Do not allow kinking or crushing of hoses or allow it to vibrate against rough or sharp or hot surfaces.

Before each use, check hoses for damage and wear and ensure all fluid connections are secure.

REPLACE any damaged hose. NEVER use tape or any device to mend the hose.

NEVER attempt to stop any leakage in the line or fittings with your hand or any part of the body. Turn off the unit and release pressure by following PRESSURE RELIEF PROCEDURE,

ALWAYS use approved high pressure fittings and replacement parts.

ALWAYS ensure fire extinguishing equipment is readily available and properly maintained.

PREVENT STATIC SPARKING FIRE/EXPLOSIONS

ALWAYS be sure all equipment & objects being sprayed are properly grounded. Always ground sprayer, paint bucket and object being sprayed. See grounding on page 6 for grounding information.

Vapors created when spraying can be ignited by sparks. To reduce the risk of fire, always locate the sprayer at least 20 feet (6 m.) away from spray area. Do not plug in or unplug any electrical cords in the spray area, which can create sparks, when there is any chance of igniting vapors still in the air. Follow the coating & solvent manufacturers safety warnings and precautions.

Use only conductive fluid hoses for airless applications. Be sure gun is grounded through hose connections. Check ground continuity in hose & equipment. Overall (end to end) resistance of unpressurized hose must not exceed 29 megohms for any coupled length or combination of hose length. Use only high pressure airless hoses with static wire approved for 3000 psi.

FLUSHING

Reduce the risk of injection injury, static sparking or splashing by following the specific cleaning process. ALWAYS follow the PRESSURE RELIEF PROCEDURE on page 6.

ALWAYS remove the spray tip before flushing. Hold a metal part of the gun firmly to the side of a metal pail and use the lowest possible fluid pressure during flushing.


NEVER use cleaning solvents with flash points below 140 degrees F. Some of these are: acetone, benzene, ether, gasoline, naphtha. Consult your supplier to be sure. NEVER SMOKE in the spraying/cleaning area.

WHEN SPRAYING & CLEANING WITH FLAMMABLE PAINTS AND THINNERS

1. When spraying with flammable liquids, the unit must be located a minimum of 25 feet away from the spraying area in a well ventilated area. Ventilation must be sufficient enough to prevent the accumulation of vapors.
2. To eliminate electrostatic discharge, ground the spray unit, paint bucket & spraying object. See GROUNDING on pg. 6. Use only high pressure airless hoses approved for 3000 psi which is conductive.
3. Remove spray tip before cleaning gun and hose. Make contact of gun with bucket and spray without the tip in a well ventilated area, into the grounded steel bucket.
4. Never use high pressure in the cleaning process. USE MINIMUM PRESSURE.
5. Do not smoke in spraying/cleaning area.

AIRLESSCO 007 SPRAY GUN

MAJOR COMPONENTS OF SPRAY GUN




SPRAY GUN

Attach spray gun to whip hose and tighten fittings securely. Set the trigger lock.* Refer to Fig. A.

* The trigger lock should always be set when the gun is not being triggered.



Read all warnings and safety precautions supplied with the spray gun and in product manual.



SPRAY TIP ASSEMBLY

Remove tip guard from spray gun. While holding tip guard upright, slide spray tip into tip guard. Make sure "flats" on spray tip are aligned with "ears" of tip guard. spray tip is installed properly when "flats" recess into tip guard cavity.



Insert tip guard. Place tip gasket in tip guard behind spray tip. Thread tip guard "assembly" onto spray gun, finger tight with "ears" on a 45 degree angle to vertical (see figure). When the tip guard nut is wrenched tight, the tip guard "ears" and spray tip pattern will be aligned for vertical spray pattern. (Spray pattern may be adjusted to horizontal if preferred.)





SPRAY TECHNIQUE

Good Spray Gun Technique is at the core of any spray paint operation. Operator skill and efficiency is as important as good equipment and good paint. Good spray technique is a skill that can be quickly learned by following these simple instructions.

If you are not familiar with spraying techniques, we recommend that you study this section of your manual and practice the proper technique on pieces of cardboard or a suitable surface.



Hold the spray gun 12 - 15 inches away from the work surface and keep it perpendicular (straight) to the surface. Move the spray gun parallel to the work and at a right angle to the surface.




Move the gun at a steady rate in order to apply a good coverage. The wet coat should be just under the thickness at which a run or sag will occur slow gun movement or gun held too close will result in an overly wet or thick wet or thick coat coverage that is likely to run or sag.

The closer the spray gun is held to the work, the thicker the paint is deposited and the faster the gun must be moved to prevent sags and runs. Holding the gun too far from the work will cause excessive fog, overspray, and a thin and grainy coat.


Do not wave the spray gun. This waving is called arching. Instead, hold the spray gun at a 12 to 15 inch distance perpendicular from the work.

SPRAY TECHNIQUE



It is important to "trigger" the gun after gun movement (arm movement) has started and release trigger (shut gun off) before gun movement ends. Gun movement is always longer than actual paint (spray) stroke. In that manner, even blending and uniform paint coat thickness is achieved over the entire surface. When the gun is in motion as the trigger is pulled, it deposits an even amount of paint.


Overlap the previous pass by half the width of the spray pattern. Aim at the bottom of the previous pass.



FOR EVEN PAINT COAT OVERLAP HALF THE WIDTH OF EACH PAINT STROKE.


Spray with uniform strokes from left to right and from right to left, holding stroke speed, distance, lapping, and triggering as uniform as possible.

TAILING




Adjust pressure control knob so that paint is completely atomized from the spray gun. Insufficient pressure will result in "tailing".

GOOD PATTERN




FOG, OVERSPRAY



Too much pressure will result in excess fog and overspray, excessive tip wear, and increased sprayer wear and tear.


POOR PATTERN

GOOD PATTERN




Always use the lowest pressure possible to obtain desirable results.

Test the spray pattern on a piece of cardboard or other surface.



INSIDE CORNER



OUTSIDE CORNER

"Inside" and "outside" corners can be sprayed.

Aim the spray gun toward the center of the corner. The spray pattern is divided in half, and the edges of the spray pattern on both walls are the same.

AIRLESS SPRAY GUN OPERATION

<u>DEFECTS</u>	<u>CAUSE</u>	<u>CORRECTION</u>
Coarse spray	Low pressure	Increase the pressure.
Excessive fogging (overspray)	High pressure Material too thin	Reduce the pressure to satisfactory pattern distribution. Use less thinner
Pattern too wide	Spray angle too large	Use smaller spray angle tip.
Pattern too narrow	Spray angle too small	Use larger spray angle tip (if coverage is OK, try tip in same nozzle group)
Too much material	Nozzle too small Material too thin Pressure too high	Use next smaller nozzle. Reduce pressure
Too little material	Nozzle too small Material too thick	Use next larger nozzle
Thin distribution in center of pattern "horns".	Worn tip Wrong tip	Change for new tip. Use nozzle with a narrow spray angle.
Thick skin on work	Material too viscous Application too heavy	Thin cautiously. Reduce pressure and/or use tip in next larger nozzle group.
Coating fails to close & smooth over	Material too viscous	Thin cautiously.
Spray pattern irregular, deflected	Orifice clogged. Tip damaged	Clean carefully. Replace with new tip.
Craters or pock marks, bubbles on work	Solvent balance	Use 1 to 3% "short" solvents remainder "long" sol (this is most likely to happen with material of low viscosity, lacquers etc.)
Clogged screens	Extraneous material in paint. Coarse pigments Poorly milled pigments (paint pigments glocculate cover screen. Incompatible paint mixture & thinners.	Clean screen Use coarse screen if orifice size allows. Use coarser screen, larger orifice tips. Obtain ball milled paint. If thinner has been added, test to see if a drop placed on top of paint mixes or flattens out on the on the surface. If not, try different thinner in fresh batch of paint.

TEST THE PATTERN


Good, full pattern.



Spotty pattern
Increase Pressure.



AIRLESSCO 007X & XL SPRAY GUNS



007XL GUN W/SWIVEL
Part No. 120-001XL

007X GUN W/O SWIVEL
Part No. 120-001X

SPRAY GUN PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1	120-036	Tip Holder with Guard	14	120-021	Nut
2		Deliberately Omitted	15	120-056	Washer
3	120-008	Tip Washer	16	120-048	Lock
4	120-023	Screw (3)	17	120-055	Wave Washer
5	120-005	Guard	18	120-049	Retaining Ring
6	120-035	Valve Seat Complete	19	120-082	Seal
7	120-037	Valve Ball with Holder	20	120-090CX	Filter-Complete-Coarse
8	120-011	Valve Spring Unit	20	120-090FX	Filter-Complete-Fine
8a	120-033	Seals PTFE (2)	21	120-088	Spring
9	120-022	Trigger Pin	22	120-087	Handle Complete 007X
10	120-046	Washer (2)	23	115-019	Connector
11	120-002	Gun Head	24	120-044	Trigger
12	120-045	Retainer Pin (2)	25	120-085	Handle with Swivel 007XL
13	120-020	Retainer	*		Tungsten Carbide Spray Tip (See Spray Tip Selection)

AIRLESSCO 007X & XL SPRAY GUNS

ADJUSTING SPRAY GUN

Hold gun with trigger locked (24) and push trigger against the lock (16). Then adjust nut (14) so that the retainer (13) will move freely back and forth approximately 1/32" to allow valve spring unit (8) to seat the valve ball (7).

IMPORTANT: Readjust nut (14) periodically for wear of valve seat (6) and valve ball (7); otherwise, leakage will occur

TO REPLACE THE VALVE BALL HOLDER (7)

KIT #2-007

3 Tip Washers (3) 1 Valve Seat (6)
1 Valve Ball Holder (7) 2 Seals- PTFE (8a)

Dismantling:

1. Unscrew tip holder (1) with a 7/8" open end wrench. Remove spray tip and washer (3).
2. Unscrew valve seat (6) with 1/2" socket wrench.

Caution

When removing and replacing valve seat (6), hold the trigger (24) in the open position so that the valve ball (7) is lifted off the valve seat. Failure to lift the ball off the seat will result in a scratched leaky valve.

3. Unscrew valve ball (7) together with the brass part of the assembly (8). Do not pull on the parts or the packing may get damaged.
4. Unscrew the valve ball (7) from the brass part of the assembly (8).

Reassembling is done in reverse sequence.

Screw the new valve ball with holder (7) into the brass part (8).

Caution

Tighten valve ball and brass part on threaded end of the shaft by hand until you feel a positive stop. Do not tighten with a wrench since this could result in breaking the shaft.

Note it is recommended that you change the valve seat (6) and valve ball (7) at the same time.

REPLACING THE VALVE SPRING UNIT (8)

KIT#3-007

3 Tip Washers (3) 1 Valve Seat (6)
1 Valve Ball Holder (7) 1 Valve Spring Unit (8)

1. Repeat dismantling procedure as outlined above under Steps 1 through 3.
2. Unscrew nut (14), remove retainer (13) with retainer pins (12) and push shaft of the valve spring unit (8) out of the gun head (11).
3. Clean gun head (11) bore with solvent and small brush. Do not use any sharp objects to scrape away dried paint, as they would cause leakage around the seal.

Reassembling is done in reverse sequence.

IMPORTANT: When reassembling, install valve spring unit (8) with spring loose.

Push firmly into gun head by hand. Install retainer pins (12), retainer (13) and nut (14) loosely onto valve spring unit (8). Place a 3/16" nut driver on front of valve spring unit and turn clockwise, tightening the valve spring unit until you feel a positive stop. At that point, continue tightening the valve spring another 1/8 turn expanding the PTFE seals against body of gun.

Caution

Do not tighten beyond 1/8 turn as this can result in breaking the valve spring unit shaft. Continue reassembly and adjustment as described above.

CLEANING 007 SPRAY GUN

Immediately after the work is finished, flush the gun out with a solvent. Brush pins (12) with solvent and oil them lightly so they will not collect dried paint.


CLEANING SPRAY TIP

Should the spray tip become clogged, relieve pressure from hoses by following the "Pressure Relief Procedure" in Machine Manual, secure the gun with safety lock (16), take off tip holder (1), take out the tip, soak in appropriate solvent & clean with a brush. (Do not use a needle or sharp pointed instrument to clean the tip. The tungsten carbide is brittle and can chip.)

CLEANING FILTER

To clean the filter, use a brush dipped in as appropriate solvent. Change or clean filters at least once a day. Some types of latex may require a filter change after four hours of operation.

AIRLESSCO 007 HI BUILD MASTIC GUN



PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
122-001	Airlessco 007 Hi Build Gun	120-022	Trigger Pin
120-002	Gun Head	120-023	Screw
122-005	Washer	122-003	Valve Seat Complete
122-002	Adapter	120-036	Tip Holder with guard
120-005	Guard	120-037	Valve Ball with holder
120-008	Tip Washer	120-044	Trigger
122-009	Valve Spring Unit	120-045	Retainer Pin
120-020	Retainer	120-046	Washer
120-021	Nut	120-048	Lock
120-082	Seal	120-049	Retaining Ring
122-010DE	Handle complete 3/8 NPSF	120-055	Wave Washer
122-010	Handle complete 3/8 NPSM	120-056	Washer
		*	Tungsten Carbide Tip

SPRAY TIP SELECTION

Spray tip selection is based on paint viscosity, paint type, and job needs. For light viscosities (thin paints), use a smaller tip; for heavier viscosities (thicker paints), use a larger tip size.

Spray tip size is based on how many gallons of paint per minute can be sprayed through the tip. Do not use a tip larger than the maximum pump flow rate or capacity the sprayer can accommodate. Pump flow rate is measured in gallons per minute (GPM).

Larger Sizes Available

NOTE: For materials requiring larger than a .021 tip, refer to the paint manufacturer's label specifications.

PATTERN WIDTH

Thickness of the paint coat per stroke is determined by spray tip "fan width", rate of the spray gun movement, and distance to surface.

SPRAY TIP SELECTION

Two tips having the same tip size, but different pattern widths will deliver the same amount of paint over a different area (wider or narrower strip).

A spray tip with a narrow pattern width makes it easy to spray in tight places.

Use only good quality, high pressure tungsten carbide spray tips.

SPRAY TIP REPLACEMENT

During use, especially with latex paint, high pressure will cause the orifice to grow larger. This destroys the pattern.

Replace tips before they become excessively worn.


Worn tips waste paint, cause overspray, make cutting-in difficult, and decreases sprayer performance.

REGULAR MAINTENANCE

1. Always stop the pump at the bottom of its' stroke when you take a break at the end of the day
This helps keep material from drying on the rod and damaging the packings.
2. Keep the displacement pump packing nut/wet cup 1/3 full of TSO at all times. The TSO helps protect the packings and rod.
3. Inspect the packing nut daily It should be tight enough to stop leakage, but no tighter Overtightening will damage the packings.

OIL AND LUBRICATION INSTRUCTIONS

FIG. 6



ELECTRIC MOTOR MAINTENANCE

1. **LUBRICATION** - This motor is supplied with pre-lubricated ball bearings, lubricated for the life of the bearing.
2. **MOTOR BRUSHES** need periodic inspection and replacement as wear indicates. Brush wear is greatly influenced by individual application. it is recommended that brush wear be checked at early intervals of operation in order to determine future required inspection. Standard Leeson brushes have an initial length of 1 and 1/4". When the brushes are worn to a length of 5/8" they should be replaced.

TO CHANGE THE BRUSHES:

1. Unplug the machine.
2. Remove the cover over the motor
3. Open the two covers at the rear of the motor
4. Loosen the screw under the brush.
5. Pull out the wire.
6. Push the brush retainer clip in and withdraw
7. Remove the worn brushes.
8. Install new brushes in the reverse order

For long life, new brushes (Part No. 301-146 for 110V service, Part No. 301-147 for 220 - 240 V service) need to have a run in period. After changing brushes, set the machine for spraying. With a bucket of Coro-Chek and water, a 50' 1/4" airless hose, airless gun and tip on unit, open the prime valve and switch on. The pump will now prime. With pump running in the prime mode, turn the pressure control knob to high pressure. (The pump has to cycle fast with no pressure in the pump). Now run the pump for 20 minutes.
After 20 minutes, the brushes will be run in.

TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION
There is spitting from the gun.	The fluid supply is low or empty	Refill the supply container
	Air entrapped in the fluid pump of hose.	Check for loose connections on the siphon assembly, tighten, then re-prime pump.
Paint leaks into the wet cup.	The wet cup is loose.	Tighten just enough to stop leakage.
	The throat packings are worn or damaged.	Replace the packings. See page 24.
	Piston Rod Worn.	Replace piston rod.
The motor operates, but the paint pump doesn't	The pressure setting is too low	Increase the pressure . See page 4.
	The displacement is seized by dried paint.	Service the pump. See pages 22,23,24,25
The motor and displacement pump operates, but paint pressure is too low or none.	The pressure setting is too low	Increase the pressure. See page 4.
	The tip or gun filter is clogged.	Remove the tip and/or filter and clean them.
	Tip is worn.	Replace Tip.
	The fluid displacement pump filter (if used) is clogged.	Clean the filter.
	There is a large pressure drop in the fluid hose.	Use a larger diameter hose.
	The lower check valve ball check is not seating properly.	Service the lower check valve ball check. See page 23.
The displacement pump operates, but the output is too low on the downstroke or both strokes.	The lower check valve ball check is not seating properly.	Service the lower check valve ball check. See page 23.
The displacement pump operates, but the output is too low on the upstroke.	The upper check valve ball is not seating properly.	Service the upper check ball valve per page 23.
	The lower packings are worn or damaged.	Replace the packings. See page 24.
The displacement pump operates but the pressure is too low	Tip too large.	Use smaller tip.
	Long Extension cord causes power drop.	Use less extension cord.
Motor stops.		Reset overload switch.
The displacement pump operates, but unit does not prime.	Upper or lower ball is stuck or obstructed.	Service upper and lower check ball valve. See page 23.
	Unit hose air leak (bubbles blowing out bypass hose)	Inspect suction hose for holes, if so equipped. Ensure suction nut is tight and lower ball cage O-ring is not worn.

TROUBLESHOOTING - Machine does not Start

CAUSE

SOLUTION

Pressure Setting

STEP 1: Ensure ON/OFF switch is in the "ON" position and the Pressure Control Knob is fully CW (maximum pressure) and that the unit is plugged in.

STEP 2: Loosen the pressure control unit on the back of the machine. Check if the green power light on the board is lit. If the light is "OFF", proceed to step 3. If the light is "ON", go to step 7.

Power Source

STEP 3: Use a multimeter to check for 110 volts across the L1 and L2 terminals on the board. If there is no voltage at these leads. There is no power to the unit. Check power source (outlet, breakers, extension cord and power cord.)

Thermal Circuit Breaker

STEP 4: if the machine has power and the green light is "OFF", check to see if the breaker has tripped (button protruding from breaker). Push to reset. If it doesn't reset allow more time and push button in again. Replace thermal circuit breaker if it won't reset.

Thermal Overload

STEP 5: If the thermal circuit breaker is okay, disconnect the two red motor leads (S1 & S2) and test for continuity between the two leads. Continuity shows that the motor's thermal coupler has not tripped. No continuity means that the thermal coupler has opened due to excessive motor heat. If the motor is still hot to touch, allow to cool and retest. If the motor is cool and there is not continuity on the red leads, contact your local Leeson repair facility to repair/replace the thermal coupler.

Pressure Control Unit

STEP 6: If all checks out fine in steps 1 through 5 and the green light is still out, the pressure control unit (board) is defective and must be replaced.

Sensor

STEP 7: If the green light is "ON", the power source, circuit breaker and thermal coupler are okay. Use a multimeter to test the resistance between the red and black wires on the sensor. This must be about 1.5-2.8 Kohms, Note: A bad sensor will usually show no resistance (open). A second option is to substitute the sensor with another one.

Potentiometer

STEP 8: With the machine still "OFF", remove the potentiometer lead from the pressure control unit of the board and read the resistance between the red and black wires. This must be 8 - 12 kohms. If outside this range, replace the potentiometer. Note: A bad pot will usually show no resistance (open). A second option is to substitute the POT with another one.

Motor

STEP 9: Remove the two black leads (A1 & A2) and test for continuity between them. Continuity is an indication that the motor is sound. The lack of continuity points to a problem in the motor. If there is not continuity on these two leads, check the motor brushes. Ensure that the brushes are evenly worn and make solid contact with motor commutator. Replace the brushes if they are less than 5/8" long. If the brushes are okay replace the motor.

Pressure Calibration

STEP 10: Complete the calibration procedures as shown on page 19.

Pressure Control Unit

STEP 11: If the unit fails to start while turning the pressure trimpot clockwise and all other components test okay in Steps 1 - 10, install a new pressure control unit.

PRESSURE CONTROL UNIT

Note: Anytime a sensor, pressure control unit or both are replaced, the first three calibrations must be performed.

1. ZERO CALIBRATION

1. Place prime/pressure relief valve in the prime (open) position.
2. Set the pressure control knob to the minimum setting (CCW).
3. Detach the pressure control unit, but ensure it is grounded to the frame or by other means.
4. Place the jumper (PN 117-207) on both prongs of the "P-ZR" terminal. Note: This jumper comes with a new Pressure Control Unit and is installed on the "P-ZR" terminal. If you are "Zero Calibrating" a Pressure Control Unit presently in the unit, remove the jumper from one prong of the "P-ZR" terminal and place on both prongs of the "P-ZR".
5. Turn machine "ON" and ensure it is not cycling.
6. If the yellow light on the electrical board is on, use an insulated screwdriver to turn the "LCD ZERO" trimpot (P501) counter-clockwise until the light goes out. Then turn it clockwise until the light just comes back on. At this point, the "Zero" Calibration is complete.
7. If the yellow light is OFF, turn the "Zero" trimpot clockwise, just until the light comes on and stop. At this point "Zero" Calibration is complete.
NOTE: If the yellow light remains constantly "ON", or "OFF" during this calibration, the sensor is defective and should be replaced.
8. When calibration is complete, move jumper from both prongs of the "P-ZR" terminal to single prong of the "P-ZR" Terminal.

2. PRESSURE CALIBRATION


1. Attach a 50', 1/4" airless hose, airless gun with 0.017 tip and a 5000 psi pressure gauge to the pump.
2. Place the suction tube into a bucket of Coro-chek and water
3. Turn Prime/pressure relief valve to the prime (open) position.
4. Complete the ZERO calibration, as per "ZERO CALIBRATION".
5. Turn pressure control knob clockwise until machine starts to prime.
6. Place the prime/pressure relief valve in the pressure (closed) position.
7. While watching pressure glycerine gauge, slowly adjust the Pressure Trimpot (P502) (clockwise to increase and counter clockwise to decrease) until the maximum static pressure is 3000 psi, with the pressure control knob fully clockwise. Trigger the gun several times to ensure pressure returns to 3000 psi.

3. MASTER VOLTAGE CALIBRATION

1. Attach a 50', 1/4" airless hose, airless gun with .017 tip and a 5000 psi glycerine filled pressure gauge to the pump.
2. Place the suction tube into a bucket of anti-freeze (or Coro-Chek) and water
3. Turn pump on and turn up pressure control until the machine starts to prime.
4. Place the prime/pressure relief valve in the pressure (closed) position.
5. Pressurize pump to 600 psi.
6. Trigger the gun several times noting the deadband (the amount of pressure drop before the pump rebuilds to set pressure).
7. If deadband is greater than 150 psi, adjust the master voltage trimpot so that the deadband is less than 150 psi and the pressure increase after the gun trigger is released is less than 250 psi. These pressure are guidelines and may vary slightly from pump to pump.
8. Reattach pressure control assembly to unit.

ELECTRICAL SYSTEM

FIG. 7



ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1	331-168C	Electrical Cord	6	301-318	Pressure Control Unit
2	331-185	Strain Relief	7	117-044	Knob
3	301-106A	1 1/4 HPDC Motor(5300)	8	331-184	Spacer
	301-023A	1 HPDC Motor(4100,3600)	9	331-297	Potentiometer
4	301-083	Toggle Switch	10	331-294	Sensor
5	301-518	35A Circuit Breaker	11	117-206	Jumper

REPLACEMENT OF POTENTIOMETER

1. Ensure that the machine is OFF and unplugged.
2. Detach the pressure control unit from the frame by unscrewing the eight screws.
3. Unplug potentiometer lead from the pressure control unit.
4. Use 1/16" allen wrench to loosen the set screw on the potentiometer knob and remove knob and spacer.
5. Use 1/2" socket or wrench to remove the retaining nut from the potentiometer stem and remove potentiometer from the frame.
6. Reassemble in reverse order

REPLACEMENT OF THERMAL CIRCUIT BREAKER

1. Ensure that the machine is OFF and unplugged.
2. Detach the pressure control unit from the frame by unscrewing the eight screws.
3. Unplug the two black wires from the circuit breaker
4. Unscrew the clear rubber boot and retaining nut on the circuit breaker stem and remove circuit breaker from the frame. This can be done by hand.
5. Reassemble in reverse order Note: the black wires are interchangeable.

REPLACEMENT OF PRESSURE CONTROL UNIT (ELECTRICAL BOARD)

1. Ensure that the machine is OFF and unplugged.
2. Detach the pressure control unit from the frame by unscrewing the eight screws.
3. Disconnect all wires, leads and hoses from the pressure control unit.
4. Remove the pressure control unit.
5. Reassemble in reverse order See Fig. 7, page 20 for wiring diagram.

REPLACEMENT OF SENSOR

1. Place prime/pressure relief valve in the prime (open) position.
2. Unplug electrical cord.
3. Detach pressure control unit from the frame by unscrewing the eight screws
4. Unplug sensor lead from the pressure control unit.
5. Use a 7/8" wrench to unscrew the sensor from the pressure control unit.
6. Place PTFE tape on the threads of the new sensor and screw it snugly into the pressure control unit.
7. Plug sensor lead into pressure control unit.
8. Complete the calibration procedures on pages 19.
9. Attach the pressure control unit frame.

SERVICING FLUID PUMP

Note: Check everything in the Troubleshooting Chart before disassembling the sprayer.

FLUID PUMP DISCONNECT

1. Flush out the material you are spraying, if possible.
2. Follow the Pressure Relief Procedure on Page 6. Stop the pump in the middle of down stroke.
3. Remove the suction tube and fluid hose (if so equipped) from the fluid pump.
4. Remove 2 retaining rings and slip the sleeve of the coupling down and remove both coupling halves. This will disconnect fluid pump from the connecting rod.
5. Unscrew the two tie rod locknuts.
6. Pull the pump off the tie rods.

FLUID PUMP REINSTALL

1. Loosen the packing nut and extend piston rod to fully up position. Slip sleeve (189-047) over the piston rod.
2. Make sure that spacer tubes (301-048) are in place.
3. Connect connecting rod with fluid pump by installing coupling halves (189-046). Slide sleeve over coupling halves. Secure with retaining ring (189-048).
4. Secure the fluid pump housing to the tie rods (100-328) and screw locknuts with washers on loosely.
5. Tighten the tie rod locknuts evenly to 30 ft. lb.

NOTE: After all the rod locknuts are tight, the alignment of both rods should allow easy assembly and disassembly of the coupling. If any binding, loosen and retighten all the rod locknuts to improve the alignment. Misalignment causes premature wear of seal and packings.

6. Tighten the packing nut clockwise until resistance against the packings can be felt. Turn it 1 full turn more. Approximately 4-5 threads of the packing nut should show.
7. Start the pump and operate it slowly (at low engine speed) to check the piston rod for binding. Adjust tie rod lock nuts if necessary to eliminate binding.
8. Prime the unit and run at maximum pressure for several minutes, then release the pressure and repeat step 6.
9. Fill the wet cup (packing nut) about 1/3 full of TSO (Throat Seal Oil).

SERVICING UPPER & LOWER CHECK VALVES

LOWER CHECK VALVE (SEE FIG. 8 & 10)

1. Screw the lower check valve nut (187-018) out of the pump housing (187-313) containing intake seat support (187-017).
2. Remove the intake seat (187-065), O-ring (187-034), intake ball (187-020) and retainer (187-016).
3. Clean all parts and inspect them for wear or damage, replacing parts as needed. Old "O" rings should be replaced with new ones.

Note: "O"ring PN 187-028 is available in the following materials:
Viton for waterbase paint - letter "V" after part no.
PTFE for other fluids - letter "T" after part no.

4. Clean inside of pump housing (187-313).
5. Reassemble the valve and screw it onto the pump housing if no further pump service is needed.

PISTON-ROD, UPPER CHECK VALVE (SEE FIG. 8 & 10)


1. Stop piston rod in middle of it's stroke. Remove retaining rings (189-048).
2. Slip the sleeve (189-047) off the coupling halves (189-046) and remove both coupling halves. This will disconnect piston rod from pump drive.
3. Screw the lower check valve nut (187-018) off the pump and remove lower check valve.
4. Loosen the packing nut and push the piston rod down and out of the housing.
5. Place rod holder Part No. 187-248 in a vise. Slide the rod into the holder and lock in place with a 1/4" pin. Push the pin through the holder and the rod. Screw the seat support (187-021) out of rod, remove "O"ring (187-033T), seat (187-044) and ball (115-022) out of the piston rod (187-311).

NOTE: Retainer (187-032) with "O"ring (187-033V) and ball stop (187-022) may remain in the piston rod. Clean and check visually the ball stop (187-022) for excessive wear. If ball stop needs to be replaced, install any screw with thread 1/2-13NC into the threaded hole of retainer (187-032) and pull straight out.

6. Clean all parts and inspect them carefully for wear or damage. Inspect the outside of the piston rod for scoring or wear. Replace these parts if needed. A worn piston rod will cause premature wear of packings.
7. Install parts back into piston rod as per Fig. 10, pg. 25 VIEW A as shown.

Note: Before installing discharge seat support (187-021), place two drops of loctite No. 242 (blue) on threads before assembling.

8. After installation and tightening of discharge seat support, check to ensure ball stop (PN 187-022) is properly installed in piston rod and has not fallen into piston bore. Check by pushing on the ball and feeling a positive stop against the ball stop.



V - PACKING REPLACEMENT

1. Remove the fluid pump as per the "Fluid Pump Disconnect" instructions on page 22.
2. Unscrew and remove the lower check valve per instructions on page 23.
3. Unscrew & remove the packing nut (187-046). Push the piston rod down through the packings and out of the pump. Wrap some masking tape around the bottom of the piston. Now push the piston back through the pump and remove through the top. The packings and glands will be removed with the piston rod, leaving the pump casing (187-313) empty. Utilizing tool (PN 187-249) the complete packing set & piston can be removed quickly and easily.
4. Disassemble and clean all parts for reassembly. Discard old packings, but retain old glands for reuse.


REASSEMBLY

5. Lubricate leather packings in lightweight oil for 10 min. prior to assembly.
6. Remove masking tape from piston. (if used)
7. Reassemble all parts onto piston as per drawing Fig. 9 in the following order:
 - a. Start with lower male gland (187-024)
 - b. Two new V-packings face down (187-029T)
 - c. Female adaptors (187-023P)
 - d. Five V-Packings face up. (alternating PTFE & Leather)
 - e. Upper male gland (184-024)
 - f. Slide on distance tube (187-315).
 - g. Three Belleville Spring (187-031) starting with the first spring facing down and next facing up and the third facing down.
 - h. Slide on upper male gland (187-025) with bevel facing up.
 - i. Six V-Packings faced down (alternating PTFE & Leather)
 - j. Female Gland (187-026)
 - k. Slide on the V-Packing holder (187-047) over upper packings.
8. Lubricate inside of cylinder & outside of packings then slide complete assembly into the pump casing (187-313). Thread packing nut (187-046) into cylinder and tighten (hand tight only).
9. Install the lower check valve and tighten the lower check valve nut (187-018).
10. Connect the pump to the machine as per fluid pump reinstall procedure (page 22).
11. Tighten the packing nut just enough to stop leaks.


V-PACKING KIT - PTFE AND LEATHER (187-040)

Note: O-ring (187-028) on lower ball cage is supplied in PTFE and Viton. Use Viton when spraying latex or oil based paints and PTFE when spraying paints with high solvents.

FIG. 9




FLUID PUMP - 187-310 FIGURE 10



REPLACEMENT OF BELT/BELT ADJUSTMENT

NOTE: The Cog Belt System does not require alignment. When upper sheave is placed on motor shaft it is pushed on until a positive stop is reached. The set screws (Fig. 16, Item 30) are then loctited. The lower pulley is placed on gearbox and held in place with keyway and snap ring (Fig. 16, Item 18) The flange on upper sheave holds the belt in alignment and the belt self aligns on lower pulley eliminating having to align.

FIG. 11



BOLTS MUST BE LOOSE TO ADJUST BELT

REPLACEMENT OF BELT:

1. Remove cover (Fig. 16, Item 32) from unit.
2. Remove Tensioner Assembly (Fig 11). Then loosen screws (Fig. 16, Item 27). Move gearbox forward to allow removal and replacement of belt.
3. Retighten screws into gearbox until they bottom out. (Fig. 16, Item 27) This will align gearbox correctly
4. Replace tensioner with bolts and leave loose to allow adjusting belt tension.
5. Tighten belt as shown in Figure 11. When properly tightened the deflection play should be 1/4 inch when pushing hard with thumb. (20 ft/lbs)

NOTE: When placing belt on pulleys and inserting the tensioner against belt, ensure cogs on belt are engaged into cogs on pulleys before tightening belts. Rotating upper pulley while holding the tensioner against the belt will allow proper engagement of cogs prior to tightening.

SUCTION ASSEMBLY - 5 GAL. - P.N. 301-090

FIG. 12




FIG. 12 PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION
*	301-517	Suction Hose Ass'y (includes items 1-5)
1	141-008	Inlet Strainer
2	301-514	Suction Tube
3	301-516	Hose Clamps (2)
4	301-513A	Hose
5	100-165	Elbow
6	188-377	Return Pipe
7	100-128	Elbow
8	100-012	Whip
9	100-126	Elbow **
10	100-385	Reducer**

** used on units equipped with either the 100-180 or 331-050 prime valves. The 301-090 suction ass'y also includes the 100-081A Elbow for units with the 138-001 marathon prime valve.

SUCTION ASSEMBLY - 55 GAL. - P.N. 301-543

FIG. 13




FIG. 13 PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION
1	141-008	Inlet Strainer
2	301-545	Suction Tube
3	301-516	Hose Clamps (2)
4	301-544	Hose
5	100-165	Elbow
6	188-377	Return Pipe
7	100-128	Elbow
8	100-012	Whip
9	100-126	Elbow **
10	100-385	Reducer**


** used on units equipped with either the 100-180 or 331-050 prime valves. The 301-090 suction ass'y also includes the 100-081A Elbow for units with the 138-001 marathon prime valve.

OPTIONAL MAXI FILTER ASSEMBLY

P.N. 301-360

FIGURE 14 PARTS LIST		
ITEM	PART NO.	DESCRIPTION
1	301-357	Plug, 1/4" NPT (4)
2	301-361	Bowl
3	301-356	Spring
4	301-363	Screen
5	301-362	Support
6	301-355	O-ring
7	301-352	Head
8	100-159	Swivel 3/8 NPS(M) X 1/4 NPT(F)
9	115-019	Connector 1/4 NPS(M) X 1/4 NPT(M)

FIG. 14




PAINT SYSTEM - PN 301-395

FIG. 15 PARTS LIST -PN 301-395		
ITEM NO.	PART NO.	DESCRIPTION
1	301-348	Bypass Hose
2	100-180	Prime/Pressure Relief Valve
3	100-115	Tee 1/4" MFF
4	100-109	Connector 3/8x3/4
5	301-526	Hose 3/8x13
6	100-050	Bushing 3/8x1/4
7	115-019	Hose Connector
8*	331-294	Sensor
9*	111-037	Screw
10*	301-318	Pressure Control Ass'y


* Not part of Paint System

FIG. 15



COMPLETE SPRAYER

FIG. 16



COMPLETE SPRAYER PARTS LIST

FIG. 16 PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1	301-189	Shield - Front	35	111-037	Screw (8)
2	301-092	Shield - Rear	36	101-057	Label 3600SL (2)
3	301-105	Hook	37	101-058	Label 4100SL (2)
4	100-360	Screw (2)	38	101-113	Label 5300SL (2)
5	100-312	Screw (4)	39	117-052	Fan Cover Screws
6	301-022	Cover	40	101-005	Warning Label
7	301-291	Connecting Rod Ass'y(3600,4100)	41	101-040	Label -Efficient Machine
	301-333	Connecting Rod Ass'y(5300)	42	101-060	Label - High voltage
8	189-048	Retaining Ring (2)	43	301-046	Rod End
9	189-046	Coupling Set	44	301-237	Pulley, Cog
10	301-047	Sleeve Bearing	45	301-231	Cog Belt
11	189-047	Coupling Cover	46	301-073	Air Wheel (2)
12	301-193	Tensioner Ass'y	47	143-029	Set Collar (2)
13	111-044	Hex Hd. Screw (2)	48	167-014	Spacer (2)
14	140-029	Washer (2)	49	301-149	Spacer
15	113-023	Washer, Splitlock (2)	50	301-123	Axle
16	111-037	Screw (6)	51	301-134	Stopper (2)
17	301-135	Grommet (6)	52	301-090	Suction Ass'y (5 gal)
18	100-332	Retaining Ring	53	301-543	Suction Ass'y (55 gal)
19	301-139	Woodruff Key	54	301-107	3/4 hp Motor Ass'y(3600)
20	331-168C	Power Cord	55	301-023A	1 hp Motor Ass'y(4100)
21	301-048	Spacer - Tube (2)	56	301-106A	1 1/4 hp Motor Ass'y(5300)
22	100-328	Stud (2)	57	113-022	Fin Hex Nut (4)
23	140-035	Washer, Lock (2)	58	113-023	Washer, Split Lock (4)
24	140-051	Nut (2)	59	140-029	Washer (4)
25	301-173	Bracket - Return Tube	60	100-028	Plug 1/4 NPT
26	136-033A	Screw (3)	61	301-190	Fan
27	301-099	Screw (3)	62	301-191	Retaining Clip, Fan
28	140-051	Nut	63	301-060A	Gearbox 3/4" (3600, 4100)
29	301-233	Sheave		301-336	Gearbox 1" (5300)
30	115-041	Set Screw (4)	64	101-114	3 labels Pressure, Thermal Overload, ON/OFF
31	112-029	Key			
32	301-091	Cover	65	187-310	Fluid Pump
33	301-240	Frame	66	301-316	Rubber Edge(1.17)(makes 2)
34	301-318	Pressure Control Ass'y(PCA)	67	301-089	Fan Cover