


WIRING DIAGRAM



Servicing Motor and Gear Train

Remove Motor

Shut off and unplug the unit, open the drain valve to release the pressure and engage the trigger safety. Remove the thumbnuts, raise the front hood and slip the shield back. Disconnect the hoses from the displacement pump.

NOTE: Don't try to remove the motor from the gearcase cover. The service replacement motor includes a cover. These are matched parts, sold assembled only. The motor includes a new gear and bearings installed, and a new gasket. Order part no. 207-960.

Remove the gearcase drain plug. See Fig 5. Disconnect the conduit and wires from the pressure control to the motor. Remove the pressure control from the cover. Remove the wheels from the frame. Screw the 4 capscrews out of the pump side of the gearcase, below the drain plug. Screw out the 4 capscrews holding the gearbox to the frame. Remove the motor and gearbox from the frame and set up on 2 x 4's as shown. Remove the 18 gearcase cover capscrews. Carefully lift the motor and cover straight up off the gearcase. Discard the old gasket. See Fig 8.

CAUTION

The loose gear cluster could stick in the cover. Don't let it drop.


Install New Motor

Position the new gasket on the gearcase. The surface must be clean and free of nicks. Be sure the gears and washers are in place, then carefully lower the motor and cover into place, turning the crank slightly to help mesh the gears.


Continue reassembly by reversing the disassembly procedure. Replace gearcase drain plug and fill to the proper level with the proper type gearcase lube. Don't use hypoid grease. The gearcase holds 3 pt (1.4 liters).

To Install New Gear Train

Order part no. 208-030. Follow the procedure above for motor replacement; also remove the displacement pump, but don't disconnect the wires.



MODELS 226-400



MODEL 226-365




Fig 8

PARTS DRAWING

ELECTRIC "AIRLESS" PAINT SPRAYER



Model 226-400 Series "K"

Model 226-365 Series "L"
 otherwise same 226-400



REPAIR KIT 208-940
 (for displ. pump). See
 end of parts list, page 11,
 for parts. PURCHASE KIT
 SEPARATELY.

Ref No. 34 Shield Assy.
 Includes items 22, 29, 37-39, 42,
 44, 45, 121, 129, 132, 134



*Suggested replacement parts

PARTS LIST

**Model 226-400
Series "K"**

**PAINT SPRAYER
includes items 1-4, 6-108, 119-121,
127-133 (includes 2 of item 19)**

**Model 226-365
Series "L"**

**PAINT SPRAYER
includes items 1-4, 6-12, 15-35,
37-133 (includes 3 of item 19
and 2 of item 17)**

REF NO.	PART NO.	DESCRIPTION	QTY	REF NO.	PART NO.	DESCRIPTION	QTY
1	100-016	LOCKWASHER, spring; 1/4 screw sz	2	65	208-030	PUMP DRIVE ASSY(for 226-400 & Series "B"	
2	100-021	CAPSCREW, hex hd; 1/4-20 x 1"	9			226-365 replaceable parts, includes items 1, 7, 11, 24, 27, 31, 32	1
3	100-055	SCREW, drive; type "U", No. 6 thd sz; 1/4 in. lg	2	66	214-905	FRAME	1
4	100-643	SCREW, soc hd cap; 1/4-20 x 1"	9	67	208-327	SPRAY GUN (for 226-365),see 307-046 for parts	1
5	100-721	PLUG, pipe; hds; 1/4 npt	3		208-663	SPRAY GUN(for 226-400),see 307-046 for parts	1
6	101-421	PIN, cotter; 1/16 in. dia, 3/8 in. lg	1	68	210-541	HOSE, paint; "Nylon", static free,1/4 in. ID; cpld 1/4 npsm(f) swivel; 50 ft(15 m)lg	1
7	101-550	CAPSCREW, soc hd; 1/4-20 x 1/2	2	69	208-856	PRESSURE CONTROL ASSY, replaceable parts incl. items 5, 25, 28, 70-78	1
9	102-607	TIP, rubber; switch actuator	1	70	100-813	. WASHER, flat	2
10	102-637	CAPSCREW, hex hd;3/8-16 thd, 1 1/2"lg	4	71	100-110	. SETSCREW, sq hd, 1/4-20 thd; 7/8 in. long	1
11	102-876	CAPSCREW, hex hd; 1/4-20 thd, 3" lg	4	72	102-271	. SCREW,rd hd mach; 6-63 thd;1" lg	2
12	101-545	PIN, cotter	2	73	102-888	. RING, backup; "Teflon"	1
15	102-952	STRAINER, inlet	1	74	103-740	. SWITCH, micro; 125 VAC, 20 amp	1
16	103-117	RING, retaining	2	75	168-518	. PACKING, o-ring; viton	1
17	103-412	TERMINAL, wire;for No. 10 wire and No. 10 screw	1or2	76	168-596	. CAP, control housing	1
18	174-063	WHEEL, semi-pneumatic	2	77	170-790	. PLUNGER, switch	1
19	103-760	CONNECTOR, wire; pressure type, No. 12, 14, 16, 18 wire size	2or3	78	171-080	. SHIELD, switch	1
20	103-927	CLAMP, hose	2	79	208-569	DISPLACEMENT PUMP ASSY Series"E" Includes items 80-108	1
21	172-412	PLATE, identification	1	80	**101-874	. BALL, steel; 1/2 in. dia	1
	175-021	PLATE, identification	1	81	**101-956	. BALL, steel; 1/4 in. dia	1
22	151-395	WASHER, flat	4	82	*105-520	. BEARING, needle	1
23	154-636	WASHER, flat	2	83	**172-423	. GLAND, male	1
24	159-346	WASHER, flat	1	84	**172-424	. GLAND, female	1
25	162-453	NIPPLE, short hex; 1/4-18 thd	1	85	**172-846	. PACKING, "v" leather	3
26	*216-xxx	SPRAY TIP, cylinder; Reverse-A-Clean III, standard (customer's choice, see 307-321)	1	86	**172-871	. PACKING, "v"; "Teflon"	1
27	164-055	WASHER, spacer	1	87	168-659	. BEARING, flanged sleeve	1
28	165-198	NIPPLE, reducing; 3/8 to 1/4 npt	1	88	169-604	. NUT, packing	1
29	176-384	LABEL, identification	1	89	**169-605	. GLAND, female	1
30	167-187	WASHER, flat	2	90	**169-606	. GLAND, male	1
31	168-521	WASHER, thrust	3	91	**169-607	. PACKING, "v" leather	3
32	168-531	GASKET, cover; gearcase	1	92	**169-608	. PACKING, "v"; "Teflon"	1
33	168-587	KNOB, shield	2	93	**170-109	. WASHER, flat; aluminum	4
34	210-606	SHELD ASSEMBLY includes items 22 29, 37-39, 45, 121, 129, 132, 134	1	94	**170-110	. WASHER, flat; aluminum	4
36	215-409	CONDUIT, flexible (for 226-400 only)	1	95	170-111	. PIN, ball stop	1
37	168-751	TRIM	1	96	170-112	. GUIDE, ball	1
38	168-758	DECAL, pressure control	1	97	170-259	. SPACER	1
39	168-759	DECAL, on-off switch	1	98	208-109	. CHECK VALVE ,incl. items 99-103	1
40	169-376	SLEEVE, handle	2	99	208-108	. VALVE HOUSING	1
41	169-377	HANDLE	1	100	101-874	. BALL, 1/2 in. dia. stainless steel	1
42	169-804	LABEL, patent	1	101	166-702	. O-RING, nitrile rubber	1
43	170-113	TUBE, suction	1	102	168-923	. SPRING	1
44	176-382	LABEL, identification; "EM 400"	1	103	168-935	. ADAPTER, housing	1
45	*172-981	LABEL, warning	1	104	208-576	. DISPLACEMENT ROD	1
47	170-240	HOSE, suction; 3/4 in. ID	1	105	208-371	. CYLINDER, displacement pump	1
48	*204-940	SWIVEL ASSY,1/4 npt(mx) incl. items 49-54	1	106	208-567	. HOUSING, piston valve	1
49	*150-516	. GLAND, male packing	1	107	208-568	. VALVE, intake	1
50	150-522	. SPRING, compression	1	108	*208-574	. DISPLACEMENT ROD ASSY Includes items 82, 104, 109	1
51	*157-894	. GLAND, female packing	1	109	100-846	. FITTING, lubrication	1
52	157-898	. ADAPTER, male; 1/4 npt	1	113	100-122	NIPPLE, pipe; short,1/2 npt (for 226-365 only)	1
53	*162-694	. PACKING, "v" leather	4	114	102-961	ELBOW, electrical; 90° (for 226-365 only)	2
54	204-978	. ADAPTER, swivel; 1/4 npt(f)	1	115	103-032	BOX, junction(for 226-365 only)	1
55	214-570	PAINT FILTER(see 307-273 for parts)	1	116	104-212	BUSHING, reducer; 3/4 to 1/2 npt electrical	2
56	206-994	THROAT SEAL LIQUID, 1 pint	1	118	208-159	CABLE, electrical(for 226-365 only)	1
57	214-638	PAINT HOSE ASSEMBLY, "Nylon"; static free; 1/4 in. ID, cpld 1/4 npsm swivel, 14 in.(355 mm)lg	1	119	171-001	LABEL, warning	1
62	207-909	ACTUATOR, switch	1	120	*104-343	SWITCH, rotary	1
63	207-912	CORD SET(for 226-400 & 226- 365)	1	121	176-250	LABEL, warning	1
64	207-960	MOTOR & COVER ASSY (for Series"A" 226-400 & 226-365)incl. gasket, item 32	1				
10	307-075						

REF NO.	PART NO.	DESCRIPTION	QTY	REF NO.	PART NO.	DESCRIPTION	QTY
123	100-718	LOCKWASHER, internal shakeproof; no. 10 (for 226-365 only)	1	131	216-001	KIT, spray tip	1
124	100-825	SCREW, rd hd mach; self tap, type "f"; 10-24 x 3/8" (for 226-365 only)	1	132	105-267	RIVET	4
125	102-276	TERMINAL, forked; No. 12-10 AWG (for 226-365 only)	1	133	104-811	CAP, hub	2
127	210-657	BALL VALVE ASSEMBLY, see 306-861 for parts	1	134	172-412	PLATE, ident(for 226-400 only)	1
128	155-665	UNION, adapter;3/8 npt(m x f)swivel	1		175-021	PLATE, ident(for 226-365 only)	1
129	176-370	BRACKET, hose	1				
130	214-701	HOSE, whip end;cpld 1/4 npt(m) x 1/4 npsm (f); 3/16 in. ID; static free; 36" (914 mm) long	1				

**Recommended "tool box" spare parts. Keep on hand to reduce down time.*

***Supplied in repair kit.*

Order parts by name and number. Always give the model number and series letter of the assembly for which you are ordering.

208-940 REPAIR PARTS KIT

Consists of the following:

REF NO.	QTY.	REF NO.	QTY.
80	1	89	1
81	1	90	1
83	1	91	3
84	1	92	1
85	3	93	4
86	1	94	4

Also includes one tube of sealant, part no. 102-969.

210-037 REPAIR PARTS KIT

For 208-569 Displacement Pump. Includes displacement rod (ref no. 108) and piston housing (ref no. 106).

SERVICE INFORMATION

No part number changes were made in this revision.

Changes and additions made in the copy on page 2 reflect the current National Spray Equipment Manufacturers Association (NSEMA) warnings/precautions.

Pressure Relief Procedure added to pages 3 and 5.


ACCESSORIES (Must be purchased separately)

SELECT-A-FAN (with tips)

3000 PSI (210 bar) MAXIMUM WORKING PRESSURE

206-310

Fits the fan pattern to both wide and narrow surfaces and clears tip stoppages.



GEAR OIL

208-230

1-quart (0.95 liter) lube oil for reduction gear drive. Gearcase capacity is 3 pints (1.4 liters).



THROAT SEAL LIQUID—TSL

Non-evaporation solvent for wet-cup.

206-995 1 quart (0.95 l) size

206-996 1 gallon (3.8 l) size



STATIC FREE NYLON HOSE

3000 PSI (210 bar) MAXIMUM WORKING PRESSURE

Part No.	ID	Length	Thd. Size
210-540	1/4''(6.4 mm)	25 ft(7.6 m)	1/4 npsm(f)
210-541	1/4''(6.4 mm)	50 ft(15.2 m)	1/4 npsm(f)
214-703	3/8''(9.5 mm)	25 ft(7.6 m)	3/8 npt(m)
214-705	3/8''(9.5 mm)	50 ft(15.2 m)	3/8 npt(m)
214-920	3/8''(9.5 mm)	100 ft(30.3 m)	3/8 npt (m)

(Use only in addition to standard 50 ft (1.5 m) hose).

Technical Data

Power requirements 120V, 60 HzAC,
1 phase, fused for 15 Amps
Electric motor 0.75 HP, 60 Cycle, 1725 RPM,
single phase with automatic reset
thermal overload and
explosion-proof switch. UL listed.
Electric cord No. 12 ga, 3 wire, use 12 ga. (minimum)
three wire extension cord
Maximum working pressure 2700 psi (185 bar)
Max. delivery (continuous duty) 0.44 gpm
(1.7 liter/min)
Cycles per minute 100
Outlet paint filter 60 mesh (250 micron)
stainless steel screen, reusable. Has 3/8 npt(f)
and 1/4 npt(f) outlets.
Wetted parts Viton®, Nitralloy, Nylon,
Rubber-impregnated Leather, Steel,
Teflon®, Stainless steel

Manual Change Summary

This manual has been reactivated since it provides necessary information for some repair kits which are still available for the EM400 sprayer.

The Graco Warranty and Disclaimers

WARRANTY

Graco warrants all equipment manufactured by it and bearing its name to be free from defects in material and workmanship on the date of sale by an authorized Graco distributor to the original purchaser for use. As purchaser's sole remedy for breach of this warranty, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment proven defective, with the exception of defects in parts on the drive train/gear box on EM and GM sprayers or power train on EH and GH sprayers, which will be repaired or replaced for twenty-four months from the date of sale for Gas-Hydraulic (GH) and Gas-Mechanical (GM) sprayers and for thirty-six months from the date of sale for Electric-Mechanical (EM), Electric-Hydraulic (EH), 390st and 490st sprayers. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for, any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility with Graco equipment of structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claim. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor and transportation.

DISCLAIMERS AND LIMITATIONS

The terms of this warranty constitute purchaser's sole and exclusive remedy and are in lieu of any other warranties (express or implied), **including warranty of merchantability or warranty of fitness for a particular purpose**, and of any non-contractual liabilities, including product liabilities, based on negligence or strict liability. Every form of liability for direct, special or consequential damages or loss is expressly excluded and denied. In no case shall Graco's liability exceed the amount of the purchase price. Any action for breach of warranty must be brought within two (2) years of the date of sale.

EQUIPMENT NOT COVERED BY GRACO WARRANTY

Graco makes no warranty, and disclaims all implied **warranties of merchantability and fitness for a particular purpose**, with respect to accessories, equipment, materials, or components sold but not manufactured by Graco. These items sold, but not manufactured by Graco (such as electric motor, switches, hose, etc.) are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

Sales Offices: Atlanta, Chicago, Dallas, Detroit, Los Angeles, Mt. Arlington (N.J.)
Foreign Offices: Canada; England; Korea; Switzerland; France; Germany; Hong Kong; Japan

GRACO INC. P.O. BOX 1441 MINNEAPOLIS, MN 55440-1441

PRINTED IN U.S.A. 307-075 7-72 Revised 10/93