

SmartWare™ Shot Dispense Kit

3A0294J

EN

Accurate metered dispensing kit for one component materials. Kits are compatible with Check-Mate® pumps and Dura-Flo™ pumps; both alone and as part of a supply system. For professional use only.

Not approved for use in European explosive atmosphere locations.



Important Safety Instructions
Read all warnings and instructions in this manual.
Save these instructions.

Kit 262370 for D200 and D60

For D200 3 inch dual post ram with NXT®2200 and larger air motors
For D60 3 inch dual post ram with NXT2200 and larger air motors

Kit 262371 for D200

For D200 3 inch dual post ram with NXT1800 and smaller air motors

Kit 262372 for D200S

For D200S 6 inch dual post ram with NXT2200 and larger air motors

Kit 262373 for S20


For S20 3 inch single post ram NXT2200 and larger air motors

Kit 262374 for S20

For S20 3 inch single post ram with NXT1800 and smaller air motors

Kit 262375 for pumps

For wall mount or floor stand pump with NXT2200 and larger air motors



Kit 262370 Shown



Contents

Related Manuals	3
Warnings	4
System Description	6
Typical Applications	6
Compatibility	6
Critical System Parameters	6
Theory of Operation	7
Component Identification	8
User Interface	10
Grounding	15
Installation	16
Location	16
Install Kits 262370 and 262372	16
Install Kit 262371	24
Install Kit 262373	30
Install Kit 262374	37
Install Kit 262375	43
Setup	50
Enter Password	50
Setup Pump	50
Pressure Relief Procedure	51
Prime/Purge	52
Set System Parameters	53
Set Units and Specific Gravity	53
Define Shot Size	54
Define Shot Sequence	55
Set Password	56
Select Pump	57
Enable/Disable Pump Functions	57
Enable/Disable Errors	58
Set Low/Empty Drum Error	58
Set Pump Runaway Error	59
Set Maintenance Parameters	59
Calibrate	60
Set Shot Accuracy Errors	61
Operation	62
Startup	62
Change Operation Mode	62
Select a Shot Number	64
Select a Shot Sequence	64
Dispense a Shot	65
Pause or Cancel a Shot	65
Errors	66
Errors with Light Tower	66
Clear Errors	66
Error Codes	67
Shutdown	70
Maintenance	71
Preventive Maintenance Schedule	71
Pump Maintenance	71
Supply System Maintenance	71
Cleaning Procedure	71
Upgrade Display Software	72
Clean User Interface Display	72
Troubleshooting	73
Repair	74
Replace Display	74
Electrical Schematics	75
Digital Output Schematic	75
Digital Input Schematic	76
Parts	77
Kits 262370 and 262372	77
Kit 262371	80
Kit 262373	83
Kit 262374	86
Kit 262375	89
Appendix A - User Interface Display	93
Display Overview	93
Display Details	93
Setup Mode Details	94
Run Mode Details	100
Appendix B - Tips	102
Calibration Procedure	102
Tips for Better Accuracy	102
Appendix C - Breakout Module (258999)	
Connections	103
Appendix D - Y-Adapter (124273) Connections	105
Accessories	106
Dimensions	106
Technical Data	106
Graco Standard Warranty	108
Graco Information	108

Related Manuals

Manuals are available at www.graco.com.

Component manuals in U.S. English:

Manual	Description
313526	Supply Systems Operation
313527	Supply Systems Repair-Parts
312376	Check-Mate® Pump Packages Instructions-Parts
312375	Check-Mate® Displacement Pumps Instructions-Parts
311827	Dura-Flo™ Displacement Pumps (145cc, 180cc, 220cc, 290cc) Instruc- tions-Parts
311825	Dura-Flo™ Displacement Pumps (430cc, 580cc) Instructions-Parts
311828	Dura-Flo™ Pump Packages (145cc, 180cc, 220cc, 290cc) Instructions-Parts
311826	Dura-Flo™ Pump Packages (430cc, 580cc) Instructions-Parts
312796	NXT® Air Motor (Mxxxxx models) Instructions-Parts
311238	NXT® Air Motor (Nxxxxx models) Instructions-Parts
3A1161	Foot Switch Kit Instructions-Parts
3A1162	Changeover Solenoid Kits Instructions-Parts

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.

WARNING

FIRE AND EXPLOSION HAZARD



Flammable fumes, such as solvent and paint fumes, in **work area** can ignite or explode. To help prevent fire and explosion:



- Use equipment only in well ventilated area.
- Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static arc).
- Keep work area free of debris, including solvent, rags and gasoline.
- Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present.
- Ground all equipment in the work area. See **Grounding** instructions.
- Use only grounded hoses.
- Hold gun firmly to side of grounded pail when triggering into pail.
- If there is static sparking or you feel a shock, **stop operation immediately**. Do not use equipment until you identify and correct the problem.
- Keep a working fire extinguisher in the work area.



SKIN INJECTION HAZARD

High-pressure fluid from dispensing device, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. **Get immediate surgical treatment.**



- Do not point dispensing device at anyone or at any part of the body.
- Do not put your hand over the fluid outlet.
- Do not stop or deflect leaks with your hand, body, glove, or rag.
- Follow the **Pressure Relief Procedure** when you stop dispensing and before cleaning, checking, or servicing equipment.
- Tighten all fluid connections before operating the equipment.
- Check hoses and couplings daily. Replace worn or damaged parts immediately.


WARNING
**EQUIPMENT MISUSE HAZARD**

Misuse can cause death or serious injury.



- Do not operate the unit when fatigued or under the influence of drugs or alcohol.
- Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See **Technical Data** in all equipment manuals.
- Use fluids and solvents that are compatible with equipment wetted parts. See Technical Data in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request MSDS from distributor or retailer.
- Do not leave the work area while equipment is energized or under pressure. Turn off all equipment and follow the **Pressure Relief Procedure** when equipment is not in use.
- Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only.
- Do not alter or modify equipment.
- Use equipment only for its intended purpose. Call your distributor for information.
- Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces.
- Do not kink or over bend hoses or use hoses to pull equipment.
- Keep children and animals away from work area.
- Comply with all applicable safety regulations.

**MOVING PARTS HAZARD**

Moving parts can pinch, cut or amputate fingers and other body parts.



- Keep clear of moving parts.
- Do not operate equipment with protective guards or covers removed.
- Pressurized equipment can start without warning. Before checking, moving, or servicing equipment, follow the **Pressure Relief Procedure** and disconnect all power sources.

**TOXIC FLUID OR FUMES HAZARD**

Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.

- Read MSDS's to know the specific hazards of the fluids you are using.
- Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.

**PERSONAL PROTECTIVE EQUIPMENT**

You must wear appropriate protective equipment when operating, servicing, or when in the operating area of the equipment to help protect you from serious injury, including eye injury, hearing loss, inhalation of toxic fumes, and burns. This equipment includes but is not limited to:

- Protective eyewear, and hearing protection.
- Respirators, protective clothing, and gloves as recommended by the fluid and solvent manufacturer

System Description

SmartWare shot dispense kits contain everything needed to convert a supply system or a pump system into a dosing system. The kits enable you to dose a pre-set amount of single-component material without using flowmeters or gear meters in the fluid stream. Instead, a sensor tracks the pump position so that the pump acts like a flowmeter. The amount dispensed is based on the pump size.

Typical Applications

- Cartridge fill
- Potting
- Encapsulating
- Mold making
- Batching or kitting

Compatibility

SmartWare shot dispense kits are compatible with J series NXT2200 and larger air motors, and D series NXT1800 and smaller air motors.

Critical System Parameters

If any of the following parameters are below the recommended value, see **Appendix B - Tips**, page 102, for tips for better accuracy.

Percentage (shot size/pump size) -



Percentage (overshoot/shot size) -
(function of valve time and pump speed)



Air motor pressure (PSI) -




Pump Speed (CPM) -



Theory of Operation

SmartWare shot dispense kits do not use flowmeters in the material path to measure the volume pumped. Instead the kit measures the volume pumped by using the following calculation. See FIG. 1 for a graphical representation.

Area of the pump piston x distance traveled (measured by the linear sensor) = volume pumped



Volume pumped = Area x Distance

FIG. 1: Volume Pumped

When the system receives the start signal, the dispense valve opens. Once the correct distance is traveled, which equates to the desired shot volume, the dispense valve closes and the pump stalls.

Just like a car does not stop the instant you push on the brake, the SmartWare kit pump does not stop pumping the instant it receives a stop signal. Therefore, during the time it takes for the dispense valve to physically close fluid is still being pumped; the volume pumped during this time is called the overshoot volume. See FIG. 2 for a graphical representation.





FIG. 2: Overshoot Volume

The SmartWare kit automatically compensates for overshoot by taking previous shots into consideration and then sending the stop signal early.

The pressure transducer compensates for pump travel during changeovers. Since only a few shots end in a changeover, this compensation will take longer than the basic overshoot compensation.

Component Identification

SmartWare Kit for D200 and D60 Rams



SmartWare Kit for S20 Rams




FIG. 3: Component Identification


Key:

- | | | | |
|----|------------------------------|----|--------------------------|
| A | Lift Ring | M | Platen Bleed Port |
| B | Air Motor | N | Platen |
| C* | Display Module | R | Ram |
| D | Air Controls | S* | Air Valve Assembly |
| E* | Air Solenoid (under shroud) | T* | Pressure Sensor Assembly |
| F* | Power Supply (under shroud) | U* | Linear Sensor Assembly |
| G* | Power Switch (within shroud) | | |
| H | Displacement Pump | | |
| J | Wet Cup | | |
| K | Fluid Outlet | | |
| L | Fluid Inlet | | |

* Included in SmartWare kits.

Component Identification (cont.)

SmartWare Kit for Wall Mount Pumps



SmartWare Kit for Floor Mount Pumps




FIG. 4: Component Identification

Key:

- | | | | |
|----|------------------------------|----|--------------------------|
| A | Lift Ring | K | Fluid Outlet |
| B | Air Motor | L | Fluid Inlet |
| C* | Display Module | P | Floor Mount Stand |
| D | Air Controls | T* | Pressure Sensor Assembly |
| E* | Air Solenoid (under shroud) | V* | Valve Assembly |
| F* | Power Supply (under shroud) | | |
| G* | Power Switch (within shroud) | | |
| H | Displacement Pump | | |
| J | Wet Cup | | |

* Included in SmartWare kits.

User Interface



FIG. 5: Display Module

NOTICE

To prevent damage to soft key buttons, do not press the buttons with sharp objects such as pens, plastic cards, or fingernails.

Table 1: Display Module Button Functions

Button	Function
Mode 	Select between Run and Setup modes.
Shot 	Start the present operation mode. Possible operation modes: shot mode, sequence mode, manual mode, and park mode
Arrows Up/Down 	Navigate up or down within a screen or to a new screen.
Soft Keys 	Soft keys activate the mode or action represented by the icon next to each soft key. See Table 2 for soft key icons and actions.
	Top Soft Key: Turn air solenoid on/off, pause shot, continue shot, edit data, accept edited data, or move right within a number field. Bottom Soft Key: Enter a screen, exit a screen, cancel a shot, or cancel edited data.

Table 2: Display Soft Key Icons

Icon	Function
Enter Screen 	In screens that have editable fields, press to access the fields and make changes.
Exit Screen 	In screens that have editable fields, press to exit edit mode.
Enter 	In screens that have editable fields, press to make data selections or to enter changes.
Right 	In screens that have editable fields, press to move to the right while in a field.
Cancel 	Cancel a selection or edited data. Returns to the original data. Cancel a shot when the shot is active.
Reset 	Reset the selected field or value.
Pause 	Pause the shot that is currently active.
Continue 	Continue the shot that is currently active.
Air On/Off 	Turn the air valve on and off.
Start Process 	Start the automatic calibration process.

User Interface Display

For details regarding the user interface display, see , page 92.

Display Screen Components

The following figures call out the navigational, status, and general informational components of each display screen.




FIG. 6: Setup Mode Screen Components





FIG. 7: Run Mode Screen Components


Setup Mode Screen Structure

The following figure demonstrates the flow of the setup mode screens beginning with setup screen 1. For details on each setup screen, see - **Setup Mode Details** on page 94.



Run Mode Screen Structure

There are only two run mode screens: run and information. However, there are four modes within the run screen: shot, sequence, manual and park. The following figure demonstrates the flow of the modes in the run screen beginning with power up screen 1. For details on each run mode, see - **Run Mode Details** on page 100.



Grounding

						
<p>The equipment must be grounded. Grounding reduces the risk of static and electric shock by providing an escape wire for the electrical current due to static build up or in the event of a short circuit. To reduce the risk of static sparking, ground the pump, the object being dispensed to, and all other dispensing equipment used or located in the dispensing area. All electrical wiring must be done by a qualified electrician and comply with local codes and regulations.</p>						

Supply System: ground the supply system as instructed in the grounding section of the Supply Systems Operation manual.

Pump: use a ground wire and clamp. Connect the ground wire to the ground stud on the air motor. Connect ground clamp to a true earth ground.




FIG. 8

Air and fluid hoses: use only electrically conductive hoses.

Air compressor: follow manufacturer's recommendations.

Dispense valve: ground through connection to a properly grounded fluid hose and pump. See dispense valve manual for instructions and guidelines.

Fluid supply container: follow local code.

Solvent pails used when flushing: follow local code. Use only conductive metal pails, placed on a grounded surface. Do not place the pail on a nonconductive surface, such as paper or cardboard, which interrupts grounding continuity.




FIG. 9

To maintain grounding continuity when flushing or relieving pressure: hold metal part of the dispense valve firmly to the side of a grounded metal pail, then trigger the valve.

Installation



The procedures in this section are specific to each shot dispense kit. Follow only the installation instructions for your particular kit.

For supply system or pump assembly installation instructions, refer to the Supply Systems Operation manual or your pump packages instructions-parts manual.

Location

NOTE: SmartWare Shot Dispense kits are not approved for use in explosive atmospheres.

Follow the location guidelines and instructions provided in the Supply Systems Operation manual or your pump packages instructions-parts manual before installing the shot dispense kit.

Install Kits 262370 and 262372

1. Close both shutoff valves on the air control panel.




FIG. 10: Close Shutoff Valves

2. Install the power supply bracket (33) to the ram post using four screws (29) and lock washers (28).





FIG. 11: Install Power Supply Bracket

3. Install the electronics subassembly (1) to the side of the power supply bracket using four screws (34). Also secure the bracket to the bottom of the air control bracket using two screws (29) and two lock washers (28).



r_262370_3A0294_7a

FIG. 12: Install Electronics Assembly

4. Install the light tower bracket (31) to the top air controls bracket using three screws (29) and lock washers (28).

r_262370_3A0294_8a





FIG. 13: Install Light Tower Bracket

5. Loosen two screws on the top air controls bracket. Install the display module bracket (2) using two screws (29) and lock washers (28) to secure it to the air controls bracket.



r_262370_3A0294_9a

FIG. 14: Install Display Module Bracket

6. Install the air valve subassembly (3).
 - a. Use two wrenches to remove the air hose, elbow fitting, and pressure gauge from the air controls.




FIG. 15: Air Control Assembly

- b. Remove the air motor slider valve label. See FIG. 15.

- c. Loosely install the air valve assembly (3). Grease the o-ring included with the air valve assembly. Install the o-ring and then finish installing the air valve assembly. Secure with screw.




FIG. 16: Install Air Valve Assembly

- d. Install the new air motor slider valve label that is included with the air valve assembly. See FIG. 15.
- e. Coat the gauge fitting with PTFE tape, and then reinstall. Use a wrench to tighten. See FIG. 15.
- f. Coat the swivel fitting (32) with PTFE tape. Install the fitting and air hose on the back of the new air valve assembly. Use two wrenches to tighten.




FIG. 17: Install Swivel Fitting

- 7. Install the linear sensor assembly (18) and the reed switch sensor (22).
 - a. *D200 systems only:* disconnect the air motor. Loosen nut below crossbar. Use wrench to hold thread adapter in place and loosen threaded rod above crossbar with another wrench.





FIG. 18: Disconnect Air Motor

- b. Remove the air motor top cover using a flat head screwdriver.



FIG. 19: Remove Air Motor Cover


- c. Use a wrench to remove the air motor lift ring. Then remove the lift ring adapter and both o-rings. Discard the adapter and both o-rings.



r_262373_3A0294_before_linear

FIG. 20: Remove Lift Ring Adapter and O-rings


- d. Place the linear sensor magnet (13) on the installation tool (27), and then insert the magnet down into the top of the motor shaft.
- e. Apply the supplied adhesive to the linear sensor assembly (18) threads. Install the linear sensor; torque to 30-36 ft-lbs (40.6-48.8 N•m). See FIG. 21.
- f. Place the new o-ring (20) on the lift ring adapter (19), and apply the supplied adhesive to the threads. See FIG. 21.



r_262373_3A0294_after_linear

FIG. 21: Install Linear Sensor

- g. Route the linear sensor cable through the lift ring adapter. Install the lift ring adapter; torque to 30-36 ft-lbs (40.6-48.8 N•m). See FIG. 21.
- h. Route the linear sensor cable through the hole on the lift ring adapter.
- i. Apply the supplied adhesive to the lift ring threads. Install the lift ring; torque to 30-36 ft-lbs (40.6-48.8 N•m). See FIG. 21.
- j. Remove the screw on the valve cover to remove the cover. See FIG. 22.
- k. Install the reed switch sensor (22). Secure with the 1 in. (25 mm) screw (24) and o-ring (23) provided. See FIG. 22.



r_262370_3A0294_16a

FIG. 22: Install Reed Switch Sensor

- l. Connect the strain relief guide (26) to the reed switch sensor. Use a wrench to tighten the 1/4-20 x 1/2 in. screw (25) on the strain relief guide and to secure it to the top plate of the air motor.




FIG. 23: Install Strain Relief Guide

- m. Use a zip tie to secure the reed switch sensor cable.
- n. Reinstall the valve cover, and tighten the nut. See FIG. 22.
- o. Remove the plug in the air motor cover. Route the linear sensor cables through the hole in the back of the cover. Snap the air motor cover back into place.




FIG. 24: Reinstall Air Motor Cover

- p. *D200 systems only:* reconnect the air motor. Install threaded rod through center hole in the crossbar. Install lock washers and nuts onto threaded rod, both above and below crossbar. Use wrench to hold lift ring adapter and tighten threaded rod into lift ring adapter using another wrench. Tighten nut below crossbar to 25 ft-lb (34 N•m) maximum. Tighten nut above crossbar to lock motor in place.




FIG. 25: Reconnect Air Motor

8. Install the pressure sensor on the pump bleed port. *D60 rams only:* If pump bleed valve is longer than the supplied, replace it with the supplied bleed valve (65).
 - a. Use a wrench to remove the pressure valve.





FIG. 26: Remove Pressure Valve

- b. Apply the supplied sealant to the adapter (36), the manifold (37), and the pressure valve. Install all three in the order listed. See FIG. 27.
- c. Disconnect sensor cable at PT1. Install the o-ring (41) and pressure sensor (38); use zip ties (35) to secure the cable to the ram and air hose.



r_262370_3A0294_20a

FIG. 27: Install Pressure Sensor

- 9. Install cables. Reference FIG. 29 for a diagram of cable connections and





FIG. 28: Breakout Module Connections

262370 and 262372 Cable Identification					
Description	Part	labels (relative to graphic)		Length in. (mm)	Connectors
Power	121226	PS1	None	16 (406.4)	
DB25	15T859	1(blue)	None	120 (3048)	
Pigtail	15X619	AM1	LS1/RS1	17 (431.8)	
Motor	15Y051	9(grey)	AM1	118 (2997.2)	
Solenoid Extension	122030	3(red)	Y1(yellow)	20 (508)	
Accessory Kit		5(grey)	Y2(orange)	20 (508)	
Air Solenoid	121806	AV	1(yellow)	20 (508)	
Fluid Solenoid		FV	2(yellow)	20 (508)	
Pressure Sensor Extension	16F562	6(blue)	PT1	80 (2032)	



ti18232a

Fig. 29: Cable Connections - D200S, D200, and D60 with Large NXT

10. Secure cables to the air hose using zip ties. Tighten all zip ties and then cut off the excess.
11. Bundle the cables and zip tie them close to the electronics bracket (1) so that they will fit under the electronics subassembly cover (4).
12. Install the electronics subassembly cover. Install the back cover first and hand tighten the screws to secure. Then install the front cover; hand tighten the screws to secure.




FIG. 30: Install Covers

13. Install the power supply cord (14).




FIG. 31: Install Power Supply Cord

14. Open the air shutoff valves on the air control assembly.

Install Kit 262371

1. Close both shutoff valves on the air control panel.




FIG. 32: Close Shutoff Valves

2. Install the power supply bracket (27) to the ram post using four screws (24) and lock washers (23).




FIG. 33: Install Power Supply Bracket

3. Install the electronics subassembly (1) to the side of the power supply bracket using four screws (28). Also secure the bracket to the bottom of the air control bracket using two screws (24) and two lock washers (23).




FIG. 34: Install Electronics Assembly

4. Install the light tower bracket (26) to the top air controls bracket using three screws (24) and lock washers (23).




FIG. 35: Install Light Tower Bracket

5. Loosen two screws on the top air controls bracket. Install the display module bracket (2) using two screws (24) and lock washers (23) to secure it to the air controls bracket.




FIG. 36: Install Display Module Bracket

6. Install the air valve subassembly (3).
 - a. Use two wrenches to remove the air hose, elbow fitting, and pressure gauge from the air controls.




FIG. 37: Air Control Assembly

- b. Remove the air motor slider valve label. See FIG. 15.

- c. Loosely install the air valve assembly (3). Grease the o-ring included with the air valve assembly. Install the o-ring and then finish installing the air valve assembly. Secure with screw.




FIG. 38: Install Air Valve Assembly

- d. Install the new air motor slider valve label that is included with the air valve assembly. See FIG. 37.
 - e. Coat the gauge fitting with PTFE tape, and then reinstall. Use a wrench to tighten. See FIG. 37.
 - f. Coat the elbow fitting with PTFE tape. Reinstall the fitting and air hose on the back of the new air valve assembly. Use two wrenches to tighten.




FIG. 39: Install Elbow Fitting

7. Snap the display (5) into the display bracket.

8. Install the linear sensor (17).
 - a. Remove the lift ring or plug.
 - b. Insert magnet and magnet holder into the top of the motor shaft using the magnet installation tool.
 - c. Install the linear sensor assembly into the top plate of the air motor.




FIG. 40: Install Linear Sensor

9. Install the reed switch assembly (20).
 - a. Remove the air line to the motor.
 - b. Adjust the air fitting to make room for the reed switch (20).
 - c. Install the reed switch (20) into the air valve as shown in FIG. 41, and secure with the screw (21).

NOTE: For air motor models M07xxx, M12xxx, and M18xxx, which have the large mufflers, remove the muffler before installing the reed switch. Reinstall the muffler after the reed switch is installed.




FIG. 41: Install Reed Switch

10. Install the pressure sensor on the pump bleed port.
 - a. Use a wrench to remove the pressure valve.




FIG. 42: Remove Pressure Valve

- b. Apply the supplied sealant to the adapter (30), the manifold (31), and the pressure valve. Install all three in the order listed. See FIG. 43.
- c. Disconnect pressure sensor at PT1.

- d. Install the o-ring (33) and pressure sensor (32); use zip ties (35) to secure the cable to the ram and air hose.




FIG. 43: Install Pressure Sensor

- 11. Install cables. Reference the table below and FIG. 46 for a diagram of cable connections.




FIG. 44: Breakout Module Connections





FIG. 45: Connect Linear Sensor/Reed Switch Cable

262371 Cable Identification					
Description	Part	Labels (relative to graphic)		Length in. (mm)	Connectors
Power Cable	121226	PS1	None	16 (406.4)	
DB25	15T859	1(blue)	None	120 (3048)	
Pigtail	16G589	AM1	LS1/RS1	52 (1320.8)	
Motor cable	15Y051	9(grey)	AM1	118 (2247.2)	
Solenoid Extension	122030	3(red)	Y1(yellow)	20 (508)	
Accessory Kit		5(grey)	Y2(orange)		
Air Solenoid	121806	AV	1(yellow)	20 (508)	
Fluid Solenoid		FV	2(yellow)		
Pressure Sensor Extension	16F562	6(blue)	PT1	80 (2032)	



tr18235a

FIG. 46: Cable Connections - D200 with Small NXT

- 12. Secure cables to the air hose using zip ties. Tighten all zip ties and then cut off the excess.
- 13. Bundle the cables and zip tie them close to the electronics bracket (1) so that they will fit under the electronics subassembly cover (4).
- 14. Install the electronics subassembly cover. Install the back cover first and hand tighten the screws to secure. Then install the front cover; hand tighten the screws to secure.




FIG. 47: Install Covers

- 15. Install the power supply cord (13).

r_262371_3A0294_40a




FIG. 48: Install Power Supply Cord

- 16. Open the air shutoff valves on the air control assembly.

Install Kit 262373

1. Close both shutoff valves on the air control panel.





FIG. 49: Close Shutoff Valves


2. Install the electronics subassembly (1) to the back of the bracket on the ram post using four screws (29) and washers (28).



r_262373_3A0294_28a

FIG. 50: Install Electronics Assembly

3. Install display bracket subassembly (2) to the bottom of the air motor using two screws (30) and two washers (31).



r_262373_3A0294_29a

FIG. 51: Install Display Bracket

4. Install the air valve subassembly (3).
 - a. Use two wrenches to remove the air hose, elbow fitting, and pressure gauge from the air controls.




FIG. 52: Air Controls

- b. Remove the air motor slider valve label.

- c. Loosely install the air valve assembly (3). Grease the o-ring included with the air valve assembly. Install the o-ring and then finish installing the air valve assembly. Secure with the two screws that are included with the air valve assembly.




FIG. 53: Install Air Valve Assembly

- d. Install the new air motor slider valve label that is included with the air valve assembly.
- e. Coat the gauge fitting and elbow fitting with PTFE tape, and then reinstall. Use a wrench to tighten.
- f. Install the fitting and air hose on the back of the new air valve assembly. Use two wrenches to tighten.




FIG. 54: Install Fitting and Air Hose

- 5. Snap the display (5) into the display bracket. See FIG. 51.
- 6. Install the linear sensor assembly (18) and the reed switch sensor (22).
 - a. Remove the air motor top cover using a flat head screwdriver.



FIG. 55: Remove Air Motor Cover

- b. Use a wrench to remove the air motor lift ring. Then remove the lift ring adapter and both o-rings. Discard the adapter and both o-rings.




FIG. 56: Remove Lift Ring Adapter and O-rings

- c. Place the linear sensor magnet (13) on the installation tool (27), and then insert the magnet down into the top of the motor shaft.
- d. Apply the supplied adhesive to the linear sensor assembly (18) threads. Install the linear sensor; torque to 30-36 ft-lbs (40.6-48.8 N•m). See FIG. 57.

- e. Place the o-ring (20) on the lift ring adapter (19), and apply the supplied adhesive to the threads. See FIG. 57.




FIG. 57: Install Linear Sensor

- f. Route the linear sensor cable through the lift ring adapter. Install the lift ring adapter; torque to 30-36 ft-lbs (40.6-48.8 N•m). See FIG. 57.
- g. Route the linear sensor cable through the hole on the lift ring adapter.
- h. Apply the supplied adhesive to the lift ring threads. Install the lift ring; torque to 30-36 ft-lbs (40.6-48.8 N•m). See FIG. 57.
- i. Remove the screw on the valve cover to remove the cover. See FIG. 58.
- j. Install the reed switch sensor (22). Secure with the 1 in. (25 mm) screw (24) and o-ring (23) provided. See FIG. 58.

vided. See FIG. 58.




FIG. 58: Install Reed Switch Sensor

- k. Connect the strain relief guide (26) to the reed switch sensor. Use a wrench to tighten the 1/2 in. screw (25) on the strain relief guide and to secure it to the top plate of the air motor.




FIG. 59: Install Strain Relief Guide

- l. Use a zip tie to secure the reed switch sensor cable.
- m. Reinstall the valve cover, and tighten the nut. See FIG. 58.
- n. Remove round plug and route the linear sensor cable through the opening in the back of the cover. Snap the air motor cover back into place.

7. Install the pressure sensor on the pump bleed port.
 - a. Use a wrench to remove the pressure valve.




FIG. 60: Remove Pressure Valve

- b. Apply the supplied sealant to the adapter (33), the manifold (34), and the pressure valve. Install all three in the order listed. See FIG. 61.
 - c. Disconnect pressure sensor at PT1.
 - d. Install the o-ring (38) and pressure sensor (35); use zip ties (32) to secure the cable to the ram and air hose.




FIG. 61: Install Pressure Sensor

8. Install cables. Reference the cable identification table on the next page and FIG. 63 for a diagram of cable connections.










FIG. 62: Breakout Module Connections

262373 Cable Identification					
Description	Part	Labels (relative to graphic)		Length in. (mm)	Connectors
Power Cable	122487	PS1	None	60 (1524)	
DB25	15T859	1(blue)	None	120 (3048)	
Pigtail	16G589	AM1	LS1/RS1	52 (1320.8)	
Motor cable	15Y051	9(grey)	AM1	118 (2997.2)	
Air Solenoid Extension	122030	1(yellow)	SX1	20 (508)	
Solenoid Extension		3(red)	Y1(yellow)		
Accessory Kit cable		5(grey)	Y2(orange)		
Air Solenoid	121806	AV	SX1	20 (508)	
Fluid Solenoid		FV	2(yellow)		
Pressure Sensor Extension	16F562	6(blue)	PT1	80 (2032)	



ti18234a

Fig. 63: Cable Connections - S20 with Large NXT

9. Secure cables to the air hose using zip ties. Tighten all zip ties and then cut off the excess.
10. Bundle the cables and zip tie them close to the electronics subassembly bracket (1) so that they will fit under the electronics subassembly cover (4).
11. Install the electronics subassembly cover; hand tighten the screws to secure.




Fig. 64: Install Electronics Cover

12. Install the power supply cord (14).




Fig. 65: Install Power Supply Cord

13. Open the air shutoff valves on the air control assembly.

Install Kit 262374

1. Close both shutoff valves on the air control panel.




Fig. 66: Close Shutoff Valves

2. Install the electronics subassembly (1) to the back of the bracket on the ram post using four screws (23) and washers (22).





Fig. 67: Install Electronics Assembly

3. Install display bracket subassembly (2) to the bottom of the air motor using two screws (25) and two washers (24).



r_262374_3A0294_66a

Fig. 68: Install Display Bracket

4. Install the air valve subassembly (3).
 - a. Use two wrenches to remove the air hose, elbow fitting, and pressure gauge from the air controls.






Fig. 69: Air Valve

- b. Remove the air motor slider valve label.


- c. Loosely install the air valve assembly (3) Remove air pressure gauge if necessary. Grease the o-ring included with the air valve assembly. Install the o-ring and then finish installing the air valve assembly. Secure with the two screws that are included with the air valve assembly.



- d. Install the new air motor slider valve label that is included with the air valve assembly.
- e. If removed, coat the gauge fitting and elbow fitting with PTFE tape, and then reinstall. Use a wrench to tighten.
- f. Install the fitting and air hose on the back of the new air valve assembly. Use two wrenches to tighten.



5. Install the linear sensor (17).
 - a. Remove the lift ring or plug.
 - b. Insert magnet holder and magnet into the top of the motor shaft using the magnet installation tool.
 - c. Install the linear sensor assembly into the top plate of the air motor.



6. Install the reed switch assembly (19).
 - a. Remove the air line to the motor.
 - b. Adjust the air fitting to make room for the reed switch (19).
 - c. Install the reed switch into the air valve as shown in FIG. 41, and secure with the screw (20).

NOTE: For air motor models M07xxx, M12xxx, and M18xxx, which have the large mufflers, remove the muffler before installing the reed switch. Reinstall the muffler after the reed switch is installed.




FIG. 73: Install Reed Switch

7. Install the pressure sensor on the pump bleed port.
 - a. Use a wrench to remove the pressure valve.




FIG. 74: Remove Pressure Valve

- b. Apply the supplied sealant to the adapter (27), the manifold (28), and the pressure valve. Install all three in the order listed. See FIG. 75.
 - c. Disconnect pressure sensor at PT1.

- d. Install the o-ring (33) and pressure sensor (29); use zip ties (26) to secure the cable to the ram and air hose.




FIG. 75: Install Pressure Sensor

8. Install cables. Reference the cable identification table on the next page and FIG. 77 for a diagram of cable connections.









FIG. 76: Breakout Module Connections

262374 Cable Identification					
Description	Part	Labels (relative to graphic)		Length in. (mm)	Connectors
Power Cable	122487	PS1	None	60 (1524)	
DB25	15T859	1(blue)	None	120 (3048)	
Pigtail	16G589	AM1	LS1/RS1	52(1320.8)	
Motor cable	15Y051	9(grey)	AM1	118 (2997.2)	
Air Solenoid Extension	122030	3(red)	Y1(yellow)	20 (508)	
Accessory Kit		5(grey)	Y2(orange)		
Air Solenoid	121806	AV	SX1	20 (508)	
Fluid Solenoid		FV	2(yellow)		
Pressure Sensor Extension	16F562	6(blue)	PT1	80 (2032)	



ti18236a

Fig. 77: Cable Connections - S20 with Small NXT

9. Route all cables out the top of the electrical enclosure. Make sure there is enough slack to extend ram to full height. Secure cables to the air hose using zip ties. Tighten all zip ties and then cut off the excess.
10. Bundle the excess cable length and zip tie them close to the electronics bracket (1) so that they will fit under the electronics subassembly cover (4).
11. Install the electronics subassembly cover. Install the back cover first and hand tighten the screws to secure. Then install the cover and hand tighten the screws to secure.





Fig. 78: Install Cover

12. Install the power supply cord (12).



r_262373_3A0294_42a

Fig. 79: Install Power Supply Cord

13. Open the air shutoff valves on the air control assembly.

Install Kit 262375

1. Shut off the air supply to the system.
2. *Floor stand kit only:* Install the control mount bracket (39) to the pump using two screws (36), and washers (37 and 40).




FIG. 80: Install Control Mount Bracket

3. Install the adapter bracket (35) to the wall mount bracket or the control mount bracket using two screws (36), washers (37), and nuts (38).




FIG. 81: Install Adapter Bracket

4. Install the electronics subassembly (1) to the side of the adapter bracket using four screws (30) and washers (29).




FIG. 82: Install Electronics Assembly

5. Install the display bracket (2) to the electronics subassembly using four screws (30) and washers (29).




FIG. 83: Install Display Bracket


6. Snap the display (5) into the display bracket.
7. Install the linear sensor assembly (18) and the reed switch sensor (22).
 - a. Remove the air motor top cover using a flat head screwdriver.



ti8218b

FIG. 84: Remove Air Motor Cover

- b. Use a wrench to remove the air motor lift ring. Then remove the lift ring adapter and both o-rings. Discard the adapter and both o-rings.




r_262373_3A0294_before_linear

FIG. 85: Remove Lift Ring Adapter and O-rings

- c. Place the linear sensor magnet (13) on the installation tool (27), and then insert the magnet down into the top of the motor shaft.
 - d. Apply the supplied adhesive to the linear sensor assembly (18) threads. Install the linear sensor; torque to 30-36 ft-lbs (40.6-48.8 N•m). See FIG. 86.

- e. Place the new o-ring (20) on the lift ring adapter (19), and apply the supplied adhesive to the threads. See FIG. 86.



r_262373_3A0294_after_linear

FIG. 86: Install Linear Sensor

- f. Route the linear sensor cable through the lift ring adapter. Install the lift ring adapter; torque to 30-36 ft-lbs (40.6-48.8 N•m). See FIG. 86
 - g. Route the linear sensor cable through the hole on the lift ring adapter.
 - h. Apply the supplied adhesive to the lift ring. Install the lift ring; torque to 30-36 ft-lbs (40.6-48.8 N•m). See FIG. 86.
 - i. Remove the screw on the valve cover to remove the cover. See FIG. 87.

- j. Install the reed switch sensor (23). Secure with the 1 in. (255 mm) screw (25) and o-ring (24) provided.




FIG. 87: Install Reed Switch Sensor

- k. Connect the strain relief guide (27) to the reed switch sensor. Use a wrench to tighten the 1/2 in. screw (26) on the strain relief guide and to secure it to the top plate of the air motor.




FIG. 88: Install Strain Relief Guide

- l. Use a zip tie to secure the reed switch sensor cable.
- m. Reinstall the valve cover, and tighten the nut.

- n. Remove the plug in the air motor cover. Route the linear sensor cables through the hole in the back of the cover. Snap the air motor cover back into place.





FIG. 89: Remove Plug

- 8. *Without integrated air controls only:* Install valve subassembly (6) and fittings.
 - a. Apply the supplied adhesive to the adapter fitting (31). Screw the fitting into bottom of the air valve so that the fitting points away from the display module.
 - b. Apply the supplied adhesive to the pipe nipple fitting (32) and the pipe swivel fitting (33). Screw both fittings onto the valve assembly as shown.




r_262375_3A0294_34a

FIG. 90: Install Valve Assembly (without air controls)

- c. Screw entire assembly onto the adapter fitting. Use two wrenches to tighten.

9. *With integrated air controls only:* Install valve assembly (6) and fittings.
 - a. Apply the supplied adhesive to the pipe nipple fitting (32). Screw the fitting into the air control assembly.
 - b. Apply the supplied adhesive to the adapter fitting (31) and the pipe swivel fitting (33). Screw both fittings onto the valve assembly as shown.



r_262375_3A0294_35a

FIG. 91: Install Valve Assembly (with air controls)

- c. Screw the entire assembly onto the pipe nipple fitting. Use two wrenches to tighten.
10. Install cables. Reference the cable identification table below and FIG. 93 for a diagram of cable connections.





FIG. 92: Breakout Module Connections

262375 Cable Identification					
Description	Part	Labels (relative to graphic)		Length in. (mm)	Connectors
Power Cable	121226	PS1	None	16 (406.4)	
DB25	15T859	1(blue)	None	120 (3048)	
Pigtail	15X619	AM1	LS1/RS1	17 (431.8)	
Motor cable	15Y051	9(grey)	AM1	118 (2997.2)	
Solenoid Extension	122030	3(red)	Y1(yellow)	20 (508)	
Accessory Kit		5(grey)	Y2(orange)		
Air Solenoid	121806	AV	1(yellow)	20 (508)	
Fluid Solenoid		FV	2(yellow)		
Pressure Sensor Extension	-	-	-	-	-



ti18233a

Fig. 93: Cable Connections - Wall Mount or Floor Stand Pumps with Large NXT

11. Install the pressure sensor on the pump bleed port.
 - a. Use a wrench to remove the pressure valve.




FIG. 94: Remove Pressure Valve

- b. Apply the supplied sealant to the adapter (42), the manifold (43), and the pressure valve. Install all three in the order listed.





FIG. 95: Install Pressure Sensor

- c. Disconnect pressure sensor at PT1.
 - d. Install the o-ring (45) and pressure sensor (44). See FIG. 95.

12. Bundle the cables and zip tie them close to the electronics bracket (1) so that they will fit under the electronics subassembly cover (4).

13. Install the air lines (34).

- a. Connect the air lines to the valve subassembly (6) as shown.



r_262375_3A0294_41a

FIG. 96: Install Air Lines - Air Valve

- b. Run the air lines between the adapter bracket and connect them to the top port and bottom port of the solenoid valve assembly as shown. See FIG. 96 and FIG. 97.




FIG. 97: Install Air Lines - Solenoid Valve

- c. Zip tie both air lines to the pump tie rod.

14. Install the electronics subassembly cover (4); hand tighten the screws to secure.





FIG. 98: Install Cover

15. Install the power supply cord (14).



Install Power Supply Cord

FIG. 99: Install Power Supply Cord

16. Turn on air supply to the system.

Setup



NOTE: For setup procedures specific your supply system or pump assembly, refer to the Supply Systems Operation manual or your specific pump package instructions-parts manual.

Enter Password

If a password is enabled, the password entry screen automatically opens when you change to setup mode. Enter the password to access setup mode.

Setup Pump

1. Follow the **Installation** guidelines on page 16.
2. Follow the **Installation** procedure for your particular shot dispense kit. The procedures start on page 16.
3. Fill displacement pump wet cup 2/3 full with Graco Throat Seal Liquid (TSL™).





Fig. 100: Fill Wet Cup

4. Attach electrically conductive fluid hose to pump outlet and tighten.
5. Attach other end of electrically conductive fluid hose to dispense valve and tighten.
6. Shut off the air valve by pressing the Air On/Off soft key on the display module.
7. Back off the air regulators to their full counterclockwise position and close all shutoff valves for the rams.

8. Connect the air line from the air source to the system air inlet. See FIG. 101. Refer to your specific pump manual to determine the correct air supply flow requirements. Connect an air supply hose that is capable of meeting the required flow to the air motor air inlet.

NOTE: Quick disconnects restrict flow for NXT2200 and larger air motors.

NXT2200 and Larger Air Motors



NXT1800 and Smaller Air Motors




Fig. 101: Connect to Air Inlet

9. Connect air supply and electrical cable to the dispense valve and solenoid valve. See the dispense valve manual for instructions.
10. Flush and/or prime before using. See **Prime/Purge**, page 52, for instructions.

Pressure Relief Procedure

						
Trapped air can cause the pump to cycle unexpectedly, which could result in serious injury from splashing or moving parts						

1. Lock the gun/valve trigger.
2. Change to manual mode in the run screen. See **Change Operation Mode**, page 62.
3. Shut off the air supply to the system.
4. Shut off the air valve by pressing the Air On/Off soft key on the display module.
5. Close the manual air valve.
6. Unlock the gun/valve trigger.
7. Hold a metal part of the gun/valve firmly to the side of a grounded metal pail, and press  or step on the foot switch.
8. Lock the gun/valve trigger.
9. Open the material line drain valve and the pump bleeder valve. Have a container ready to catch the drainage.





FIG. 102: Drain Material

10. Leave the pump bleeder valve open until you are ready to spray/dispense again.
11. If you suspect that the spray tip/nozzle or hose is completely clogged, or that pressure has not been fully relieved after following the previous steps, very slowly loosen the tip guard retaining nut hose end coupling and relieve pressure gradually; then loosen completely. Now clear the tip/nozzle or hose.

Prime/Purge



1. Follow **Pressure Relief Procedure** on page 51.
2. *Priming only:* replace pail of material if necessary.
3. Remove the spray tip and tip guard from gun or remove the nozzle from the dispense valve.
4. *Flushing only:* If desired, remove built-in fluid filter (present on some models). Reinstall filter cap after removing fluid filter.
5. Place pump in material (if priming) or solvent (if flushing).
6. Turn air regulator to 0 psi.
7. Open the manual shutoff valve(s).
8. Perform a manual purge.
 - a. Change to manual mode in the run screen. See **Change Operation Mode**, page 62.
 - b. Place a drain tube in a grounded waste pail. Open drain/purge valve slightly by rotating counterclockwise.

9. Prime or purge hose and gun/valve.
 - a. If necessary, change to manual mode in the run screen. See **Change Operation Mode**, page 62.
 - b. Hold a metal part of the gun/valve firmly to the side of a grounded metal pail.



- c. Press  and hold or step on the foot switch (purchase separately) until all air in the hose is purged
10. If priming, the system is now ready to dispense; go to **Dispense a Shot**, page 65.

If flushing, follow the **Operation** on page 62; leave the solvent in and store the equipment.




FIG. 103: Flush with Solvent

- c. Increase pressure on the air regulator until the pump begins to move. Run the pump until no air is released from the drain/purge valve or until clean solvent flows from the drain tube. Close drain/purge valve by rotating clockwise. The pump will stall.

Set System Parameters

NOTE: Refer to **Appendix B - Tips**, page 102, for setup guidelines and tips.

Set Units and Specific Gravity

1. Navigate to setup screen 1.



2. Press  to access fields to make changes.
3. Press   to navigate to the units of measure fields.
4. Press  to open the first drop-down box. Press   to select the desired units.
5. Press  to save selection.
6. Press  to navigate to the next drop-down box, and perform the same two steps.


7. Press  to navigate to the specific gravity (SG) field.

NOTE: If the specific gravity is unknown, use the calibration routine to enter it automatically. See **Calibrate** on page 60 for calibration instructions.

8. Press  and   to increment or decrement to the specific gravity of the material being dispensed.
9. Press  to save the selection.
10. Press  to exit edit mode.

Define Shot Size

Up to 25 shots (1 – 25) can be defined in the setup shot screen.



To define a shot size:

1. Navigate to setup screen 2.
2. Press  to access fields to make changes.
3. Press   to navigate to the shot number field.
4. Press   to scroll through the 25 shot numbers.
5. Press  to select the desired shot number.

6. Press  to navigate to the fluid weight field.
7. Press  and   to increment or decrement to the desired shot size.
8. Press  to accept the shot size.
9. Define another shot size.
 - a. Press  to move to the shot number field.
 - b. Repeat steps 4 through 8 to define the next shot size.
10. Press  to exit edit mode.


Define Shot Sequence

Up to 5 sequences (A – E) can be programmed. Each sequence can have up to 14 shot positions and each shot position can be one of the possible 25 shots.

NOTE: Only shots that are already defined can be added to a shot sequence.

To edit a shot sequence:


1. Navigate to setup screen 3.



2. Press to access the fields.
3. Press to navigate to the shot sequence field. Press to select the field.
4. Press to scroll through the shot sequences.
5. Press to select the desired shot sequence.
6. Press to navigate to the shot positions.

7. Press and to navigate through each shot position and to select shot numbers.

NOTE: When a shot number is selected the shot volume box will display.




8. Press to select the desired shot.
9. Once all shot positions and shot numbers are configured for the shot sequence, press to exit edit mode.

Set Password

NOTE: When the password is “00000,” the setup screens can be accessed without entering a password.

1. Navigate to setup screen 4.



2. Press  to access fields to make changes.
3. Press   to navigate to the first password field.
4. Press  and   to increment or decrement to the desired digits of the password.
5. Press  to enter the password.
6. Press  to navigate to the next password field. Follow steps 4-5 to enter and confirm the password.
7. Press  to exit edit mode.

Disable Password

To disable the password, follow **Set Password**, page 56, to change the password to “00000.”

Reset Password

If the password is forgotten, it can be reset without losing the current settings or shot data.

1. Disconnect power to the user interface.
2. Reconnect power to the user interface.
3. When the power up screen appears, immediately press and hold both the top soft key and the  for six seconds. The password automatically resets to “00000.”
4. Follow the **Set Password**, page 56, instructions to set the password if desired.

Select Pump

1. Navigate to setup screen 4, if necessary.




2. Press  to access fields to make changes.
3. Press   to navigate to the pump selection field.
4. Press   to scroll through the pump options.
5. Press  to select the correct pump size for the system.
6. Press  to exit edit mode.

Enable/Disable Pump Functions

See **Setup Screen 5 - Enable/Disable Pump Functions**, page 96, for a description of each pump function.

1. Navigate to setup screen 5.




2. Press  to access fields to make changes.
3. Press   to navigate to each pump function field.
4. Press  to enable or disable each pump function.
5. Press  to exit edit mode.

Enable/Disable Errors

See , page 92, for an explanation of each error function.

1. Navigate to setup screen 6.



2. Press  to access fields to make changes.
3. Press   to navigate to each error field.
4. Press  to enable or disable each error code.
5. Press  to exit edit mode.

Set Low/Empty Drum Error

Follow the **Enable/Disable Errors** steps to set either the empty drum alarm or low drum advisory.

Refer to the **Errors** section on page 66 for more information on alarms and advisories, and how to clear an alarm or advisory.


The low/empty drum error code **L1** is used for the empty drum alarm  , and error code **L2** is used for the low drum advisory .

When **L1** is enabled the drum empty alarm is enabled and  displays. The alarm icon  displays if an empty drum alarm occurs.

When **L2** is enabled the low drum advisory is enabled and  displays. The advisory icon  displays if a low drum advisory occurs.

Set Pump Runaway Error

1. Navigate to setup screen 7.




2. Press to access fields to make changes.
3. Press to navigate to the pump runaway cycle rate field.
4. Press and to increment or decrement to the desired cycle rate. Graco recommends setting the cycle rate to 60 or less. Choose a value that is just above the maximum cycle rate of the application.
5. Press to save the set cycle rate.
6. Press to exit edit mode.

Set Maintenance Parameters

Set the amounts of material moved through the pump and dosing valve that will result in a maintenance advisory or alarm.

1. Navigate to setup screen 8.



Maintenance Setpoint

Total Volume Dispensed


2. Press to access fields to make changes.
3. Press to navigate to the maintenance setpoint field.
4. Press and to increment or decrement to the desired amount of material that will result in an advisory when the total volume dispensed exceeds the maintenance setpoint.
5. Press to save this amount.
6. If an advisory occurs, press to navigate to the total volume dispensed field. Clear the field to reset the advisory.
7. Press to exit edit mode.

Calibrate


The actual weight/volume of material dispensed may vary slightly from the displayed weight/volume. Use the following procedure to calibrate the system as needed.

Calibration values can be set manually. However, it is recommended to run the calibration procedure when needed.

1. Navigate to setup screen 10.




2. Press  to start the overshoot calibration process. The icons will display.




3. Place a container that is at least as large as the pump volume under the dispense valve.

4. Hold down  or the foot switch to run the system. The manual mode icon will flash. The pump will go through the first changeover, stop to measure the overshoot, then complete the second changeover and stop.

5. Release the start button or foot switch. The hour glass icon is updated and the shot mode icon will display.



6. Remove any excess material from the dispense valve, if necessary.
7. Empty the container, if necessary. Set the scale to zero.
8. Press  to dispense a shot into the container. When the shot completes the shot icon will disappear and the first digit of the weight field will be highlighted.



9. Remove any excess material from the dispense valve, if necessary. Include this material in the weight of the shot.
10. Weigh the shot on the scale.
11. Press  and   to enter the shot weight in the weight field.

NOTE: The weight must be entered in GRAMS.

12. Set the scale to zero.
13. Perform steps 8-12 three more times.

After you have entered the fourth shot weight in the weight field, the material delta top and bottom fields (calibration values) will automatically update and the spe-


cific weight **SG** on setup screen 1 will update. The calibration procedure is now complete.

Set Shot Accuracy Errors

Use this screen to set the shot volume deviation from the shot setpoint that will cause an advisory or alarm.

NOTE: If either the advisory field or alarm field is set to zero, the error is disabled.

1. Navigate to setup screen 11.



2. Press  to access fields to make changes.
3. Press   to navigate to the advisory field.
4. Press  to enter the advisory field.
5. Press  and   to set the value in the advisory field.
6. Press  to enter the value.
7. Follow steps 4 through 7 for the alarm field.
8. Press  to exit edit mode.

Operation

NOTE: The shot dispense kit controller modifies pump packages and supply systems. However, the operation procedures from the pump packages instructions-parts manuals and the Supply Systems Operation manual still apply.

Startup


1. Refer to your Supply System Operation manual or pump package instruction-parts manual for system startup instructions.
2. Turn on the user interface display and wait for the power up screen to complete and the run screen to appear.

Change Operation Mode

There are four operation modes: shot mode, sequence mode, manual mode, and park mode. This section explains each operation mode. See , page 92, for more details about the operation modes and the run screens.

Use the following instructions to change between operation modes.

1. Press  to access fields to make changes.
2. Press   to navigate to the operation mode field.




3. Press  to enter operation mode field.

4. Press   to scroll through the operation mode choices.
5. Press  to select the desired operation mode.
6. Press  to exit edit mode.

Shot Mode


Shot mode dispenses a specific volume or weight of material. When the shot completes the user can start another identical shot. Shots first need to be defined in setup screen 1. Up to 25 shots can be programmed. See **Define Shot Size**, page 54.



Sequence Mode


Sequence mode dispenses a sequence of shots in a specific order. Sequences first need to be defined in setup screen 3. Up to five (A - E) sequences can be programmed. See **Define Shot Sequence**, page 55.

After the first shot in a sequence completes, the next shot can start. After all of the shots in a sequence have completed, the sequence will start over at the first shot.



Park Mode


Park mode dispenses material until the pump reaches the bottom of its stroke. Then the system will disable.



Manual Mode

Manual mode runs the pump when  is pressed or when the dispense valve is triggered. Use manual mode to determine how much material is needed to fill a container, prime the system, flush the system, or verify system operation.

NOTE: All errors are ignored in this mode.




Select a Shot Number

Shots are defined in setup screen 2. See **Define Shot Size**, page 54, for instructions.

1. Change operation mode to shot, if necessary. See **Change Operation Mode**, page 62, for instructions.

2. Press   to navigate to the shot number field .




3. Press  to enter the shot number field.
4. Press   to increment or decrement to the desired shot number.
5. Press  to select the desired shot number.
6. Dispense the shot. See **Dispense a Shot**, page 65. The actual volume dispensed will display under the desired dispense volume.
7. Follow steps 2 through 6 to select and dispense another shot.
8. When you are finished selecting and dispensing shots press  to exit edit mode.

Select a Shot Sequence

Sequences are defined in setup screen 3. See **Define Shot Sequence**, page 55, for instructions.

1. Change operation mode to sequence, if necessary. See **Change Operation Mode**, page 62, for instructions.

2. Press   to navigate to the current mode field, which should be set to shot sequence .




3. Press  to enter the field.
4. Press   to scroll through the available shot sequences.

NOTE: All defined sequences (A-E) can be selected from the run screen. Any sequences that are not defined can not be selected from the run screen. Sequences are defined in Setup Mode; see **Define Shot Sequence** on page 55.

5. Press  to select the desired shot sequence.

- Dispense the shot sequence. See **Dispense a Shot**, page 65. The actual volume dispensed will display under the desired dispense volume.




- Follow steps 2 through 6 to select and dispense another shot sequence.
- When you are finished selecting and dispensing shot sequences press  to exit edit mode.

Dispense a Shot



- Ensure the air is on.
- Follow **Select a Shot Number**, page 64, or **Select a Shot Sequence**, page 64.

- Press  or step on the foot switch (purchase separately) to begin dispensing. The shot progress bar will display on the screen during the shot.




Pause or Cancel a Shot

When a shot is in progress, press , , or step on the foot switch to pause the shot. Press  to cancel the shot. When the system is paused, press , , or the foot switch to continue dispensing.

NOTE: The dispense will automatically stop once the target shot size has been dispensed.

Errors

From the Run screen, press   to navigate to the Information screen. The Information screen displays the current alarm or advisory, and the amount of remaining material in the drum.



Alarms, indicated by , require immediate attention; therefore, the system disables and the Information screen automatically displays. Deviations, indicated by , require attention, but not immediately. Advisories, indicated by , do not require attention. Therefore, if a deviation or advisory occur, the system continues running and  or  displays next to the operation mode field.

Errors with Light Tower

If you have a system that uses a light tower, errors are indicated by the light tower as well as on the display. The following table explains the error type that is associated with the particular light tower LED.

Light Tower LED	Description
No LED	No errors exist
Yellow Solid	An advisory exists 
Red Flashing	A deviation exists 
Red Solid	An alarm exists and the system shuts down 

Clear Errors

To clear an error:

1. Press  to access the fields.
2. Press   to navigate to the error code reset field.
3. Highlight the error code. Press  to clear the error code.
4. Press  to exit edit mode

Error Codes

Code	Icon	Code Name	Light Tower Code	Cause	Solution
Alarms					
B1		Shot Volume Less than Error Setpoint	Red Solid	Shot volume is less than the error setpoint.	Increase the error setpoint on Setup screen 11. Increase shot consistency by decreasing speed and valve shutoff time, and increasing material back-pressure.
B4		Shot Volume Greater than Error Setpoint	Red Solid	Shot volume is greater than the error setpoint.	Increase the error setpoint on Setup screen 11. Increase shot consistency by decreasing speed and valve shutoff time, and increasing material back-pressure.
DA		Pump Runaway	Red Solid	Pump is running faster than set runaway limit because of high air pressure, high material output, or exhausted material supply.	Decrease air pressure.
					Decrease material output.
					Replace material supply drum.
DD		Pump Cavitation	Red Solid	Pump is diving down more than a half a stroke because of exhausted material supply.	Replace material supply drum.
DJ		Linear Sensor	Red Solid	Linear sensor is not connected or it is reading outside maximum values.	Check linear sensor wiring and replace if necessary.
					Check linear sensor and replace if necessary.
DK		Reed Switch	Red Solid	Multiple up strokes without a down stroke, or multiple down strokes without an up stroke caused by damaged or disconnected reed switch.	Reconnect reed switch wiring.
					Replace reed switch.
DL		Top Changeover Solenoid	Red Solid	Solenoid is disconnected.	Plug in disconnected solenoid.
					Replace damaged solenoid wires.
DM		Bottom Changeover Solenoid	Red Solid	Solenoid is disconnected	Plug in disconnected solenoid.
					Replace damaged solenoid wires.

Code	Icon	Code Name	Light Tower Code	Cause	Solution
Alarms (continued)					
K1		Piston	Red Solid	Piston traveled less than one inch in ten seconds.	Verify dispense valve is not stuck closed.
					Verify adequate air pressure to machine.
L1		Drum Empty	Red Solid	Drum empty sensor tripped.	Replace empty drum with a full drum.
P6		Pressure Sensor	Red Solid	Pressure sensor is disconnected.	Reconnect pressure sensor.
				Damaged pressure sensor wires.	Replace pressure sensor.
WE		Dispense Valve	Red Solid	Dispense valve is stuck open.	Check air solenoid wiring and air connection. Replace or repair if necessary.
					Check dispense valve air connection. Replace or repair if necessary.
WJ		Air Solenoid	Red Solid	Air solenoid is disconnected.	Plug in disconnected air solenoid.
				Damaged air solenoid wires.	Replace air solenoid.
WK		Fluid Solenoid	Red Solid	Fluid solenoid is disconnected.	Plug in disconnected fluid solenoid.
				Damaged fluid solenoid wires.	Replace fluid solenoid.
WS		Invalid Pump	Red Solid	Invalid pump setup.	Select a valid pump in the Setup screens.

Code	Icon	Code Name	Light Tower Code	Cause	Solution
Deviations					
DF		Diving Up	Red Flashing	Pump leaking during up stroke.	Replace worn piston valve or packings.
DG		Diving Down	Red Flashing	Pump leaking during down stroke.	Replace worn intake valve or priming rod seal.
Advisories					
B2		Shot Volume Less than Advisory Setpoint	Yellow Solid	Shot volume is less than the advisory setpoint.	Increase the advisory setpoint on Setup screen 11. Increase shot consistency by decreasing speed and valve shutoff time, and increasing material back-pressure.
B3		Shot Volume Greater than Advisory Setpoint	Yellow Solid	Shot volume is greater than the advisory setpoint.	Increase the advisory setpoint on Setup screen 11. Increase shot consistency by decreasing speed and valve shutoff time, and increasing material back-pressure.
B9		Inconsistent Shot	Yellow Solid	A possible inconsistent shot caused by a shot volume less than overshoot.	Request a larger shot. Verify that shot volume variation is okay.
L2		Drum Low	Yellow Solid	Drum low empty sensor has tripped.	Replace empty drum with a full drum.
MA		Maintenance Counter	Yellow Solid	Maintenance counter has expired. Maintenance counter has counted down to 0 from setpoint.	Volume specified by setpoint has passed since last reset.

Shutdown



NOTICE

Never leave water or water-base material in pump overnight. If you are pumping water-base material, flush with water first, then with a rust inhibitor, such as mineral spirits solvent (or white spirit). Relieve pressure, but leave rust inhibitor in pump to protect parts from corrosion.

1. Follow the **Pressure Relief Procedure** on page 51.
2. Remove the spray tip and tip guard from gun or remove the nozzle from the dispense valve.
3. Place siphon tube in grounded metal pail containing cleaning fluid.





FIG. 104

4. Turn the regulator adjustment knob counterclockwise to the lowest possible fluid pressure.
5. Change to manual mode in the run screen. See **Change Operation Mode**, page 62.
6. Hold a metal part of the gun/valve firmly to the side of a grounded metal pail, and press  or step on the foot switch (purchase separately) until clean solvent dispenses.
7. Follow the **Pressure Relief Procedure** on page 51, again.

Maintenance



Preventive Maintenance Schedule

The operating conditions of your particular system determine how often maintenance is required. Establish a preventive maintenance schedule by recording when and what kind of maintenance is needed, and then determine a regular schedule for checking your system.

Pump Maintenance

Wet Cup

Check the wet cup daily. Keep it 2/3 full with Graco Throat Seal Liquid (TSL) or compatible solvent.

Corrosion Protection

Always flush the pump before the material dries on the displacement rod. Never leave water or water-based material in the pump overnight. First, flush with water or a compatible solvent, then with mineral spirits solvent (or white spirit). See **Prime/Purge**, page 52, for flushing instructions. Relieve the pressure (see **Operation**, page 62), but leave the mineral spirits in the pump to protect the parts from corrosion.

Seals

Once a week, check and tighten throat seals on pump. Be sure to follow the **Operation**, page 62, prior to tightening seals.

Supply System Maintenance

Platen Maintenance

If the platen does not come out of the pail easily when the pump is being raised, the air assist tube, or check valve may be plugged. A plugged valve prevents air from reaching the underside of the plate to assist in raising it from the pail. See the Supply Systems Repair-Parts manual for instructions.

Adjust Spacers

Adjust spacers to be used with tapered pails if necessary. See the Supply Systems Repair-Parts manual for instructions.

Replace Wipers

To replace worn or damaged wipers, see the Supply Systems Repair-Parts manual for instructions.

Cleaning Procedure



1. Ensure all equipment is grounded. See **Installation**, page 16.
2. Ensure the area where the system will be cleaned is well ventilated; and remove all ignition sources.
3. Relieve pressure. See **Operation**, page 62.
4. Shutdown system and turn off all power. See **Shutdown**, page 70.
5. Clean external surfaces only using a rag soaked in solvent that is compatible with the dispense material and the surfaces being cleaned.
6. Clean the display with any alcohol-based household cleaner, such as glass cleaner.
7. Allow enough time for solvent to dry before using system.

Upgrade Display Software

NOTICE

To avoid damaging circuit board, wear a grounding strap.

1. Disconnect power.
2. Pull display out of bracket clips to remove it.
3. Remove screw and then access cover.




FIG. 105: Upgrade Display Software

4. Insert and press token firmly into slot.

NOTE: There is no preferred orientation of token.

5. Turn power on.
6. The red indicator light will flash until new software is completely loaded.
7. Turn power off.
8. Remove token.
9. Reassemble access cover and screw.
10. Snap display back into bracket and reconnect power.

Clean User Interface Display

Use any alcohol-based household cleaner, such as glass cleaner, to clean the display.

Troubleshooting



NOTE: Troubleshooting covered in this manual is specific to the shot dispense kits. Refer to your Supply Systems Repair-Parts manual or pump packages instructions-parts manual for system specific troubleshooting. For air motor or pump troubleshooting questions, refer to your NXT air motor instruction-parts manual or pump instructions-parts manual. See **Related Manuals**, page 3, for specific manual numbers.

1. Follow the **Operation**, page 62.
2. Disconnect all power to the supply system or pump package before repairing.
3. Check all possible problems before disassembling any part of the supply system, pump package, or shot dispense kit.

Problem	Cause	Solution
Display volume matches pump volume but is consistently higher than nominal shot size.	System has not finished compensating for higher overshoot.	Dispense more shots. Shot volumes should converge on nominal.
Display volume matches pump volume but is consistently lower than nominal shot size.	System has not finished compensating for lower overshoot.	Dispense more shots. Shot volumes should converge on nominal.
Display volume does not match actual volume pumped.	Changeovers are out of calibration.	Perform calibration procedure; see Errors , page 66.
	Incorrect pump selected during setup.	Chose correct pump and pump size in setup screen 4.
Shots are consistently inaccurate.	See Tips for Better Accuracy , page 102.	See Tips for Better Accuracy , page 102.
Display shows shot is active when start button is pushed, but no material is pumped.	No air supply to the air motor.	Check air supply to air motor.
	Dispense valve is stuck closed.	Check the dispense valve to ensure it is opening and closing correctly.
	No air supply to dispense valve.	Check the dispense valve to ensure it is opening and closing correctly.
Shots that end near a changeover are noticeably less accurate.	Not enough shots have taken place within this area for the compensation factor to be accurate.	Continue dispensing shots. As more shots take place in this area accuracy will improve.

Repair



The shot dispense kits do not include any repairable parts. They include only replacement parts. Therefore, see the **Installation** section that is specific to your kit for instructions on replacing kit parts. Also use the **Electrical Schematics** section, page 75, as a reference.

For system specific repair procedures, refer to your Supply Systems Repair-Parts manual or pump package instructions-parts manual.

Replace Display

NOTE: Order Kit 262539 for replacement.

NOTICE


To avoid damaging circuit board, wear a grounding strap.

1. Disconnect power.
2. Pull display out of bracket clips to remove it.
3. Disconnect both CAN cables.
4. Replace with new display. Reconnect both CAN cables.
5. Load the correct display software for the system. Follow the steps in **Upgrade Display Software** on page 72.

Electrical Schematics


Digital Output Schematic

The SmartWare shot dispense kit uses high side switches for all digital outputs. When they are on, the module power supply voltage is switched to the output pin. When they are off the power supply voltage goes through a pull up resistor that limits the current to a maximum of the supply voltage divided by 51100 ($24 / 51100 = 0.00047$ amps).




Digital Input Schematic

The SmartWare shot dispense kit uses low side switches for all digital inputs. The input is off when nothing is connected between the input pin and the ground pin. The input is on when the ground pin is connected to the input pin.






Parts

Kits 262370 and 262372




Kits 262370 and 262372 (continued)





Kit 262370 and 262372 Parts

Ref.	Part	Description	Qty	Ref.	Part	Description	Qty
			.	35★	103473	STRAP, tie, wire	10
2	262408	BRACKET, subassembly, LCM	1	36	164856	ADAPTER	1
3	262412	VALVE (includes 3a - 3c)	1	37	16G410	MANIFOLD, pressure transducer	1
	3a	SOLENOID, air motor (includes o-ring and screws)	1	38	15M669	SENSOR, pressure, fluid outlet	1
	3b▲	189285 LABEL, caution	1	40★	16F562	CABLE, pressure sensor extension; M12, male/female, reverse key	1
	3c	15V954 LABEL, valve shutoff, air control	1	41★	111457	O-RING	1
4	262410	COVER, front, electronics	1	42	15M293	POWER SUPPLY; 24Vdc, 2.5 A, 60W	1
5	262539	KIT, module, LCM, display (includes 5a and 5b)	1	43	258999	ENCLOSURE, LCM, breakout box	1
	5a❁	262416 MODULE, LCM, display, bare	1	44	101845	SCREW, self tapping	6
	5b	16G294 TOKEN, software	1	45	255634	COVER, power	1
6★	121226	CABLE, CAN, male / female; 0.4m	1	46	112738	GROMMET	1
7★	15T859	CABLE, assembly, DB25; 10 ft.	1	47	111593	SCREW, grounding	1
8★	15X619	CABLE, pigtail, linear motor sensor, M12	1	49	100272	WASHER, lock	2
9★	15Y051	CABLE, M12, 8 pin, female/male	1	50	121070	SCREW, mach; #8x1 0.375	4
10★	122030	CABLE, GCA, solenoid extension; M12-5P	3	51	121255	SCREW, countersunk; 6-32 x 0.38	2
11★	121806	CABLE, solenoid	1	52	255636	BRACKET, mounting, right side	1
12★	124273	CONNECTOR, splitter	2	53	121254	SWITCH, power, 115/250V	1
13	15G747	MAGNET, linear sensor	1	54	121261	FUSE; 250V / 1.2 A	2
14	122622	CORD, power	1	55▲	196548	LABEL, caution	1
15		LABEL, identification	1	65	255616	KIT, bleed valve, short; 262370 only, shipped loose	1
18	287839	SENSOR, assembly	1	66	119400	SEALANT, pipe, sst	1
19	15F772	ADAPTER, lift ring; 1-9/16 sst	1				
20	108014	O-RING	1				
21★	113500	ADHESIVE, anaerobic	1	❁	The bare display module does not have SmartWare software already installed. Use the software upgrade token (5b) to install the SmartWare software before using.		
22	119700	SENSOR, reed switch	1	★	Not shown.		
23	118605	O-RING	1	▲	Replacement Danger and Warning labels, tags, and cards are available at no cost.		
24	120730	SCREW, machined, hex washer head; 1/4-20 x 1 in. (25 mm)	1		Reference cable identification table and cable connection diagram, page 21 and page 22.		
25	107257	SCREW, thd forming, hex washer head; 1/4-20 x 1/2 in. (13 mm)	1				
26	120143	GUIDE, strain relief	1				
27★	16E792	TOOL, magnet install	1				
28	100016	WASHER, lock	11				
29	101682	SCREW, socket head cap	11				
30		COVER, rear	1				
	277590	Kit 262370 only					
	277592	Kit 262372 only					
31		BRACKET, light tower	1				
	255383	Kit 262370 only					
	15R108	Kit 262372 only					
32	157785	FITTING, swivel	1				
33		BRACKET, power supply	1				
34	121255	SCREW, countersunk, 6-32 x 0.38	4				

Kit 262371



Kit 262371 (continued)



Kit 262371 Parts

Ref.	Part	Description	Qty	Ref.	Part	Description	Qty
			.	35	15M293	POWER SUPPLY; 24Vdc, 2.5 A, 60W	1
2	262408	BRACKET, subassembly, LCM	1	36	258999	ENCLOSURE, LCM, breakout box	1
3	262412	VALVE (includes 3a - 3c)	1	37	101845	SCREW, self tapping	6
	3a	SOLENOID, air motor (includes o-ring and screws)	1	38	255634	COVER, power	1
	3b▲	189285 LABEL, caution	1	39	112738	GROMMET	1
	3c	15V954 LABEL, valve shutoff, air control	1	40	111593	SCREW, grounding	1
4	262410	COVER, front, electronics	1	42	100272	WASHER, lock	2
5	262539	KIT, module, LCM, display (includes 5a and 5b)	1	43	121070	SCREW, mach; #8x1 0.375	4
	5a♣	262416 MODULE, LCM, display, bare	1	44	121255	SCREW, countersunk; 6-32 x 0.38	2
	5b	16G294 TOKEN, software	1	45	255636	BRACKET, mounting, right side	1
6★	121226	CABLE, CAN, male / female, 0.4m	1	46	121254	SWITCH, power, 115/250V	1
7★	15T859	CABLE, assembly, DB25, 10-ft	1	47	121261	FUSE; 250V / 1.2 A	2
8★	15X619	CABLE, pigtail, linear sensor, M12	1	48▲	196548	LABEL, caution	1
9★	15Y051	CABLE, M12, 8 PIN, F/M	1	49	119400	SEALANT, pipe, sst	1
10★	122030	CABLE, GCA, solenoid extension; M12-5P	3				
11★	121806	CABLE, solenoid	1				
12★	124273	CONNECTOR, splitter	2				
13★	122622	CORD, power	1				
14		LABEL, identification	1				
17	24C404	KIT, linear sensor	1				
18	16E067	BUSHING	1				
19	110782	O-RING	1				
20	24A032	SWITCH, reed assy	1				
21	15V719	SCREW, pan head; 8-32 x 1.50	1				
22★	16G589	CABLE, linear sensor and reed	1				
23	100016	WASHER, lock	11				
24	101682	SCREW, socket head cap	11				
25	277590	COVER, rear	1				
26	255383	BRACKET, light tower	1				
27		BRACKET, power supply	1				
28	121255	SCREW, countersunk; 6-32 x 0.38	4				
29★	103473	STRAP, tie, wire	10				
30	164856	ADAPTER	1				
31	16G410	MANIFOLD, pressure transducer	1				
32	15M669	SENSOR, pressure, fluid outlet	1				
33	111457	O-RING	1				
34★	16F562	CABLE, pressure sensor extension; M12, male/female, 2m, reverse key	1				


♣ The bare display module does not have SmartWare software already installed. Use the software upgrade token (5b) to install the SmartWare software before using.

★ Not shown.


▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.

Reference cable identification table and cable connection diagram, page 27 and page 28.

Kit 262373



Kit 262373 (continued)



Kit 262373 Parts

Ref.	Part	Description	Qty	Ref.	Part	Description	Qty
			.	39	15M293	POWER SUPPLY; 24Vdc, 2.5 A, 60W	1
2	262430	BRACKET, subassembly, lcm	1	40	258999	ENCLOSURE, LCM, breakout box	1
3	262432	VALVE (includes 3a - 3c)	1	41	121254	SWITCH, power; 115/250V	1
	3a	SOLENOID, air motor (includes o-ring and screws)	1	42	101845	SCREW, self-tapping	6
	3b▲	189285 LABEL, caution	1	43	255634	COVER, power	1
	3c	15V954 LABEL, valve shutoff, air control	1	44	121262	FUSE; 250V / 1.2 A	2
4	262424	COVER, electronics	1	45▲	196548	LABEL, caution	1
5	262539	KIT, module, LCM, display (includes 5a and 5b)	1	46	112738	GROMMET	1
	5a✿	262416 MODULE, LCM, display, bare	1	47	111593	SCREW, grounding	1
	5b	16G294 TOKEN, software	1	49	100272	WASHER, lock	6
6★	122487	CABLE, CAN, male / female; 1.5m	1	50	256979	ENCLOSURE, power supply	1
7★	15T859	CABLE, assembly, DB25; 10 ft.	1	52	117683	SCREW, mach, pan head	4
8★	15X619	CABLE, pigtail, linear motor sensor, M12	1	53	121255	SCREW, countersunk; 6-32 x 0.38	2
9★	15Y051	CABLE, M12, 8 pin, female/male	1	54	119400	SEALANT, pipe, sst	1
10★	122030	CABLE, GCA, solenoid extension; M12-5P	4				
11★	121806	CABLE, solenoid	1				
12★	124273	CONNECTOR, splitter	2				
13	15G747	MAGNET, linear sensor	1				
14★	122622	CORD, power	1				
15		LABEL, identification	1				
18	287839	SENSOR, assembly	1				
19	15F772	ADAPTER, lift ring; 1-9/16 sst	1				
20	108014	O-RING	1				
21★	113500	ADHESIVE, anaerobic	1				
22	119700	SENSOR, reed switch	1				
23	118605	O-RING	1				
24	120730	SCREW, machined, hex washer head	1				
25	107257	SCREW, thd forming, hex washer head	1				
26	120143	GUIDE, strain relief	1				
27★	16E792	TOOL, magnet install	1				
28	100016	WASHER, lock	4				
29	101682	SCREW, socket head cap	4				
30	100133	WASHER, lock	2				
31	121293	SCREW, socket head cap	2				
32★	103473	STRAP, tie, wire	10				
33	164856	ADAPTER	1				
34	16G410	MANIFOLD, pressure transducer	1				
35	15M669	SENSOR, pressure, fluid outlet	1				
37★	16F562	CABLE, pressure sensor extension; M12, male/female, 2m, reverse key	1				
38	111457	O-RING	1				


✿ The bare display module does not have SmartWare software already installed. Use the software upgrade token (5b) to install the SmartWare software before using.

★ Not shown.


▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.

Reference cable identification table and cable connection diagram, page 34 and page 35.

Kit 262374






Kit 262374 (continued)



Kit 262374 Parts




Ref.	Part	Description	Qty	Ref.	Part	Description	Qty
			.	33	15M293	POWER SUPPLY; 24Vdc, 2.5 A, 60W	1
2	262430	BRACKET, subassembly, LCM	1	34	258999	ENCLOSURE, LCM, breakout box	1
3	262432	VALVE (includes 3a - 3c)	1	35	121254	SWITCH, power; 115/250V	1
	3a	SOLENOID, air motor (includes o-ring and screws)	1	36	101845	SCREW, self-tapping	6
	3b▲	189285 LABEL, caution	1	37	255634	COVER, power	1
	3c	15V954 LABEL, valve shutoff, air control	1	38	121262	FUSE; 250V / 1.2 A	2
4	262424	COVER, front, electronics	1	39▲	196548	LABEL, caution	1
5	262539	KIT, module, LCM, display (includes 5a and 5b)	1	40	112738	GROMMET	1
	5a✿	262416 MODULE, LCM, display, bare	1	41	111593	SCREW, grounding	1
	5b	16G294 TOKEN, software	1	43	100272	WASHER, lock	6
6★	122487	CABLE, CAN, male/female; 1.5m	1	44	256979	ENCLOSURE, power supply	1
7★	15T859	CABLE, assembly, DB25; 10ft	1	46	117683	SCREW, mach, pan head	4
8★	15Y051	CABLE, M12, 8 PIN, female/male	1	47	121255	SCREW, countersunk; 6-32 x 0.38	2
9★	122030	CABLE, GCA, solenoid extension; M12-5P	4	48	119400	SEALANT, pipe, sst	1
10★	121806	CABLE, solenoid	1	✿ <i>The bare display module does not have SmartWare software already installed. Use the software upgrade token (5b) to install the SmartWare software before using.</i>			
11★	124273	CONNECTOR, splitter	2	★ <i>Not shown.</i>			
12★	122622	CORD, power	1	▲ <i>Replacement Danger and Warning labels, tags, and cards are available at no cost.</i>			
13		LABEL, identification	1	<i>Reference cable identification table and cable connection diagram, page 40 and page 41.</i>			
16	24C404	KIT, linear sensor	1				
17	16E067	BUSHING	1				
18	110782	O-RING	1				
19	24A032	SWITCH, reed assy	1				
20	15V719	SCREW, pan head; 8-32 x 1.50	1				
21★	16G589	CABLE, linear sensor and reed switch	1				
22	100016	WASHER, lock	4				
23	101682	SCREW, socket head cap	4				
24	100133	WASHER, lock	2				
25	121293	SCREW, socket head cap	2				
26★	103473	STRAP, tie, wire	10				
27	164856	ADAPTER	1				
28	16G410	MANIFOLD, pressure transducer	1				
29	15M669	SENSOR, pressure, fluid outlet	1				
31★	16F562	CABLE, pressure sensor extension; M12, male/female, 2m, reverse key	1				
32	111457	O-RING	1				

Kit 262375



 Apply thread sealant to threads.

Kit 262375 (continued)



Kit 262375 Parts

Ref.	Part	Description	Qty	Ref.	Part	Description	Qty
			.	36	100101	SCREW, cap, hex head	4
2	262420	BRACKET, subassembly, LCM	1	37	100731	WASHER	6
4	262424	COVER, electronics	1	38	101566	NUT, lock	2
5	262539	KIT, module, LCM, display (includes 5a and 5b)	1	39	1	BRACKET, controls mount	1
5a❁	262416	MODULE, LCM, display, bare	1	40	100133	WASHER, lock	2
5b	16G294	TOKEN, software	1	41★	103473	STRAP, tie, wire	10
6		VALVE, subassembly (includes 6a - 6g)	1	42	164856	ADAPTER	1
6a	C59752	VALVE, pneumatic, 3-way	1	43	16G410	MANIFOLD, pressure transducer	1
6b	111530	MUFFLER	1	44	15M669	SENSOR, pressure, fluid outlet	1
6c	111337	FITTING, tee, street	1	45	111457	O-RING	1
6d	100615	BUSHING, hex steel	1	46		VALVE, subassembly (includes 46a - 46e)	1
6e	C19405	FITTING, connector, male	1	46a	198446	VALVE, dispense, closer	1
6f	C20365	FITTING, tee, air	1	46b	C19405	FITTING, connector, male	1
6g	16F609	PLUG, seal; 1/4 tube	1	46c	112698	ELBOW, male, swivel	1
7★	121226	CABLE, CAN, male / female; 0.4m	1	46d	C06061	MUFFLER	1
8★	15T859	CABLE, assembly, DB25; 10 ft.	1	46e	100403	PLUG, pipe	1
9★	15X619	CABLE, pigtail, linear motor sensor, M12	1	47	15M293	POWER SUPPLY; 24 Vdc, 2.5 A, 60W	1
10★	15Y051	CABLE, M12, 8 pin, female/male	1	48	258999	MODULE, LCM, breakout box	1
11★	122030	CABLE, GCA, solenoid extension; M12-5P	1	49	121254	SWITCH, power; 115/250V	1
12★	121806	CABLE, solenoid	1	50	101845	SCREW, self-tapping	6
13★	124273	CONNECTOR, splitter	1	51	255634	COVER, power	1
14	15G747	MAGNET, linear sensor	1	52	121261	FUSE; 250 V / 1.2 A	2
15★	122622	CORD, power	1	53▲	196548	LABEL, caution	1
16		LABEL, identification	1	54	112738	GROMMET	1
19	287839	SENSOR, assembly	1	55	111593	SCREW, grounding	1
20	15F772	ADAPTER, lift ring; 1-9/16 sst	1	57	100272	WASHER, lock	6
21	108014	O-RING	1	58	256979	ENCLOSURE, power supply	1
22★	113500	ADHESIVE, anaerobic	1	59	117683	SCREW, machined, pan head	4
23	119700	SENSOR, reed switch	1	60	121255	SCREW, countersunk; 6-32 x 0.38	2
24	118605	O-RING	1	61	116798	SCREW, machined, pan head; 4 x 1.25	2
25	120730	SCREW, machined, hex washer head	1	62	C27076	NUT	2
26	107257	SCREW, thd forming, hex washer head	1	64	114225	TRIM, edge protection; 0.19 ft.	-
27	120143	GUIDE, strain relief	1	65	119400	SEALANT, pipe, sst	1
28★	16E792	TOOL, magnet install	1				
29	100016	WASHER, lock	8				
30	101682	SCREW, socket head cap	8				
31	160327	FITTING, union, adapter; 90 deg.	1				
32	119992	FITTING, pipe, nipple; 3/4 x 3/4 npt	1				
33	157785	FITTING, swivel	1				
34★	C12509	TUBE, nylon, round; 10 ft.	-				
35		BRACKET, assembly, adapter	1				

❁ The bare display module does not have SmartWare software already installed. Use the software upgrade token (5b) to install the SmartWare software before using.

★ Not shown.

▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.

Reference cable identification table and cable connection diagram, page 46 and page 47.

Appendix A - User Interface Display

Display Overview

The display is divided into two main functions: Setup mode and Run mode.

Setup Mode Functions

Setup mode functions enable users to:

- set units of measurement displayed on screen;
- program shot size;
- program shot sequence;
- set system password;
- modify pump configurations;
- enable/disable pump functions;
- enable/disable error codes;
- set pump runaway;
- set drum size;
- view or modify system and maintenance totalizers;
- view or clear shot totalizers;
- view error totalizers;
- and perform calibration.

Run Mode Functions

Run mode functions enable users to:

- change run mode between shot, sequence, manual, and park;
- set shot number;
- record shot volume or time;
- switch air valve on and off;
- view shot progress;
- dispense material shots;
- clear errors;
- and fill material drum.

Display Details

Power Up Screen

The following screen appears when the display module is powered up. It remains on while the display module runs through initialization and establishes communication with other components in the system.



Soft Keys

Icons to the left of the soft keys indicate which mode or action is associated with each soft key. Soft keys that do not have an icon to the left of them are not active in the current screen.

Enter/Exit Screens

In screens that have editable fields, press  to access the fields and make changes. When changes are complete press  to exit edit mode.

Navigation within Screens

Press  to open drop-down menus and select data to edit. Also, press  to enter changes or make a selection.

Press   to navigate to a new screen and to navigate up and down within a screen. Also, press   to move between fields within a drop-down menu, and to increment or decrement numbers within a field.


Setup Mode Details

Setup mode screens enable users to view or modify system configuration data. Users can set units, set shot sizes, program shot sequences, set the password, select specific pump sizes, adjust pump configuration, setup errors, and view totalizers.

Setup Screen 1 - Units

Setup screen 1 enables users to set units of measurement that will display on other screens. This screen also uses the specific gravity of the material being dispensed to convert units. Additionally, this screen displays the software number and version. Refer to the following table for more information.


Icon	Function
	Units of Measure Select units of measurement for material volume or material weight.
SG	Specific Gravity The system uses the material's specific gravity that is entered in the field to convert volume units (cc) to weight units (grams). The weight units will display on other screens if the Shot Weight field on the Shot Size screen is enabled.



Setup Screen 2 - Shot Size

Setup screen 2 enables users to program up to 25 shots (1 – 25). Each shot number can be defined so that the system will dispense the predetermined quantity of material when the shot number is selected and a shot is initiated. Refer to the following table for more information.


Icon	Function
	Set Volume/Weight Select shot number. Set weight/volume of specific material for the shot. Weight units are displayed when the Shot Weight icon is checked. Volume units are displayed when the Shot Weight icon is unchecked.
	Shot Weight Configure system to use shot weight (if checked) or shot volume (if unchecked).
	Shot Time Displays shot time (if checked) or shot volume/weight (if unchecked).




Setup Screen 3 - Shot Sequence

Setup screen 3 enables users to program up to five sequences (A – E). Each sequence can have up to 14 steps and each step can be one of the possible 25 shots (programmed from the Shot Size setup screen). If any sequence contains either an undefined shot or one of the positions is undefined, no material will be dispensed when that shot is taken. Refer to the following table for more information.

Icon	Function
	Set Shot Set number of shots for each step in the sequence.
	Shot Sequence Select shot sequence letter (A-E).
	Shot Volume The shot volume box displays the volume of the selected (highlighted) shot number.




Shot sequence screen shown with shot number selected, which also displays the shot volume box.



Setup Screen 4 - Password and Pump

Setup screen 4 enables users to set a password and select the pump size used by the specific system. Refer to the following table for more information.


Icon	Function
	Password The setup screens can be protected by a password to restrict their accessibility. See Set Password , page 56, for more information and instructions for setting a password.
	Pump Select pump used on the system.



Setup Screen 5 - Enable/Disable Pump Functions

Setup screen 5 enables users to enable and disable functions that directly relate to pump activity. Disabling functions in this screen will prevent them from being used in run mode. Refer to the following table for more information.


Icon	Function
	Air Pressure After Shot Check the box to have the air pressure remain on after a shot completes. Or uncheck the box to have the air pressure turn off after a shot completes.
	Shot Switch Tap Mode Change shot switch mode. There are two modes: turn switch on and off (tap mode) or turn switch on and hold (hold mode). Tap mode is enabled when field is checked. Hold mode is enabled when field is not checked.
	Shot Editing Enables shot key on display, and the editing of the shot number or operation mode.
	Changeover Solenoid If checked, the changeover solenoid function is enabled.



Setup Screen 6 - Enable/Disable Errors

Setup screen 6 enables users to enable and disable specific error codes that will be issued if an alarm, advisory, or deviation is detected in the system. See **Errors**, page 66, for an explanation of each error code. Refer to the following table for more information.


Icon	Function
	Diving Up Deviation Indicates the pump is cavitating during the bottom changeover.
	Diving Down Deviation Indicates the pump is cavitating during the top changeover.
	Empty Drum Alarm If checked, the empty drum alarm is enabled. If unchecked, the empty drum advisory is enabled.
	Pump Runaway Error Enable or disable pump runaway error.



Setup Screen 7 - Setup Pump Runaway and Drum Size

Setup screen 7 enables users to set the pump runaway cycle rate, drum size, and drum fill volume. Refer to the following table for more information.

Icon	Function
	Pump Runaway Cycle Rate Set the pump runaway cycle rate, which if surpassed will issue a pump runaway error. Graco recommends setting the cycle rate to 60 or less. Choose a value that is just above the maximum cycle rate of the application.
	Drum Size Enter the size of the material supply drum.
	Drum Fill Volume Enter the exact volume of the material in the supply drum. If unknown, contact the supplier for the exact volume. This value is used to determine the remaining volume in the supply drum.



Setup Screen 8 - Grand, Batch, and Maintenance Totalizer

Setup screen 8 enables users to view the grand and batch totals for the pump. This screen also enables users to set maintenance setpoint amount for the pump and dosing valve.


The units of measurement are displayed in the corner, and in the units of measurement selected in the Setup Units screen.

Grand and Batch Totalizers

The grand totalizer tracks and displays the amount of material the system has dispensed during its lifetime. The batch totalizer tracks and displays the amount of material since the last user reset.

Maintenance Totalizers


Set the amounts of material moved through the pump and dosing valve that will result in a maintenance advisory when the Total Volume Dispensed exceeds the Maintenance Setpoint. Clearing the Total Volume Dispensed will clear the advisory.




Setup Screen 9 - Shot and Error Totalizer

Setup screen 9 enables users to view the shot and error totals. Refer to the following table for more information.

Icon	Function
	Shot Totalizer Records and displays the number of times each shot number has occurred.
	Error Totalizer Records and displays the number of times each error type has occurred.




Shot and error totalizer screen shown with shot number highlighted, which enables the user to clear a shot by then pressing $\begin{matrix} 123 \\ \downarrow \\ 000 \end{matrix}$.



Setup Screen 10 - Calibration

Setup screen 10 enables users to start the calibration process for top changeover, bottom changeover, and shot weight. Refer to the following table for more information.

Icon	Function
	Material Delta Fields are updated after four shot weights are entered into the Weight box.
	Weight Used to enter the weight of the shot.
	Timer Displays when the calibration process starts.
	Shot Calibration Displays when calibrating a shot.
	Pump Calibration Displays when calibrating the pump.




Setup Screen 11 - Shot Accuracy Errors

Setup screen 11 enables users to set the shot volume difference from the shot setpoint that will cause an advisory or alarm. Refer to the following table for more information.

Icon	Function
	Advisory If the final shot volume is greater or less than the shot setpoint by the value entered in this field, an advisory is generated.
	Alarm If the final shot volume is greater or less than the shot setpoint by the value entered in this field, an alarm is generated.

NOTE: If either the advisory field or alarm field is set to zero, the error is disabled.



Run Mode Details

Run mode enables users to perform material shots, adjust shot number, view shot volume/time, monitor pump movement, and view shot time. Users can access the Information screen from the run screen, which enables them to clear errors and fill material drums.

The system always starts with the run screen. See **Operation**, page 62, for instructions on using the Run screen.

Operation Modes

Users can perform material shots using one of three operation modes: Shot, Sequence, or Manual.

Mode	Function
	Shot Mode Enables users to repeatedly dispense 1 of 25 shots.
	Sequence Mode Enables users to dispense a sequence of shots in a specified order.
	Manual Mode Enables users to manually dispense shots.
	Park Mode Runs pump to bottom of the stroke, and then disables the system.

Air Valve On/Off

Press the Air On/Off button to turn the air valve on and

off. If the Air Pressure After Shot  field is checked on the screen 5 (Enable/Disable Pump Functions screen), the air will remain on after the shot.


When the air valve is on, the Current Mode box displays a black background and white icon. And when the air valve is off, the Current Mode box displays a white background and black icon.

Fluid Valve On/Off

When the fluid valve is on during a shot, the Actual Shot Volume or Time starts at zero and increments, the pump icon displays pump movement, and the Progress Bar Graph starts incrementing.

NOTE: The progress bar graph is only displayed during a shot.

Run Screen in Shot Mode Shown



Information Screen

This screen displays the present alarm or advisory, along with the current error icon and error code. The information screen also displays the current volume of material in the drum. This screen also displays the average overshoot and the largest deviation from the average overshoot.

Users can clear alarms or advisories and reset the drum volume from this screen.


There are three alarm possibilities:

Icon	Function	Description
	Advisory	Advisories do not require attention; therefore, the system continues running and  displays next to the operation mode field.
	Deviation	Deviations require attention, but not immediately; therefore, the system continues running and  displays next to the operation mode field.
	Alarm	Alarms require immediate attention; therefore, the system disables and the Information screen automatically displays.

The information screen is accessed by pressing either



from the run screen.



Appendix B - Tips

Calibration Procedure

Performing the calibration procedure is not necessary for the system to work. However, performing the procedure will increase shot accuracy depending on the changeover characteristics of your supply system.


Each pump and material combination may have unique changeover characteristics (volume pumped during the changeover). Performing the calibration procedure will calibrate your particular SmartWare kit to more accurately count the material dispensed during the changeover portion of the pump stroke.

Tips for Better Accuracy


- Repeatable dispense components: Use a high quality and highly repeatability dispense valve and solenoid. Always use the greatest air pressure available to actuate the dispense valve.
- Faster valve: Use the smallest dispense valve that will work for your flow rate and pressure. A small dispense valve will open and close faster, which will reduce overshoot; see , page 92, for overshoot values. Use a large enough solenoid and large enough air lines to maximize the air flow, which will increase the speed of the dispense valve.
- Slower pump speeds: Decrease the pump speed to decrease overshoot and increase accuracy.
- If pumping higher viscosity materials with a DuraFlo pump, install a spring loaded ball check at the pump inlet. Doing so will provide more consistent pumping through the top and bottom changeovers.
- Use the smallest diameter and shortest length outlet hose possible to minimize the amount of material between the pump and the dispense point.
- Minimize the material temperature swings to help prevent changes in material properties that will affect accuracy.


Appendix C - Breakout Module (258999) Connections


The following table provides descriptions and pins of all connectors used on the breakout module. These can be used if the components are being wired directly to the breakout module. See **Appendix D - Y-Adapter (124273) Connections**, page 105, if the component is being connected to the Y-adapter (124273) before connecting to the breakout module.

Light Tower Connector 2 - Blue	Pin Description	Pin Number
M12 Connector, 5 pin, Female, A code	Lamp 1 Yellow Digital Output	4
Phoenix Contact Part Number 1542761	Lamp 2 Red Digital Output	2
	Digital Output Power (24 volt)	1
	Digital Output Ground	3
	Shield Digital	5


Solenoid Air / Fluid Connector 3 - Red	Pin Description	Pin Number
M12 Connector, 5 pin, Female, A code	Solenoid Air Digital Output	4
Phoenix Contact Part Number 1542761	Solenoid Fluid Digital Output	2
	Digital Output Power (24 volt)	1
	Digital Output Ground	3
	Shield Digital	5

Solenoid Air / Fluid Connector 4 - Green	Pin Description	Pin Number
M12 Connector, 5 pin, Female, A code	Solenoid Changeover Kit Top Digital Output	4
Phoenix Contact Part Number 1542761	Solenoid Changeover Kit Bottom Digital Output	2
	Digital Output Power (24 volt)	1
	Digital Output Ground	3
	Shield Digital	5

Prox / Start - Stop Connector 5 - Grey	Pin Description	Pin Number
M12 Connector, 5 pin, Female, A code	Drum Low Digital Input	4
Phoenix Contact Part Number 1542761	Start / Stop Digital Input	2
	Digital Input Power (24 volt)	1
	Digital Input Ground	3
	Shield Digital	5

Pressure Connector 6 - Blue	Pin Description	Pin Number
M12 Connector, 5 pin, Female, B code	Pressure Differential Analog Input +	4
Phoenix Contact Part Number 1543650	Pressure Differential Analog Input -	2
	Pressure Power (5 volt)	1
	Pressure Ground	3
	Shield Analog	5

Shot Active Connector 8 - Grey	Pin Description	Pin Number
M8 Connector, 4 pin, Female	Shot Active (5 volts) or Not Active (0 volts) Analog Output	4
Phoenix Contact Part Number 1694376	Shot Active Power (5 volt)	1
	Shot Active Ground	3
	Shield Analog	2

Air Motor Connector 9 - Grey	Pin Description	Pin Number
M12 Connector, 8 pin, Female, A code	Motor Top Reed Switch Digital Input	3
Phoenix Contact Part Number 1542774	Motor Bottom Reed Switch Digital Input	4
	Reed Switch Ground	5
	Linear Sensor Analog Input	1
	Linear Sensor Power (5 volt)	6
	Linear Sensor Ground	7
	Shield Analog	8

Appendix D - Y-Adapter (124273) Connections

The Y-adapter is used when two components are connected to the same connector on the breakout module. The branch connectors, labeled 1 and 2, have identical pinouts and are combined in the trunk connector. The following table provides descriptions and pins of all connectors used on the Y-adapter.

Branch Connector 1 - Black	Pin Description	Pin Number
M12 Connector, 5 pin, Female, A code	Digital Input or Output	4
Used for Drum Low Input and Solenoid Air Output	Not Used	2
	Power	1
	Ground	3
	Shield Digital	5
Branch Connector 2 - Silver	Pin Description	Pin Number
M12 Connector, 5 pin, Female, A code	Digital Input or Output	4
Used for Start / Stop Input and Solenoid Fluid Output	Not Used	2
	Power	1
	Ground	3
	Shield Digital	5
Trunk Connector - Silver	Pin Description	Pin Number
M12 Connector, 5 pin, Male, A code	Digital Input or Output from Branch 1	4
	Digital Input or Output from Branch 2	2
	Power	1
	Ground	3
	Shield Digital	5

Accessories

Changeover Kits, 262453 and 262464

Use the changeover kit to increase shot accuracy and eliminate changeovers on shots that are less than 20% of the pump volume. There are two changeover kits available. For NXT2200 and larger air motors, order 262453. For NXT1800 and smaller air motors, order 262464.

Foot Switch Kit, 262530

The foot switch kit enables the operator to trigger the dispense valve using a foot pedal.

Dimensions

For supply system or pump package dimensions, refer to the supply system or pump package manual.

Technical Data

Power supply requirements	100 – 240 Vac, 50/60 Hz, single phase, 1.2 amps max
Pressure transducer manifold: maximum working fluid pressure	7500 psi (52.5 MPa, 5.25 bar)
Ambient operating temperature range	32 – 120°F (0 – 49°C)
Operating humidity range	0 – 90% non-condensing

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

For the latest information about Graco products, visit www.graco.com.

For patent information, see www.graco.com/patents.

TO PLACE AN ORDER, contact your Graco distributor or call to identify the nearest distributor.

Phone: 612-623-6921 or Toll Free: 1-800-746-1334 Fax: 330-966-3006

All written and visual data contained in this document reflects the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice.

Original instructions. This manual contains English. MM 3A0294

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA

Copyright 2010, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com

Revision J, August 2016