

Kits for HVLP Sprayers

3A5024C
EN

For repair of components in HVLP sprayers.



Important Safety Instructions







Read all warnings and instructions in your sprayer and gun manuals.
Be familiar with the controls and the proper usage of the equipment.
Save these instructions.

Related Manuals:	
3A4967	FinishPro HVLP Sprayer
3A4980	HVLP Edge II/Edge II Plus Gun

Section	Description	Kit #
Turbine Repair, page 4	120VAC, 7.0 Models,	17R936
	120VAC, 9.0 Models	17R937
	120VAC, 9.5 Models	17R938
	230VAC, 7.0 Models	17R939
	230VAC, 9.0 Models	17R940
	230VAC, 9.5 Models	17R941
Control Board Repair, page 6	120VAC, Standard Models	17R942
	120VAC, ProContractor/ProComp Models	17R943
	230VAC, Standard Models	17R944
	230VAC, ProContractor/ProComp Models	17R945
Potentiometer Repair, page 8	Standard Models	17R946
	ProContractor/ProComp Models	17R948
Compressor Repair (ProComp Models only), page 11	120VAC Models	17R962
	230VAC Models	17R964

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual or on warning labels, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.

 WARNING	
 	ELECTRIC SHOCK HAZARD <p>This equipment must be grounded. Improper grounding, setup, or usage of the system can cause electric shock.</p> <ul style="list-style-type: none">• Turn off and disconnect power cord before servicing equipment.• Connect only to grounded electrical outlets.• Use only 3-wire extension cords.• Ensure ground prongs are intact on power and extension cords.• Do not expose to rain. Store indoors.
 	PRESSURIZED EQUIPMENT HAZARD <p>Fluid from the equipment, leaks, or ruptured components can splash in the eyes or on skin and cause serious injury.</p> <ul style="list-style-type: none">• Follow the Pressure Relief Procedure when you stop spraying/dispensing and before cleaning, checking, or servicing equipment.• Tighten all fluid connections before operating the equipment.• Check hoses, tubes, and couplings daily. Replace worn or damaged parts immediately.
	PERSONAL PROTECTIVE EQUIPMENT <p>Wear appropriate protective equipment when in the work area to help prevent serious injury, including eye injury, hearing loss, inhalation of toxic fumes, and burns. This protective equipment includes but is not limited to:</p> <ul style="list-style-type: none">• Protective eyewear, and hearing protection.• Respirators, protective clothing, and gloves as recommended by the fluid and solvent manufacturer.

Pressure Relief Procedure



Follow the Pressure Relief Procedure whenever you see this symbol.

If using a FlexLiner System:


4. Disconnect tubing from gun to relieve pressure in the cup.




The spray gun cup is pressurized. To reduce the risk of splashing from pressurized fluid, always follow the **Pressure Relief Procedure** before removing cup.

1. Turn the ON/OFF switch to **OFF** position.



Standard Models:



ProContractor and ProComp Models:




2. Unplug power cord to disconnect power.
3. Disconnect spray gun from air hose.




If using a ProComp remote cup:

5. Turn compressor ON/OFF switch to OFF position.



6. Disconnect air hose from remote cup. Turn out pressure regulator one turn. Wait until pressure is completely relieved before removing cover.



Turbine Repair

Standard Models



NOTICE

Use blue thread locker provided in turbine repair kit to avoid loosening of spacers due to turbine vibration. Failure to use thread locker may result in premature turbine failure.

Refer to the **Parts List - Standard Models**, page 13.

Removal:

1. Perform **Warnings**, page 2.
2. Turn power switch (36) to **OFF** and unplug the power cord to disconnect power.
3. Disconnect air hose from the turbine outlet.
4. Remove eight screws (16) and the top cover (31).

NOTE: Be cautious not to damage the wires that connect to the cover.

5. Remove five screws (16), disconnect air hose (29), and remove the rear panel (22).
6. Remove three screws (16) and the air filter housing (15). Remove gasket (14) from the filter housing (15) and discard.

7. Disconnect the motor leads from the control board (20).
8. Remove the 3 turbine mounting bolts (13) and spacers (9 & 11).
9. Remove the turbine assembly (12).
10. Remove plate (10) and gasket (8).
11. Remove three nuts (7) and gaskets (6).

Installation:

1. Apply thread locker to studs on the turbine enclosure (1) and install three new nuts (7) and gaskets (6). Torque to 110-115 in-lb (12.5 - 13.0 N•m).
2. Install new turbine assembly (12) along with new plate (10) and gasket (8).
3. Apply thread locker to turbine mounting bolts (13) and slide into place through the spacers (9 & 11). Torque to 110-115 in-lb (12.5 - 13.0 N•m).
4. Connect motor leads to the control board (20). Refer to **Wiring Diagrams (Standard)**, page 18.
5. Place new gasket (14) onto filter housing (15) and install using 3 screws (16). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).
6. Connect air hose (29) to rear panel (22) and install using five screws (16). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).
7. Install top cover (31) using 8 screws (16). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).

ProContractor & ProComp Models



NOTICE

Use blue thread locker provided in turbine repair kit to avoid loosening of spacers due to turbine vibration. Failure to use thread locker may result in premature turbine failure.

Refer to the **Parts List - ProContractor Models**, page 15 & **Parts List - ProComp Models**, page 17.

Removal:

1. Perform **Warnings**, page 2.
2. Turn the power switch (36) to **OFF** and unplug the power cord to disconnect power.
3. Disconnect air hose from the turbine outlet.
4. Remove eleven screws (16) and the top cover (31).

NOTE: Be cautious not to damage the wires that connect to the cover.

5. Remove six screws (16), disconnect air hose (18), and remove the rear panel (22).
6. Remove five screws (16), leaving two outlet valve (17) mounting screws (16) in place. Remove the front panel (30). Pull straight out to remove the outlet valve assembly (17) from the turbine (12) outlet.
7. Use a flat blade screwdriver to pry strain relief (39) from inner panel (15). Disconnect the monitor leads from the control board (20).

8. Loosen two mounting nuts (83) on the inner panel (15).
9. Remove the three turbine mounting bolts (13) and spacers (9 & 11) (Some models only have a single spacer).
10. Remove the turbine assembly (12). Remove the mounting plate (10) and gasket (8).
11. Remove three nuts (7) and gaskets (6).

Installation:

1. Apply thread locker to studs on the turbine enclosure (1) and install three new nuts (7) and gaskets (6).
2. Install new turbine assembly (12) along with new plate (10) and gasket (8).
3. Apply blue thread locker to turbine mounting bolts (13) and slide into place through the spacers (9 & 11). Torque to 110-115 in-lb (12.5 - 13.0 N•m).
4. Tighten the mounting nuts (83) on the inner panel (15). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).
5. Route the turbine (12) leads through the strain relief (39) and install back into inner panel (15).
6. Connect motor leads to the control board (20). Refer to **Wiring Diagrams (ProContractor)**, page 19 and **Wiring Diagrams (ProComp)**, page 20.
7. Install the front panel (30) using five screws (16). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).
8. Connect air hose (18) to rear panel (22) and install using six screws (16). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).
9. Install top cover (31) using eleven screws (16). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).

Control Board Repair

Standard Models



Refer to the **Parts List - Standard Models**, page 13.

Removal:

1. Perform **Warnings**, page 2.
2. Turn the power switch (36) to **OFF** and unplug the power cord to disconnect power.
3. Remove eight screws (16) and the top cover (31).

NOTE: Be cautious not to damage the wires that connect to the cover.

4. Remove five screws (16), disconnect air hose (29), and remove the rear panel (22).
5. Disconnect turbine motor leads (12) and the potentiometer (45) from the control board (20). Refer to **Wiring Diagrams (Standard)**, page 18.
6. Disconnect control board leads to the power switch (36) and power cord receptacle (23). Refer to **Wiring Diagrams (Standard)**, page 18.
7. Remove four control board mounting screws (21) and remove control board (20).

Installation:

1. Install new control board (20) using four screws (21). Torque to 15-20 in-lbs (1.7 - 2.3 N•m).
2. Connect control board leads to the power switch (36) and power cord receptacle (23). Refer to **Wiring Diagrams (Standard)**, page 18.
3. Connect turbine motor leads (12) and potentiometer (45) to the new control board (20). Refer to **Wiring Diagrams (Standard)**, page 18.
4. Connect air hose (29) to rear panel (22) and install using five screws (16). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).
5. Install top cover (31) using eight screws (16). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).

ProContractor & ProComp Models



Refer to the **Parts List - ProContractor Models**, page 15 & **Parts List - ProComp Models**, page 17.

Removal:

1. Perform **Warnings**, page 2.
2. Turn the power switch (36) to **OFF** and unplug the power cord to disconnect power.
3. Remove eleven screws (16) and the top cover (31).

NOTE: Be cautious not to damage the wires that connect to the cover.


4. Remove two screws (21) that mount the TurboControl LED (20a) to the top cover.
5. Peel foam gasket (90) back and remove wires from power switch (36) and potentiometer (47) from the wire bundle. Refer to Fig. 1.
6. For ProComp models, peel open foam gasket (91) to remove wire bundle and discard.
7. Remove six screws (16), disconnect air hose (18), and remove rear panel (22).
8. Disconnect all leads going to and from the control board (20). Refer to **Wiring Diagrams (ProContractor)**, page 19 and **Wiring Diagrams (ProComp)**, page 20.
9. Remove the air line (19) going to control board (20).
10. Remove four control board mounting screws (21) and remove control board (20).

Installation:

1. Install new control board (20) using four screws (21). Torque to 15-20 in-lbs (1.7 - 2.3 N•m).
2. Connect the air line (19) to the control board (20).

3. Peel off the paper backing and place sticky side of foam gasket (88) onto the TurboControl LED (20a). Install mounting screws (21) to top cover (31). Torque to 15-20 in-lbs (1.7 - 2.3 N•m).
4. Route ribbon cable from TurboControl LED (20a), wires from potentiometer (47), and wires from power switch (36) through the foam gasket (90) as shown. Place sticky side of foam gasket (90) down onto the TurboControl LED (20a). Refer to Fig. 1.
5. For ProComp models, wrap foam gasket (91) around the wire bundle to protect against damage from the compressor power switch (77).
6. Connect all leads going to and from the control board (20). Refer to **Wiring Diagrams (ProContractor)**, page 19 and **Wiring Diagrams (ProComp)**, page 20.
7. Connect air hose (18) to rear panel (22) and install using six screws (16). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).
8. Install top cover (31) using eleven screws (16). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).

Fig. 1



Potentiometer Repair

Potentiometer Repair

Standard Models



Refer to the **Parts List - Standard Models**, page 13.

Removal:

1. Perform **Warnings**, page 2.
2. Turn power switch (36) to **OFF** and unplug the power cord to disconnect power.
3. Loosen two set screws and remove the knob (37).
4. Remove eight screws (16) and the top cover (31).

NOTE: Be cautious not to damage the wires that connect to the cover.

5. Remove mounting nut and washer of potentiometer (45) from the top cover (31).
6. Disconnect potentiometer (45) from the control board (20).

Installation:


1. Connect new potentiometer (45) to the control board (20). Refer to **Wiring Diagrams (Standard)**, page 18.
2. Remove the mounting nut from the potentiometer (leave washer in place)* and slide through opening in the top cover (31). For proper alignment, the locating tab on the potentiometer (45) should be inserted into the hole in the top cover (31). Refer to Fig. 2.

*Remove and discard plain washer if unit has Isolator (17X783).

3. Install the mounting nut. Torque to 10-15 in-lb (1.1 - 1.7 N•m).
4. Install top cover (31) using eight screws (16). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).

5. Rotate the shaft of the potentiometer (45) clockwise as far as it can go. Slide the knob (37) over the shaft and align the pointer to the maximum setting on the control label (35). While applying a light pressure to the knob (37), tighten the two set screws to 3-5 in-lb (0.3 - 0.6 N•m).

Fig. 2



ProContractor & ProComp Models



Refer to the **Parts List - ProContractor Models**, page 15 & **Parts List - ProComp Models**, page 17.

Removal:

1. Perform **Warnings**, page 2.
2. Turn power switch (36) to **OFF** and unplug the power cord to disconnect power.
3. Loosen the two set screws and remove the knob (37).

4. Remove eleven screws (16) and the top cover (31).

NOTE: Be cautious not to damage the wires that connect to the cover..

5. Remove mounting nut and washer of potentiometer (45) from the top cover (31).
6. For ProComp models only, peel open foam gasket (91) to remove wire bundle and discard. See Fig. 1 on page 7.
7. Disconnect potentiometer (47) from control board (20).
8. Peel foam gasket (90) attached to top cover (31) back and slide the potentiometer (47) wires from the bundle. See Fig. 1 on page 7.

Potentiometer Repair


Installation:

1. Route the wire from the new potentiometer (47) through the foam gasket (90).
2. Connect potentiometer (47) to the control board (20). Refer to **Wiring Diagrams (ProContractor)**, page 19 and **Wiring Diagrams (ProComp)**, page 20.
3. For ProComp models, wrap the foam gasket (91) around the wire bundle to protect against damage from the compressor power switch (77).
4. Remove the mounting nut from the potentiometer (leave washer in place)* and slide through opening in the top cover (31). For proper alignment, the locating tab on the potentiometer (47) should be inserted into the hole in the top cover (31). Refer to Fig. 3.

*Remove and discard plain washer if unit has Isolator (17X783).

5. Install the mounting nut. Torque to 10-15 in-lb (1.1 - 1.7 N•m).
6. Install top cover (31) using eight screws (16). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).
7. Rotate the shaft of the potentiometer (45) clockwise as far as it can go. Slide the knob (37) over the shaft and align the pointer to the maximum setting on the control label (35). While applying a light pressure to the knob (37), tighten the two set screws to 3-5 in-lb (0.3 - 0.6 N•m).

Fig. 3



Compressor Repair (ProComp Models only)

Compressor Repair (ProComp Models only)



Refer to the **Parts List - ProComp Models**, page 17.

Removal:

1. Perform **Warnings**, page 2.
2. Turn the turbine power switch (36) to **OFF** and the compressor power switch (77) to **OFF**. Unplug the power cord to disconnect power.
3. Remove eleven screws (16) and the top cover (31).

NOTE: Be cautious not to damage the wires that connect to the cover.

4. Remove six screws (16), disconnect air hose (18), and remove the rear panel (22).
5. Remove the airline (81) from the front panel (30). Pay close attention to how the airline (81) is routed from the compressor (78) to the front panel (30).
6. Disconnect the leads from the fan (113), remove the mounting screws (112), nuts (114) and lock washers (28). Remove the fan (113) from the enclosure (1).
7. Disconnect the leads from the compressor (78). Refer to **Wiring Diagrams (ProComp)**, page 20.






8. Remove three screws (46) and lock washers (28) from the base of the enclosure (1).


Installation:

1. Install wire-tap connectors onto the new compressor (78) leads. For proper location, reference the compressor that was removed and the **Wiring Diagrams (ProComp)**, page 20.
2. Install new air line (81) onto the new compressor (78) outlet. Place the compressor (78) into the enclosure (1).
3. Apply thread locker to the compressor mounting screws (46) and install lock washers (28) and screws (46) through the base of the enclosure (1). Torque to 5-8 in-lb (0.5- 0.9 N•m).
4. Connect leads from the compressor (78). Refer to **Wiring Diagrams (ProComp)**, page 20.
5. Connect the airline (81) to the front panel (30), making sure the line isn't kinked.
6. Connect the fan (113) leads to the wire-tap connectors. Install fan (113) using the mounting screws (112), nuts (114), and lock washers (28). Torque to 15-20 in-lb (1.7 - 2.3 N•m).
7. Connect air hose (18) to rear panel (22) and install using six screws (16). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).
8. Install top cover (31) using eleven screws (16). Torque to 20-25 in-lbs (2.5 - 3.0 N•m).

Parts

Standard Models

Ref.	Torque
 1	110-115 in-lb (12.5 - 13.0 N•m)
 2	20--25 in-lb (2.5 - 3.0 N•m)
 3	15-20 in-lb (1.7 - 2.3 N•m)
 4	10-15 in-lb (1.1 - 1.7 N•m)
 5	35-40 in-lb (4.0 - 4.5 N•m)



ti30624b

Parts List - Standard Models

Ref. Part	Description	Qty	Ref. Part	Description	Qty
1	17R054 BOX, bottom, painted	1	21	108860 SCREW, machine	4
2	129531 SCREW, cap hex hd	1	22	17R055 COVER, back, painted	1
3	113817 BUMPER	4	23	114064 PLUG, inlet	1
4	100057 SCREW, cap, hex hd	4	24	15W998 SCREW, mach, torix	2
5	111040 NUT, lock, insert, nylock, 5/16	4	25	17N459 FITTING, barbed, exhaust	1
6	125135 WASHER, flat	3	26	100639 WASHER, lock	1
7	129443 NUT, coupler	3	27	101448 NUT, jam	1
8	GASKET, turbine	1	28	111593 SCREW, grounding	1
	15W153 7.0 Standard		29	17N871 HOSE, air	1
	15W152 9.0 Standard		30	17R056 COVER, front, painted	1
9	SPACER, back, turbine	3	31	17X786 KIT, cover	1
	17N374 7.0 Standard		32	17N390 HANDLE, carry, pivot	1
	17N376 9.0 Standard		33	17R608 SCREW, mach, torx pan hd	4
10	194094 PLATE, turbine	1	34	116969 NUT, lock	4
11	SPACER, front, turbine	3	35	LABEL, standard series	1
	17N373 7.0 Standard			17P297 7.0 Standard	
	17N375 9.0 Standard			17P298 9.0 Standard	
12	KIT, repair, turbine (includes 6, 7, 8, 9, 10, 11, 13, 14, 18)	1		17U103 Model 17T980	
	17R936 Model 17N263, 17T980, 17U105		36	120660 SWITCH, rocker	1
	17R937 Model 17N264		37	17N957 KNOB, potentiometer	1
	17R939 Models 17P528, 17P534, 17R074		38	CIRCUIT, breaker	1
	17R940 Models 17P529, 17P535, 17R075			114403 120V Models	
13	101530 SCREW, cap	3		16A348 230V Models	
14	192845 GASKET, duct	1	39	17R296 KIT, filter (includes 39a, 39b)	1
15	17N388 HOUSING, filter, inlet, motor	1	40	17N387 COVER, filter, turbine	1
16	129444 SCREW, machine, torx pan head	23	41	100011 NUT, wing	1
17	15Y606 FITTING, barbed	1	45	17R946 KIT, repair, potentiometer (includes 37, 67)	1
18	17M388 PACKING, o-ring	1	55▲	17R297 LABEL, warning	1
19	17N436 FITTING, outlet	1	56▲	15K616 LABEL, caution	1
20	KIT, repair, control, board (includes 21)	1	62	102063 WASHER, lock, ext	1
	17R942 120V Models		63▲	186620 LABEL, symbol, ground	1
	17R943 230V Models		67	17X783 ISOLATOR	1
	116168 Model 17T980		69▲	17R747 LABEL, set, international (not shown)	1
			70	17X785 WASHER, nylon	1

▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.

Parts List - ProContractor Models

Parts List - ProContractor Models

Ref.Part	Description	Qty	Ref.Part	Description	Qty
1	17R057 BOX, bottom, painted	1	30	17N477 COVER, front, painted	1
2	129604 GROMMET, rubber	1	31	17X788 KIT, cover	1
3	113817 BUMPER	4	32	17N390 HANDLE, carry, pivot	1
4	100057 SCREW, cap, hex hd	4	33	17R608 SCREW, mach, torx pan hd	4
5	111040 NUT, lock, insert, nylock, 5/16	4	34	116969 NUT, lock	4
6	125135 WASHER, flat	3	35	LABEL, ProContractor series	1
7	129443 NUT, coupler	3		17P299 7.0 ProContractor	
8	GASKET, turbine	1		17P300 9.0 ProContractor	
	15W153 7.0 ProContractor			17P301 9.5 ProContractor	
	15W152 9.0 ProContractor		36	129590 SWITCH, power	1
	192788 9.5 ProContractor		37	17N957 KNOB, potentiometer	1
9	SPACER, back, turbine	3	38	CIRCUIT BREAKER	1
	17N374 7.0 ProContractor			114403 120V Models	
	17N376 9.0 ProContractor			16A348 230V Models	
10	194094 PLATE, turbine	1	39	114689 BUSHING, strain relief	1
11	SPACER, front, turbine	3	40*	17R298 FILTER, air, motor	1
	17N373 7.0 ProContractor		41	17N467 COVER, filter	1
	17N375 9.0 ProContractor		42	129666 SCREW, mach	4
	17N377 9.5 ProContractor		43	17N930 DRAWER, tool	1
12	KIT, repair, turbine (includes 6, 7, 8, 9, 10, 11, 13, 14, 17a)	1	44*	17R298 FILTER, air, turbine	1
	17R936 Model 17N265		45	17P447 HOLDER, gun	1
	17R937 Model 17N266		47	17R948 POTENTIOMETER, assy (includes 21, 37, 88, 90, 93)	1
	17R938 Model 17N267, 17T982		61▲	17R297 LABEL, warning	1
	17R939 Models 17P530, 17P536, 17R078		62▲	15K616 LABEL, caution	1
	17R940 Models 17P531, 17P537, 17R079		70	17P909 INSERT, toolbox	1
	17R941 Models 17P532, 17P538, 17R080		72	117727 CLIP, wire	1
13	101530 SCREW, cap	3	73	17J933 LABEL, SmartStart	1
14	192845 GASKET, duct	1	79	15Y606 FITTING, barbed	1
15	17N481 PANEL, wall, inner	1	80	M70394 FITTING, barbed	1
16	129444 SCREW, machine, torx pan head	28	83	102040 NUT, lock	2
17	17N425 VALVE, check	1	85	186620 LABEL, ground	1
17a	17M388 PACKING, o-ring	1	86*	17R298 FILTER, air, turbine	1
18	17N871 HOSE, air	1	87	17P656 GASKET, wall, inner	1
19	17R093 TUBE, air, sensor	1	88	17P789 GASKET, board, display	1
20	KIT, repair, control board (includes 21, 88, 90)	1	90	17R394 GASKET, barrier, ribbon	1
	17R944 120V Models		93	17X783 ISOLATOR	1
	17R945 230V Models		97	17R769 PAD, drawer	1
21	108860 SCREW, machine	6	98	17S011 TAPE, high temp	1
22	17R058 COVER, back, painted	1	99▲	17R747 LABEL, set, international (not shown)	1
23	114064 PLUG, inlet	1	109	17R638 THERMISTER, harness	1
24	15W998 SCREW, mach, torx	2	110	17X785 WASHER, nylon	1
25	17N459 FITTING, barbed, exhaust	1			
26	100639 WASHER, lock	1			
27	101448 NUT, jam	1			
28	102063 WASHER, lock	1			
29	111593 SCREW, grounding	1			








▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.


* Filter Kit 17R298 includes items 40, 44, 86

Parts

Parts

ProComp Models

Ref.	Torque
	110-115 in-lb (12.5 - 13.0 N•m)
	20-25 in-lb (2.5 - 3.0 N•m)
	15-20 in-lb (1.7 - 2.3 N•m)
	10-15 in-lb (1.1 - 1.7 N•m)
	35-40 in-lb (4.0 - 4.5 N•m)
	5-8 in-lb (0.5 - 0.9 N•m)
	20-23 ft-lb (28.0 - 31.0 N•m)



ti30880a


Parts List - ProComp Models

Parts List - ProComp Models


Ref. Part	Description	Qty	Ref. Part	Description	Qty
1	17R057 BOX, bottom, painted	1	41	17N467 COVER, filter	1
2	129604 GROMMET, rubber	1	42	129666 SCREW, mach	4
3	113817 BUMPER	4	43	17N930 DRAWER, tool	1
4	100057 SCREW, cap, hex hd	4	44*	17R298 FILTER, air, turbine	1
5	111040 NUT, lock, insert, nylock, 5/16	4	45	17P447 HOLDER, gun	1
6	125135 WASHER, flat	3	46	116431 SCREW, mach, hex wash hd	3
7	129443 NUT, coupler	3	47	17R948 POTENTIOMETER, assy (includes 21, 37, 88, 90, 91, 93)	1
8	192788 GASKET, turbine	1	61▲	17R297 LABEL, warning	1
10	194094 PLATE, turbine	1	62▲	15K616 LABEL, caution	1
11	17N377 SPACER, front, turbine	3	70	17P909 INSERT, toolbox	1
12	KIT, repair, turbine (includes 6, 7, 8, 9, 10, 11, 13, 14, 17a)	1	72	117727 CLIP, wire	1
	17R938 Model 17N269		73	17J933 LABEL, SmartStart	1
	17R941 Models 17P533, 17P539, 17R081		77	120660 SWITCH, rocker	1
13	101530 SCREW, cap	3	78	KIT, repair, compressor	1
14	192845 GASKET, duct	1	17R962	Model 17N269 (includes 46, 81, 116)	
15	17N481 PANEL, wall, inner	1	17R964	Models 17P533, 17P539, 17R081 (includes 46, 81)	
16	129444 SCREW, machine, torx pan head	28	79	15X246 FITTING, connect, quick	1
17	17N425 VALVE, check	1	80	101936 NUT, jam, hex	2
17a	17M388 PACKING, o-ring	1	81	TUBE, air	1
18	17N871 HOSE, air	1	17Y952	120V Models	
19	17R093 TUBE, air, sensor	1	17R735	230V Models	
20	CONTROL, board, assembly, (includes 21, 88, 90, 91)	1	83	102040 NUT, lock	2
	17R944 Model 17N269		85	186620 LABEL, ground	1
	17R945 Models 17P533, 17P539, 17R081		86*	17R298 FILTER, air, turbine	1
21	108860 SCREW, machine	6	87	17P656 GASKET, wall, inner	1
22	17R058 COVER, back, painted	1	88	17P789 GASKET, board, display	1
23	114064 PLUG, inlet	1	90	17R394 GASKET, barrier, ribbon	1
24	15W998 SCREW, mach, torix	2	91	17R395 GASKET, barrier, ribbon, LED	1
25	17N459 FITTING, barbed, exhaust	1	93	17X783 ISOLATOR	1
26	100639 WASHER, lock	1	94	15Y606 FITTING, barbed	1
27	101448 NUT, jam	1	95	M70394 FITTING, barbed	1
28	102063 WASHER, lock	8	97	17R769 PAD, drawer	1
29	111593 SCREW, grounding	1	98	17S011 TAPE, high temp	1
30	17P294 COVER, front	1	99▲	17R747 LABEL, set, international (not shown)	1
31	17X787 KIT, cover	1	109	17R638 THERMISTOR, harness	1
32	17N390 HANDLE, carry, pivot	1	112	120094 SCREW	2
33	17R608 SCREW, mach, torx pan hd	4	113	FAN	1
34	116969 NUT, lock	4	17S031	Model 17N269	
35	17P302 LABEL, ProComp 9.5	1	17S141	Models 17P533, 17P539, 17R081	
36	129590 SWITCH, power	1	114	109466 NUT, lock	2
37	17N957 KNOB, potentiometer	1	115	17X785 WASHER, nylon	1
38	CIRCUIT BREAKER	1	116	115489 CLAMP	1
	114403 Model 17N269		▲ Replacement Danger and Warning labels, tags, and cards are available at no cost.		
	16A348 Models 17P533, 17P539, 17R081		* Filter Kit 17R298 includes items 40, 44, 86		
39	114689 BUSHING, strain relief	1			
40*	17R298 FILTER, air, motor	1			

Wiring Diagrams (Standard)

120V WIRING DIAGRAM




230V WIRING DIAGRAM




ti30765a

Wiring Diagrams (ProContractor)

120V WIRING DIAGRAM



120V UK & 230V WIRING DIAGRAM




ti30771a


Wiring Diagrams (ProComp)

Wiring Diagrams (ProComp)

120V WIRING DIAGRAM



230V WIRING DIAGRAM



ti30903a

Graco Information

For the latest information about Graco products, visit www.graco.com.

For patent information, see www.graco.com/patents.

TO PLACE AN ORDER, contact your Graco distributor or call 1-800-690-2894 to identify the nearest distributor.

All written and visual data contained in this document reflects the latest product information available at the time of publication.

Graco reserves the right to make changes at any time without notice.

Original instructions. This manual contains English. MM 3A5024

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA

Copyright 2014, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com

Revision C, January 2019