

## XP<sub>s</sub>-hf<sup>TM</sup> Proportioners

3A6283K

EN

***Mechanically linked, fixed ratio, plural-component system used for proportioning, mixing, and spraying two component coatings.***

***For professional use only.***


See page 10 for model information and working pressures.

See page 11 for component approvals.



### **Important Safety Instructions**

Read all warnings and instructions in this manual and in related manuals before using the equipment. Save these instructions.



# Contents

|   |           |   |           |
|---|-----------|---|-----------|
| <b>Related Manuals</b> .....                        | <b>3</b>  | <b>Maintenance</b> .....  | <b>50</b> |
| <b>Warnings</b> .....                               | <b>4</b>  | Hose Electrical Resistance .....                                      | 50        |
| <b>Important Isocyanate (ISO) Information</b> ..... | <b>7</b>  | Filters .....   | 50        |
| Isocyanate Conditions .....                         | 7         | Seals .....   | 50        |
| Keep Components A and B Separate .....              | 7         | Cleaning Procedure .....  | 50        |
| Moisture Sensitivity of Isocyanates .....           | 8         | Change the Mix Ratio .....  | 50        |
| Changing Materials .....                            | 8         | Clean Inlet Strainer Screen .....                                     | 51        |
| <b>Usage</b> .....                                  | <b>9</b>  | Check Heating Fluid Level .....                                       | 51        |
| <b>Models</b> .....                                 | <b>10</b> | Drain Heating Fluid .....   | 51        |
| XP-s-hf Systems .....                               | 11        | Feed Pumps .....  | 52        |
| Approvals .....                                     | 11        | Solvent Pump .....  | 52        |
| <b>Component Identification</b> .....               | <b>15</b> | XP Displacement Pumps .....   | 52        |
| XP-s-hf Proportioners (Model 577101 shown) .....    | 15        | Agitators .....   | 52        |
| Junction Box .....                                  | 17        | <b>Troubleshooting</b> .....  | <b>53</b> |
| Fluid Control Assembly .....                        | 18        | Pump Troubleshooting .....  | 55        |
| Main Air Controls .....                             | 18        | <b>Repair</b> .....   | <b>56</b> |
| Solvent Pump .....                                  | 19        | Pump Assembly Repair .....  | 56        |
| Heated Hopper Assembly .....                        | 20        | Recirculation Manifold with Over Pressure Relief Valves .....         | 57        |
| <b>System Components</b> .....                      | <b>21</b> | Replace Over Pressure Relief Valves .....                             | 58        |
| Air Control Components .....                        | 21        | <b>Parts</b> .....  | <b>60</b> |
| Fluid Line Components .....                         | 21        | XP50s-hf and XP70s-hf Proportioner .....                              | 60        |
| Heaters .....                                       | 22        | XP50s-hf and XP70s-hf Proportioners (Continued) .....                 | 61        |
| Pumps .....   | 22        | XP50s-hf and XP70s-hf Proportioners (Continued) .....                 | 62        |
| <b>Setup</b> .....                                  | <b>23</b> | Water Jacketed Heated Hose Packages .....                             | 64        |
| Initial System Setup .....                          | 23        | Non-Heated Hose Packages .....  | 66        |
| Proper Lifting of Sprayer .....                     | 23        | Non-Hazardous Location Electric Heated Hose Packages .....            | 68        |
| Grounding .....                                     | 24        | Hazardous Location Electric Heated Hose Packages .....                | 69        |
| Connect Power Source .....                          | 25        | Air Control Filter 25N583 Parts .....                                 | 71        |
| Connect Explosion-Proof Heaters .....               | 27        | Air Control Regulator 25N575 Parts .....                              | 72        |
| Motor Position .....                                | 27        | Solvent Pump 262392 Parts .....                                       | 73        |
| Connect Air Supply .....                            | 29        | Solvent Air Control 24F126 Parts .....                                | 74        |
| Connecting Heated Hose to Proportioner .....        | 29        | Heater Block Remote Manifold Kit .....                                | 75        |
| Connect Static Mixers, Gun, and Hoses .....         | 29        | Material Recirculation Manifold with Over Pressure Relief Valve ..... | 76        |
| Add Heating Fluid to Heated Hoppers .....           | 30        | Diaphragm Pump 273093 Parts .....                                     | 77        |
| Agitators (ED) .....                                | 32        | XP-hf Pump Assembly Parts .....                                       | 78        |
| Feed Pumps (EE) .....                               | 32        | <b>Recommended Spare Parts</b> .....                                  | <b>80</b> |
| Solvent Pump (BA) .....                             | 33        | <b>Accessories and Kits</b> .....                                     | <b>81</b> |
| XP Displacement Pumps (D) .....                     | 33        | <b>Dimensions</b> .....   | <b>82</b> |
| Add Heating Fluid to Hoses .....                    | 33        | System Dimensions .....   | 82        |
| <b>Operation</b> .....                              | <b>34</b> | <b>Technical Specifications</b> .....                                 | <b>83</b> |
| Flush Before Using Equipment .....                  | 34        | End of Product Life .....   | 85        |
| Prime the Empty System .....                        | 34        | <b>Graco Standard Warranty</b> .....                                  | <b>86</b> |
| Startup/Recirculate .....                           | 36        |   |           |
| Prime Solvent Pump .....                            | 38        |   |           |
| Prime the Material Lines .....                      | 40        |   |           |
| Spray .....   | 41        |   |           |
| Adjust the Restrictor .....                         | 42        |   |           |
| Pressure Relief Procedure .....                     | 43        |   |           |
| Flushing .....                                      | 44        |   |           |
| Overnight Shutdown .....                            | 48        |   |           |
| System Verification .....                           | 49        |   |           |
| Mix and Integration Tests .....                     | 49        |   |           |
| Appearance Test .....                               | 49        |   |           |
| Monitor Fluid Supply .....                          | 49        |   |           |
| Check Pot Life .....                                | 49        |   |           |
| Ratio Check .....                                   | 49        |   |           |




# Related Manuals







Manuals are available at [www.graco.com](http://www.graco.com).

| Manuals<br>in English                | Description  |
|--------------------------------------|--|
| 3A7469                               | XTR 5+™ and XTR 7+™ Spray Guns, Instructions - Parts         |
| <b>XP-hf Pump Package Components</b> |  |
| 334644                               | Xtreme® XL Air Motor, Instructions - Parts                   |
| 311762                               | Xtreme® Displacement Pumps, Instructions - Parts             |
| <b>Hopper Kits</b>                   |  |
| 3A6110                               | 25 Gallon Double-Wall Hopper Kit, Instructions - Parts       |
| 3A4032                               | Xtreme-Duty™ Agitator and Packages, Operation - Parts        |
| 307043                               | Monark® Air Motor, Instructions - Parts                      |
| <b>Heating</b>                       |  |
| 3A2954                               | Viscon® HF Heater, Instructions - Parts                      |
| 3A7523                               | XP™ Junction Box, Installation - Parts                       |
| <b>Solvent Flush</b>                 |  |
| 310863                               | Feed and Solvent Flush Kits, Instructions Parts              |
| 312794                               | Merkur® Pump Assembly, Instructions - Parts                  |
| <b>Accessories and Kits</b>          |  |
| 3A3320                               | XP and XP-hf™ PressureTrak™ Kit, Instruction - Parts         |
| 3A1331                               | XP Pressure Monitor Kit, Instructions - Parts                |
| 312769                               | Feed Pump and Agitator Kits, Instructions - Parts            |
| 3A0421                               | Ratio Check Kit, Instructions - Parts                        |
| 3A2573                               | Gun Splitter Valve, Instructions - Parts                     |
| <b>Water Heated Hose</b>             |  |
| 309524                               | Viscon HP Heater, Instructions - Parts                       |
| 3A5313                               | Xtreme-Wrap Water Heated Hose, Instructions - Parts          |
| 3A5314                               | Hose Heat Circulation XP and XP-hf Kit, Instructions - Parts |
| <b>Electric Heated Hose</b>          |  |
| 3A0590                               | Mix Manifold, Quickset Mix Manifold, Instructions - Parts    |
| 3A7524                               | Xtreme-Wrap Electric Heated Hose, Instructions - Parts       |





# Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual or on warning labels, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.

|  <b>DANGER</b>  |  |
|--|--|
| <br> | <p><b>SEVERE ELECTRIC SHOCK HAZARD</b></p> <p>This equipment can be powered by more than 240 V. Contact with this voltage will cause death or serious injury.</p> <ul style="list-style-type: none"> <li>• Turn off and disconnect power at main switch before disconnecting any cables and before servicing equipment.</li> <li>• This equipment must be grounded. Connect only to grounded power source.</li> <li>• All electrical wiring must be done by a qualified electrician and comply with all local codes and regulations.</li> <li>• Do not expose to rain. Store indoors.</li> </ul> |

|  <b>WARNING</b>  |   |
|--|---|
| <br><br><br> | <p><b>FIRE AND EXPLOSION HAZARD</b></p> <p>Flammable fumes, such as solvent and paint fumes, in <b>work area</b> can ignite or explode. Paint or solvent flowing through the equipment can cause static sparking. To help prevent fire and explosion:</p> <ul style="list-style-type: none"> <li>• Use equipment only in well ventilated area.</li> <li>• Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static sparking).</li> <li>• Ground all equipment in the work area. See <b>Grounding</b> instructions.</li> <li>• Never spray or flush solvent at high pressure.</li> <li>• Keep work area free of debris, including solvent, rags and gasoline.</li> <li>• Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present.</li> <li>• Use only grounded hoses.</li> <li>• Hold gun firmly to side of grounded pail when triggering into pail. Do not use pail liners unless they are anti-static or conductive.</li> <li>• <b>Stop operation immediately</b> if static sparking occurs or you feel a shock. Do not use equipment until you identify and correct the problem.</li> <li>• Keep a working fire extinguisher in the work area.</li> </ul> |
|   | <p><b>SPECIAL CONDITIONS FOR SAFE USE</b></p> <ul style="list-style-type: none"> <li>• If using the Viscon HP and HF Heaters see manuals for special conditions for safe use.</li> <li>• If using the PressureTrak, see the manual for special conditions for safe use.</li> </ul>  |



|  <h1>WARNING</h1> |   |
|--|---|
|                   | <p><b>SKIN INJECTION HAZARD</b></p> <p>High-pressure fluid from gun, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. <b>Get immediate surgical treatment.</b></p> <ul style="list-style-type: none"> <li>• Do not spray without tip guard and trigger guard installed.</li> <li>• Engage trigger lock when not spraying.</li> <li>• Do not point gun at anyone or at any part of the body.</li> <li>• Do not put your hand over the spray tip.</li> <li>• Do not stop or deflect leaks with your hand, body, glove, or rag.</li> <li>• Follow the <b>Pressure Relief Procedure</b> when you stop spraying and before cleaning, checking, or servicing equipment.</li> <li>• Tighten all fluid connections before operating the equipment.</li> <li>• Check hoses and couplings daily. Replace worn or damaged parts immediately.</li> </ul> |
|                 | <p><b>ENTANGLEMENT HAZARD</b></p> <p>Rotating parts can cause serious injury.</p> <ul style="list-style-type: none"> <li>• Keep clear of moving parts.</li> <li>• Do not operate equipment with protective guards or covers removed.</li> <li>• Do not wear loose clothing, jewelry or long hair while operating equipment.</li> </ul>  |
|                 | <p><b>MOVING PARTS HAZARD</b></p> <p>Moving parts can pinch, cut or amputate fingers and other body parts.</p> <ul style="list-style-type: none"> <li>• Keep clear of moving parts.</li> <li>• Do not operate equipment with protective guards or covers removed.</li> <li>• Equipment can start without warning. Before checking, moving, or servicing equipment, follow the <b>Pressure Relief Procedure</b> and disconnect all power sources.</li> </ul>   |



# WARNING



## EQUIPMENT MISUSE HAZARD

Misuse can cause death or serious injury.

- Do not operate the unit when fatigued or under the influence of drugs or alcohol.
- Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See **Technical Specifications** in all equipment manuals.
- Use fluids and solvents that are compatible with equipment wetted parts. See **Technical Specifications** in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request Safety Data Sheet (SDS) from distributor or retailer.
- Do not leave the work area while equipment is energized or under pressure.
- Turn off all equipment and follow the **Pressure Relief Procedure** when equipment is not in use.
- Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only.
- Do not alter or modify equipment. Alterations or modifications may void agency approvals and create safety hazards.
- Make sure all equipment is rated and approved for the environment in which you are using it.
- Use equipment only for its intended purpose. Call your distributor for information.
- Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces.
- Do not kink or over bend hoses or use hoses to pull equipment.
- Keep children and animals away from work area.
- Comply with all applicable safety regulations.



## PERSONAL PROTECTIVE EQUIPMENT

Always wear appropriate personal protective equipment and cover all skin when spraying, servicing equipment, or when in the work area. Protective equipment helps prevent serious injury, including long-term exposure; inhalation of toxic fumes, mists or vapors; allergic reaction; burns; eye injury and hearing loss. This protective equipment includes but is not limited to:

- A properly fitting respirator, which may include a supplied-air respirator, chemically impermeable gloves, protective clothing and foot coverings as recommended by the fluid manufacturer and local regulatory authority.
- Protective eyewear and hearing protection.



## BURN HAZARD

Equipment surfaces and fluid that is heated can become very hot during operation. To avoid severe burns:

- Do not touch hot fluid or equipment.



## TOXIC FLUID OR FUMES HAZARD





Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled or swallowed.

- Read Safety Data Sheets (SDSs) for handling instructions and to know the specific hazards of the fluids you are using, including the effects of long-term exposure.
- When spraying, servicing equipment, or when in the work area, always keep work area well-ventilated and always wear appropriate personal protective equipment. See **Personal Protective Equipment** warnings in this manual.
- Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.




# Important Isocyanate (ISO) Information

Isocyanates (ISO) are catalysts used in two component materials.

## Isocyanate Conditions

|  |   |   |   |  |
|--|---|---|---|--|
|   |  |  |  |  |
| <p>Spraying or dispensing fluids that contain isocyanates creates potentially harmful mists, vapors, and atomized particulates.</p> <ul style="list-style-type: none"> <li>• Read and understand the fluid manufacturer's warnings and Safety Data Sheets (SDSs) to know specific hazards and precautions related to isocyanates.</li> <li>• Use of isocyanates involves potentially hazardous procedures. Do not spray with this equipment unless you are trained, qualified, and have read and understood the information in this manual and in the fluid manufacturer's application instructions and SDSs.</li> <li>• Use of incorrectly maintained or mis-adjusted equipment may result in improperly cured material. Equipment must be carefully maintained and adjusted according to instructions in the manual.</li> <li>• To prevent inhalation of isocyanate mists, vapors, and atomized particulates, everyone in the work area must wear appropriate respiratory protection. Always wear a properly fitting respirator, which may include a supplied-air respirator. Ventilate the work area according to instructions in the fluid manufacturer's SDSs.</li> <li>• Avoid all skin contact with isocyanates. Everyone in the work area must wear chemically impermeable gloves, protective clothing and foot coverings as recommended by the fluid manufacturer and local regulatory authority. Follow all fluid manufacturer recommendations, including those regarding handling of contaminated clothing. After spraying, wash hands and face before eating or drinking.</li> </ul> |   |   |   |  |

## Keep Components A and B Separate

|   |  |   |  |  |
|---|--|---|--|--|
|    |  |  |  |  |
| <p>Cross-contamination can result in cured material in fluid lines which could cause serious injury or damage equipment. To prevent cross-contamination:</p> <ul style="list-style-type: none"> <li>• <b>Never</b> interchange component A and component B wetted parts.</li> <li>• Never use solvent on one side if it has been contaminated from the other side.</li> </ul> |  |   |  |  |

## Moisture Sensitivity of Isocyanates

Exposure to moisture (such as humidity) will cause ISO to partially cure, forming small, hard, abrasive crystal that become suspended in the fluid. Eventually a film will form on the surface and the ISO will begin to gel, increasing in viscosity.

### NOTICE

Partially cured ISO will reduce performance and the life of all wetted parts.

- Always use a sealed container with a desiccant dryer in the vent, or a nitrogen atmosphere. **Never** store ISO in an open container.
- Keep the ISO pump wet cup or reservoir (if installed) filled with appropriate lubricant. The lubricant creates a barrier between the ISO and the atmosphere.
- Use only moisture-proof hoses compatible with ISO.
- Never use reclaimed solvents, which may contain moisture. Always keep solvent containers closed when not in use.
- Always lubricate threaded parts with an appropriate lubricant when reassembling.

**NOTE:** The amount of film formation and rate of crystallization varies depending on the blend of ISO, the humidity, and the temperature.

## Changing Materials

### NOTICE

Changing the material types used in your equipment requires special attention to avoid equipment damage and downtime.

- When changing materials, flush the equipment multiple times to ensure it is thoroughly clean.
- Always clean the fluid inlet strainers after flushing.
- Check with your material manufacturer for chemical compatibility.
- When changing between epoxies and urethanes or polyureas, disassemble and clean all fluid components and change hoses. Epoxies often have amines on the B (hardener) side. Polyureas often have amines on the B (resin) side.

## Usage

The XPs-hf proportioner is a plural component sprayer that can mix and spray most two component epoxy and urethane protective coatings. It is a fixed-ratio system, where XP lowers can be changed to reconfigure the system to different volume mix ratios or spray pressures. See details on page 15.

All models are mounted on a metal skid, and are equipped with heated hoppers where the resin (A material) and catalyst (B material) are heated and pressure fed to the XP-hf pump assembly.

The materials are pumped to the primary heaters, where the resin and hardener are heated to the required spray temperatures. Heat improves the chemical reaction and lowers viscosity to improve the spray pattern.

The materials then flow to the mix manifold assembly. The mix manifold assembly consists of a recirculation manifold, mix manifold, and solvent flush valve. At the recirculation manifold, the materials either recirculate back to the heated hopper for continued heating, or combine at the mix manifold into one fluid line. The mixed material then flows through static mixers for continued mixing to the whip hose and out the spray gun.

The solvent flush system flushes the mixed material out of the manifold, static mixers, mixed material hoses, and spray gun.

When using quick-setting materials (less than 10 minute pot life) a remote mix manifold must be used. The mix manifold is separated from the recirculation manifold and mounted on a remote carriage. Heated hoses are used to prevent temperature loss in the materials while flowing to the remotely mounted mix manifold. Systems are configured to connect either a water heated hose, or an electric heated hose. Heated hoses are sold separately in various configurations and lengths depending on customer need.

## Over Pressure Protection



Mechanically linked pumps can create excessive fluid pressure if the full motor force is applied to only one of the fluid pumps.

To reduce the risk of injury due to skin injections, perform the following:

- A maximum air pressure set point blow-off valve is provided to limit maximum fluid pressure. Do not remove these valves.
- Color-coded, automatic, over-pressure relief valves are used to transfer excess fluid pressure back to the supply. Never plug the return hoses. See **Fluid Control Assembly**, on page 18.
- Never install individual shut off valves on the “A” and “B” lines. Common handles link the fluid control valves.
- A rupture disk is provided on the “B” material pump (pumps 145 cc and smaller) as a back-up to the over-pressure relief valve. If the rupture disk ever opens, do not operate the machine until the over-pressure valve and the rupture disc have been replaced.
- If changing pump lowers on your system, use the correct over-pressure relief valves from the chart on page 58.

# Models



XPs-hf sprayers are not approved for use in hazardous locations unless all components, all accessories, all kits, and all wiring meet local, state, and national code.

**NOTE:** Not all configurations are available.

## PART NUMBER CODE EXAMPLE:

| First Three Digits            |   |   | Fourth Digit             | Fifth Digit  | Last Digit   |
|-------------------------------|---|---|--------------------------|--|--|
| <b>+System Pressure Ratio</b> |   |   | <b>*Volume Mix Ratio</b> | <b>See ♦ Power Type (Fifth Digit of Part Number); page 11.</b> | <b>See Heated Hose Package (Last Digit of Part Number); page 11.</b> |
| 5                             | 7 | x | x                        | x  | x  |

### +System Pressure Ratio (First Three Digits of Part Number)

| First Three Digits | System Ratio | Maximum Fluid Working Pressure<br>psi (MPa, bar) |
|--------------------|--------------|--|
| 577xxx             | 70 : 1       | 7250 (50, 500)                                   |
| 578xxx             | 50 : 1       | 5000 (34, 344)                                   |

### \*Volume Mix Ratios - 70:1 (Fourth Digit of Part Number)

| Fourth Digit | Pump Ratio (A/B) | A Side Pump | B Side Pump | Combined Fluid Output (cc/cycle) | Fluid Flow at 40 cpm gpm (lpm) | Over-Pressure Relief Valve | Maximum Air Working Pressure psi (MPa, bar) | Fluid to Air Pressure Ratio | Maximum Fluid Working Pressure psi (MPa, bar) |
|--------------|------------------|-------------|-------------|----------------------------------|--------------------------------|----------------------------|---|-----------------------------|---|
| 5771xx       | 1 : 1            | L14AC0      | L14AC0      | 290                              | 3.0 (11.3)                     | Silver                     | 100 (0.7, 7)                                | 71 : 1                      | 7100 (49, 490)                                |
| 5772xx       | 2 : 1            | L18AC0      | L090C0      | 270                              | 2.8 (10.6)                     | Silver                     | 95 (0.65, 6.5)                              | 76 : 1                      | 7250 (50, 500)                                |
| 5773xx       | 3 : 1            | L22XC0      | L072C0      | 292                              | 3.0 (11.3)                     | Silver                     | 100 (0.7, 7)                                | 71 : 1                      | 7100 (49, 490)                                |
| 5774xx       | 4 : 1            | L22XC0      | L054C0      | 274                              | 2.8 (10.6)                     | Silver                     | 95 (0.65, 6.5)                              | 76 : 1                      | 7250 (50, 500)                                |

### \*Volume Mix Ratios - 50:1 (Fourth Digit of Part Number)

| Fourth Digit | Pump Ratio (A/B) | A Side Pump | B Side Pump | Combined Fluid Output (cc/cycle) | Fluid Flow at 40 cpm gpm (lpm) | Over-Pressure Relief Valve | Maximum Air Working Pressure psi (MPa, bar) | Fluid to Air Pressure Ratio | Maximum Fluid Working Pressure psi (MPa, bar) |
|--------------|------------------|-------------|-------------|----------------------------------|--------------------------------|----------------------------|---|-----------------------------|---|
| 5781xx       | 1 : 1            | L22AC0      | L22AC0      | 440                              | 4.6 (17.4)                     | Gold                       | 100 (0.7, 7)                                | 48 : 1                      | 4750 (33, 330)                                |
| 5782xx       | 2 : 1            | L29AC0      | L14AC0      | 435                              | 4.6 (17.4)                     | Gold                       | 100 (0.7, 7)                                | 48 : 1                      | 4750 (33, 330)                                |
| 5783xx       | 3 : 1            | L29AC0      | L097C0      | 387                              | 4.0 (15.1)                     | Gold                       | 95 (0.65, 6.5)                              | 53 : 1                      | 5000 (35, 345)                                |
| 5784xx       | 4 : 1            | L29AC0      | L072C0      | 362                              | 3.8 (14.4)                     | Gold                       | 85 (0.59, 5.9)                              | 59 : 1                      | 5000 (35, 345)                                |

## XPs-hf Systems

### ◆ Power Type (Fifth Digit of Part Number)


| Fifth Digit | VAC | Environment                      |
|-------------|-----|----------------------------------|
| xxxx0x      | 240 | Non-Hazardous/Ordinary Locations |
| xxxx1x      | 240 | Class I, Division 1              |
| xxxx2x      | 480 | Non-Hazardous/Ordinary Locations |
| xxxx3x      | 480 | Class I, Division 1              |

### Heated Hose Package (Last Digit of Part Number)


| Sixth Digit | Water Hose Heat with Circulation Pump | Electric Heated Hose |
|-------------|---------------------------------------|----------------------|
| xxxxx1      | ✓                                     |                      |
| xxxxx2      |                                       |                      |
| xxxxx3      |                                       | ✓                    |


## Approvals

### XPs-hf System Approvals





| System | Approvals   |
|--------|---|
| 57xx0x |                                |
| 57xx1x | System is intended for hazardous locations with the classification of Class I, Division 1, Group D T3 0°C to 54°C |
| 57xx2x |   |
| 57xx3x | System is intended for hazardous locations with the classification of Class I, Division 1, Group D T3 0°C to 54°C |







## Component Level Approvals







| Primary Heaters |                       | North American Location |           | European Atmosphere |           | Approvals   |
|-----------------|-----------------------|-------------------------|-----------|---------------------|-----------|---|
| Component       | Description           | Non-Hazardous           | Hazardous | Non-Explosive       | Explosive |   |
| 26C476          | 480V HF Ex            | ✓                       | ✓         | ✓                   | ✓         |  |
| 24W248          | 240V HF Ex            | ✓                       | ✓         | ✓                   | ✓         |   |
| 24P016          | 240V HF Non-Hazardous | ✓                       |           | ✓                   |           |   |
| 26C475          | 480V HF Non-Hazardous | ✓                       |           | ✓                   |           |   |









| Solvent Pump |              | North American Location |           | European Atmosphere |           | Approvals   |
|--------------|--------------|-------------------------|-----------|---------------------|-----------|---|
| Component    | Description  | Non-Hazardous           | Hazardous | Non-Explosive       | Explosive |   |
| 262392       | Solvent Pump | ✓                       | ✓         | ✓                   | ✓         |  |







| Junction Box                    |  | North American Location |           | European Atmosphere |           | Approvals   |
|---------------------------------|--|-------------------------|-----------|---------------------|-----------|---|
| Component                       | Description  | Non-Hazardous           | Hazardous | Non-Explosive       | Explosive |   |
| Hazardous Location Junction Box |  | ✓                       | ✓         |                     |           | <br>Class I, Division 1, Groups B, C, & D<br>UL 1203/CSA C22.2 No. 25 & 30   |
| 26C583                          | 480V Hazardous Location Junction Box                     | ✓                       | ✓         |                     |           | Designed to Standards:<br>UL 60079-0<br>UL 60079-25   |
| 26C906                          | 480V Hazardous Location Junction Box, Electric Hose Heat | ✓                       | ✓         |                     |           |   |
| 26C581                          | 240V Hazardous Location Junction Box                     | ✓                       | ✓         |                     |           |   |
| 26C905                          | 240V Hazardous Location Junction Box, Electric Hose Heat | ✓                       | ✓         |                     |           |   |
| Ordinary Location Junction Box  |  | ✓                       |           | ✓                   |           |   <br>Intertek<br>5024314<br>Conforms to UL STD 508A<br>Certified to CAN/CSA C22.2 No. 286 |
| 26C582                          | 480V Junction Box  | ✓                       |           | ✓                   |           |   |
| 26C904                          | 480V Junction Box, Electric Hose Heat                    | ✓                       |           | ✓                   |           |   |
| 26C580                          | 240V Junction Box  | ✓                       |           | ✓                   |           |   |
| 26C899                          | 240V Junction Box, Electric Hose Heat                    | ✓                       |           | ✓                   |           |   |

| Heated Hopper Assembly |                             | North American Location |           | European Atmosphere |           | Approvals  |
|------------------------|-----------------------------|-------------------------|-----------|---------------------|-----------|--|
| Component              | Description                 | Non-Hazardous           | Hazardous | Non-Explosive       | Explosive |  |
| 25P239                 | Immersion Heaters, 480V     | ✓                       | ✓         |                     |           | <br>For US/CAN:<br>Class I, Division 1, Groups B, C, & D (T4)   |
| 25N577                 | Immersion Heaters, 240V     | ✓                       | ✓         |                     |           | <br>For US/CAN:<br>Class I, Division 1, Groups B, C, & D (T4)   |
| 25N584                 | 5:1 Monark Pump             | ✓                       | ✓         | ✓                   | ✓         |  <br>II 1/2 G<br>Ex h IIb T2 Ga/Gb<br>ETL23ATEX0276<br>ITS21UKEX0322     |
| 25N588                 | Xtreme Duty Hopper Agitator | ✓                       | ✓         | ✓                   | ✓         |  <br>II 1/2 G<br>Ex h IIb T4 Ga/Gb<br>ITS16ATEX100984X<br>ITS21UKEX0262X |


| Heated Hose<br>(sold separately)                                       |                | North American<br>Location |           | European<br>Atmosphere |           | Approvals   |
|--|----------------|----------------------------|-----------|------------------------|-----------|---|
| Component  | Description    | Non-Hazardous              | Hazardous | Non-Explosive          | Explosive |   |
| See your water heated hose manual for complete list of part numbers    | Water Jacketed | ✓                          | ✓         | ✓                      | ✓         |  <br> II 2 G Ex h T5 Gb  |
| See your electric heated hose manual for complete list of part numbers | Electric       | ✓                          | ✓         | ✓                      |           |  <br>Heating Element Rating:<br><br>38141<br>Class I, Division 1 |

| Hot Water Heater |                          | North American<br>Location |           | European<br>Atmosphere |           | Approvals   |
|------------------|--------------------------|----------------------------|-----------|------------------------|-----------|---|
| Component        | Description              | Non-Hazardous              | Hazardous | Non-Explosive          | Explosive |   |
| 245864           | 480V HP<br>Hazardous     | ✓                          | ✓         | ✓                      | ✓         |   <br>Intertek<br>5024314<br>Class I, Division 1, Groups C, D (T3)<br>Ta = -20°C to 60°C<br>Certificate No:<br> 18-KA4BO-0072X<br>ATEX Ratings:  II 2 G Ex db IIB T4 Gb<br>ATEX Certificate No.<br>ITS14ATEX18155X<br>ITS21UKEX0367X<br>IECEx Ratings EX db IIB T4 Gb<br>IECEx Certificate No. IECEx ETL<br>14.0046X<br>Ta = -20°C to 60°C |
| 245863           | 240V HP<br>Hazardous     | ✓                          | ✓         | ✓                      | ✓         |   |
| 245869           | 240V HP<br>Non-Hazardous | ✓                          |           | ✓                      |           |   <br>Intertek<br>5024314<br>Certified to CAN/CSA C22.2 No.<br>61010-1-12 and 61010-2-010<br>Conforms to UL 61010-1 and<br>UL 61010-2-010  |
| 245870           | 480V HP<br>Non-Hazardous | ✓                          |           | ✓                      |           |   |


| 273093<br>Circulation Pump Kit |                | North American<br>Location |           | European<br>Atmosphere |           | Approvals  |
|--------------------------------|----------------|----------------------------|-----------|------------------------|-----------|--|
| Component                      | Description    | Non-Hazardous              | Hazardous | Non-Explosive          | Explosive |  |
| 24T461                         | Diaphragm Pump | ✓                          | ✓         | ✓                      | ✓         |   <br> II 2 G Ex h IIc Ta Gb |

# Component Identification

## XP-hf Proportioners (Model 577101 shown)



### XP-hf Pump Assembly





## Component Identification

### Key:

|   |  |    |  |
|---|--|----|--|
| A | XP-hf Motor Air Supply Hose            | T  | Yoke with Rod Bearings   |
| B | Stand                                  | U  | Recirculation Lines  |
| C | <b>Main Air Controls</b> , see page 18 | X  | Motor Position Indicator Bracket                                     |
| D | XP Displacement Pump                   | V  | Connecting Rod Nut   |
| E | Xtreme XL Air Motor                    | Y  | Over-Pressure Rupture Disk;<br>(for pumps that are 145cc or smaller) |
| F | Primary Heaters                        | BA | Solvent Pump, see page 19  |
| H | Solvent Pump Controls; see page 19     | ZC | Electrical Enclosure, see page 17                                    |
| J | Heated Hopper Assembly; see page 20    | ZF | Hot Water Reservoir (if equipped)                                    |
| K | Frame, Skid                            | ZG | Diaphragm Pump (if equipped)   |
| N | Fluid Control Assembly; see page 18    | ZP | Diaphragm Pump Needle Valve (if equipped)                            |
| P | Pump Tie Rods                          | ZT | Hot Water Heater (if equipped)                                       |
| R | Motor Adapter Plate                    | ZU | Mixed Material Gun and Hose  |
| S | Adjustable Packing Nuts with Wet Cups  |    |  |

## Junction Box




### Key:

MP Main Power Switch  
 ZA Power Indicator Light  
 ZB Primary Heater Switches  
 ZC Electrical Enclosure  
 ZE Hose Heater Switch  
 ZH Strain Relief (Non-hazardous locations only)  
 ZJ Electric Heated Hose Temperature Controller / Display (Non-hazardous locations only)

ZK Hose Heater Harness Entry Point  
 ZL Thermocouple Sensor Entry Point  
 ZM Fluid Heater and Hopper Heater Harness Entry Point  
 ZN Hopper Heater Switches  
 ZR Electric Heated Hose Temperature Controller (Hazardous locations only)  
 ZS Main Power Entry Point  
 ZW Temperature Display (Hazardous locations only)

## Fluid Control Assembly


Shown with water-heated hose configuration



### Key:

- AA Recirculation Manifold
- AB Mix Manifold
- AC Recirculation Handle (shown closed), see page 21.
- AD Solvent Flush Valve
- AE Dual Shutoff Handle (shown closed)
- AF Fluid Pressure Gauges
- AH Fluid Recirculation Fittings
- AJ B Component Adjustable Fluid Restrictor; see page 42
- AK A and B Mix Manifold Check Valves
- AL Solvent Inlet Check Valve
- AM Automatic, Spring Loaded, Color-Coded, Over-Pressure Relief Valves; with grease fittings
- AN Static Mixer Tubes; 3/8 npt(m)
- AP Recirculation Manifold Outlet
- AR Mix Manifold Inlet
- AW Primary Static Mixer Tubes
- AV Cleanup Static Mixer Tube
- AU Long Fasteners (shipped loose with Remote Manifold kit)
- MC Remote Manifold Carriage

## Main Air Controls




### Key:

- AI Main Air Inlet
- CA Motor Air Valve
- CB Motor Air Pressure Regulator
- CC Air Filter with Auto Drain
- CD Main Motor Air Pressure Gauge
- CE Filtered Air Distribution Manifold
- CF Main Air Shutoff Valve
- CG XP-hf Motor Air Pressure Relief Valve

# Solvent Pump


## Pump



### Key:

- BA Solvent Pump
- BB Siphon Tube
- BE Solvent Prime Valve
- BF Solvent Supply Hose
- BG Solvent Prime Hose
- BH Solvent Pump Wet Cup


## Air Controls



### Key:


- DA Solvent Air Shutoff Valve (Relieving)
- DB Solvent Air Pressure Regulator
- DC Solvent Air Pressure Gauge
- DD Solvent Air Outlet
- DE Solvent Air Inlet

## Heated Hopper Assembly



**Key:**

- EA Double-Wall Hopper
- EB Hopper Lid
- EC Hopper Heater
- ED Agitator
- EE Feed Pump
- EF Y-Strainer
- EG Recirculation Tube
- EH Material Drain
- EJ Heating Fluid Drain Valve



- EK Heating Fluid Fill Port
- EL Heating Fluid Vent
- EM Air Valve (Feed Pump)
- EN Air Regulator (Feed Pump)
- EP Air Valve (Agitator)
- ER Air Regulator (Agitator)
- ES Y-Strainer Valve
- ET Fill Port Cap
- EU Accessory Ports



# System Components

## Air Control Components

### XP-hf Motor Air Valve (CA)



Trapped air can cause the pump to cycle unexpectedly, which could result in serious injury from splashing or moving parts. Use the XP-hf Motor Air Valve (CA) to relieve trapped air.

Be sure the valve is easily accessible from the pump and located downstream from the air regulator (CB).

To relieve air trapped between the air motor when the valve is closed:

1. Open the valve to supply air to the motor.
2. Close the valve to shut off air to the motor, and bleed any trapped air from the motor.

### XP-hf Motor Air Pressure Relief Valve (CG)

Automatically opens to relieve air pressure if supplied pressure exceeds preset limit. Use the correct air pressure relief valve for the system ratio:

| XP70s-hf |            | XP50s-hf |            |
|----------|------------|----------|------------|
| Ratio    | Valve Part | Ratio    | Valve Part |
| 1:1      | 113498     | 1:1      | 113498     |
| 2:1      | 114055     | 2:1      | 113498     |
| 3:1      | 113498     | 3:1      | 114055     |
| 4:1      | 114055     | 4:1      | 16M190     |

### Main Air Filter (CC)

Removes harmful dirt from compressed air supply. A minimum 40 micron filter is used.

### XP-hf Motor Air Pressure Regulator (CB)

Adjusts air pressure to the motor and fluid outlet pressure of pump. Locate the air regulator close to the pump. Read air pressure on the gauge.

### Main Air Shutoff Valve (CF)

Controls the flow of inlet air. Close main air shutoff valve to stop all components and pumps.

## Fluid Line Components

### Recirculation Manifold (AA)

Controls recirculation and pump priming.

### Mix Manifold (AB)

Combines A and B fluid into one fluid line.

### Recirculation Handle (AC)

Directs fluid flow for recirculation or mixing. Move to open position to relieve fluid pressure, prime pumps, and circulate material in hoppers. Move to closed position to spray mixed material.

### Dual Shutoff Handle (AE)

Controls A and B fluid flow for mixing and dispensing. Close before flushing.

### Solvent Flush Valve (AD)

Controls solvent flow to the mix manifold, hose, and spray gun.

### Static mixer (AV, AW)

Thoroughly mixes the two fluids and delivers the mixed fluid to the spray gun.

## Heaters

### Primary Heaters (F)

Viscon HF Fluid Heaters heat resin and hardener before the materials combine in the mix manifold assembly. The heater improves chemical reaction and lowers viscosity of material to improve the spray pattern. There are two Viscon HF heater variants (hazardous location heaters, and non-hazardous location heaters). For approval rating, see **Approvals**, page 11 regarding your primary fluid heaters.

### Hot Water Heater (ZT)

Viscon HP Fluid Heater is included in the water heated hose packages. Heating fluid is circulated by a diaphragm pump through the heater and into the water jacketed lines surrounding the material hoses. There are two Viscon HP heater variants (hazardous location heaters and non-hazardous location heaters). For approval rating, see **Approvals**, page 14, regarding your primary fluid heaters.

### Hopper Heaters (EC)

Immersion heaters used to heat the outer jacketed area of the double walled hoppers. The outer jacket is filled with heating fluid to condition the resin and hardener materials.

## Pumps

### XP-hf Pump Assembly

A mechanically linked, fixed-ratio system that consists of a singular air motor and two individual XP displacement pumps.

### XP Displacement Pump (D)

Pump used to deliver the resin and hardener materials at high pressure to the mix manifold and spray gun.

### Solvent Pump (BA)

Pump used to flush the mix manifold, hose, and gun.

### Feed Pumps (EE)

Pumps that transfer conditioned resin and hardener materials to the primary pump. Using feed pumps is the preferred method to transfer viscous material compared to the gravity feed method.

### Diaphragm Pump (ZG)

Pump equipped on water heated hose packages, used to circulate the heating fluid through the water heated hose.

# Setup

## Initial System Setup



1. Check the shipment for accuracy. Ensure you have received everything you ordered. See **Component Identification**, page 15.
2. Check for loose fittings and fasteners.
3. If any accessories are added, refer to their **Related Manuals** listed on page 3 for all warnings and instructions.
4. Confirm air supply requirements. This system requires a 1.0 in. airline.
5. Confirm electric power requirements and make sure a properly sized electrical cord is used.

**NOTE:** A minimum of 25 gallons (95 liters) of heating fluid is needed. Additional heating fluid is needed if water heated hose is used.

**NOTE:** A minimum of 10 gallons (39 liters) of “A” and “B” materials are needed to load the hoppers and prime the system.


**NOTE:** A minimum of 25 gallons (95 liters) of solvent is required for flushing.

**NOTE:** Empty metal pails for both “A” and “B” materials are required for flushing.

### Location

1. Locate the proportioner on a level surface. Follow the **Proper Lifting of Sprayer** procedure.
2. Position the proportioner for convenient operator access and maintenance, proper routing of air and fluid lines, and easy connection of components and accessories.

## Proper Lifting of Sprayer



Follow these instructions to help prevent serious injury or damage to equipment. Never lift while a hopper is filled.

### NOTICE


To prevent spilling and to ensure even weight distribution, drain all fluid prior to lifting the proportioner.

### Lift Using a Forklift

The proportioner can be raised and moved using a forklift. Disconnect power and air from the system. Carefully lift the proportioner; make sure it balances evenly.

### Lift Using a Hoist

- Lift the system with a lift apparatus rated appropriately for the weight of the system (see **Technical Specifications**, page 83).
- Do not lift the system by the handle on the hoppers or air motor lift ring.
- Lift the system using the lift eyes shown in the lifting illustration.



t34194a


## Grounding



The equipment must be grounded to reduce the risk of static sparking and electric shock. Electric or static sparking can cause fumes to ignite or explode. Improper grounding can cause electric shock. Grounding provides an escape wire for the electric current.

**System:** Connect the supply ground wire in the electrical compartment as shown in **Connect Power Source** on page 25.

**Pump:** Connect ground wire 244524 (GW) to the ground stud (GS) on the air motor (E).



Connect the other end of the ground wire to a true earth ground for system without heaters, otherwise connect to HF heater clamp bar.

**Air and fluid hoses:** Use only electrically conductive hoses with a maximum of 300 ft (91 m) combined hose length to ensure grounding continuity. Check electrical resistance of hoses regularly. If total resistance to ground exceeds 29 megohms, replace hose immediately.

**Spray gun:** Ground through connection to a properly grounded fluid hose and pump.

**Solvent pails:** Follow your local code. Use only metal pails, which are conductive, placed on a grounded surface. Do not place pail on a non-conductive surface, such as paper or cardboard, which interrupts grounding continuity.

**To maintain grounding continuity when flushing or relieving pressure:** Hold the metal part of the spray gun firmly to the side of a grounded metal pail, then trigger the gun.

**Work area:** Ground the object being sprayed, fluid supply container, and all other equipment in the work area.



**Air compressor:** Follow manufacturer's recommendations.

**Object being sprayed:** Follow your local code.

**Material supply container:** Follow your local code.

## Connect Power Source

**NOTE:** Required voltage and amperage is noted on the control panel label. See **Power Cord Guidelines** tables below.

|   |   |  |  |  |
|---|---|--|--|--|
|    |  |  |  |  |
| <p>To help prevent injury from electric shock, turn off and disconnect power at the main switch before connecting any cables and before servicing equipment. All electrical work must be done by a qualified electrician and comply with local codes and regulations.</p> |   |  |  |  |

Use the intended entry locations shown in **Junction Box**, page 17.

1. Turn the main power switch (MP) off.
2. Open the junction box door.
3. **Non-Hazardous Locations only:** Route the power cord through the strain relief (ZH) into the electrical enclosure (ZC).

**Hazardous Locations only:** Follow local codes and regulations for routing the power through the main power entry point (ZS).

**NOTE:** The machine is provided with jumpers in the 380 Vac 3-Phase Wye position.

**NOTE:** Terminal jumpers are not used for 480V.

4. Connect the ground wire to the ground terminal (G).
5. Connect the power cord to the disconnect as shown in **XP's-hf Wiring Diagram**, page 26. Gently pull on all connections to verify that they are properly secured.
6. **Non-Hazardous Locations only:** Tighten the strain relief (ZH).
7. **Hazardous Locations:** Follow local codes and regulations for sealing the power cable entering into the enclosure.
7. Install the supplied terminal jumpers in the positions shown in the **XP's-hf Wiring Diagram**, page 26.
8. Verify that all items are connected properly as shown in the **XP's-hf Wiring Diagram**, page 26, then close the electrical enclosure (ZC) door.

## Power Cord Guidelines


Use the guidelines listed in the table below to determine the power cord needed for your specific system.

| Models with 240 Volt Viscon HF Fluid Heater |                            |        |        |        |        |        |
|---|----------------------------|--------|--------|--------|--------|--------|
| Junction Box                                | Full Load Peak Amperes (A) |        |        |        |        |        |
|   | xxxx01                     | xxxx11 | xxxx02 | xxxx12 | xxxx03 | xxxx13 |
| 240 V, 1 Phase                              | 87                         | 87     | 71     | 71     | 84     | 84     |
| 240 V, 3 Phase                              | 76                         | 76     | 65     | 65     | 73     | 73     |
| 380 V, 3 Phase                              | 48                         | 48     | 48     | 48     | 48     | 48     |
| 480 V                                       |                            |        |        |        |        |        |


| Models with 480 Volt Viscon HF Fluid Heater |                            |        |        |        |        |        |
|---|----------------------------|--------|--------|--------|--------|--------|
| Junction Box                                | Full Load Peak Amperes (A) |        |        |        |        |        |
|   | xxxx21                     | xxxx31 | xxxx22 | xxxx32 | xxxx23 | xxxx33 |
| 240 V, 1 Phase                              |                            |        |        |        |        |        |
| 240 V, 3 Phase                              |                            |        |        |        |        |        |
| 380 V, 3 Phase                              |                            |        |        |        |        |        |
| 480 V                                       | 28                         | 28     | 26     | 26     | 27     | 27     |

XPShf Wiring Diagram

NON-HAZARDOUS LOCATIONS



HAZARDOUS LOCATIONS







230 Vac  
1-Phase Delta

230 Vac  
3-Phase Delta





380 Vac  
3-Phase Wye

480 Vac  
3-Phase Delta

Disconnect




Terminal  
Jumpers



## Connect Explosion-Proof Heaters

### Hazardous location proportioners only (xxx1x, xxxx3x)



If your sprayer is intended for hazardous locations, a qualified electrician must connect the explosion-proof heater wiring. Ensure wiring and installation comply with local electrical codes and regulations.

Improperly installed or connected equipment may result in fire, explosion, or electric shock. Follow all local codes and regulations.

Ensure wiring, wiring connections, switches, and electrical distribution panel all meet flame-proof (explosion-proof) installation requirements.

Refer to your Junction Box manual for the wiring diagram for hazardous locations.

Refer to your Viscon HP heater manual for electrical connection instructions and guidelines in hazardous locations.

Refer to your Viscon HF heater manual for electrical connection instructions and guidelines in hazardous locations.


## Motor Position

The motor position must be set for the volume mix ratio of the system.

**NOTE:** Changing the motor position does not change the mix ratio.

### Check Motor Position

1. Verify that the correct pumps are mounted for your volume mix ratio. See the **Models** chart on page 10.




2. Verify that the motor position is adjusted correctly for that volume mix ratio. If not, perform the following **Change Motor Position** procedure.


### Change Motor Position

There are specific motor positions for each mix ratio setting. To Adjust the position of the air motor:

1. Verify that the XP-hf motor air valve (CA) is closed.
2. Perform the **Check Motor Position** procedure. If the position is incorrect, continue to the next step.
3. Loosen the eight fasteners and remove the two pump guards.



4. Loosen the three nuts below the motor tie rods (P).



5. Slide the tie rods (P) and motor (E) until the indicator lines are aligned with your ratio.

**NOTICE**

Do not hit the tie rods (P) with a hammer. Damage to the air motor base may result.

6. Tighten the three nuts.
7. Install the pump guards.




## Connect Air Supply

Connect the air supply hose to the main air inlet (AI).


Use a 1.0 in. (25.4 mm) ID minimum air hose. Do not use pin fitting type quick disconnect.

Connect any air-powered accessories to the accessory port (CM).



## Connecting Heated Hose to Proportioner


1. Disconnect the solvent outlet hose (BF) and elbow fitting (BK) from the solvent flush valve (AD).
2. Loosen the union fittings (AR) on the mix manifold inlet that connect to the recirculation manifold (AA) to disconnect the mix manifold (AB).



3. **For water jacketed heated hoses**, follow **Connect Static Mixers, Gun, and Hoses**, page 30.
4. **For electric heated hoses**, see your heated hose manual for installation. See **Related Manuals**, page 3.

## Connect Static Mixers, Gun, and Hoses

1. Connect the outlet of the two primary static mixer tubes (AW) to the gun and hose assembly (ZU).
2. Check that all connections are tight.



### NOTICE

To prevent creating a flare on the mixer tube, do not use a union swivel end on the mix tube inlet.

## Add Heating Fluid to Heated Hoppers




1. Use a 50/50 mixture of water and ethylene glycol (engine coolant) for heating fluid in the outer cavity of the hopper. Approximately 12 gallons (45 liters) of heating fluid is needed for each hopper.


### NOTICE

Other glycols (RV/Marine Antifreeze) are not recommended for use as a heating fluid. These materials are not rated for higher temperatures and could cause damage to the immersion heaters.

**NOTE:** The ethylene glycol mixture provides the fastest heat-up time and prevention of algae build-up regardless of ambient temperature. Oil can be used but heat-up time will increase and the hopper level needs to be lower to allow for thermal expansion.



2. Remove fill port cap (ET) and pour heating fluid in the outer cavity through the fill port (EK).




3. Use approximately 12 gallons (53 liters) to fill the cavity. Stop filling when fluid is visible at the bottom of the port elbow.


**NOTE:** Thermal expansion may cause the heating fluid to overflow after it rises to temperature.

**NOTE:** If using water mix, the maximum fluid level must be 1 in. (2.5 cm) below side port level.

**NOTE:** If oil is the heating fluid, the maximum oil level must be 3 in. (7.6 cm) below the hopper side port level.



4. Replace the fill port cap (ET).





**NOTICE**

Any portion of the heating element exposed to air will lead to overheating and premature burnout. Ensure that the element is completely submerged.


## Agitators (ED)

The Xtreme-Duty Agitator is provided with an airline lubricator to aid in proper maintenance. Fill the lubricator with Air Motor Oil 202659 (do not fill past the maximum level shown in the oil fill sight glass). Set the lubricator feed rate at one drop of oil per minute. Do not overfeed the oil, or the exhaust air may become contaminated.

Adjusting Knob




Fill Port




## Feed Pumps (EE)

Fill the wet-cup half full with Graco Throat Seal (TSL™) or a compatible solvent.




## Solvent Pump (BA)

Before starting, fill wet cup (BH) 1/3 full with Graco Throat Seal Liquid (TSL) or compatible solvent.



## XP Displacement Pumps (D)


Make sure the A and B pump packing nuts are tightened. Fill the A and B pump packing nuts with TSL.



## Add Heating Fluid to Hoses

(Water jacket heated hose packages only)

1. Add a 50/50 mixture of water and ethylene glycol to the reservoir (ZF) of the diaphragm pump (ZG).
2. Slowly open the needle valve (ZP) to circulate the fluid with the diaphragm pump (ZG) to remove air from the system.
3. Continue adding heating fluid to the reservoir (ZF) as air continues to bleed from the system.
4. Stop the pump when there is no more air in the system, fill the reservoir (ZF) halfway, then replace the cap.




# Operation

## Flush Before Using Equipment


The system was tested with lightweight oil, which is left in the fluid passages to protect parts. To avoid contaminating your fluid with oil, first flush the equipment with a compatible solvent before using the equipment. Follow the **Flushing** procedure, page 44.

## Prime the Empty System




To help prevent injury from burns, wear gloves when using solvents and/or if the fluid temperature exceeds 122 °F (50 °C).


1. Prepare your materials prior to adding to heated hoppers. Ensure resin materials are thoroughly agitated, homogeneous, and pourable prior to adding them to the hopper. Stir hardeners back into suspension prior to adding material to the hopper.
2. Move the recirculation lines (U) to grounded empty containers.




3. Fill the "A" and "B" hoppers (J) with respective material, up to 25 gallons. Fill the "A" side (blue) with resin or base material. Fill the "B" side (green) with the hardener or catalyst.




4. Open the main air valve.
5. Close the dual shutoff handle (AE).



6. Open the recirculation handle (AC).




7. Fully open the feed pump air regulator (EN) and turn the feed pump air valve (EM) to OPEN.
8. Slowly open the feed pump air regulator (EN) to start the feed pump.



**NOTE:** If the material is too thick, the XP-hf pump will need to be used. See **Startup/Recirculate** on page 36.

9. Dispense fluid into the containers until clean fluid flows through the “A” and “B” recirculation lines.
10. Close the feed pump air regulator (EN).
11. Close the feed pump air valve (EM).

12. Move the recirculation lines (U) back to the correct hopper.



13. Repeat for the other side.
14. If running solvent through the system for the first time, proceed to **Flushing** on page 44 to empty the system of solvent, then repeat this process with “A” and “B” materials.




## Startup/Recirculate




**NOTE:** Use recirculation mode to condition materials prior to spraying; agitating and heating materials evenly. The hopper heaters are factory set to maintain temperatures of conditioned materials only. To bring spray material up to temperature, the material needs to circulate through the HF heaters while adjusting the heater set point to the desired temperature.


1. Ensure that the main power switch (MP) is ON at the junction box.




2. Turn on the hopper heat switches (ZN).




3. Ensure the agitator air regulator is fully closed and open the agitator air valve (EP) to the OPEN position.



4. Slowly increase the agitator air regulator (ER) to turn the agitator until the desired speed is reached.
5. Ensure the feed pump air regulator (EN) is fully closed and open the feed pump air valve (EM) to the OPEN position.



6. Slowly open the feed pump air regulator (EN) until the pump starts. Cycle the feed pump slowly until the feed pump stalls.
7. Repeat steps 3-6 for the other heated hopper.
8. Open the recirculation valve handle (AC).



9. Fully open the XP-hf air pressure regulator (CB) then turn the air valve (CA) to OPEN. Use the XP-hf air pressure regulator (CB) to slowly increase the air pressure until the XP-hf pumps start running slowly.
10. Turn on the primary heater switches (ZB). To adjust the heater temperature, refer to your Viscon heater manual for instructions.
11. Recirculate the fluids to raise the temperature of the materials in the hoppers evenly. Continue running the pump until the material is uniform and reached the desired temperature.

**NOTE:** Begin circulating the XP-hf pump to run at approximately 10 cycles/min to evenly heat materials, increase or decrease the pump rate depending on material conditions.



12. **For systems with water-heated hose:** Pump setting - Set the flow rate of the heating fluid by opening the diaphragm pump (ZG) needle valve (ZP) 45°- 60° open until the pump cycles 60-80 cycles/min (0.7-1.0 gpm or 2.6-3.8 l/min).

13. **For systems with water-heated hose only:** Heater setting - Adjust the heater thermostat to the desired temperature. The setting at the heater output thermometer should be approximately 10 °F (6 °C) higher than the desired paint temperature. Never exceed the XP system 160 °F (71 °C) maximum fluid temperature rating. See your Viscon HP heater manual for instructions.

As a general guideline, heater knob settings are #7 for 105 °F (40 °C), #8 for 135 °F (57 °C), and #8 1/2 for 150 °F (65 °C).


**NOTE:** If the hose heat is not being used for more than one hour, shut off the hot water heater (ZT) and diaphragm pump (ZG) to lengthen heater life.

14. On initial start-up, proceed to **Flushing** on page 44.


## Prime Solvent Pump




1. Connect a ground wire (not included) to a metal pail of solvent.
2. Place the siphon tube (BB) and the solvent circulation hose (BG) in the pail of solvent.




3. Open the solvent prime valve (BE).
4. Open the solvent pump air valve (DA). Slowly turn the solvent pump air regulator (DB) clockwise to prime the solvent pump and route solvent back to the pail. Close the solvent prime valve (BE) and air valve (DA).




5. Open the solvent flush valve (AD) on the mix manifold.




6. Ensure the trigger lock (TL) is engaged. Remove the spray tip.




7. Disengage the trigger lock (TL) and trigger the gun into a grounded metal pail while holding the metal part of the gun firmly against the side of the pail. Use a pail lid with a hole to dispense through. Seal around the hole and gun with a rag to prevent splash back. Be careful to keep fingers away from the front of the gun.



8. Slowly turn the solvent pump air regulator (DB) clockwise to prime the solvent pump and push air out of the mix hose and gun. Continue to hold the metal part of the gun firmly against the side of the grounded metal pail and trigger the gun until all air is purged.



9. Close the solvent pump air valve (DA) and trigger the gun to relieve pressure. Engage the trigger lock (TL). Replace the spray tip.



10. Close the solvent flush valve (AD).


**NOTE:** Solvent pump may stay pressurized while spraying.

**NOTICE**


To prevent material from curing inside the system, never spray mixed material without the solvent pump and hose primed with solvent for proper flushing in time to clear the mixed material.

## Prime the Material Lines


(Units with heated hose and remote mix manifold)




1. Follow the **Prime the Empty System** procedure on page 34.
2. Follow the **Startup/Recirculate** procedure on page 36.
3. Close the recirculation handle (AC).




4. Open the dual shutoff handles (AE).



5. Engage the trigger lock (TL). Remove the spray tip.




6. Slowly increase the XP-hf motor air regulator (CB) enough to cycle the pumps.
7. Disengage the trigger lock (TL) and trigger the gun into a grounded metal pail while holding the metal part of the gun firmly against the side of the pail. Use a pail lid with a hole to dispense through. Seal around the hole and gun with a rag to prevent splash-back. Keep fingers away from the front of the gun.




8. Close the XP-hf motor air valve (CA).


# Spray




1. Follow the **Startup/Recirculate** procedure on page 36.
2. Ensure that the XP-hf air pressure regulator (CB) and is fully closed and open the XP-hf air valve (CA).




3. Close the recirculation handle (AC) and the solvent flush valve (AD). Open the dual shutoff handle (AE).




4. Slowly increase the XP-hf air regulator (CB) to cycle the pumps.



5. Engage the trigger lock (TL). Remove the spray tip.




6. Disengage the trigger lock (TL) and trigger the gun while holding against a grounded metal pail. Use a metal pail lid with a hole to dispense through to avoid splashing-back. Dispense out of the mix hose until a well mixed coating flows from the gun.



7. Engage the trigger lock (TL). install the tip on the gun.

8. Adjust the XP-hf motor air regulator (CB) to the necessary spraying pressure and apply a coating to a test panel.

**NOTE:** Run **System Verification** tests everyday (see page 49).



**NOTE:** Excess pressure increases overspray and pump wear.

9. Check and record gauge readings frequently during operation. A change in gauge readings indicates a change in system performance.

**NOTE:** A pressure drop occurs during pump stroke changeover. It should be quick and synchronous.


10. Flush the mix manifold as necessary during the day's operation. Follow the **Flush Mixed Material** on see page 44.
11. Follow the **Flushing** procedure on page 44. when you are finished spraying or before potlife expires.

**NOTE:** Mixed material potlife or working time decreases with increased temperature. Pot life in the hose is much shorter than the dry time of the coating

## Adjust the Restrictor

The B side restrictor (AJ) reduces momentary “lead/lag” ratio imbalance of the A and B flow into the static mixer tubes (AN, AW) when the gun opens. The error is caused by differences in viscosity, volume, and hose expansion.

The restrictor is used primarily when the mix manifold is positioned remotely from the machine with a short mix hose to the spray gun. It can also be used in the ratio check procedure.




If the mix manifold (AB) is mounted on the machine, you do not need to adjust the restrictor. Leave the restrictor stem open two turns minimum from fully closed.

Use the wrench restrictor (92) to balance the “B” pressure to the “A” pressure. Turn the restrictor clockwise to increase pressure, or counterclockwise to decrease pressure.

## Pressure Relief Procedure




Follow the Pressure Relief Procedure whenever you see this symbol.




This equipment stays pressurized until pressure is manually relieved. To help prevent serious injury from pressurized fluid, such as skin injection, splashing fluid and moving parts, follow the Pressure Relief Procedure when you stop spraying and before cleaning, checking, or servicing the equipment.


1. Close the XP-hf motor air valve (CA).




2. Hold a metal part of the gun firmly to a grounded metal pail. Trigger the gun to relieve pressure in material hoses.




3. Engage the trigger lock (TL), then remove the spray tip.




4. Close the dual shutoff handle (AE).




5. Open the recirculation handle (AC) to relieve "A" and "B" fluid pressure.



6. Close both feed pump air valves (EM).



## Flushing



To avoid fire and explosion, always ground equipment and waste container. To avoid static sparking and injury from splashing, always flush at the lowest possible pressure. Hot solvent may ignite. To avoid fire and explosion:

- Flush equipment only in a well-ventilated area
- Ensure main power is off and heater is cool before flushing
- Do not turn on heater until fluid lines are clear of solvent

### Guidelines

Flushing will help prevent materials from setting or gelling in the pumps, lines, and valves. Flush the system when any of the following situations occur:

- Any time the system will not be used for more than one week (depending on materials used)
- If the materials used have fillers that will settle
- If using materials that are moisture sensitive
- Before servicing
- If the machine is going into storage, replace the solvent with light oil. Never leave the equipment empty of any fluid.


Flush the mix manifold when any of the following situations occur:

- Breaks in spraying
- Overnight shutdown


Mixed material in system approaching end of pot life

## Flush Mixed Material

1. Follow the **Pressure Relief Procedure** on page 43.
2. Ensure the solvent pump regulator (DB) is fully closed and open the solvent air valve (DA).



3. Open the solvent flush valve (AD).
4. Disengage the trigger lock (TL), hold the gun against a grounded metal pail, and trigger the gun into the pail. Use a pail lid with a hole to dispense through. Seal around the hole and gun with a rag to prevent splash back. Be careful to keep fingers away from the front of the gun. Continue flushing until clean solvent dispenses.




5. Close the solvent pump air valve (DA).
6. Hold a metal part of the gun against a grounded metal pail and trigger the gun to relieve pressure. Close the solvent flush valve (AD) after relieving the pressure.
7. Engage the trigger lock (TL). Disassemble and clean the spray tip with solvent by hand. Reinstall spray tip on the gun.




## Flush Hoppers Procedure


1. Follow the **Flush Mixed Material** procedure on page 44.
2. Turn off all heater switches (ZB, ZE, ZN) and the main power switch (MP). Allow the system to cool before flushing.




3. Engage the trigger lock (TL).




4. Turn the XP-hf motor air pressure regulator (CB) fully counter-clockwise to shut off.




5. Open the recirculation handle (AC).




6. Move the recirculation lines (U) to separate grounded fluid containers and pump remaining spray material out of the system.




7. Open the feed pump air valve (EM) and pump material out of the hopper.




8. Run the feed pumps until they are dry. Turn off the feed pump air valve (EM) and agitator air valve (EP).



9. Place a small pail under the hopper and open the material drain (EH) to fully drain the spray material.




10. Close the material drain (EH) and fill the hopper with solvent.



11. Return the recirculation lines (U) to their respective hoppers.


12. Open on the agitator air valve (EP) and pump air valve (EM). Circulate for two to three minutes.




13. Repeat steps 4 - 10. Change the flushing solvent until it runs clean. To flush the remainder of the system, follow **Flush Material Lines Procedure** on page 47.

## Flush Material Lines Procedure


1. Follow the **Flush Mixed Material** procedure on page 44.
2. Follow the **Flush Hoppers Procedure** on page 45.
3. Close the recirculation handle (AC) and open the dual shutoff handle (AE).




4. Open the XP-hf motor air shutoff valve (CA) and increase the XP-hf motor air pressure regulator (CB) to dispense fresh solvent from the hoppers through the mix manifold valves and out the gun.
5. Continue flushing solvent until it runs clean.
6. Close the motor air shutoff valve (CA).
7. Lift to close the dual shutoff handle (AE).



8. Close the main inlet air shutoff valve (CF).



9. Remove the filters of the XP displacement pumps and soak in solvent. Clean and replace the filter cap. Always replace the filter o-rings. See your Xtreme lower pump manual.
10. Fill the pump packing nuts of the XP displacement pumps with TSL.



### NOTCE


Always leave some type of fluid, such as solvent or oil, in the system to prevent scale build up. This build up can flake off later and cause damage to the equipment.

**NOTE:** Always keep the A side and B side solvent containers separate to avoid cross-contamination.


## Overnight Shutdown




1. Follow the **Pressure Relief Procedure** procedure on page 43.
2. Flush the mix manifold, hoses, and gun. Follow the **Flush Mixed Material** procedure on page 44.
3. Open the recirculation handle (AC) and adjust the XP-hf motor air regulator (CB) so that the pump runs slowly.




4. When the pump is at the bottom of the stroke, close the XP-hf motor air valve (CA) and turn the air regulator (CB).



5. Turn off all heater switches (ZB, ZE, ZN) and the main power switch (MP).




6. Close the feed pump air valve (EM) when the feed pump is at the bottom of the stroke.



### NOTICE

If fluid is allowed to dry on the exposed displacement rod, damage to the throat packings may occur. To prevent damage, always stop the feed pump at the bottom of the stroke.

7. Close the agitator air valve (EP).



8. Turn off main air shutoff valve (CF).

## System Verification

Graco recommends running the following tests daily.

### Check for Normal Operation

Every time you start spraying:

- Watch the fluid gauges (AF). A pressure drop occurs during pump stroke changeover. It should be quick and synchronous.
- Stop the pumps on the upstroke. Check that both gauges hold pressure for at least 20 seconds.

If one gauge drops, the others will rise.

- Stop the pumps on the down stroke. Check that all gauges hold pressure.
- If using feed pumps, check that both feed pumps run during the proportioner upstroke.

## Mix and Integration Tests



Use the following tests to check for proper mix and integration.

### Butterfly Test

At low pressure, and with the spray tip reversed, dispense a 1/2 in. (12.7 mm) bead of material onto foil until multiple changeovers of each pump have occurred. Fold the sheet of foil over the fluid then peel it back and look for unmixed material (appears marble-like), or color changes.

### Curing Test

Spray a single continuous pattern on foil at typical pressure setting, flow rate, and tip size until multiple changeovers of each pump have occurred. Trigger and de-trigger at typical intervals for the application. Do not overlap or cross over your spray pattern.

Check curing at various time intervals, listed on the material data sheet. For example, check for dry to touch by running your finger along the test pattern's entire length at the time listed on the data sheet.

Spots that take longer to cure indicate insufficient pump loading, leakage, or lead/lag errors at a remote mix manifold.

## Appearance Test

Spray material onto foil. Look for variations in color, gloss, or texture that may indicate improperly catalyzed material.

## Monitor Fluid Supply

**NOTE:** To prevent pumping air into the system, which causes incorrect proportioning, never allow the feed pump or solvent pump containers to run dry.

An empty pump will quickly accelerate to a high speed, and may damage itself and the other displacement pump because it causes a pressure rise in the other pump. If a supply container runs dry, stop the pump immediately, refill the container, and prime the system. Be sure to eliminate all air from the system.

## Check Pot Life

Check the fluid manufacturer's instructions for fluid pot life at your fluid temperature. Flush mixed fluid out of the mix manifold, hose, and gun before pot life time expires, or before a rise in viscosity affects the spray pattern.

## Ratio Check

Check the ratio at the mix manifold after any changes to the proportioning system. Use Ratio Check Kit 24F375 to check the ratio at the mix manifold. See manual ratio check kit manual for instructions and parts.

To prevent an inaccurate ratio check when feed pumps are used in your system, the feed pressure cannot be more than a maximum of 25% of the proportioner outlet pressure. High feed pressure can float the proportioner pump check balls, resulting in an inaccurate ratio check. There must be back pressure on both sides of the mix manifold when checking the ratio.

# Maintenance

## Hose Electrical Resistance

Check electrical resistance of hoses regularly. If total resistance to ground exceeds 29 megohms, replace hose immediately.

## Filters

Once a week check, clean, and replace (if needed) the following filters.


- Both pump filters; see your Xtreme lower pump manual for instructions.
- Spray gun handle filter; see your spray gun manual.

## Seals

Once a week, check and tighten throat seals on both pumps (see table for torque specifications). Follow the **Pressure Relief Procedure** procedure on page 43 prior to tightening seals. There must be zero pressure on the pumps when adjusting.

| Pump Size | Torque Specification    |
|-----------|-------------------------|
| All       | 25-30 ft-lb (34-41 N•m) |

## Cleaning Procedure



1. Ensure all equipment is grounded. See **Grounding**, page 24.
2. Ensure the area where the system will be cleaned is well ventilated and remove all ignition sources.

3. Turn off all heaters and allow equipment to cool.
4. Flush mixed material. Follow the complete **Flushing** procedure starting on page 44.
5. Follow the **Overnight Shutdown** procedure on page 48. Turn off all power.
6. Clean the external surfaces only using a rag soaked in solvent that is compatible with the spray material and surfaces being cleaned.
7. Allow enough time for the solvent to dry before using the system.

## Change the Mix Ratio

In order to change the mix ratio, one or both pumps need to be replaced, the air motor needs to be re-positioned, and the over pressure relief valves may need to be changed.

1. Check the **Models** table on page 10 for the correct pump sizes.
2. Remove and replace pump. See **Remove XP Displacement Pump** page 56.
3. Adjust the position of the air motor. See **Recirculation Manifold with Over Pressure Relief Valves** page 57.
4. **If changing from one type of XPs-hf system to another (for example - changing from XP50s-hf to XP70s-hf or from XP70s-hf to XP50s-hf):** Remove the existing over pressure relief valves (702) and install the correct valves for the new system type. See **Replace Over Pressure Relief Valves** on page 58, and **Material Recirculation Manifold Replacement Table** on page 59.
5. Change the **XP-hf Motor Air Pressure Relief Valve (CG)** as required, depending on the ratio. See page 21.




## Clean Inlet Strainer Screen



The inlet strainers filter out particles that can plug the pump inlet check valves. Inspect the screens daily as part of the startup routine, and clean as required.

1. Follow the **Startup/Recirculate** on page 36.
2. Ensure that all pumps are shut off and close the Y-strainer valve (ES).
3. Place a container under the strainer base to catch drain off when removing the strainer plug.
4. Remove the screen from the strainer manifold. Thoroughly flush the mesh screen (MS) with compatible solvent and shake it dry.



5. Inspect the screen. No more than 25% of the mesh should be restricted. If more than 25% of the mesh is blocked, replace the screen. Inspect the gasket and replace as needed. See your heated hopper manual for replacement components.
6. Ensure that the pipe plug (PP) is screwed into the strainer plug (SP). Install the strainer plug (SP) with the mesh screen (MS) and gasket (SG) in place and tighten. Do not over tighten the strainer plug--let the gasket make the seal.
7. Open the Y-strainer valve (ES). Ensure that there are no leaks and wipe the equipment clean.

## Check Heating Fluid Level


Gradual fluid evaporation can occur. Check the level of heating fluid monthly. Add fluid as needed.

### NOTICE

Freezing temperatures can cause damage that may result in the heating fluid leaking into the terminal enclosure. To avoid damage, do not expose the unit to freezing conditions.

## Drain Heating Fluid

Replace heating fluid once a year to improve heating efficiency and increase heater element life. Keep the heating element above the sediment deposits. Sediment deposits will drain out from the coolant drain valve (EJ).




**NOTE:** The heater will not operate in sediment deposits.

## Feed Pumps



Keep the packing nut/wet-cup half filled with Graco Throat Seal Liquid (TSL™) or compatible solvent to help prolong packing life.



Adjust the packing nut weekly so it is just tight enough to prevent leakage. Use a spanner wrench or a 0.25 in. (6.3 mm) diameter rod to tighten the nut. Do not over-tighten.

Never leave the pump or hoses filled with water or air. To help prevent corrosion, flush the water and all air out of the system and leave it filled with mineral spirits or an oil-based solvent.

## Solvent Pump

Keep the wet cup half filled with Graco Throat Seal Liquid (TSL™).

## XP Displacement Pumps

Check packing nut. Torque to 25-30 ft-lb (34-41 N•m).

Keep the wet cup half filled with Graco Throat Seal Liquid (TSL™).

## Agitators

### NOTICE

To prevent air motor failure and possible damage to equipment, always keep the air motor properly lubricated using Air Motor Lubricant.


After the first 100 hours, or two weeks of operation, change the gear reducer oil. After that, change the oil every 2500 hours, or six months (whichever comes first) of operation under normal conditions. More frequent oil changes are needed under severe operating conditions or in atmospheres containing excessive moisture or abrasives. See your agitator manual for the oil changing procedure.

If the air motor is operating sluggish or inefficiently, flush the air motor (see your agitator manual).

Every 2500 hours, or six months (whichever comes first) of operation, inspect the bearing block (see your agitator manual).



# Troubleshooting



1. Follow **Pressure Relief Procedure** on page 43 before checking or repairing the system.
2. Check all possible problems and causes before disassembling the gun.

| Problem  | Cause  | Solution   |
|--|--|--|
| System stops or will not start.  | Air pressure or volume too low.  | Increase; check air compressor.                        |
|  | Closed or restricted air line or air valve.                            | Open or clean.   |
|  | Fluid valves closed.   | Open.  |
|  | Clogged fluid hose.  | Replace.   |
|  | Air motor worn or damaged.   | Repair air motor; see your air motor manual.           |
|  | Displacement pump stuck.   | Repair pump; see your Xtreme pump manual.              |
| System speeds up or runs erratically.                                      | Fluid containers are empty.◆   | Check often; keep filled.                              |
|  | Air in fluid lines.◆   | Purge; check connections.                              |
|  | Displacement pump parts worn or damaged.                               | Repair pump; see your Xtreme pump manual.              |
| Pump operates, but resin output pressure drops on upstroke.✕               | Dirty, worn, or damaged resin pump piston valve or piston packings.    | Clean, repair pump; see your Xtreme pump manual.       |
| Pump operates, but resin output pressure drops on downstroke.              | Dirty, worn, or damaged resin pump intake valve.                       | Clean, repair pump; see your Xtreme pump manual.       |
| Pump operates, but resin output pressure drops on both strokes.✕           | Hardener output restriction.   | Clean, unplug hardener side. Open manifold restrictor. |
|  | Fluid supply low.◆   | Refill or change container.                            |
| Pump operates, but hardener output pressure drops on upstroke.✕            | Dirty, worn, or damaged hardener pump piston valve or piston packings. | Clean, repair pump; see your Xtreme pump manual.       |
| Pump operates, but hardener output pressure drops on downstroke.✕          | Dirty, worn, or damaged hardener pump intake valve.                    | Clean, repair pump; see your Xtreme pump manual.       |
| Pump operates, but hardener output pressure drops on both strokes.         | Resin output restriction.  | Clean, unplug resin side.                              |
|  | Fluid supply low.◆   | Refill or change container.                            |
| Fluid leak in packing nut.   | Loose packing nut or worn throat packings.                             | Tighten; replace; see your Xtreme pump manual.         |
| Fluid leak under packing nut   | Packing cartridge o-ring.  | Replace o-ring; see your Xtreme pump manual.           |
| Relief valve (AM) leaks back to supply, opens too soon, or will not close. | Relief valve is dirty or damaged.                                      | Replace over pressure relief valve (302)               |

| Problem   | Cause  | Solution  |
|---|--|---|
| No pressure on hardener side; fluid leaking from hardener pump outlet rupture disk fitting.             | Overpressure rupture disk blown.   | Determine cause of overpressurization and correct. Replace rupture disk assembly 258962 (see page 15) and over pressure relief valve (302). |
| Pressure and flow surges on upstroke.   | Feed pressure too high. Every 1 psi of feed pressure adds 2 psi during upstroke. | Reduce feed pressure. See <b>Repair</b> , page 56.  |
| Fluid outlet pressure gauges split only at the top changeover (if one gauge drops the other will rise). | Not fully loading one side on upstroke.  | Increase feed pressure on side that dropped.<br>Increase feed hose size.<br>Clean inlet strainer or hopper screen.                          |
|   | Air mixed in fluid from excessive agitation or circulation.                      | Flush and add new fluid.  |

✗ *Fluid ratio will be wrong.*


◆ *Purge all air from system before proportioning fluids.*

# Pump Troubleshooting

This chart uses proportioning fluid gauges to determine pump malfunctions. Observe the gauge readings during the stroke direction indicated by the bold arrow, and immediately after closing the gun or mix manifold. Refer to other manuals to troubleshoot individual components.


## TROUBLE AREA: Resin Pump Leakage

1. Throat packing
2. Piston packing
3. Piston ball check




## TROUBLE AREA: Hardener Pump Leakage

1. Throat packing
2. Piston packing
3. Piston ball check




## TROUBLE AREA: Resin Pump Leakage

1. Throat packing
2. Intake ball check




## TROUBLE AREA: Hardener Pump Leakage

1. Throat packing
2. Intake ball check




# Repair



Follow the complete **Flushing** procedure starting on page 44, which includes pressure relief and full system flushing if service time may exceed pot life time before servicing fluid components and before transporting the system to a service area.


## Pump Assembly Repair



The displacement pumps and air motor may be removed and serviced separately or the entire pump and motor assembly can be removed with a hoist.

### Pump Assembly Removal


1. Flush all system components. Follow the complete **Flushing** procedure starting on page 44.
2. Disconnect all hoses from the pump assembly.
3. Disconnect the hopper fluid lines from the pump fluid inlet (228).
4. Remove screws (6) and washers (5) under the tie plate (901). For additional parts identification, see **Parts** starting on page 60.



5. Use hoist to remove the pump assembly by the lift ring and carefully lift out of stand (1).

### Remove XP Displacement Pump

1. Flush all system components. Follow the complete **Flushing** procedure starting on page 44.
2. Disconnect the hopper fluid lines from the pump fluid inlet (228).
3. Disconnects the outlet hose (12 or 24). For parts identification, see **Parts** starting on page 60.
4. Remove the spring clamp (930) and coupling (919).




5. Use a wrench to hold the tie rod (902) flats to keep the rods from turning. Unscrew the nuts (908) from the tie rods and carefully remove the displacement pump (917 or 918) and lower straps (935).
6. Refer to the Xtreme Displacement Pump manual to service or repair the displacement pump.
7. Follow the steps in reverse order to reinstall the displacement pump.


**NOTE:** Torque nuts (908) to 95-105 ft-lb (129-142 N•m).

## Remove Motor

1. Flush all system components. Follow the complete **Flushing** procedure starting on page 44.
2. Disconnect the air line from the air motor.
3. Remove the air motor rod cover (921) and pump guards (922).




4. Use a wrench to hold the tie rod (902) flats to keep the rods from turning. Unscrew the nuts (908) from the tie rods.



5. Place a wrench on the motor shaft hex flats (HX). Loosen coupling nut (909).
6. Use a hoist to remove the air motor by the lift ring.
7. Refer to the air motor manual to service or repair the air motor.


## Recirculation Manifold with Over Pressure Relief Valves

1. Flush all system components. Follow the complete **Flushing** procedure starting on page 44.
2. Disconnect all fluid hoses from the material recirculation manifold (35).
3. Remove the mix manifold if it is assembled to the material recirculation manifold.
4. Loosen the two screws (37) that secure the manifold (35) to the cart (1).
5. Remove the two screws (37) and material recirculation manifold (35) from the cart (1).



## Replace Over Pressure Relief Valves

1. Flush all system components. Follow the complete **Flushing** procedure starting on page 44.
2. Ensure handle (712) is in the down position. Remove the screws (713), jam nut (704), handles (711), handle rod (712), clips (718), and springs (720).




3. Unscrew both over pressure relief valves (702) from the manifold.
4. Apply blue threadlock to new over pressure relief valves (702) and install in the manifold. Torque to 28-32 ft-lb (38-43 N•m).

5. Place a spring (720) over each valve stem. Place a clip (718) in each valve stem groove to retain the springs.
6. Slide handle (711) onto valve stem and rotate approximately 90° until you feel it fully lock against the valve seat. Repeat for opposite side.
7. Remove handle then place handle (711) on valve stem (302) at the vertical, or near vertical, position.
8. Apply blue threadlock on the nut (704) threads and tighten the handle against the spring (720) and clip (718). Torque to 70-80 in-lb (7.9-9 N•m).
9. Place the rod (712) and the second handle (711) on second valve stem aligned with the opposite handle.
10. Repeat step 9.
11. Install two screws (713) in handles (711).
12. Check operation of the handle and valves.
13. Operate the handle in and out of the spray and circulate positions.
14. Check for clearance with fittings.

### NOTE:

- Both valves should settle firmly into the spray position inward against the seats in the valve.
- Both valve stems should rotate out to their most extended positions when the handle is pulled down to the circulate position.


Material Recirculation Manifold Replacement Guide



| Material Recirculation Manifold Replacement Table |                         |                    |  |                     |
|---|-------------------------|--------------------|--|---------------------|
| Circulation Manifold (35) Part                    | Relief Valve (302) Part | Valve Sleeve Color | Target Opening Pressure psi (MPa, bar) | Use with:           |
| 262783  | 262809                  | Gold               | 7100 (49, 490)                         | All XPs50-hf models |
| 262806  | 262520                  | Silver             | 9250 (64, 638)                         | All XPs70-hf models |


# Parts

## XP50s-hf and XP70s-hf Proportioner






### XP50s-hf and XP70s-hf Proportioners (Continued)




XP50s-hf and XP70s-hf Proportioners (Continued)



## XP50s-hf and XP70s-hf Proportioners Parts List


| Ref. | Part   | Description                                | Qty. | Ref.   | Part   | Description                     | Qty. |
|------|--------|--|------|--|--------|---------------------------------|------|
| 1    | 25N579 | CART, painted, XPs,                        | 1    | 55▲  | 16F359 | LABEL, warning, fire/exp hazard | 1    |
| 2    | 25N583 | MODULE, air controls, filter (see page 72) | 1    | 56   | -----  | VALVE, safety (see page 79)     | 1    |
| 3    | 25N575 | MODULE, air controls, regulator            | 1    | 58   | 16F615 | TOOL, wrench, Xtreme            | 1    |
| 4    | -----  | PUMP (see page 79)                         | 1    | 59   | 111192 | SCREW, cap, hex head            | 2    |
| 5    | 100133 | WASHER, lock, 3/8                          | 6    | 60   | 24F126 | MODULE, air controls, solvent   | 1    |
| 6    | 100101 | SCREW, cap, hex head                       | 4    | 61   | 262392 | PUMP, solvent (see page 79)     | 1    |
| 7    | 17V986 | HOSE, coupled, 1 in.                       | 1    | 202  | 25N578 | BASE, painted, XPs, pallet      | 1    |
| 12   | H75004 | HOSE, 7250 psi, 4 ft                       | 3    | 206  | 17V987 | TUBE, recirculation, material   | 2    |
| 13   | 17N487 | HOSE, XP-hf Air Motor supply               | 1    | 207  | 116704 | FITTING, adapter                | 2    |
| 15   | 112958 | NUT, hex, flanged, 3/8-16                  | 2    | 208  | H52506 | HOSE, recirculation material    | 2    |
| 16   | 100015 | NUT, hex, flange head                      | 2    | 209  | 111192 | SCREW, cap, socket head         | 8    |
| 17   | 104429 | SCREW, cap                                 | 2    | 210  | 108851 | WASHER, plain                   | 4    |
| 18   | 100131 | NUT, hex                                   | 2    | 211  | 100133 | WASHER, lock, 3/8               | 4    |
| 19   | 16F206 | LABEL, XP, handles                         | 1    | 212  | 123433 | SCREW, cap, socket head         | 4    |
| 20   | 100016 | WASHER, lock                               | 2    | 213  |        | GUN, ovl, hnd                   | 1    |
| 21   | 111218 | CAP, tube, square                          | 4    |  | XTR522 | XTR5 (578xxx)                   |      |
| 22   | 158491 | FITTING, nipple                            | 4    |  | XTR722 | XTR7 (577xxx)                   |      |
| 23   | 15M987 | FITTING, elbow, 60°                        | 4    | 214  | 162024 | COUPLING                        | 2    |
| 24   | H75002 | HOSE, 7250 psi, 2 ft                       | 1    | 215  | 262478 | HOUSING, mixer                  | 3    |
| 25   | 110755 | WASHER, plain                              | 4    | 217  |        | HOSE, coupled                   | 1    |
| 29   | 214037 | VALVE, ball                                | 1    |  | H53825 | 5600 psi (578xxx)               |      |
| 30   | 156971 | FITTING, nipple                            | 1    |  | H73825 | 7250 psi (577xxx)               |      |
| 31   | 104984 | FITTING, tee                               | 1    | 218  | 15B729 | COUPLING                        | 1    |
| 32   | H42503 | HOSE, solvent, outlet                      | 1    | 219  | 150287 | COUPLING                        | 1    |
| 35   |        | MANIFOLD, recirculation                    | 1    | 220  |        | HOSE, coupled                   | 1    |
|      | 262783 | XP50 (578xxx)                              |      |  | H52510 | 5600 psi (578xxx)               |      |
|      | 262806 | XP70 (577xxx)                              |      |  | H72510 | 7250 psi (577xxx)               |      |
| 36   | 262807 | MANIFOLD, mix, 1/2 in. valves              | 1    | 221  | 121620 | FITTING, reducer,               | 2    |
| 37   | 106212 | SCREW, cap, hex head                       | 2    | 222  | 15R424 | LABEL, A-B                      | 1    |
| 41   | 158683 | FITTING, elbow                             | 2    | 223  | 101566 | NUT, lock                       | 2    |
| 43   | 16G819 | TOOL, wrench, Xtreme, filter               | 1    | 224  | 124293 | BOLT, u-bolt                    | 1    |
| 47   | 206995 | FLUID, TSL                                 | 1    | 225  | 248927 | KIT, mixer element, (25 pack)   | 3    |
| 48   | 126786 | TOOL, restrictor                           | 1    | 227  | 214961 | HOSE, coupled                   | 2    |
| 51   | 205447 | COUPLING, hose                             | 1    | 228  | 121571 | FITTING, elbow, female          | 2    |
| 52   | 16F537 | HOSE, air, inlet, solvent control          | 1    | 229  | 203320 | HOSE, coupled                   | 2    |
| 53   | 15B772 | HOSE, air, solvent pump                    | 1    | 230  | 114030 | UNION, adapter, swivel          | 1    |
| 54   | 061132 | HOSE, circulation, solvent                 | 1    | ▲ Replacement safety labels, tags, and cards are available at no cost. |        |                                 |      |

# Water Jacketed Heated Hose Packages



## Water Jacketed Heated Hose Packages Parts List


| Ref. | Part   | Description                        | Qty.                  |                        |                       |                        |
|------|--------|------------------------------------|-----------------------|------------------------|-----------------------|------------------------|
|      |        |                                    | 240V                  |                        | 480V                  |                        |
|      |        |                                    | Ordinary<br>Locations | Hazardous<br>Locations | Ordinary<br>Locations | Hazardous<br>Locations |
|      |        |                                    | XXXX01                | XXXX11                 | XXXX21                | XXXX31                 |
| 10   | 17N599 | HARNESS, B heater, non-hazardous   | 1                     |                        | 1                     |                        |
| 11   | 17N598 | HARNESS, A heater, non-hazardous   | 1                     |                        | 1                     |                        |
| 14   | 116171 | BUSHING, strain relief             | 2                     |                        | 2                     |                        |
| 27   | 26C580 | JUNCTION BOX, 240V, non-hazardous  | 1                     |                        |                       |                        |
|      | 26C581 | JUNCTION BOX, 240V, hazardous      |                       | 1                      |                       |                        |
|      | 26C582 | JUNCTION BOX, 480V, non-hazardous  |                       |                        | 1                     |                        |
|      | 26C583 | JUNCTION BOX, 480V, hazardous      |                       |                        |                       | 1                      |
| 28   | 25C961 | HEATER, hf, 240V, non-hazardous    | 2                     |                        |                       |                        |
|      | 25C962 | HEATER, hf, 240V, hazardous        |                       | 2                      |                       |                        |
|      | 26C471 | HEATER, hf, 480V, non-hazardous    |                       |                        | 2                     |                        |
|      | 26C476 | HEATER, hf, 480V, hazardous        |                       |                        |                       | 2                      |
| 33   | 166590 | FITTING, bushing adapter           |                       | 3                      |                       | 3                      |
| 34   | 185065 | ADAPTER, cable                     |                       | 5                      |                       | 5                      |
| 38   | 110963 | SCREW, cap, flanged head           | 4                     |                        | 4                     |                        |
|      | C19075 | SCREW, cap, hex head               |                       | 4                      |                       | 4                      |
| 63   | 111841 | WASHER                             |                       | 4                      |                       | 4                      |
| 203  | 26C482 | HOPPER, heated, 240V               | 2                     | 2                      |                       |                        |
|      | 26C479 | HOPPER, heated, 480V               |                       |                        | 2                     | 2                      |
| 204  | 17X398 | HARNESS, hopper                    | 2                     |                        | 2                     |                        |
| 231  | 16P608 | CLAMP, mounting, top, heater       | 2                     | 2                      | 2                     | 2                      |
| 232  | 117535 | SCREW, cap, socket head            | 4                     | 4                      | 4                     | 4                      |
| 233  | 121603 | GRIP, cord                         | 2                     |                        | 2                     |                        |
| 234  | 126896 | FITTING, elbow                     | 1                     | 1                      | 1                     | 1                      |
| 235  | 126898 | FITTING, elbow                     | 1                     | 1                      | 1                     | 1                      |
| 236  | 126900 | FITTING, elbow                     | 1                     | 1                      | 1                     | 1                      |
| 237  | 17D306 | FITTING, coupler                   | 1                     | 1                      | 1                     | 1                      |
| 238  | 113796 | SCREW, flanged                     | 8                     | 8                      | 8                     | 8                      |
| 239  | 17P759 | TUBE                               | 1                     | 1                      | 1                     | 1                      |
| 240  | 122032 | NUT, wire (not shown)              | 10                    |                        | 10                    |                        |
| 241  | 273093 | PUMP, heated hose                  | 1                     | 1                      | 1                     | 1                      |
| 242  | 17X552 | BRACKET, recirc pump               | 1                     | 1                      | 1                     | 1                      |
| 243  | 245869 | HEATER, hose, 240V, non-hazardous  | 1                     |                        |                       |                        |
|      | 245863 | HEATER, hose 240V, hazardous       |                       | 1                      |                       |                        |
|      | 245870 | HEATER, hose 480V, non-hazardous   |                       |                        | 1                     |                        |
|      | 245864 | HEATER, hose, 480V, hazardous      |                       |                        |                       | 1                      |
| 244  | 17N600 | HARNESS, WJ, hose heat             | 1                     |                        | 1                     |                        |
| 245  | 17P594 | FITTING, house coupler             | 1                     | 1                      | 1                     | 1                      |
| 246  | 17S051 | FITTING, hose nipple               | 1                     | 1                      | 1                     | 1                      |
| 247  | 24Z934 | KIT, heater block, remote manifold | 1                     | 1                      | 1                     | 1                      |
| 248  | 113974 | SCREW, mach, slotted               | 1                     | 1                      | 1                     | 1                      |



## Non-Heated Hose Packages Parts List


| Ref. | Part   | Description                       | Qty.                  |                        |                       |                        |
|------|--------|-----------------------------------|-----------------------|------------------------|-----------------------|------------------------|
|      |        |                                   | 240 V                 |                        | 480 V                 |                        |
|      |        |                                   | Ordinary<br>Locations | Hazardous<br>Locations | Ordinary<br>Locations | Hazardous<br>Locations |
|      |        |                                   | XXXX02                | XXXX12                 | XXXX22                | XXXX32                 |
| 10   | 17N599 | HARNESS, B heater, non-hazardous  | 1                     |                        | 1                     |                        |
| 11   | 17N598 | HARNESS, A heater, non-hazardous  | 1                     |                        | 1                     |                        |
| 14   | 116171 | BUSHING, strain relief            | 1                     |                        | 1                     |                        |
| 27   | 26C580 | JUNCTION BOX, 240V, non-hazardous | 1                     |                        |                       |                        |
|      | 26C581 | JUNCTION BOX, 240V, hazardous     |                       | 1                      |                       |                        |
|      | 26C582 | JUNCTION BOX, 480V, non-hazardous |                       |                        | 1                     |                        |
|      | 26C583 | JUNCTION BOX, 480V, hazardous     |                       |                        |                       | 1                      |
| 28   | 25C961 | HEATER, hf, 240V, non-hazardous   | 2                     |                        |                       |                        |
|      | 25C962 | HEATER, hf, 240V, hazardous       |                       | 2                      |                       |                        |
|      | 26C471 | HEATER, hf, 480V, non-hazardous   |                       |                        | 2                     |                        |
|      | 26C476 | HEATER, hf, 480V, hazardous       |                       |                        |                       | 2                      |
| 33   | 166590 | FITTING, bushing adapter          |                       | 2                      |                       | 2                      |
| 34   | 185065 | ADAPTER, cable                    |                       | 4                      |                       | 4                      |
| 38   | 110963 | SCREW, cap, flanged head          |                       | 4                      |                       | 4                      |
|      | C19075 | SCREW, cap, hex head              | 4                     |                        | 4                     |                        |
| 63   | 111841 | WASHER                            |                       | 4                      |                       | 4                      |
| 203  | 26C482 | HOPPER, heated, 240V              | 2                     | 2                      |                       |                        |
|      | 26C479 | HOPPER, heated, 480V              |                       |                        | 2                     | 2                      |
| 204  | 17X398 | HARNESS, hopper                   | 2                     |                        | 2                     |                        |
| 233  | 121603 | GRIP, cord                        | 2                     |                        | 2                     |                        |
| 240  | 122032 | NUT, wire (not shown)             | 8                     |                        | 8                     |                        |

Non-Hazardous Location Electric Heated Hose Packages






# Hazardous Location Electric Heated Hose Packages



## Electric Heated Hose Packages Parts List

| Ref. | Part   | Description                       | Qty.               |                     |                    |                     |
|------|--------|-----------------------------------|--------------------|---------------------|--------------------|---------------------|
|      |        |                                   | 240 V              |                     | 480 V              |                     |
|      |        |                                   | Ordinary Locations | Hazardous Locations | Ordinary Locations | Hazardous Locations |
|      |        |                                   | XXXX03             | XXXX13              | XXXX23             | XXXX33              |
| 10   | 17N599 | HARNESS, B heater, non-hazardous  | 1                  |                     | 1                  |                     |
| 11   | 17N598 | HARNESS, A heater, non-hazardous  | 1                  |                     | 1                  |                     |
| 14   | 116171 | BUSHING, strain relief            | 1                  |                     | 1                  |                     |
| 27   | 26C899 | JUNCTION BOX, 240V, non-hazardous | 1                  |                     |                    |                     |
|      | 26C905 | JUNCTION BOX, 240V, hazardous     |                    | 1                   |                    |                     |
|      | 26C904 | JUNCTION BOX, 480V, non-hazardous |                    |                     | 1                  |                     |
|      | 26C906 | JUNCTION BOX, 480V, hazardous     |                    |                     |                    | 1                   |
| 28   | 25C961 | HEATER, hf, 240V, non-hazardous   | 2                  |                     |                    |                     |
|      | 25C962 | HEATER, hf, 240V, hazardous       |                    | 2                   |                    |                     |
|      | 26C471 | HEATER, hf, 480V, non-hazardous   |                    |                     | 2                  |                     |
|      | 26C476 | HEATER, hf, 480V, hazardous       |                    |                     |                    | 2                   |
| 33   | 166590 | FITTING, bushing adapter          |                    | 2                   |                    | 2                   |
| 34   | 185065 | ADAPTER, cable                    |                    | 5                   |                    | 4                   |
| 38   | 110963 | SCREW, cap, flanged head          |                    | 4                   |                    | 4                   |
|      | C19075 | SCREW, cap, hex head              | 4                  |                     | 8                  |                     |
| 63   | 111841 | WASHER                            |                    | 4                   |                    | 4                   |
| 64   | 18C158 | SPLICE BOX                        | 1                  |                     |                    |                     |
|      | 18B948 | SPLICE BOX, explosion-proof       |                    | 2                   |                    | 2                   |
| 65   | 115942 | NUT                               | 3                  |                     |                    |                     |
|      | 112958 | NUT                               |                    | 4                   | 4                  |                     |
| 66   | 18C151 | COVER, splice box                 | 1                  |                     |                    |                     |
|      | 19B335 | BRACKET, splice box               |                    | 1                   |                    |                     |
| 67   | 19Y807 | BUSHING, strain relief            | 1                  |                     | 1                  |                     |
| 68   | 19B130 | CORD, cable                       | 1                  |                     | 1                  |                     |
| 69   | 128986 | CONNECTOR, splice                 | 2                  |                     |                    |                     |
| 70   | 26C791 | TRANSFORMER                       |                    |                     | 1                  |                     |
|      | 19B356 | TRANSFORMER, 5kV, hazardous       |                    |                     |                    | 1                   |
| 71   | 19B359 | BRACKET, transformer              |                    |                     | 1                  |                     |
| 72   | 132001 | BOLT, flange, serrated            |                    |                     | 4                  |                     |
| 73   | 112395 | SCREW, cap                        |                    | 4                   | 4                  |                     |
| 74   | 112958 | NUT, hex flanged                  |                    | 4                   | 4                  |                     |
| 75   | 25T264 | KIT, fittings (not shown)         | 1                  | 1                   | 1                  | 1                   |
| 203  | 26C482 | HOPPER, heated, 240V              | 2                  | 2                   |                    |                     |
|      | 26C479 | HOPPER, heated, 480V              |                    |                     | 2                  | 2                   |
| 204  | 17X398 | HARNESS, hopper                   | 2                  |                     | 2                  |                     |
| 233  | 121603 | GRIP, cord                        | 2                  |                     | 2                  |                     |
| 240  | 122032 | NUT, wire (not shown)             | 8                  |                     | 8                  |                     |

# Air Control Filter 25N583 Parts




ti34274b

## Parts List

| Ref. | Part   | Description                              | Qty. | Ref. | Part   | Description                          | Qty. |
|------|--------|--|------|------|--------|--------------------------------------|------|
| 302  | 116648 | FITTING, swivel, 1 in. m x f             | 2    | 313  | 127785 | COUPLING, universal, 1 in. nptf      | 1    |
| 303  | 17N485 | FITTING, tee, 1 x 1 x 1 npt(f), cs, 2.2k | 1    | 314  | 16W586 | CABLE, lanyard, whip check           | 1    |
| 304  | 158555 | FITTING, nipple, 1 x 3/4 npt             | 1    | 315  | 113161 | SCREW, flange, hex hd                | 2    |
| 305  | 15E145 | MANIFOLD, air distribution               | 1    | 316  | 16P338 | SCREW, mach, serrated hex head       | 4    |
| 306  | 100615 | BUSHING, hex steel                       | 1    | 317  | 17X550 | BRACKET, XPs, filter, mount, painted | 1    |
| 307  | 157350 | ADAPTER                                  | 3    | 318  | 17X551 | BRACKET, XPs, filter, painted        | 1    |
| 308  | 115781 | CAP plug                                 | 2    | 319  | 114526 | FITTING, tee                         | 1    |
| 309  | 17N486 | FITTING, elbow, 1 in. npt                | 2    | 320  | 155665 | UNION, adapter                       | 2    |
| 310  | 17N462 | FILTER, air, 1 in. npt                   | 1    | 321  | 156849 | PIPE, nipple                         | 1    |
| 311  | 113163 | VALVE, ball, vented, 1                   | 1    | 322  | 111763 | FITTING, elbow, 1/4 npt              | 1    |
| 312  | 127784 | COUPLING, universal, 1 in. nptm          | 1    |      |        |                                      |      |


Air Control Regulator 25N575 Parts



ti34499b

| Ref. | Part   | Description                        | Qty. | Ref. | Part   | Description                      | Qty. |
|------|--------|------------------------------------|------|------|--------|----------------------------------|------|
| 402  | 119363 | FITTING, swivel, pipe              | 1    | 406  | 108638 | FITTING, pipe, tee               | 1    |
| 403  | 113163 | VALVE, ball, vented, 1.0           | 1    | 407  | 100960 | GAUGE, press air                 | 1    |
| 404  | 17S719 | FITTING, 1 in. npt x 3 in., nipple | 1    | 408  | 116648 | FITTING, swivel, 1 in. m x f     | 1    |
| 405  | 17N463 | REGULATOR, air, 1 in. npt          | 1    | 409  | 16P338 | SCREW, mach, serrated hex head   | 4    |
|      |        |                                    |      | 410  | 17X553 | BRACKET, XPs, regulator, painted | 1    |

# Solvent Pump 262392 Parts




△2 Torque to 50-55 ft-lb (68-75 N•m).  
 △3 Torque to 50-60 ft-lb (68-81 N•m).

△4 Torque to 75-80 ft-lb (102-108 N•m).

| Ref. | Part   | Description                            | Qty. | Ref. | Part   | Description                     | Qty. |
|------|--------|--|------|------|--------|---------------------------------|------|
| 501  | 24F079 | MOTOR, air, 6 in., std, slvt only      | 1    | 513  | LW050A | LOWER, assy, 50 cc              | 1    |
| 503  | 111799 | SCREW, cap, hex hd                     | 4    | 514  | 15T337 | RESERVOIR, tsl, 50 cc lwr 7 1/2 | 2    |
| 504  | 244675 | HOSE, coupled, suction                 | 1    |      |        | motor (not shown)               |      |
| 505  | 108143 | STRAINER                               | 1    | 515  | 184128 | COLLAR, coupling                | 1    |
| 506  | 116395 | FITTING, swivel, elbow                 | 1    | 516  | 15T311 | NUT, coupler                    | 1    |
| 507  | 100081 | BUSHING, pipe                          | 1    | 517  | 277743 | SHIELD, 6.0/7.5 in.             | 1    |
| 508  | 157350 | ADAPTER                                | 1    | 518  | 15V028 | SHIELD, drip                    | 1    |
| 510  | 15M662 | ROD, tie                               | 3    | 528  | 156589 | FITTING, union, adapter, 90 deg | 1    |
| 511  | 16U431 | ADAPTER, 50 cc, pump lower (not shown) | 1    | 529  | 100505 | BUSHING, pipe                   | 1    |
| 512  | 15U606 | NUT, lock, m16 x 2                     | 3    | 530  | 156849 | PIPE, nipple                    | 1    |
|      |        |  |      | 533  | 105335 | SCREW, mach, pnh                | 1    |

## Solvent Air Control 24F126 Parts




| Ref. | Part   | Description                             | Qty. |
|------|--------|---|------|
| 551  | -----  | PANEL, air controls, slvt, painted      | 1    |
| 552  | 15T500 | GAUGE, pressure, air, pl mnt, 1/8       | 1    |
| 553  | 15T536 | REGULATOR, air, 3/8 npt                 | 1    |
| 554  | 16F810 | NUT, regulator, steel                   | 1    |
| 555  | 114362 | VALVE, ball, air                        | 1    |
| 556  | 15T498 | FITTING, 90, swvl, 5/32 t x 1/8 fnpt    | 1    |
| 558  | 113498 | VALVE, safety, 110 psi                  | 1    |
| 559  | 15T937 | FITTING, elbow, swivel 1/4 npt x 5/32 t | 1    |
| 560  | 155699 | FITTING, elbow, street                  | 2    |
| 561  | 164672 | ADAPTER                                 | 2    |
| 563  | 054753 | TUBE, nylon, rd, black                  | 0.75 |
| 568  | 108296 | SCREW, mach, hex wash hd                | 4    |
| 569  | 109544 | FITTING, elbow, pipe, male              | 1    |


# Heater Block Remote Manifold Kit

(Water Jacketed Heated Hose Packages Only)

Kit 24Z934



ti31155a



1 Apply thread sealant to all non-swiveling pipe threads.

2 Supplied loose, not installed.


| Ref. | Part   | Description                                   | Qty. |
|------|--------|---|------|
| 601  | 24F834 | CARRIAGE, weldment, remote manifold           | 1    |
| 602  | 16T294 | PLATE, heater transfer, PFP 2k                | 1    |
| 603  | 110837 | SCREW, flange, hex                            | 2    |
| 604  | 110996 | NUT, hex, flange head                         | 2    |
| 605  | 126692 | FITTING, tube, NPT x tube                     | 2    |
| 606  | 100721 | PLUG, pipe                                    | 2    |
| 608▲ | 189285 | LABEL, safety, burn                           | 1    |
| 609  | 120736 | SCREW, hex flange HD                          | 2    |
| 610  | 126894 | FITTING, union, 1/2 tube x 1/2 tube           | 2    |
| 611* | 054960 | TUBE, red, nylon, 0.375 (9.5 mm) ID (1.5 ft)  | 1    |
| 612* | 054961 | TUBE, blue, nylon, 0.375 (9.5 mm) ID (1.5 ft) | 1    |

\* Supplied loose, not installed.

▲ Replacement safety labels, tags, and cards are available at no cost.

# Material Recirculation Manifold with Over Pressure Relief Valve

Assembly 262783 (XP50s-hf); 262806 (XP70s-hf)



r\_258988\_3a0420a\_1c

1. Apply anaerobic pipe sealant to all non-swiveling pipe threads.

△2 Torque to 28-32 ft-lb (38-43 N•m).

△3 Apply blue anaerobic adhesive to threads.

△4 Further tighten either valve (302) as required to line up handle straight across.

△5 Apply grease to spring ends.

△6 Torque to 70-90 in-lb (7.9-9 N•m).

| Ref  | Part   | Description                                   | Qty |
|------|--------|---|-----|
| 701  | 16D693 | BLOCK, manifold, recirculation                | 1   |
| 702† | 262520 | VALVE, over pressure relief, silver, XP70s-hf | 2   |
| ◆    | 262809 | VALVE, over pressure relief, gold, XP50s-hf   | 2   |
| 703  | 156684 | UNION; 1/2 in. male x female                  | 2   |
| 704  | 112309 | NUT, hex, jam                                 | 2   |
| 705  | 198241 | PLUG, port, pressure; 11/16-24                | 2   |
| 707  | 114434 | GAUGE, pressure, fluid, sst; 10k psi          | 2   |
| 708  | 100840 | FITTING, elbow, street; 1/4 npt               | 4   |
| 709  | 156971 | FITTING, nipple; 1/4 npt x npsm               | 2   |
| 710  | 557349 | PLUG, dry seal 1/8 npt                        | 2   |
| 711  | 16E334 | HANDLE, manifold                              | 2   |
| 712  | 16E332 | ROD, connecting, handle                       | 1   |
| 713  | 124859 | SCREW, button head                            | 2   |
| 716  | 156684 | FITTING, nipple, 1/2 npt x 1/2 npt            | 2   |

| Ref  | Part   | Description                     | Qty |
|------|--------|---------------------------------|-----|
| 717  | 121399 | O-RING, solvent resistant       | 2   |
| 718  | 124676 | RING, snap, external            | 2   |
| 720  | 150829 | SPRING, compression             | 2   |
| 751X | 159239 | FITTING, nipple, pipe, reducing | 2   |
| 752X | 156173 | UNION, swivel                   | 2   |

X Not shown. Shipped loose.

◆ For XP50s-hf systems only.


† For XP70s-hf systems only.

**NOTE:** Loose fittings are supplied with replacement manifold to also fit Series A (XP70s) Proportioners with 3/8 in. mix manifold ball valves.

\* Fitting orientation can be modified to allow for easier routing of recirculation lines. Remove fitting (708) and reinstall fitting (709).



# Diaphragm Pump 273093 Parts (Water Jacketed Heated Hose Packages Only)





- 1 Apply thread sealant to all non-swiveling pipe threads.
- 2 Orient fittings as shown.
- 4 Install two loose plugs and muffler provided with pump in the ports indicated.

- 6 Orient fittings approximately 15 degrees away from pump.
- 8 Install ground wire between screw and washer. The nut is held in the slot of the pump.

| Ref. | Part   | Description                         | Qty. | Ref. | Part   | Description                       | Qty. |
|------|--------|-------------------------------------|------|------|--------|-----------------------------------|------|
| 801  | 108126 | FITTING, tee, street                | 1    | 808  | 206264 | VALVE, needle                     | 1    |
| 802  | 126897 | FITTING, elbow, 1/2 tube x 1/4 nptm | 2    | 809  | 24T761 | PUMP, acetal, w/pvdf check, husky | 1    |
| 803  | 126898 | FITTING, elbow, 1/2 tube x 1/2 nptm | 1    | 810  | 113161 | SCREW, flange, hex hd             | 2    |
| 804  | 126899 | FITTING, 1/2 tube x 1/2 nptm        | 1    | 811  | 17N910 | TUBE, red, 0.5 o.d., nylon        | 2    |
| 805  | 16D939 | FITTING, nipple, reducing           | 1    | 812  | 17N911 | TUBE, blue, 0.5 o.d., nylon       | 1    |
| 806  | 16R871 | BOTTLE, overflow, 1/2 npt           | 1    | 814  | 126900 | FITTING, 1/2 tube x 3/8 nptm      | 1    |
| 807  | 17P088 | BRACKET, XP-hf, re-circ, painted    | 1    | 815  | 17D307 | FITTING, nipple, quick coupling   | 1    |
|      |        |                                     |      | 818  | 17N595 | WIRE, ground, door to enclosure   | 1    |
|      |        |                                     |      | 819  | 248208 | HOSE, coupled                     | 1    |

# XP-hf Pump Assembly Parts



ti34200b

- 2 Torque to 50-60 ft-lb (68-81 N•m).
- 3 Torque to 145-155 ft-lb (196-210 N•m).
- 4 Apply medium strength (blue) threadlock to top thread only.
- 5 Pins and lanyards must be positioned toward the outside of the pump as shown. Allow ends of lanyard to hang freely.
- 6 Remove ground screw and washer from the motor, then use to install ground wire.

- 12 Torque together to 230-250 ft-lb (312-339 N•m).
- 13 Torque together to 95-105 ft-lb (129-142 N•m).

## XP-hf Pump Assembly Parts List

| Ref. | Part   | Description                      | Qty. | Ref.   | Part   | Description                     | Qty. |
|------|--------|----------------------------------|------|--|--------|---------------------------------|------|
| 901  | 273087 | PLATE, XP-hf, motor              | 1    | 921a   | 16P338 | SCREW, mach, serrated hex hd    | 2    |
| 902  | 273086 | ROD, tie, 4 in. long, 1 in. dia  | 3    | 921b   | 17N312 | PLATE, XP-hf, finger guard      | 1    |
| 903  | 273088 | MOTOR, air, 13 in.               | 1    | 922  | 273092 | COVER, pump                     | 2    |
| 904  | 273085 | ROD, adapter                     | 1    | 922a   | 121803 | SCREW, cap, button head         | 8    |
| 905  | 262468 | ROD, tie, 14.25 long, w/shoulder | 4    | 922b   | 124172 | WASHER, retaining, nylon, 10-32 | 8    |
| 906  | 262469 | ROD, tie, 14.25 long, 1.25 dia   | 2    | 922c   | 124665 | NUT, captive, 10-32             | 4    |
| 907  | 129383 | NUT, 5/8-11, flanged, sst        | 3    | 922d▲  | 15T468 | LABEL, warning                  | 2    |
| 908  | 101712 | NUT, lock                        | 6    | 930  | 124078 | CLAMP, spring, constant-tension | 2    |
| 909  | 184096 | NUT, yoke                        | 1    | 931▲   | 15H108 | LABEL, safety, warning, pinch   | 1    |
| 910  | 17R501 | BRACKET, ratio indicator         | 1    | 932  | 111192 | SCREW, cap flange hd            | 2    |
| 911  | 273090 | YOKE, pump assembly              | 1    | 934  | 184130 | BRACKET, ratio indicator        | 1    |
| 912  | 273091 | ROD, adapter, Xtreme, hf         | 2    | 935  | 16E882 | STRAP, lowers                   | 2    |
| 913  | 262472 | SLEEVE, bearing                  | 2    | 940  | 244525 | WIRE, grounding assembly        | 1    |
| 916  | 123976 | RING, snap, external             | 2    | ▲ Replacement safety labels, tags, and cards are available at no cost. |        |                                 |      |
| 921  | 273089 | BRACKET, XP-hf, finger guard     | 1    |  |        |                                 |      |

| Ref. | Description    | 57710x | 57720x | 57730x | 57740x | 57810x | 57820x | 57830x | 57840x | Qty. |
|------|----------------|--------|--------|--------|--------|--------|--------|--------|--------|------|
| 4    | PUMP, assembly | 572100 | 572200 | 572300 | 572400 | 573100 | 573200 | 573300 | 573400 | 1    |
| 917  | PUMP, lower, A | L14AC0 | L18AC0 | L22XC0 | L22XC0 | L22AC0 | L29AC0 | L29AC0 | L29AC0 | 1    |
| 918  | PUMP, lower, B | L14AC0 | L090C0 | L072C0 | L054C0 | L22AC0 | L14AC0 | L097C0 | L072C0 | 1    |
| 919  | COUPLING, A    | 244819 | 244819 | 244819 | 244819 | 244819 | 244819 | 244819 | 244819 | 1    |
| 920  | COUPLING, B    | 244819 | 247167 | 247167 | 247167 | 244819 | 244819 | 247167 | 247167 | 1    |
| 929  | LABEL, XP-hf   | 17N281 | 17N281 | 17N281 | 17N281 | 17N282 | 17N282 | 17N282 | 17N282 | 4    |
| 56   | VALVE, safety  | 113498 | 114055 | 113498 | 114055 | 113498 | 113498 | 114055 | 16M190 | 1    |

## Recommended Spare Parts

Keep these spare parts on hand to reduce downtime.

### Pump Repair Kits

See **Models** (page 10) to see what pumps are used on your system. See lower manual for repair kits.

### Pump Filter O-Rings (packs of 10)

262483, Top o-ring  
244895, Middle o-ring  
262484, Bottom o-ring

### Recirculation/Overpressure Valve (see page 59)

XP50-hf: 262809, gold  
XP70-hf: 262520, silver

### 15K692, Seal Mix Manifold Check Valve Cartridge

**NOTE:** 15K692 must be replaced when cleaning the check valves.

### 1/2 in. Mix Manifold Inlet Ball Valves

24M601, Ball valve repair kit  
262740, Spare valve (no handle)  
262739, Spare valve (single handle)

### 248927, Spare Mix Elements (pack of 25)

1/2 in. OD x 12 element, acetal plastic

### 248837, XTR Spray Gun Repair Kit

### XHD010, Seat/Seal Kit for XHD RAC Tips (5 pack)

### XHDxxx, Spray Tips

See spray gun manual for tips.

# Accessories and Kits

## **PressureTrak™ Kit, 25C452**

Monitors pressures to provide ratio assurance on XP-hf plural component sprayers in hazardous and non-hazardous locations.

## **Twistork® Agitator Kit, 256274**

For mixing viscous materials held within a 55 gallon drum. See manual 312769 for more information.

## **5:1 Feed Pump Kit, 256276**

For supplying viscous materials from a drum to XP-hf system. See manual 312769 for more information.

## **5:1 Drum Feed Kit, 256255**

One 5:1 pump feed kit and one Twistork agitator kit for mixing and supplying viscous materials from a 55 gallon drum to XP-hf system. See manual 312769 for more information.

## **10:1 Drum Feed Kit, 256433**

For supplying highly viscous material from a 55 gallon drum to XP-hf system. See manual 312769 for more information.

## **1-1/2 in. ID Hose Flex Feed Kit, 262820**

## **XP Wall Mount Bracket, 262812**

Works with air systems.

## **Leg Stand, 24M281**

Includes wall bracket 262812.

## **1/2 in. Ball Valve Upgrade Kit for Mix Manifold, 24M593**

## **Remote Mix Manifold with Heater Block, 24Z934**

A mounting carriage with a heater block to circulate water-jacketed hose heat to maintain heat on the mix manifold.

## **Remote Mix Manifold Carriage, 262522**

A protective guard to mount mix manifold remote. See mix manifold manual 3A0590 for more information.

## **Mix Manifold Restrictor Wrench, 126786**

## **Gun Splitter with Carriage, 262826**

One splitter valve to use one, two, or three spray guns with the system. Provides independent flush for two guns. Optional 3rd gun port does not have independent flush. See manual 3A2573 for more information.

## **Filter Element, 116635**

40 micron filter element.

## **Automatic Float Drain Kit, 17P521**

Internal auto float drain for filter bowl.

## **2:1 Feed Pump Kit, 256275**

For supplying viscous materials from a drum to XP-hf system. See manual 312769 for more information.

## **2:1 Drum Feed Kit, 256232**

One T2 pump feed kit and one Twistork agitator kit for mixing and supplying viscous materials from a 55 gallon drum to XP-hf system. See manual 312769 for more information.

## **Wall Line Powered Pressure Monitor Kit, 26C008\***

## **Air Turbine Powered Pressure Monitor Kit, 26C009**


Automatically monitors difference between A and B pressures when at spray pressure and shuts down the system if there is a problem.

*\* Not approved for Hazardous locations*


# Dimensions

## System Dimensions

Top View



Side View



# Technical Specifications

| XPs-hf System   |  |                           |
|---|--|---------------------------|
|   | U.S.   | Metric                    |
| Output  |  |                           |
| Maximum Fluid Working Pressure                        | See <b>Models</b> section beginning on page 10.  |                           |
| Combined Fluid Output (cc/cycle)                      | See <b>Models</b> section beginning on page 10.  |                           |
| Pressure Ratio  | See <b>Models</b> section beginning on page 10.  |                           |
| Fluid Flow at 20 cpm                                  | See <b>Models</b> section beginning on page 10.  |                           |
| Maximum Storage Time                                  | 5 years (To maintain original performance, replace soft seals after 5 years of inactivity) |                           |
| Air Specifications                                    |  |                           |
| Required Air Flow                                     | 185 cfm (minimum)  | 5.23 m3/min (minimum)     |
| Supply Pressure                                       | 30-100 psi   | 2.0-6.7 bar, 0.2-0.67 MPa |
| Inlet Size  | 1 in. npsm   | 2.54 cm npsm              |
| Inlet Filtration                                      | 40-micron filter/separator included  |                           |
| Electrical Specifications                             |  |                           |
|   | See <b>XPs-hf Wiring Diagram</b> , page 26   |                           |
| Filtration  |  |                           |
| Feed Pump Outlet/Y-Strainer                           | 20 mesh  |                           |
| XP Pump Outlets                                       | 30 mesh  |                           |
| XTR Spray Gun   | 60 mesh  |                           |
| Viscosity   |  |                           |
| Gravity Feed  | 200 - 20,000 cps (pourable)  |                           |
| Pressure Feed   | Any viscosity that will not require feed pressure more than 15% of outlet pressure         |                           |
| Temperature   |  |                           |
| CE (North America) Operating                          | 40-130 °F (41-104 °F)  | 4-54 °C (5-40 °C)         |
| Storage   | 30-160 °F  | 1-71 °C                   |
| Maximum Fluid Temperature                             | 160 °F   | 71 °C                     |
| Wetted Materials                                      |  |                           |
| Housings and Manifold                                 | Carbon steel with electroless nickel plating   |                           |
| Displacement Pump Packings                            | Carbon filled PTFE, proprietary UHMWPE   |                           |
| Solvent Pump  | Stainless steel, PTFE, UHMWPE, aluminum, tungsten carbide                                  |                           |
| Hoses   | Plated carbon steel, Nylon   |                           |
| Feed Pump   | Plated carbon steel, PTFE  |                           |
| Agitator  | Stainless steel  |                           |
| Hopper  | Stainless steel, brass, nickel plating   |                           |
| Miscellaneous Parts                                   | Carbide, acetal, solvent resistant plastics  |                           |
| Dry Weight (does not include stand alone transformer) |  |                           |
| XXXX01  | 1350 lb  | 612 kg                    |
| XXXX02  | 1300 lb  | 590 kg                    |
| XXXX03  | 1325 lb  | 596 kg                    |
| XXXX11  | 1350 lb  | 612 kg                    |
| XXXX12  | 1300 lb  | 590 kg                    |
| XXXX13  | 1475 lb  | 700 kg                    |
| XXXX21  | 1475 lb  | 700 kg                    |
| XXXX22  | 1425 lb  | 646 kg                    |
| XXXX23  | 1450 lb  | 658 kg                    |

|        |         |        |
|--------|---------|--------|
| XXXX31 | 1475 lb | 700 kg |
| XXXX32 | 1425 lb | 646 kg |
| XXXX33 | 1450 lb | 658 kg |

#### Sound Data

|   |                       |
|---|-----------------------|
| Sound Power measured at 70 psi<br>(0.48 MPa, 4.8 bar), 20 cpm, per ISO-9614-2 | Greater than 96 dBA   |
| Sound Pressure tested at<br>3.28 ft (1 m) from equipment                      | Greater than 86.8 dBA |

#### Proportioner

|  | U.S.  | Metric                           |
|--|---|----------------------------------|
| Input  |   |                                  |
| Maximum air input                            | 100 psi                                     | 6.7 bar, 0.67 MPa                |
| Air inlet size                               | 1 in. npsm                                  |                                  |
| Fluid pump inlets                            | 1-1/4 npt (m)                               |                                  |
| Output                                       |   |                                  |
| Fluid gauge manifold                         | 1/2 in. npt(f)                              |                                  |
| Fluid mix manifold inlets (ball valves)      | 1/2 in. npsm                                |                                  |
| Mix manifold material outlet                 | 1/2 npt(f)                                  |                                  |
| Sound Data                                   |   |                                  |
|  | See XL 10k Air Motor manual for sound data. |                                  |
| Air consumption per 1 gpm (3.78 lpm) of flow |   |                                  |
| XPs70-hf                                     | 75 cfm at 100 psi                           | 2.12 m3/min at 6.7 bar, 0.67 MPa |
| XPs50-hf                                     | 60 cfm at 100 psi                           | 1.7 m3/min at 6.7 bar, 0.67 MPa  |

#### Double Wall Hopper

|                         | U.S.       | Metric      |
|-------------------------|------------|-------------|
| Temperature (set point) | 110 °F     | 43 °C       |
| Spray material capacity | 25 gallons | 94.6 liters |
| Heating fluid capacity  | 12 gallons | 53 liters   |

#### Feed Pump

|  | U.S.  | Metric                           |
|--|---|----------------------------------|
| Input  |   |                                  |
| Maximum air input                            | 100 psi                                     | 6.7 bar, 0.67 MPa                |
| Air inlet size                               | 3/8 in. npt(f)                              |                                  |
| Output                                       |   |                                  |
| Maximum working pressure                     | 500 psi                                     | 34.4 bar, 3.4 MPa                |
| Fluid outlet size                            | 3/4 in. npt(f)                              |                                  |
| Flow at maximum pump speed: (66 cycles/min)  | 2.5 gallons per minute                      | 9.5 liters per minute            |
| Air consumption per 1 gpm (3.78 lpm) of flow |   |                                  |
|  | 8 cfm at 100 psi                            | 0.23 m3/min at 6.7 bar, 0.67 MPa |
| Sound Data                                   |   |                                  |
|  | See Monark Air Motor manual for sound data. |                                  |



| Xtreme Duty Agitator                              |  |                   |
|---|--|-------------------|
|   | U.S.                                   | Metric            |
| Input   |  |                   |
| Maximum air input                                 | 100 psi                                | 6.7 bar, 0.67 MPa |
| Air inlet size                                    | 3/8 in. npsm                           |                   |
| Air Consumption                                   |  |                   |
| 30 rpm at 20 psi (1.4 bar, 0.14 MPa)              | 7 cfm                                  | 0.198 m3/min      |
| 60 rpm at 80 psi (5.5 bar, 0.55 MPa)              | 30 cfm                                 | 0.850 m3/min      |
| Maximum free speed at 100 psi (6.7 bar, 0.67 MPa) | 60 cfm                                 | 1.70 m3/min       |
| Speed   |  |                   |
| Maximum shaft speed                               | 60 rpm                                 |                   |
| Gear ratio  | 20:1                                   |                   |
| Torque:   |  |                   |
| Stall torque at maximum pressure                  | 1120 in-lb                             | 127 N•m           |
| Sound Data  |  |                   |
|   | See XD Agitator manual for sound data. |                   |

| Solvent Pump                        |                                   |                                       |
|-------------------------------------|-----------------------------------|---------------------------------------|
|                                     | U.S.                              | Metric                                |
| Input                               |                                   |                                       |
| Air pressure                        | 10 - 100 psi                      | 0.67 MPa - 6.7 bar                    |
| Air inlet size                      | 1/2 in. npt(f)                    |                                       |
| Output                              |                                   |                                       |
| Maximum working pressure            | 4500 psi                          | 3.1 MPa, 31 bar                       |
| Fluid outlet size                   | 3/8 in. npt                       |                                       |
| Flow at maximum pump speed (60 cpm) | 0.9 gpm                           | 3.0 lpm                               |
| Air Consumption                     |                                   |                                       |
| Per 0.5 gpm (1.89 lpm) of flow      | 20 cfm @70 psi                    | 0.57 m^3/min at<br>0.48 MPa, 4.83 bar |
| Sound Data                          |                                   |                                       |
|                                     | See your Merkur air motor manual. |                                       |

## Recycling and Disposal

### End of Product Life

At the end of a product's useful life, recycle it in a responsible manner.

## California Proposition 65

### CALIFORNIA RESIDENTS

 **WARNING:** Cancer and reproductive harm – [www.P65warnings.ca.gov](http://www.P65warnings.ca.gov).

# Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

**THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.**

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

**GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO.** These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

## **FOR GRACO CANADA CUSTOMERS**

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présent document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

# Graco Information

For the latest information about Graco products, visit [www.graco.com](http://www.graco.com).

For patent information, see [www.graco.com/patents](http://www.graco.com/patents).

**TO PLACE AN ORDER**, contact your Graco distributor or call to identify the nearest distributor.

**Phone:** 612-623-6921 **or Toll Free:** 1-800-328-0211 **Fax:** 612-378-3505

*All written and visual data contained in this document reflects the latest product information available at the time of publication.  
Graco reserves the right to make changes at any time without notice.*

Original instructions. This manual contains English. MM 3A6283

**Graco Headquarters:** Minneapolis

**International Offices:** Belgium, China, Japan, Korea

**GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA**  
**Copyright 2021, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.**

[www.graco.com](http://www.graco.com)  
Revision K, February 2024