

PR-X

333589A

Fixed Ratio System

EN

For accurate metering, mixing, and dispensing of two-component materials. For professional use only.

Not approved for use in explosive atmospheres or hazardous (classified) locations.


1200 psi (8.3 MPa, 83 bar) Maximum Working Pressure

100 psi (0.7 MPa, 7 bar) Maximum Air Inlet Pressure



Important Safety Instructions

Read all warnings and instructions in this manual before using the equipment.
Save these instructions.



Contents

Related Manuals	3	Recycling and Disposal	56
Models	4	End of Product Life	56
Warnings	5	Troubleshooting	57
Keep Components A and B Separate	7	Repair	60
Changing Materials	7	Prepare Machine for Piston/Cylinder Replacement Kit Installation	60
Typical Installation	8	Disassemble Cylinder	60
In Line	8	Install Cylinder	61
Stand Alone	10	Prepare Machine for Operation	61
Component Identification	12	Parts	62
PR-X Machine, Supply Pump Feed	12	Overview	62
PR-X Machine, Cartridge Feed	13	PR-X System, Supply Pump Feed, Direct, 133646 and 133647	63
PR-X Control Box	14	PR-X System, Supply Pump Feed, Remote, 133648 and 133649	64
General Information	15	PR-X System, Supply Cartridge Feed, Direct, 133650 and 133651	65
Installation	15	PR-X System, Supply Cartridge Feed, Remote, 133652 and 133653	66
Unpacking	15	PR-X Base Assembly, Supply Pump Feed	67
Locate and Install	16	PR-X Base Assembly, Supply Cartridge Feed . .	68
Grounding	18	Supply Pump Assembly	79
System Connections	19	Supply Cartridge Assembly, 25R425	82
Flush Before Using Equipment	19	Kits and Accessories	88
HMI Display Operation and Identification	20	Cable	88
Screen Navigation Diagrams	20	Dimensions	89
Automatic Screen 1	23	PR-X Machine, Supply Pump Feed	89
Automatic Screen 2	25	PR-X Machine, Cartridge Feed	89
Automatic Screen 3	27	PR-X Control Box	90
Automatic Screen 4	29		
Automatic Screen 5	29		
Automatic Screen 6 (For Cartridge Version Only)	31		
System Main Screen	32		
System Information Screen	32		
Manual Screen 1	33		
Manual Screen 2	34		
Manual Screen 3 (For Cartridge Version Only) .	34		
Setup Screen	35		
Advanced Screen 1	45		
Advanced Screen 2	46		
Operation	47		
Startup	47		
Prime the System	48		
Ratio Check Procedure	49		
Shutdown	49		
Pressure Relief Procedure	50		
Flush the Equipment	50		
Software Setup	51		
Maintenance	55		
Preventive Maintenance	55		

Schematics	91
Schematic Diagram Control Box	91
Schematic Diagram Junction Box	92
Power Supply	93
Power Supply 24 V DC	94
Servo Drive Power	95
Emergency Stop Stand Alone	96
Emergency Stop In Line	97
Output Valve 1-4	98
Output Valve 5-7	99
Digital Input	100
Digital Input_1	101
Digital Input_2	102
Digital Input_3	103
Pressure Sensor	104
Digital Output	105
Digital Output_1	106
Interface C-Box - J-Box	107
Control Panel	108
PLC	109
CPU	110
Digital Input 4K1 / 4K5	111
Digital Input 5K1 / 5K5	112
Digital Output 6K1 / 6K5	113
Digital Output 7K1 / 7K5	114
Analog Input	115
Digital Input Spare	116
Digital Output Spare	117
Analog Input Spare	118
Interface C-Box - J-Box	119
Valves J-Box	120
Sensor J-Box	121
Pressure Sensor	122
Connection lines C-Box <-> J-Box	123
Summarized Parts List	124
Summarized Parts List_1	125
Cable diagram =C_Box+001-W2	126
Cable diagram =C_Box+001-W31	127
Cable diagram =C_Box+001-W33	128
Cable diagram =C_Box+001-W34	129
Cable diagram =C_Box+001-W121	130
Cable diagram =C_Box+001-W121_1	131
Cable diagram =C_Box+001-W122	132
Cable diagram =C_Box+001-W122_1	133
Cable diagram =C_Box+001-W201	134
Cable diagram =J_Box+001-W31	135
Cable diagram =J_Box+001-W32	136

Cable diagram =J_Box+001-W33	137
Cable diagram =J_Box+001-W34	138
Cable diagram =J_Box+001-W35	139
Cable diagram =J_Box+001-W36	140
Cable diagram =J_Box+001-W37	141
Cable diagram =J_Box+001-W38	142
Cable diagram =J_Box+001-W39	143
Cable diagram =J_Box+001-W41	144
Cable diagram =J_Box+001-W42	145
Cable diagram =J_Box+001-W121	146
Cable diagram =J_Box+001-W122	147
I/O signals	148
Profinet Map	149
Timing Chart	150
Technical Specifications	151
California Proposition 65	151
Graco Standard Warranty	152

Related Manuals

Manuals in English	Description
312185	MD2 Dispense Valve Instructions and Parts Manual
308876	1K Ultra-Lite™ Instructions and Parts List Manual


Models

Part	Description	Includes:					
		PR-X Machine	PR-X Control Box (part 133656)	MD2 Dispense Valve	Static Mixer Package	Hose Package	Direct Connection
133646	PR-X System, Supply Pump Feed, Direct, SST ⁽¹⁾ , 50 CC, I/O	✓	✓	✓	✓		✓
133647	PR-X System, Supply Pump Feed, Direct, HW ⁽²⁾ , 50 CC, I/O	✓	✓	✓	✓		✓
133648	PR-X System, Supply Pump Feed, Remote, SST ⁽¹⁾ , 50 CC, I/O	✓	✓	✓	✓	✓	
133649	PR-X System, Supply Pump Feed, Remote, HW ⁽²⁾ , 50 CC, I/O	✓	✓	✓	✓	✓	
133650	PR-X System, Cartridge Feed ⁽³⁾ , Direct, SST ⁽¹⁾ , 50 CC, I/O	✓	✓	✓	✓		✓
133651	PR-X System, Cartridge Feed ⁽³⁾ , Direct, HW ⁽²⁾ , 50 CC, I/O	✓	✓	✓	✓		✓
133652	PR-X System, Cartridge Feed ⁽³⁾ , Remote, SST ⁽¹⁾ , 50 CC, I/O	✓	✓	✓	✓	✓	
133653	PR-X System, Cartridge Feed ⁽³⁾ , Remote, HW ⁽²⁾ , 50 CC, I/O	✓	✓	✓	✓	✓	

⁽¹⁾ SST: Stainless steel material

⁽²⁾ HW: High wear resistant abrasive material

⁽³⁾ For plastic cartridge, M20 x 2, length < 220 mm, diameter: 49-50 mm only.












If the cartridge size or material is different, please contact Graco sales representative for a custom solution.

NOTE: All PR-X systems are 1:1 fixed ratio systems. If you want to order other ratio systems (1:1 - 2.4:1), please contact Graco sales representative for a custom solution.

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual or on warning labels, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.

 <h2 style="margin: 0;">WARNING</h2>	
 	<p>ELECTRIC SHOCK HAZARD</p> <p>This equipment must be grounded. Improper grounding, setup, or usage of the system can cause electric shock.</p> <ul style="list-style-type: none"> • Turn off and disconnect power at main switch before disconnecting any cables and before servicing or installing equipment. • Connect only to grounded power source. • All electrical wiring must be done by a qualified electrician and comply with all local codes and regulations.
    	<p>SKIN INJECTION HAZARD</p> <p>High-pressure fluid from dispensing device, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. Get immediate surgical treatment.</p> <ul style="list-style-type: none"> • Do not point dispensing device at anyone or at any part of the body. • Do not put your hand over the fluid outlet. • Do not stop or deflect leaks with your hand, body, glove, or rag. • Follow the Pressure Relief Procedure when you stop dispensing and before cleaning, checking, or servicing equipment. • Tighten all fluid connections before operating the equipment. • Check hoses and couplings daily. Replace worn or damaged parts immediately.
	<p>TOXIC FLUID OR FUMES HAZARD</p> <p>Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled, or swallowed.</p> <ul style="list-style-type: none"> • Read Safety Data Sheets (SDSs) to know the specific hazards of the fluids you are using. • Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines.



WARNING



PERSONAL PROTECTIVE EQUIPMENT

Wear appropriate protective equipment when in the work area to help prevent serious injury, including eye injury, hearing loss, inhalation of toxic fumes, and burns. Protective equipment includes but is not limited to:

- Protective eyewear, and hearing protection.
- Respirators, protective clothing, and gloves as recommended by the fluid and solvent manufacturer.







FIRE AND EXPLOSION HAZARD

Flammable fumes, such as solvent and paint fumes, in **work area** can ignite or explode. Paint or solvent flowing through the equipment can cause static sparking. To help prevent fire and explosion:






- Use equipment only in well-ventilated area.
- Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static sparking).
- Ground all equipment in the work area. See **Grounding** instructions.
- Never spray or flush solvent at high pressure.
- Keep work area free of debris, including solvent, rags and gasoline.
- Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present.
- Use only grounded hoses.
- Hold gun firmly to side of grounded pail when triggering into pail. Do not use pail liners unless they are anti-static or conductive.
- **Stop operation immediately** if static sparking occurs or you feel a shock. Do not use equipment until you identify and correct the problem.
- Keep a working fire extinguisher in the work area.

! WARNING

 	<p>EQUIPMENT MISUSE HAZARD Misuse can cause death or serious injury.</p> <ul style="list-style-type: none"> • Do not operate the unit when fatigued or under the influence of drugs or alcohol. • Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See Technical Specifications in all equipment manuals. • Use fluids and solvents that are compatible with equipment wetted parts. See Technical Specifications in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request Safety Data Sheets (SDSs) from distributor or retailer. • Turn off all equipment and follow the Pressure Relief Procedure when equipment is not in use. • Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only. • Do not alter or modify equipment. Alterations or modifications may void agency approvals and create safety hazards. • Make sure all equipment is rated and approved for the environment in which you are using it. • Use equipment only for its intended purpose. Call your distributor for information. • Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces. • Do not kink or over bend hoses or use hoses to pull equipment. • Keep children and animals away from work area. • Comply with all applicable safety regulations.
 	<p>MOVING PARTS HAZARD Moving parts can pinch, cut or amputate fingers and other body parts.</p> <ul style="list-style-type: none"> • Keep clear of moving parts. • Do not operate equipment with protective guards or covers removed. • Equipment can start without warning. Before checking, moving, or servicing equipment, follow the Pressure Relief Procedure and disconnect all power sources.

Keep Components A and B Separate

				
<p>Cross-contamination can result in cured material in fluid lines which could cause serious injury or damage equipment. To prevent cross-contamination:</p> <ul style="list-style-type: none"> • Never interchange component A and component B wetted parts. • Never use solvent on one side if it has been contaminated from the other side. 				


Changing Materials

NOTICE
<p>Changing the material types used in your equipment requires special attention to avoid equipment damage and downtime.</p> <ul style="list-style-type: none"> • When changing materials, flush the equipment multiple times to ensure it is thoroughly clean. • Always clean the fluid inlet strainers after flushing. • Check with your material manufacturer for chemical compatibility. • When changing between epoxies and urethanes or polyureas, disassemble and clean all fluid components and change hoses. Epoxies often have amines on the B (hardener) side. Polyureas often have amines on the B (resin) side.

Component Identification

PR-X Machine, Supply Pump Feed

Direct Connection Shown



Remote Connection Shown




FIG. 3: PR-X Machine, Supply Pump Feed

Key:

- AA Junction Box Assembly
- AB Fixed Ratio Base Frame Assembly
- AC Ball Screw Assembly
- AD PR-X Drive
- AE MD2 Dispense Valve
- AF Direct Connection ⁽¹⁾
- AG Remote Hose Connection ⁽²⁾
- AH Static Mixer Package
- AJ Nose Piece
- AK PR-X Bottom Plate
- AL Inlet Valve (1K Ultra-Lite Valve) ⁽³⁾
- AS Leaking Hole


⁽²⁾ For remote version only

⁽³⁾ For supply pump feed version only

⁽¹⁾ For direct version only

PR-X Machine, Cartridge Feed

Direct Connection Shown



Remote Connection Shown




FIG. 4: PR-X Machine, Cartridge Feed

Key:

- AA Junction Box Assembly
- AB Fixed Ratio Base Frame Assembly
- AC Ball Screw Assembly
- AD PR-X Drive
- AE MD2 Dispense Valve
- AF Direct Connection ⁽¹⁾
- AG Remote Hose Connection ⁽²⁾
- AH Static Mixer Package
- AJ Nose Piece
- AK PR-X Bottom Plate
- AM Inlet Valve ⁽³⁾
- AN Cylinder Assembly ⁽³⁾
- AP Cartridge Sleeve Nut ⁽³⁾
- AR Cartridge Sleeve Assembly ⁽³⁾
- AS Leaking Hole

⁽¹⁾ For direct version only

⁽²⁾ For remote version only

⁽³⁾ For cartridge feed version only

PR-X Control Box




FIG. 5: PR-X Control Box

Key:



- BA Human Machine Interface (HMI) Display
- BB Emergency Stop Switch
- BC Remote I/O Connection (37 pin, T type)
- BD Junction Box Connection
- BE Pressure Sensor A Connection
- BF Pressure Sensor B Connection
- BG Remote Ethernet Connection (RJ45)
- BH Servo Encoder Connection
- BJ Start Signal Connection
- BK Servo Motor Connection
- BL Cooling Fan
- BM Grounding
- BN Power Connection

General Information

Different types of Static Mixer Package (AH) and Remote Hose Connection (AG) or Direct Connection (AF) are available from Graco. Make certain the Static Mixer Package (AH) and Remote Hose Connection (AG) or Direct Connection (AF) are adequately sized and pressure-rated to meet your system needs.

FIG. 3, FIG. 4 and FIG. 5 are only a guide for identifying system components and for assisting in installation. Contact your Graco distributor or Graco China Customer Service for assistance in designing a system to suit your specific needs.

Installation

				
All electrical wiring must be done by a qualified electrician and comply with all local codes and regulations.				

Unpacking

1. Inspect the shipping container carefully for damage. Contact the carrier promptly if there is damage.
2. Open the box and inspect the contents carefully. There should not be any loose or damaged parts in the container.
3. Compare the packing slip against all the items in the box. Report any shortage or other inspection problems immediately.
4. Remove the PR-X system components from the container.

Locate and Install

1. The PR-X Machine (H) can be directly mounted on a Customer Robot (M) or remotely mounted on a motion table or table top. Verify the location has access to compressed air and AC power.

2. Place the PR-X Machine (H) onto the designated location.
3. Attach the PR-X Bottom Plate (AK) to the selected location by installing fasteners (not provided with the PR-X machine) through the four mounting holes. There are also two position pin holes. Refer to FIG. 6 or FIG. 7 for mounting hole dimensions.




FIG. 6: Mounting Hole Dimensions for Installing the PR-X Machine - Supply Pump Feed








FIG. 7: Mounting Hole Dimensions for Installing the PR-X Machine - Cartridge Feed

Grounding

				
<p>The equipment must be grounded to reduce the risk of static sparking and electric shock. Electric or static sparking can cause fumes to ignite or explode. Improper grounding can cause electric shock. Grounding provides an escape wire for the electric current.</p>				

PR-X Machine (H): grounded through the PR-X Bottom Plate (AK). Use the supplied ground wire and clamp to ground the metal PR-X Bottom Plate (AK) or Customer Robot (M) to a true earth ground.




FIG. 8 Grounding

PR-X Control Box (J): grounded through the power cord.

Air and fluid hoses: use only electrically conductive hoses with a maximum of 500 ft. (150 m) combined hose length to ensure grounding continuity. Check electrical resistance of hoses. If total resistance to ground exceeds 29 megohms, replace hose immediately.

Air compressor: follow manufacturer's recommendations.

MD2 Dispense Valve (AE): ground through connection to a properly grounded fluid hose and pump.

Fluid supply container: follow local code.

Solvent pails used when flushing: follow local code. Use only conductive metal pails, placed on a grounded surface. Do not place the pail on a nonconductive surface, such as paper or cardboard, which interrupts grounding continuity.

System Connections

1. Connect the PR-X System Air Line (D) to the air inlet at the rear of Junction Box Assembly (AA). The maximum air pressure is 100 psi (0.7 MPa, 7 bar).
2. For supply pump feed version, connect the Material Supply Lines (M and N) to the corresponding material inlet at the top of Inlet Valve (AL or AM). For cartridge feed version, remove the Cartridge Sleeve Nut (AP), put the customer's cartridge into the Cartridge Sleeve Assembly (AR).
3. Using the power cord provided, connect AC power (220 V, 50/60 Hz, single phase) to the Power Connection (BN) on the back of PR-X Control Box (J).
4. Use cables to connect junction box, pressure sensor A and B, servo motor power and servo motor encoder from the PR-X Machine (H) to PR-X Control Box (J).




FIG. 9: Cable Connections - Supply Pump Feed Version


Flush Before Using Equipment

The equipment was tested with lightweight oil, which is left in the fluid passages to protect parts. To avoid contaminating your fluid with oil, flush the equipment with a compatible solvent before using the equipment. Follow **Flush the Equipment** on page 50.


HMI Display Operation and Identification

Screen Navigation Diagrams


NOTE: 'Automatic Screen 1' is the start screen after 'Start' is selected in the 'Start Center' screen.




Continued



Continued

Note: Press the  button to display the System Main Screen on each Setup Screen.



Automatic Screen 1





FIG. 10 Automatic Screen 1

After power up, the PLC program will be loaded automatically or by pressing ‘Start’ button at ‘Siemens Start Center Screen’. Automatic Screen 1 will be shown on the display. Press ‘F4’ or select the button to display the Automatic Screen 2. Press the button to display the System Main Screen. This button can only be used when the system is in standby mode or is in alarm free state. While System Main Screen is shown on the screen, the system will not operate in automatic mode.


The content and functions of this screen are as follows:

Information bar




- To illustrate the current status of equipment, such as Auto-Standby or Auto-Shot dispense.
- To show error information when an alarm is active.

System working status



- Standby: The system has checked the home position, but is not pre-charged.
- In Job: The job starts from pressure pre-charge and ends after depressurization. The system will record the dispense volume for each job. In shot or bead mode, ‘job start’ signal must be ‘1’ during one job. In sequence mode, step 0 to step 15 will be considered one job.
- Ready: Pre-charge has been completed and the system is ready to dispense material.
- Dispensing: The system is dispensing material.
- Precharging: The system is pre-charging pressure for current job.
- Depressurization: The system is in the last step of the current job. In shot or bead mode, when ‘job start’ is from ‘1’ to ‘0’, system completes de-pressurization and finishes the current job.
- Reloading: The system is reloading material.
- Purging: The system is purging some material based on the preset flow rate and volume.

Current pressure, motor torque and piston position




- Current pressure
 - Part A: Current pressure of A material.
 - Part B: Current pressure of B material.
- Motor torque: The torque of the drive motor is shown in NM.
- Piston position: Display how much material is in the cylinders (0-100%). When the rod slider is at the home position, ‘Piston position’ will show 100%. When the slider moves to the ‘empty’ position, ‘Piston position’ will show 0%.

‘Reset’ Button




Reset button will reset all non-standing alarms and warnings.

Progress bar and dispense volume



- Progress bar
 - Shot mode: The progress bar displays the completion of the current target.
 - Bead mode: the progress bar always displays 100%.
- Dispense volume: There are two dispense volume values. The left is the volume for current dispense, and the right is the current job's accumulative volume.

Control mode



Automatic mode includes three control modes: shot mode, bead mode and sequence mode.

- Shot mode: Per the style selected, the system will dispense a shot at the volume of flow rate preset in the style selected.
- Bead mode: The system according to the selected style will complete the dispensing at the preset flow rate.
- Sequence mode: When the system works in automatic status, the Customer Control Box (N) can send 'dispense' signal to initiate the sequence. The working sequence can only be edited before dispense starts. (The sequence includes 16 steps maximum, and the operator can edit step 1 to 14, as step 0 and 15 are reserved respectively for pre-charge and depressurization).
 - When 'Enable Sequence Mode' option is not selected and the system is not dispensing, the operator may choose between 'Bead' or 'Shot' mode by using the touch screen or customer signal.
 - When 'Enable Sequence Mode' option is selected, control mode will be fixed as 'Sequence' mode. 'Bead' or 'Shot' mode will be inaccessible.

NOTE: 'Enable Sequence Mode' option is in screen 3 of Advanced setup. See **Advanced Setup Screen 3** on page 43.

System working information

This area will show information unique to each control mode.

- Shot mode



In Shot mode, the selected style number, target flow rate and target volume will be shown. Shot style can be selected by touch screen or customer signals. Preset styles include 16 styles, 0-15.

- Bead mode with preset value




In Bead mode with preset value, the selected style number and target flow rate will be shown. The process for style number selection is the same as in Shot mode.

- Bead mode with custom setting



In Bead mode with custom setting, 'Rate CMD' will be shown as voltage value and target flow rate will be shown. The flow rate will change based on rate command.

- Sequence mode



In Sequence mode, the step number, remaining repeat times, target flow rate and volume will be shown in different screens based on different step types. The operator can edit the step by using the touch screen prior to or following the current job. Once dispensing has begun, the 'Control mode' display will show the current step, including pre-charge, shot dispense, bead dispense, reload and depressurization.

Automatic Screen 2





FIG. 11 Automatic Screen 2

On the Automatic Screen 2, press 'F1' or select the ◀ button to display the Automatic Screen 1. Press 'F4' or select the ▶ button to display the Automatic Screen 3.


The content and functions of this screen are as follows:

Sensors status




To show the 3 slider position sensors.

Emergency stop status




- Red circle: E-stop button is pushed in.
- Green circle: E-stop button is released.

Servo motor signals




- Servo ON: This signal will be shown as green after system start.
- Servo ready: Motor can be used or is working without problem.
- Servo alarm: Something is wrong with the motor. Operator should push the reset button or send a remote reset signal. If reset does not work, the PR-X control box needs to be restarted.

Supply cartridge empty sensor




When the PR-X system is cartridge feed version, this area will be displayed.

Dispense valve and inlet valves status




Supply Pump Version



Cartridge Version

If the system is a cartridge version, because the Inlet Valve (AM) is used for reloading, the on/off sensor status will be displayed.

Motor position




This display shows the number of motor steps. Each revolution of motor is 150 steps.

Purge time




If the operator has set the 'Purge alarm time' on **Setup Screen 5 - Purge**, see page 38, the purge timer will be shown and the time displayed will count down. If the timer reaches ZERO, the system will send a 'purge request' signal and show 'purge request' in the information bar.

Auto reduction time



If the operator enabled 'End job automatically' and set 'Max idle time in job' on **Setup Screen 7 - De-pressurization**, see page 40, the auto reduction time will be shown in box. If the timer times out, the system will automatically reduce the pressure and end the current job.

'HOME' button



This is the return to the Home point command. When the 'HOME' button is selected, the system must be inactive. Once the button to start the Home operation is selected, the button will blink until the piston returns to the Home point, and then the button will remain on until the next operation is started.

Automatic Screen 3




FIG. 12 Automatic Screen 3 (I/O Communication Mode)




FIG. 13 Automatic Screen 3 (Profinet Communication Mode)

On the Automatic Screen 3, press 'F1' or select the ◀ button to display the Automatic Screen 2. Press 'F4' or select the ▶ button to display the Automatic Screen 4.

The content and functions of this screen are as follows:

Input signals status




The input signals display shows the current signal status from customer inputs.

- Rate CMD
 - If 'distributed IO' is selected as 'Other CMD Resource' on **Advanced Setup Screen 2**, see page 42, the input voltage signal will be shown as 0-10.0, where 0 means 0 voltage, 10.0 means 10 V.
 - If 'Gateway' is selected as 'Other CMD Resource' on **Advanced Setup Screen 2**, see page 42, the input data sent by Profinet will be shown as a value from 0 to 1000.

NOTE: The Gateway option is only included in the Profinet communication mode. Any PR-X system can be converted to use Profinet communication mode.

Output signals status



I/O communication mode



Profinet communication mode

The output signals display shows the current signal status from the PR-X control box.

Error code	Port code	Error Type	Comment
0	00000	----	No Error
1	00001	Error	Estop
2	00010	Error	Lowest limit has been reached
3	00011	Error	Highest limit has been reached
4	00100	Error	Pre-charge time out
5	00101	Error	Pressure relief time out
6	00110	Error	Reload time out
7	00111	Error	Servo fault
8	01000	Error	Part A Supplier is in low level
9	01001	Error	Part B Supplier is in low level
10	01010	Error	Part A pressure exceeds system limit
11	01011	Error	Part B pressure exceeds system limit
12	01100	Error	Part A/B pressure is not balanced
13	01101	Error	Servo unit lost power
14	01110	Error	Inlet valve A does not turn on in time
15	01111	Error	Inlet valve B does not turn on in time
16	10000	Error	Dispense valve does not turn on in time
17	10001	Error	Inlet valve A does not turn off in time
18	10010	Error	Inlet valve B does not turn off in time
19	10011	Error	Dispense valve does not turn off in time
20	10100	Error	Pressure relief fault
21	10101	Error	Pre-charge fault
22	10110	Error	Homing fault
23	10111	Error	Motor torque is over limit
24	11000	Error	Motor peak torque is over limit
25	11001	Deviation	Illegal setting
26	11010	Deviation	Illegal command
27	11011	Deviation	Home is lost
28	11100	Deviation	Reload is requested (System is in job) or metering tube pump is empty (System is not in job)
29	11101	Deviation	Purge is requested
30	11110	Deviation	Automatic relief after idle

NOTE: The information below is exclusive to the Profinet communication mode.

- Disp vol: Dispense volume during current shot. The value from the PR-X control box is an integer and must be multiplied by 0.01 to calculate the requested volume. The unit is cc.
- Disp rate: Dispense flow rate. The value from the PR-X control box is an integer and must be multiplied by 0.001 to calculate the requested volume. The unit is cc/s.
- Disp press A: Current working pressure value of part A. The value from the PR-X control box is an integer and the unit is psi.
- Disp press B: Current working pressure value of part B. The value from the PR-X control box is an integer and the unit is psi.
- MTR torque: Current driver motor working torque. The value is an integer and must be multiplied by 0.001 to calculate the requested volume. The unit is NM.
- Vol ratio: Current dispense mixing ratio. The value is an integer and must be multiplied by 0.01 to calculate the requested volume.

Automatic Screen 4






FIG. 14 Automatic Screen 4

On the Automatic Screen 4, press 'F1' or select the  button to display the Automatic Screen 3. Press 'F4' or select the  button to display the Automatic Screen 5. This screen shows the error history. It will record the error number, time, date and explanation text for the last 50 system errors.

Automatic Screen 5







FIG. 15 Automatic Screen 5

On the Automatic Screen 5, press 'F1' or select the  button to display the Automatic Screen 4. If the system is supply pump feed version, press 'F4' or select the  button to display the Automatic Screen 6. If the system is cartridge feed version, press 'F4' or select the  button to return to the Automatic Screen 1.

The content and functions of this screen are as follows:

Select box



After one or several selection boxes are selected, the 'Reset' button will appear. The operator can clear the selected record and restart data recording.

Workload record

Part Name	Disp Vol(Litre)	Cycle Times
Dispense Valve	#####...	#####...
Inlet valve A	#####...	#####...
Inlet valve B	#####...	#####...
Piston A	#####...	#####...
Piston B	#####...	#####...

To record the workload of important parts. This data can be reset.

System statistics



This section displays the whole system workload record. This data cannot be reset.

Automatic Screen 6 (For Cartridge Version Only)







FIG. 16 Automatic Screen 5

On the Automatic Screen 6, press 'F1' or select the  button to display the Automatic Screen 5. Press 'F4' or select the  button to return to the Automatic Screen 1.

The content and functions of this screen are as follows:

Part A and Part B supply status





To show the supply status of Part A and part B.

Supply system operation



- Part A or B feed: Activate to start or stop supply device A or B, regardless of supply type (supply pump feed or cartridge feed).
- Part A or B smart feed: Only activate to drive supply device in reloading.
 - For supply pump feed, the system will start the pump only while reloading.
 - For cartridge feed, the piston is only active in reloading. When the system is dispensing, the piston is in a neutral position.

				
To prevent injury from moving parts, make sure the cartridge change is completed before pressing 'F3' to resume feed.				

- Cart change: Only activate to change cartridge after the job is finished. Select 'Cart Change' to move back the cartridge cylinder rod. Press 'F3' to move forward the cartridge cylinder rod.

System Main Screen







FIG. 17 System Main Screen

On the Automatic Screen 1, press  button to display the System Main Screen. On this screen, the operator can switch the system to Automatic mode, Manual mode, Setup mode, Pressure relief function or Advanced Mode.

Press 'F1' or select the  button to display language options (Chinese or English). Press 'F2' or select the  button to display the System Information Screen.

If the operator has already set up password protection on **Advanced Setup Screen 1**, see page 41, the password must be entered to open the Setup Screens.

To open the Advanced mode, the operator must enter the password **1492**. The Advanced option won't show until the password has been entered.

Select 'Pressure relief' button, the system will identify whether the inlet valve (AL or AM) is closed. If the Inlet Valve (AL or AM) is opened, it will be closed. Then the MD2 Dispense Valve (AE) will be opened. The whole system pressure is relieved. When the 'Pressure relief' is selected, the real-time pressure of part A and part B will be displayed on the System Main Screen.

System Information Screen





FIG. 18 System Information Screen

General system information can be found in this screen. Press 'F1' or select the  button to return to the System Main Screen.

Manual Screen 1





FIG. 19 Manual Screen 1

On the Manual Screen, press 'F1' or select the button to display the Manual Screen 2. Press 'F4' or select the button to execute the operation which is selected in 'Function mode' dropdown list . Select the button to display the System Main Screen. This button can only be selected when the system is in standby or alarm mode. When the operator has entered the System Main Screen, the system will not work in Automation mode.

The content and functions of this screen are as follows:

Function mode operation select



Function includes 7 operations: Homing, Pre-charge, Shot dispense, Bead dispense, Reload, Depressurization and Purge.

Flowrate and target volume




Parameter setting of flow rate and target volume.

Progress bar and actual dispense volume



- Shot mode: Displays the progress bar showing the completion of the current target and the actual dispensing volume.
- Bead mode: The progress bar always displays 100%. The actual dispensing volume will increase during bead dispensing and the target volume will display a value consistent with the actual volume.

Current pressure, motor torque and piston position



- Current pressure
 - Part A: Current pressure of A material.
 - Part B: Current pressure of B material.
- Motor torque: The torque of the drive motor is shown in NM.
- Piston position: Displays how much material is in the cylinders (0-100%). When the rod slider is at the home position, 'Piston position' will show 100%. When the slider moves to the 'empty' position, 'Piston position' will show 0%.

Manual Screen 2




FIG. 20 Manual Screen 2 (I/O Communication Mode)






FIG. 21 Manual Screen 2 (Profinet Communication Mode)

On the Manual Screen 2, press 'F1' or select the  button to display the Manual Screen 1. If the system is cartridge feed version, press 'F2' or select the  button to display the Manual Screen 3.

The Manual Screen 2 is used to check the signal exchange only.

Manual Screen 3 (For Cartridge Version Only)







FIG. 22 Manual Screen 3

On the Manual Screen 3, press 'F1' or select the  button to display the Manual Screen 2. Press 'F4' or select the  button to return to the Manual Screen 1.


The content and functions of this screen are as follows:

Part A and Part B supply status



To show the supply status of Part A and part B.

Supply system operation



- Part A or B feed: Activate to start or stop supply device A or B, regardless of supply type (supply pump feed or cartridge feed).
- Part A or B smart feed: Only activate to drive supply device in reloading.
 - For supply pump feed, the system will start the pump only while reloading.
 - For cartridge feed, the piston is only active in reloading. When the system is dispensing, the piston is in a neutral position.

<p>To prevent injury from moving parts, make sure the cartridge change is completed before pressing 'F3' to resume feed.</p>				

- Cart change: Only activate to change cartridge after the job is finished. Select 'Cart Change' to move back the cartridge cylinder rod. Press 'F3' to move forward the cartridge cylinder rod.

Setup Screen

Setup Screen 1 - Reload





FIG. 23 Reload Setup Screen

On the Reload Setup Screen, press 'F1' or select the button to display the System Main Screen. Press 'F2' or select the button to return to the previous screen. Press 'F4' or select the button to continue to the next screen.

The content and functions of this screen are as follows:

Reload speed setup



Set both the reloading speed and 'Home' operations speed.

Reload pressure setup

Reload pressure:
 Part A: ###... psi
 Part B: ###... psi

Set the reload pressure for part A and B. During reloading, after piston returns to home position, the system will keep the Inlet Valve (AL or AM) open until part A and B pressure has exceeded the preset reload pressure.

Maximum reload time

Max reload time:
 ###... sec

Set reload time limit. If the reload process exceeds the time limit, the system will send out an alarm as a reload time out.

Reload type setup

Auto reload setup

- Reload after each job
- Reload after multi jobs
- Custom signal reload

- Reload after each job: The system automatically reloads after each job.
- Reload after multi jobs: The system automatically reloads after multiple jobs.
- Custom signal reload: The system will not reload automatically. The system will reload only when prompted by external signal.

Reload request position

Reload request position:
 ## %

- When the material in the supply pump system or supply cartridge is less than the percentage set here, the system will send out an alarm, but the system can still work.
- If Reload after each job or Reload after multi jobs is selected, and the material in the supply pump system or supply cartridge is less than the percentage set here, the system automatically reloads after each job or multiple jobs.

Setup Screen 2 - Shot



FIG. 24 Shot Setup Screen

On the Shot Setup Screen, press 'F1' or select the button to display the System Main Screen. Press 'F2' or select the button to return to the previous screen. Press 'F4' or select the button to continue to the next screen.

This screen includes 4 pages to set flowrate and target volume for 16 styles.

Setup Screen 3 - Bead




FIG. 25 Bead Setup Screen (Preset value)

Setup Screen 4 - Sequence




FIG. 27 Sequence Setup Screen

On the Sequence Setup Screen, press 'F1' or select the button to display the System Main Screen. Press 'F2' or select the button to return to the previous screen. Press 'F4' or select the button to continue to the next screen.

Sequence includes 16 steps maximum. Step 0 and step 15 are used to start job (Pre-charge) and end job (Depressurization). Operator can select functions including shot, bead, reload and none. If the shot or bead function is selected, repeat time can be set (1-99).




FIG. 26 Bead Setup Screen (Custom setting)

On the Bead Setup Screen, press 'F1' or select the button to display the System Main Screen. Press 'F2' or select the button to return to the previous screen. Press 'F4' or select the button to continue to the next screen.

There are two Rate command types:

- Preset value: The flow rate is defined on **Setup Screen 2 - Shot**, see page 36. 'Shot bit 0-3' signals or style numbers are used to select flow rate.
- Custom setting: The operator should set 'Max Rate' first. The Operator can use 0-10 V signal to control flow rate.

Setup Screen 5 - Purge








FIG. 28 Purge Setup Screen

On the Purge Setup Screen, press 'F1' or select the  button to display the System Main Screen. Press 'F2' or select the  button to return to the previous screen. Press 'F4' or select the  button to continue to the next screen.

The content and functions of this screen are as follows:

Purge volume and rate setup




- Purge volume: Set the target purge volume.
- Purge rate: Set the purge flowrate.

Purge alarm time



Set the purge request timer. When the equipment doesn't dispense, the PR-X control box will start the countdown for the time chosen by the operator. When the time is 0, the system will send out the purge alarm signal.

Purge type setup



- Auto reload after purge button: When enabled, the system automatically reloads after purge is completed.
- Auto depressurize after purge button: When enabled, the system automatically performs depressurization after purge is completed.

Setup Screen 6 - Pre-charge





FIG. 29 Pre-charge Setup Screen

On the Pre-charge Setup Screen, press 'F1' or select the button to display the System Main Screen. Press 'F2' or select the button to return to the previous screen. Press 'F4' or select the button to continue to the next screen.


The content and functions of this screen are as follows:

Pre-charge pressure




The operator may set the pre-charge pressure in psi.

Maximum pre-charge time limit



The operator may set the time in seconds the system may spend pre-charging. If pre-charging exceeds the set time, the system will activate the alarm to alert the operator the limit has been reached.

Pre-charge speed



The operator may set two separate pre-charge rates. The system will pre-charge at the set 'Hi' speed until reaching the decelerate point. The decelerate point is the target pressure at which the system will switch from the "Hi" to the "Lo" pre-charge rate. Enter the decelerate point as a percentage of the Pre-charge pressure. For example, if the pre-charge pressure is 500 psi and the decelerate point is 75%, the system will switch to the 'Lo' speed once pressure has reached 375 psi. The system will then continue pre-charging at the set 'Lo' speed until system confirms the pressure has exceeded the set target pressure.

Setup Screen 7 - De-pressurization








Fig. 30 De-pressurization Setup Screen

On the De-pressurization Setup Screen, press 'F1' or select the  button to display the System Main Screen. Press 'F2' or select the  button to return to the previous screen. Press 'F4' or select the  button to continue to the next screen.

The content and functions of this screen are as follows:

De-pressurization setup




- Depressurization target: The operator may set the depressurization target. The system will reduce the pressure to the target value automatically when the job is finished.

NOTE: Set different depressurization targets according to different materials. For detailed information, please contact your Graco distributor.

- Max depressurization time: The operator may set a maximum time in seconds for the system to perform depressurization. If depressurization function exceeds the set time, the system alarm will be activated.
- Depressurization rate: The operator may input a value here to set the piston speed during depressurization.

End job automatically






After this option is enabled, the operator must set the maximum idle time for the system while performing a job. After the set period passes without any operation, the depressurization program will be automatically executed and the current job ended.

Advanced Setup Screen

Advanced Setup Screen 1



FIG. 31 Advanced Setup Screen - 1

On the Advanced Setup Screen 1, press 'F1' or select the  button to display the System Main Screen. Press 'F2' or select the  button to return to the previous screen. Press 'F4' or select the  button to continue to the next screen.

The content and functions of this screen are as follows:

Flowrate unit

The operator may select either cc/minute or cc/second from the dropdown list to customize the units used for flowrate setup.

Pressure unit

The operator may select psi, bar or MPa from the dropdown list to customize the units used for pressure setup.

Password

If this function is selected, a 4-digit number should be set. After the 4-digit number is set, the operator must be prompted to input the password before navigating to any of the setup screens.

Language

The operator may select either Chinese (by selecting the Chinese flag) or English (by selecting British flag) to change the language used on the system's user interface.

Advanced Setup Screen 2







Fig. 32 Advanced Setup Screen - 2 (I/O Communication Mode)



Fig. 33 Advanced Setup Screen - 2 (Profinet Communication Mode)

On the Advanced Setup Screen 2, press 'F1' or select the  button to display the System Main Screen. Press 'F2' or select the  button to return to the previous screen. Press 'F4' or select the  button to continue to the next screen.

The content and functions of this screen are as follows:

Mode selected by

Options for mode selection input include Display, Distributed IO or Gateway.

- If 'Distributed IO' or 'Gateway' is selected, in Automatic mode, the shot or bead working mode (Sequence mode will be inaccessible) must be controlled by customer signals. The operator will not be able to change working mode using the touch screen.
- If 'Display' is selected, working mode will include Shot, Bead and Sequence mode. The operator will be able to change working mode using the touch screen.

Style No. selected by

The operator may choose whether the style number may be changed by Display, Distributed IO or Gateway.

Dispense CMD resource

The operator may choose whether the Dispense Command (CMD) resource comes from Distributed I/O communication or Gateway (Profinet) communication. Display option is unavailable.

Other CMD resource

The operator may choose whether the Other Command (CMD) Resource comes from Distributed I/O communication or Gateway (Profinet) communication. Display option is unavailable. Other command (CMD) includes job start, reload, purge start, remote reset.

NOTE: The Gateway option is only included in the Profinet communication mode. Any PR-X system can be converted to use Profinet communication mode.

Advanced Setup Screen 3







Fig. 34 Advanced Setup Screen - 3

On the Advanced Setup Screen 3, press 'F1' or select the  button to display the System Main Screen. Press 'F2' or select the  button to return to the previous screen. Press 'F4' or select the  button to continue to the next screen.

The content and functions of this screen are as follows:

Enable remote E-stop

If this function is selected, the PR-X system can be shut down from an external signal. When the signal changes to a '0', the PR-X system will shut down. This function acts the same as the Emergency Stop Switch (BB) on the front of the PR-X control box.

Enable sequence mode

If this function is selected, the PR-X system will run in sequence mode. In this mode, the operator can edit the working sequence (The sequence includes 16 steps maximum. The operator can edit step 1 to 14, as step 0 and 15 are tied to pre-charge and depressurization). When the system works in automatic status, the Customer Control Box (N) can send 'dispense' signal to start the sequence mode and then dispense step by step.

Enable pressure check after homing

If this function is selected, the system pressure will be checked when the piston is in the home position.

Enable remote supply lock (For cartridge version only)

If this function is selected, the supply cartridge can not feed the material until the customer's control system sends out the unlock signal.

Advanced Setup Screen 4





FIG. 35 Advanced Setup Screen - 4

On the Advanced Setup Screen 4, press 'F1' or select the button to display the System Main Screen. Press 'F2' or select the button to return to the previous screen. Press 'F4' or select the button to continue to the next screen.


The content and functions of this screen are as follows:

Pressure sensor offset



The operator may input values to adjust the pressure offset on the sensors.

Pressure limit



If the Part A or B pressure is higher than the preset max pressure, the system will activate the alarm and send the alarm signal to customer system. During dispensing, the system will check the difference between part A and B. If the pressure difference is higher than preset limit, the system will send the alarm signal and stop dispensing.

Advanced Screen 1






FIG. 36 Advanced Screen 1

On the Advanced Screen 1, press 'F4' or select the  button to display the Advanced Screen 2. Advanced screens 1 and 2 are dedicated to repairing and testing the system. After navigating to this screen, the logic relationship between the drive motor, reloading valves and dispense valves will be overrode and the operator may control each part individually. For this reason, only qualified personnel who have received equipment maintenance training should be authorized to navigate to this screen and perform system check.


The content and functions of this screen are as follows:

Move speed




This box is for setting the speed of the slide block.

Piston move up



This button is for motor, slide block and piston tests. Jog control pistons and slide block move away from the outlet port.

Piston move down



Jog control pistons and slide block move toward the outlet port.




FIG. 37 Piston move up or down

Advanced Screen 2






FIG. 38 Advanced Screen 2

On the Advanced Screen 2, press 'F1' or select the  button to return to the Advanced Screen 1.


The content and functions of this screen are as follows:


Dispense valve



Selecting this button enables testing of the MD2 Dispense Valve (AE) by controlling the opening or closing of the valve. When the MD2 Dispense Valve (AE) is open, the button will be green; when the MD2 Dispense Valve (AE) is closed, the button will be gray.


Inlet valve A and inlet valve B






Selecting each of these buttons enables testing of inlet valve A and B (AL or AM), respectively, by controlling the opening or closing of the valve. When the Inlet Valve (AL or AM) is open, the button will be green; when the Inlet Valve (AL or AM) is closed, the button will be gray.

Supply A start and supply B start (For cartridge version only)





Selecting each of these buttons enables starting supply cartridges.

Operation

Startup

1. Locate the Power Switch (BM) at the rear of the PR-X Control Box (J) and turn the power on.
2. With the air line (C) connected to the PR-X Machine (H), go to the Advanced Screen 2 of the PR-X Control Box (J), then select 'Inlet valve A' and 'Inlet valve B' to turn on Inlet Valve A and B (AL or AM).

NOTE: Very viscous, compressible materials may continue to leak after system is primed. Reduce flow rate as required to produce air-free dispensation. Very thin materials may require tilting the valve greater than 45 degrees and dispensing shots until material is air-free.

NOTE: Air entering the machine should be filtered.




FIG. 39 Advanced Screen 2

3. Adjust the Pressure Regulating Valve (F) so the air pressure provided by the customer is at least 80 psi (0.6 MPa, 6 bar), and no higher than 100 psi (0.7 MPa, 7 bar).

NOTE: If needed, add the pressure relief valve to reduce pressure to 100 psi (0.7 MPa, 7 bar).

4. Perform **Prime the System** on page 48.
5. Perform the **Ratio Check Procedure** on page 49.
6. Install Static Mixer Package (AH).
7. Dispense several full stroke shots until the PR-X Machine (H) is free of air and there is no leakage at the Nose Piece (AJ) after shutoff.

Prime the System

1. Remove Static Mixer Package (AH) from the MD2 Dispense Valve (AE) (if installed) and place a waste container below it.
2. Pressurize the A and B Material Feed System (K and L); set the lower pressure to 20 psi (0.14 MPa, 1.4 bar).
3. Go to the Advanced Screen 1 of the PR-X control box (J). Select 'Piston move up', the piston moves up until the sensor sends out the stop signal, then set the move speed to 0.2 cc/s.




FIG. 40 Advanced Screen 1

4. Select 'Dispense valve', 'Inlet valve A' and 'Inlet valve B' to turn on MD2 Dispense Valve (AE) and Inlet Valve A and B (AL or AM).




FIG. 41 Advanced Screen 2

5. When both sides of the system have a continuous and stable flow, select 'Dispense valve' again to turn off the MD2 Dispense Valve (AE).
6. Return to the Manual screen 1. Change the function to reload, then run the system.





FIG. 42 Manual Screen 1

7. Dispense several full stroke shots until the PR-X Machine (H) is free of air.

Ratio Check Procedure

Perform the Ratio Check Procedure at startup and after rebuild.

1. Weigh six small cups and label as indicated. Record weights.



2. Remove Static Mixer Package (AH) from MD2 Dispense Valve (AE).
3. Install the ratio check nozzle onto the MD2 Dispense Valve (AE).



4. Dispense into a waste container to prime the ratio check nozzle.
5. Place cups as indicated under ratio check nozzle and cycle the machine one time.
6. Repeat until all three sets of cups have been used.
7. Re-weigh all six cups and record weights.
8. Subtract weight of empty cups from weight of filled cups to get material weights.
9. Complete ratio calculations.

The following formula can be used when the density or specific gravity of both the “A” and “B” components are known and only one of the ratios:

$$\frac{\text{Weight Ratio}}{\text{Volume Ratio}} = \frac{\text{Specific Gravity}}{\text{Specific Gravity}}$$

Example:

A material has a weight ratio of 10:1, the “A” material has a specific gravity of 1.20 and the “B” material has a specific gravity of 1.00. To calculate volume ratio:

$$\frac{10:1}{\text{Volume Ratio}} = \frac{1.20}{1.00}$$

$$\text{Volume Ratio} = \frac{10}{1.20}$$


$$\text{Volume Ratio} = 8.33:1$$


Shutdown



1. Remove Static Mixer Package (AH) from MD2 Dispense Valve (AE).
2. Place a waste container below the MD2 Dispense Valve (AE) and activate a small shot to flush mixed material out of the valve.
3. Perform the **Pressure Relief Procedure** on page 50.
4. Turn off the system power.
5. Wipe the Nose Piece (AJ) with a clean rag, being careful to avoid contact between dispense materials.
6. Install the PTFE night cap (1:1 valves - 15K652) and retaining nut (15K688) on the MD2 Dispense Valve (AE).

Pressure Relief Procedure

 Follow the Pressure Reduction Procedure whenever you see this symbol.



This equipment stays pressurized until pressure is manually relieved. To help prevent serious injury from pressurized fluid, such as skin injection, splashing fluid and moving parts, follow the Pressure Reduction Procedure when you stop dispensing and before cleaning, checking, or servicing the equipment.

1. Remove Static Mixer Package (AH) from MD2 Dispense Valve (AE).
2. Close the Bleed-type Master Air Valve (G, page 7) (required in the system).
3. Place a waste container below the MD2 Dispense Valve (AE).
4. Go to System main screen of the PR-X control box (J), then select 'Pressure relief'.




FIG. 43 System Main Screen

5. Turn off the system power and the air supply when the fluid pressure drops to ZERO.

Flush the Equipment



To avoid fire and explosion, always ground equipment and waste container. To avoid static sparking and injury from splashing, always flush at the lowest possible pressure.

- Flush out old fluid with new fluid or flush out old fluid with compatible solvent before introducing a new fluid.
- Use the lowest possible pressure when flushing.
- All fluid components are compatible with common solvents.
- To flush the entire system, circulate through the MD2 Dispense Valve (AE), then drain the valve.

Software Setup

Insert the SD card

1. Turn off and disconnect the control box power.
2. Remove the control box cover.
3. Insert the SD card.
4. Change the toggle switch position into run.
5. Put the cover back on and restart the control box again.






FIG. 44 Insert the SD Card

PLC IP Address Setup


1. Start PR-X control box and push 'Settings' button on the 'Start Center' screen.




2. Select 'Service & Commissioning' on the 'Settings' screen.





3. Select 'Assign IP Address' from the 'Service & Commissioning' list, then touch the cycle in the middle of screen to see complete information.



4. Select 'Accessible devices in target subnet' on the 'Step 1/4' screen. Then select '>' to proceed to the next screen.




5. Select 'Start search' button on the 'Step 2/4' screen, HMI will then find PLC in the Net. Select the device with the IP address you want to change. Then select '>' to proceed the next screen.




6. Edit IP address directly on the 'Step 3/4' screen. Then select '>' to proceed to the next screen.



7. Choose 'Accept' on the 'Step 4/4' screen.




8. Select 'Edit Connections' from the 'Service & Commissioning' list. Next, touch the middle cycle to open the whole screen.




9. Select 'HMI_Connection_1' on the 'Step 1/3' screen. Then select '>' to proceed to the next screen.




10. Select 'ON' for the 'Override' item on the 'Step 2/3' screen. Then select '>' to proceed to the next screen.



11. Select 'Accept' on the 'Step 3/3' screen.



12. Return to the 'Start Center' screen and restart HMI before HMI IP address setup.




3. Edit IP address directly from the 'Network Interface' screen.




HMI IP Address Setup


1. Start PR-X control box and select 'Settings' on the 'Start Center' screen.



4. Return to the 'Start Center' main screen and restart HMI.



2. Select 'Network Interface' on the 'Settings' screen.



Maintenance

Preventive Maintenance

There is a grease filled secondary seal/bearing area on each valve shaft (MD2 Dispense Valve (AE) and Inlet Valve (AL or AM). Every 10,000 cycles or twice each month, new grease should be flushed across this area.

To grease the valve:

1. Remove the fitting from each side of the front or back of the valve. For the detailed information, please check MD2 Dispense Valve (AE) Instruction and Parts Manual 312185 and 1K Ultra-Lite Instructions and Part List Manual 308876.
2. Pump grease (115982) with grease gun (117792) across the valve until clean grease comes out the other side.
3. Reinstall the fitting.


Maintenance Schedule

Item	Task	Daily	Monthly	Quarterly	Yearly
1	Inspect cable and air tubes for leaks	✓			
2	Clean up all material and dust of supply pump or cartridge	✓			
3	Clean dust and foreign matter from the PR-X machine and the PR-X control box	✓			
4	Inspect fluid lines and adapters for leaks	✓			
5	Inspect inlet air filter equipment, expel water and clean filter	✓			
6	Use dry and clean compressed air to remove dust buildup on motor, control boards and fan		✓		
7	Clean and grease Inlet Valve (AL or AM) and MD2 Dispense Valve (AE) and repair broken seal components (see valve manual)		✓		
8	Inspect supply pumps' wet cup, cleanup leaking material and fill TSL oil		✓		
9	Inspect leaking holes (AS) on the both side of PR-X machine		✓		
10	Grease the ball screw, slides and bearings			✓	
11	Inspect sealant condition with high pressure and repair broken seal components			✓	
12	Inspect and tighten screws and nuts on moving parts			✓	
13	Verify sensors are affixed correctly			✓	
14	Inspect and calibrate pressure sensor				✓
15	Replace PR-X machine's pistons and O-rings				✓
16	Replace valve seal components (MD2 Dispense Valve (AE) and Inlet Valve (AL or AM))				✓
17	Replace supply pump seal components				✓


Recycling and Disposal

End of Product Life

At the end of the product's useful life, dismantle and recycle it in a responsible manner.

- Perform the **Pressure Reduction Procedure** on page 50.
- Drain and dispose of fluids according to applicable regulations. Refer to the material manufacturer's Safety Data Sheet.
- Remove motors, circuit boards, LCDs (liquid crystal displays), and other electronic components. Recycle according to applicable regulations.
- Do not dispose of electronic components with household or commercial waste. 
- Deliver remaining product to a recycling facility.

Troubleshooting



1. Follow **Pressure Relief Procedure** on page 50, before checking or repairing the system.
2. Disconnect AC power from the system.

Problem	Cause	Solution
Display module completely dark	No power	Verify AC power switch (BM) is ON
	Thrown breaker	Check machine breakers and reset
	Loose connection	Tighten screen data cable
	Bad display module	Replace display module
No or incorrect amount of material dispensed from either side	MD2 Dispense Valve (AE) closed	Verify supply air pressure
	Needle or Static Mixer Package (AH) clogged	Replace needle or Static Mixer Package (AH)
	Supply pump ball valve closed (if installed)	Open ball valve
	Cartridge or pail empty	Exchange cartridge or pail
	Supply pump clogged	Clean supply pump
	Air in PR-X machine	Purge and prime the system
Significant material leaking from pump seal	Pump shaft and/or shaft seal worn	Remove pump shaft assembly and reinstall pump rebuild kit
Material weight incorrectly dispensed	Needle or Static Mixer Package (AH) clogged	Replace needle or Static Mixer Package (AH). Incorporate purge timer or decrease purge timer delay to prevent Static Mixer Package (AH) blockage
	MD2 Dispense Valve (AE) or fluid lines clogged	Clean MD2 Dispense Valve (AE) or fluid lines
	MD2 Dispense Valve (AE) opened or closed incorrectly	<ol style="list-style-type: none"> 1. Verify MD2 Dispense Valve's (AE) inlet air pressure. 2. Inspect MD2 Dispense Valve (AE) air cylinder and adapters for leaks.
	Input air reduced or removed	Reconnect input air line to system. Increase air pressure regulator adjustment
	Inlet Valve (AL or AM) not closed (if installed)	<ol style="list-style-type: none"> 1. Inspect the Inlet Valve (AL or AM) for wear and tear. 2. Verify rotary cylinder inlet pressure.
	Inlet 1K Ultra-Lite valve leaking (if installed)	Inspect needle and seal components
	Piston worn out or broken	Replace piston

Problem	Cause	Solution
Leakage from Static Mixer Package (AH) tip	Air in Static Mixer Package (AH)	Slow speed purging
	MD2 Dispense Valve (AE) not closed	<ol style="list-style-type: none"> 1. Verify MD2 Dispense Valve's (AE) inlet air pressure. 2. Clean blockage between needle and seat. 3. Verify solenoid valve status.
	MD2 Dispense Valve (AE) needle and/or seat worn out (pressure reduces after closing the valve)	Replace MD2 Dispense Valve (AE) needle and/or seat
	Damaged or missing gasket (O-ring) between seat and housing (hard seat only)	Replace gasket (O-ring)
	Insufficient valve off time	Increase valve off time to release pressure in Static Mixer Package (AH)
High pressure	MD2 Dispense Valve (AE) clogged	Clean MD2 Dispense Valve (AE)
	Material in Static Mixer Package (AH) and/or needle cured	Replace Static Mixer Package (AH) and/or needle
	Dispense speed unsuitable for Static Mixer Package (AH) and needle	<ol style="list-style-type: none"> 1. Replace the current Static Mixer Package (AH) and/or needle with a bigger gauge. 2. Slow down dispensing speed to decrease working pressure (continuous and stable dispensing pressure should be within a range of 150-400 psi).
	Pressure sensor error	Replace pressure sensor
Pressure imbalance	One side of MD2 Dispense Valve (AE) or fluid lines clogged	Clean the high pressure side of MD2 Dispense Valve (AE) or fluid lines
	Air or hole in material	Prime the system
	Low pressure side piston worn out	Replace the piston
"Home" error	Error not reset	Pull up E-stop button and press "reset"
	Pressure higher than set point	Go to the Advanced Screen of control box, select 'Dispense valve' to open MD2 Dispense Valve (AE) to reduce pressure
	"Home" button flashing and waiting	<ol style="list-style-type: none"> 1. Verify reload pressure value is correctly set. 2. Verify air supply. 3. Inspect low level sensor status. 4. Confirmed inlet ball valve is opened (if installed). 5. Verify cartridge or pail is not empty. 6. Verify supply pump is working.
	Servo motor alarm	<ol style="list-style-type: none"> 1. Inspect ball screw and slides are functional. 2. Verify motor and encoder cable are connected.

Problem	Cause	Solution
System does not dispense or dispenses in the incorrect amount/mode	Signal error between platform and PR-X control box	<ol style="list-style-type: none"> 1. Verify signal was correctly sent and received. 2. Verify signal cable is correctly connected.
	Wrong "Dispense mode"	Choose correct mode
	Wrong "Dispense type"	Choose correct type
	Wrong mode and/or type trigger method	Choose correct trigger method in "Setup" menu (job can be triggered by outside signal or manually)
Incorrect pressure value	Loose pressure sensor cable or adapters	Exchange cable, tighten adapters
	Pressure sensor error	Replace pressure sensor
	Pressure sensor signal incorrect	Calibrate pressure sensor

Repair

Prepare Machine for Piston/Cylinder Replacement Kit Installation

NOTE: Graco suggests using TSL™ only in repair procedures. All procedures should be performed by an appropriate professional.

1. Perform the step 1 to step 4 of **Pressure Relief Procedure** on page 50.
2. Turn off the air supply when the fluid pressure drops to ZERO.
3. Go to the Advanced Screen of the PR-X control box (J). Set the move speed at about 0.2 cc/s, then jog select “Piston move down” until the lower switch light is activated.




FIG. 45 Advanced Screen 1

NOTE: To open the Advanced mode, the operator must enter the password **1492**.

4. Turn off the system power.
5. Disconnect all cables and tubes from Junction Box Assembly (AA).
6. Open the top cover of the Junction Box (AA) and loosen the four fix screws in the cylinder housing (10202a). Next, take off the Junction Box Assembly (AA).

Disassemble Cylinder




FIG. 46 Disassemble Cylinder

1. Remove the MD2 Dispense Valve (AE).
2. Remove the six end cap screws (111).
3. Remove the cylinder end caps (106).
4. Remove the cylinder (108) and O-rings (109) from the cylinder housing (10202a).
5. Use the specific tools remove the piston nut (105).
6. Remove the piston (103) and piston plate (104) from the rod.
7. Remove the O-ring (10201e) from the rod.
8. Clean all parts that have been removed.

Install Cylinder

1. Install the new O-ring (10201e) to the rod with TSL oil.
2. Install the piston plate (104) and the new piston in the correct direction.
3. Install the piston nut (105) (Tighten the piston screw with correct torque).
4. Lubricate the new O-rings (109) and inside the cylinder (108) with TSL oil.
5. Insert the lubricated O-rings (109) into the grooves of the Cylinder housing (10202a) and cylinder end caps (106).
6. Carefully slide the end of the cylinder into the cylinder housing (10202a) in the correct direction. Ensure the cylinder doesn't damage the sides of the piston as the cylinder is inserted.
7. Install the cylinder end caps (106).
8. Secure cylinder in place with the six end cap screws (111). Diagonally tighten the screw by slowly and progressively increasing torque until the screws are securely housed.
9. Install the Junction Box Assembly (AA) and connect all cables or tubes.
10. Install the MD2 Dispense Valve (AE).
11. Turn on the air supply and power.

Prepare Machine for Operation

1. Pressurize Supply Pump Systems A and B (K and L) connected to the PR-X Inlet Valve (AL or AM). Perform **Prime the System** on page 48.
2. Perform the **Ratio Check Procedure** on page 49.
3. Install Static Mixer Package (AH).
4. Dispense several full stroke shots until the PR-X Machine (H) is free of air and there is no leakage at the nose piece after shutoff.

Parts

Overview

Parts Description	Page
1. PR-X System, Supply Pump Feed, Direct, 133646 and 133647	63
2. PR-X System, Supply Pump Feed, Remote, 133648 and 133649	64
3. PR-X System, Supply Cartridge Feed, Direct, 133650 and 133651	65
4. PR-X System, Supply Cartridge Feed, Remote, 133652 and 133653	66
5. PR-X Base Assembly, Supply Pump Feed	67
6. PR-X Base Assembly, Supply Cartridge Feed	68
6.1. Fixed Ratio Base Assembly	69
6.1.1. Junction Box Assembly and Fixed Ratio Base Frame Assembly	70
a) Junction Box Assembly	72
b) Fixed Ratio Base Frame Assembly	74
6.1.2. Power Transmission Assembly	76
a) Ball Screw Assembly	77
b) PR-X Drive	78
7. Supply Pump Assembly	79
7.1. Pump Slide Assembly, 25R430	80
8. Supply Cartridge Assembly, 25R425	82
8.1. Cartridge Sleeve Assembly, 25R426	84
8.2. Cylinder Assembly, 25R597	85
8.3. Inlet Valve, 25R427	86
8.4. Bottom Plate, 25R428	87

PR-X System, Supply Pump Feed, Direct, 133646 and 133647




FIG. 47: PR-X System, Supply Pump Feed, Direct

Ref.	Part	Description	Qty.
101	----	ASSEMBLY, PR-X base, ceramic, see page 67	1
	----	ASSEMBLY, PR-X base, SST, see page 67	1
102	----	ASSEMBLY, supply pump, see page 79	1
103	133656	PR-X CONTROL BOX	1
104	255180	VALVE, MD2	1
105	LC0058	PACKAGE, static mixer	1
106	18C123	FITTING, UN13/16-16, UN9/16-18	2
107	18C122	FITTING, UN13/16-16, female	2
108	18C121	FITTING, UN13/16-16, male	2

PR-X System, Supply Pump Feed, Remote, 133648 and 133649




FIG. 48: PR-X System, Supply Pump Feed, Remote

Ref.	Part	Description	Qty.
201	----	ASSEMBLY, PR-X base, ceramic, see page 67	1
	----	ASSEMBLY, PR-X base, SST, see page 67	1
202	----	ASSEMBLY, supply pump, see page 79	1
203	133656	PR-X CONTROL BOX	1
204	255180	VALVE, MD2	1
205	LC0058	PACKAGE, static mixer	1
206	16C522	PACKAGE, hose with JIC fitting (model 133648 only)	2
	18C198	PACKAGE, hose with ORFS fitting (model 133649 only)	2
207	18C124	FITTING, UN13/16-16, JIC9/16-18 (model 133648 only)	2
	18C226	FITTING, UN13/16-16 (model 133649 only)	2
208	18C727	FITTING, UN9/16-18, JIC9/16-18, 90° (model 133648 only)	2
	18C220	FITTING, UN9/16-18 (model 133649 only)	2

PR-X System, Supply Cartridge Feed, Direct, 133650 and 133651




FIG. 49: PR-X Machine, Supply Cartridge Feed, Direct

Ref.	Part	Description	Qty.
301	----	ASSEMBLY, PR-X base, ceramic, see page 68	1
	----	ASSEMBLY, PR-X base, SST, see page 68	1
302	25R425	ASSEMBLY, supply cartridge, see page 82	1
303	133656	PR-X CONTROL BOX	1
304	255180	VALVE, MD2	1
305	LC0058	PACKAGE, static mixer	1
306	18C123	FITTING, UN13/16-16, UN9/16-18	2
307	18C122	FITTING, UN13/16-16, female	2
308	18C121	FITTING, UN13/16-16, male	2

PR-X System, Supply Cartridge Feed, Remote, 133652 and 133653





FIG. 50: PR-X Machine, Supply Cartridge Feed, Remote

Ref.	Part	Description	Qty.
401	----	ASSEMBLY, PR-X base, ceramic, see page 68	1
	----	ASSEMBLY, PR-X base, SST, see page 68	1
402	25R425	ASSEMBLY, supply cartridge, see page 82	1
403	133656	PR-X CONTROL BOX	1
404	255180	VALVE, MD2	1
405	LC0058	PACKAGE, static mixer	1
406	16C522	PACKAGE, hose with JIC fitting (model 133652 only)	2
	18C198	PACKAGE, hose with ORFS fitting (model 133653 only)	2
407	18C124	FITTING, UN13/16-16, JIC9/16-18 (model 133652 only)	2
	18C226	FITTING, UN13/16-16 (model 133653 only)	2
408	18C727	FITTING, UN9/16-18, JIC9/16-18, 90°(model 133652 only)	2
	18C220	FITTING, UN9/16-18 (model 133653 only)	2

PR-X Base Assembly, Supply Pump Feed



▲ Torque to 3.0-3.7 ft-lb (4-5 N•m).


▲ Apply sealant, Anaerobic, blue.

FIG. 51: PR-X Base Assembly, Supply Pump Feed

Ref.	Part	Description	Qty.
501	----	ASSEMBLY, fixed ratio base, see page 69	1
502	----	ASSEMBLY, supply, pump, see page 79	1
503	----	BRANDING LABEL	1
504▲	189930	LABEL, caution, electric shock	2
505▲	15H108	LABEL, caution, pinch	2
506	----	SERIES LABEL	1
507	----	PLUG, UN13/16-16	2

▲ Replacement safety labels, tags, and cards are available at no cost.

PR-X Base Assembly, Supply Cartridge Feed



▲ Torque to 3.0-3.7 ft-lb (4-5 N•m).


▲ Apply sealant, Anaerobic, blue.

FIG. 52: PR-X Base Assembly, Supply Cartridge Feed

Ref.	Part	Description	Qty.
601	----	ASSEMBLY, fixed ratio base, see page 69	1
602	25R425	ASSEMBLY, supply, cartridge, see page 82	1
603	----	BRANDING LABEL	1
604▲	189930	LABEL, caution, electric shock	2
605▲	15H108	LABEL, caution, pinch	2
606	----	SERIES LABEL	1
607	----	PLUG, UN13/16-16	2

▲ Replacement safety labels, tags, and cards are available at no cost.

Fixed Ratio Base Assembly




- Torque to 3.7-4.4 ft-lb (5-6 N•m).
- Torque to 11.1 ft-lb (15 N•m).
- Apply sealant, Anaerobic, blue.

FIG. 53: Fixed Ratio Base Assembly

Ref.	Part	Description	Qty.
6101	----	ASSEMBLY, junction box and fixed ratio base frame, see page 70	1
6102	----	ASSEMBLY, power transmission, see page 76	1
6103*	----	SCREW, M12 x 1.75-20, SST	1
6104*	----	WASHER, flat, M12	1
6105	18B949	SCREW, shoulder, DIA 8,M6	8
6106*	----	WASHER, spring, DIA 12	1

* Parts included in Kit 25R588 (purchase separately).

Junction Box Assembly and Fixed Ratio Base Frame Assembly



- | | |
|---|--|
| ⚠ 1 Torque to 0.74-1.29 ft-lb (1-1.75 N•m). | ⚠ 5 Apply sealant, Anaerobic, blue. |
| ⚠ 2 Torque to 3.69-4.79 ft-lb (5-6.5 N•m). | ⚠ 6 Metering tube direction should be appointing as shown. |
| ⚠ 3 Torque to 5.2-5.9 ft-lb (7-8 N•m). | ⚠ 7 Must use TSL oil to seal. |
| ⚠ 4 Torque to 7.4-8.9 ft-lb (10-12 N•m). | |

FIG. 54: Junction Box and Fixed Ratio Base Frame Assembly


Junction Box Assembly and Fixed Ratio Base Frame Assembly

Ref.	Part	Description	Qty.
6201	133890	ASSEMBLY, junction box, see page 72	1
6202	----	ASSEMBLY, fixed ratio base frame, see page 74	1
6203*†	18B482	PISTON	2
6204*†	18B952	PLATE, support back, tube	2
6205*†	18B953	NUT, cylinder piston	2
6206	18B954	CYLINDER END CAPS	1
6207	----	COVER, control	1
6208*	LCC960	TUBE, pump, SST Metering Tube assy, PR70, SIC	2
†	LCG960	TUBE, pump, Ceramic Metering Tube assy, PR70, SIC	2
6209*†	120874	O-RING	4
6210	18C018	TRANSMITTER, pressure	2
6211	18B956	SCREW, M8 x 1.25-50, SST, Partially	6
6212	----	SCREW, M3 x 0.5-4, pan head, SST	4
6213	----	SCREW, M5 x 0.8-6, button head, hex	2
6214	----	SLEEVE, screw	4

* *Parts included in Kit CU2960 (purchase separately).*

† *Parts included in Kit CU3960 (purchase separately).*

Junction Box Assembly




- ⚠️ 1 Torque to 0.74-1.29 ft-lb (1-1.75 N•m).
- ⚠️ 2 Torque to 1.70-2.58 ft-lb (2.3-3.5 N•m).
- ⚠️ 3 Fitting top surface to mounting plate 12±0.5 mm.
- ⚠️ 4 Rubber gasket should be assembled on the outer surface.
- ⚠️ 5 Torque to 0.52-0.92 ft-lb (0.7-1.25 N•m).
- ⚠️ 6 Apply sealant, Anaerobic, blue.
- ⚠️ 7 Apply sealant, pipe, SST.

FIG. 55: Junction Box Assembly

Junction Box Assembly

Ref.	Part	Description	Qty.
6301	----	ASSEMBLY, solenoid valve	1
6301a	----	BASE, manifold	1
6301b	----	FITTING, DIA 6, PT1/8	1
6301c	----	PLUG, socket, PT1/8	3
6301d	----	VAVLE, solenoid	5
6301e	----	FITTING, M5 x 0.8, Rc1/8	2
6301f	----	SCREW, M4 x 0.7-20, socket	4
6301g	----	FITTING, DIA 6, M5 x 0.8	8
6301h	----	MUFFLER, M5	2
6301i	----	FITTING, DIA 4, M5 x 0.8	2
6302	----	PLATE, top	1
6303	----	SENSOR, close	3
6304	----	BRACKET, support	1
6305	----	FITTING, DIA 6, M14 x 1	8
6306	----	TERMINAL, integrated, connector	1
6307	----	FITTING, PIN 4, M6	6
6308	----	FITTING, DIA 4, M12 x 1	2
6309	----	FITTING, PIN 3, M12	2
6310	----	SCREW, M6 x 1-10, button head, hex	2
6311	----	FRAME, control	1
6312	----	PLUG, DIA 6	4
6313	----	SCREW, M3 x 0.5-4, Phillips	2
6314	----	SCREW, M4 x 0.7-5, Phillips, w washer	6
6315	----	SCREW, M3 x 0.5-4, pan head, SST	2
6316	----	FITTING, DIA 6, NPT 1/4	1
6317	----	FITTING, DIA 6, NPT 1/4 male	1
6318	----	FITTING, DIA 1/4 in, NPT 1/4 male	1

Fixed Ratio Base Frame Assembly



- △1 Torque to 1.70-2.58 ft-lb (2.3-3.5 N•m).
- △2 Torque to 2.95-3.69 ft-lb (4-5 N•m).
- △3 Torque to 3.69-4.42 ft-lb (5-6 N•m).
- △4 Torque to 7.4-8.9 ft-lb (10-12 N•m).
- △5 Apply sealant, Anaerobic, blue.
- △6 Must use TSL oil to seal.

FIG. 56 Fixed Ratio Base Frame Assembly

Fixed Ratio Base Frame Assembly


Ref.	Part	Description	Qty.
6401	----	ASSEMBLY, piston rod	1
6401a*	----	ROD, piston	2
6401b❖	----	PLATE, bearing limit	2
6401c†	----	BUSH	2
6401d❖	----	ROD, guide	2
6401e*	18B940	O-RING	2
6401f	18B941	BLOCK, push	1
6401g❖	----	BEARING	2
6401h†	----	FITTING, w nut	2
6401i*	----	NUT, M8	4
6401j	----	SCREW, SET, M6 x 1.0-5, flat	2
6401k❖	----	SCREW, M3 x 0.5-8, socket	4
6402	----	ASSEMBLY, block, piston rod	1
6402a	18D946	SEAT, tube	1
6402b	18B947	PLATE, side	2
6402c	18B948	SLEEVE, guide	2
6402d	18B949	SCREW, shoulder, DIA 8, M6	8
6402e	----	SCREW, M4 x 0.7-8, sockethead, SST	2
6402f	----	PLATE, PR-X	1
6403	----	SCREW, SET, M4 x 0.7-8	2


* *Parts included in Kit 25R589 (purchase separately).*

† *Parts included in Kit 25R590 (purchase separately).*

❖ *Parts included in Kit 25R591 (purchase separately).*

Power Transmission Assembly



 Torque to 2.95-3.69 ft-lb (4-5 N•m).



 Apply sealant, Anaerobic, blue.

FIG. 57: Power Transmission Assembly

Ref.	Part	Description	Qty.
6501	----	ASSEMBLY, ball screw, see page 77	1
6502	----	PR-X Drive, see page 78	1
6503	18B956	SCREW, M8 x 1.25-50, socket head, Steel	4
6504	----	SCREW, SET, M5 x 0.8-8	2

Ball Screw Assembly



Torque to 1.70-2.58 ft-lb (2.3-3.5 N•m).


Open direction face to motor side.

FIG. 58: Ball Screw Assembly

Ref.	Part	Description	Qty.
6601	18D959	SEAT, sleeve	1
6602	18B962	WASHER	1
6603	18B963	COUPLER, lead screw	1
6604	25R237	ASSEMBLY, ball screw w nut	1
6605	18B968	RING, bearing retaining	1
6606	18B950	SCREW, SET, M4 x 0.7-8	2
6607	18B969	BEARING, thrust	1
6608	18B970	SCREW, M5 x 0.8-16, socket head, SST	4
6609	18B971	BEARING, ball, angular contact	2

Parts

PR-X Drive




- ▲1 Torque to 3.69-4.79 ft-lb (5-6.5 N•m).
- ▲2 Torque to 5.53-5.90 ft-lb (7.5-8 N•m).
- ▲3 Apply sealant, Anaerobic, blue.
- ▲4 Installation direction as show.

FIG. 59: PR-X Drive

Ref.	Part	Description	Qty.
6701	18D972	SEAT, reduction	1
6702	133663	MOTOR, PR-X drive, servo, 4 frame	1
6703	18B973	GEAR REDUCER, PR-X drive, 20:1	1
6704	18B974	SCREW, M4 x 0.7-16, socket head, SST	4
6705	18B970	SCREW, M5 x 0.8-16, socket head, SST	4

Supply Pump Assembly




- 1 Torque to 3.0-3.7 ft-lb (4-5 N•m).
- 2 Apply sealant, Anaerobic, blue.
- 3 Adjust the fitting thread direction as shown.
- 4 Apply sealant, pipe, SST.

Fig. 60: Supply Pump Kit

Ref.	Part	Description	Qty.
701	25R430	ASSEMBLY, slide, pump, see page 80	2
702	243666	VALVE, 1K Ultra-Lite	2
703*	----	FITTING, UN13/16-16, male, female	2
704	18C103	FITTING, DIA 6, PT1/8, PV	4
705	----	SCREW, M6 x 1-6, button head	4
706*	----	FITTING, UN13/16-16, NPT1/4	2
707	18B951	SCREW, shoulder, DIA 8, M6	2
708	----	SCREW, M5 x 0.8-10, socket head, SST	6
709	18C106	PLATE, bottom, base, pump	1

* Parts included in Kit 25R592 (purchase separately).

Pump Slide Assembly, 25R430




- △1 Torque to 0.74-1.29 ft-lb (1-1.75 N•m).
- △2 Torque to 1.70-2.85 ft-lb (2.3-3.5 N•m).
- △3 Torque to 3.0-3.7 ft-lb (4-5 N•m).
- △4 Apply sealant, Anaerobic, blue.

FIG. 61: Pump Slide Assembly

Ref.	Part	Description	Qty.
7101	18C094	PLATE, mounting, valve	1
7102	18C095	PLATE, mounting, slide	1
7103	18C096	PLATE, mounting, base	1
7104	18C097	RAIL, pump	1
7105	----	NUT, M3 x 0.5, THK2.4, SST	2
7106	----	SCREW, M4 x 0.7-10, button head, SST	4
7107	----	SCREW, M5 x 0.8-8, button head, SST	2
7108	----	SCREW, M3 x 0.5-10, socket head, SST	2
7109	----	SCREW, M3 x 0.5-8, socket	2

Supply Cartridge Assembly, 25R425



- ① Torque to 0.74-1.29 ft-lb (1-1.75 N•m).
- ② Torque to 1.70-2.58 ft-lb (2.3-3.5 N•m).
- ③ Torque to 3.0-3.7 ft-lb (4-5 N•m).
- ④ Right spring bracket is at mirror side.
- ⑤ Adjust the position to be align with fixed ratio base assembly.
- ⑥ Keep bottom hole as down side.
- ⑦ Connect the spring to the spring bracket after assembly.
- ⑧ Apply sealant, Anaerobic, blue.
- ⑨ Keep air outlet as shown.

FIG. 62: Supply Cartridge Assembly

Supply Cartridge Assembly

Ref.	Part	Description	Qty.
801	25R426	ASSEMBLY, cartridge sleeve, see page 84	2
802	25R597	ASSEMBLY, Cylinder, see page 85	2
803	25R427	UNIT, inlet valve, see page 86	2
804	25R428	UNIT, bottom plate, see page 87	1
805*	----	PLATE, mounting sliding rail left	1
806*†	----	PLATE, mounting sliding block front	2
807*†	----	PLATE, mounting sliding block top	2
808*	----	BRACKET, spring, left	1
809†	----	PLATE, mounting sliding rail right	1
810†	----	BRACKET, spring, right	1
811*†	----	RING, check	4
812*†	----	BRACKET, spring, top	2
813*†	----	RAIL, sliding block	2
814*†	----	SPRING	2
815	18C087	FITTING, UN13/16-16, G3/8	2
816	18C088	FITTING, UN13/16-16, G3/4	2
817	18C102	FITTING, UN13/16-16, male, female	2
818*†	----	NUT, M3 x 0.5, THK2.4, SST	2
819*†	----	SCREW, M3 x 0.5-8, socket	24
820	----	SCREW, M4 x 0.7-16, socket head, SST	8
821*†	----	SCREW, M3 x 0.5-8, pan, Philips	4
822*†	----	SCREW, M3 x 0.5-14, socket	2
823*†	----	SCREW, M3 x 0.5-18, socket	2
824	18C093	FITTING, UN13/16-16, G3/8	2
825*†	----	SCREW, M4 x 0.7-8, socket head, SST	16

* Parts included in Kit 25R593 (purchase separately).

† Parts included in Kit 25R594 (purchase separately).

Cartridge Sleeve Assembly, 25R426





FIG. 63: Cartridge Sleeve Assembly

Ref.	Part	Description	Qty.
8101	18C054	SEAT, sleeve bottom	1
8102	18C055	SLEEVE, middle, 200	1
8103	18C056	SLEEVE, top	1
8104	18C057	NUT, sleeve	1
8105	18C108	O-RING	1

Cylinder Assembly, 25R597




- △1 Apply sealant, Anaerobic, blue.
- △2 Torque to 3.0-3.7 ft-lb (4-5 N•m).
- △3 Keep air outlet as shown.

FIG. 64: Cylinder Assembly

Ref.	Part	Description	Qty.
8201	18C075	PLATE, mounting cylinder	1
8202	18C084	CYLINDER	1
8203	18C089	FITTING, DIA 6, PT1/4	2
8204	----	SCREW, M8 x 1.25-16, button head, socket, SST	4
8205	18C058	PISTON, plug	1
8206	18C059	O-RING	2

Inlet Valve, 25R427




- △1 Torque to 1.70-2.58 ft-lb (2.3-3.5 N•m).
- △2 Torque to 2.21-3.32 ft-lb (3.0-4.5 N•m).
- △3 Torque to 3.0-3.7 ft-lb (4-5 N•m).
- △4 Torque to 7.4-8.9 ft-lb (10-12 N•m).
- △5 Apply sealant, Anaerobic, blue.
- △6 Apply sealant, pipe, SST.

FIG. 65: Inlet Valve

Ref.	Part	Description	Qty.	Ref.	Part	Description	Qty.
8301	18C060	PLATE, bottom	1	8307	----	SCREW, M4 x 0.7-16, socket head, SST	4
8302	18C061	BOSS, support	4	8308	18C066	CYLINDER, double vane rotary	1
8303	18C062	PLATE, mounting cylinder	1	8309	----	SCREW, M8 x 1.25-16, SST	2
8304	18C063	COUPLING	1	8310	18B911	FITTING, DIA 6, PT1/8	2
8305	18C064	VALVE, high pressure	1	8311	----	SCREW, SET, M4 x 0.7-3	2
8306	----	SCREW, M4 x 0.7-8, socket head, SST	4				

Bottom Plate, 25R428



1 Torque to 1.70-2.85 ft-lb (2.3-3.5 N•m).

2 Torque to 3.0-3.7 ft-lb (4-5 N•m).

3 Apply sealant, Anaerobic, blue.

FIG. 66: Bottom Plate

Ref.	Part	Description	Qty.
8401	----	BLOCK, support, top	2
8402	----	BLOCK, support, bottom	2
8403	----	PLATE, bottom	1
8404	----	NUT, M4 x 0.7, SST	2
8405	----	SCREW, M4 x 0.7-20, socket	2
8406	----	SCREW, M6 x 1-16, socket, SST	4
8407	----	SCREW, M5 x 0.8-25, socket, SST	2
8408	----	SCREW, M4 x 0.7-10, button head, SST	6
8409	----	SCREW, SHSC, M6 x 1.0-30, SST	2

Kits and Accessories

Cable

Part	Description
18C295	CABLE, 3 m, remote I/O connection
133839	CABLE, 5 m, servo motor
133838	CABLE, 5 m, servo encoder
18C298	CABLE, 5 m, start signal
18C299	CABLE, 5 m, pressure sensor, PR-X
18C300	CABLE, 5 m, junction box

Dimensions

PR-X Machine, Supply Pump Feed




FIG. 67: PR-X Machine Dimensions, Supply Pump Feed

PR-X Machine, Cartridge Feed




FIG. 68: PR-X Machine Dimensions, Cartridge Feed

PR-X Control Box






FIG. 69: Control Box Dimensions


Schematic Diagram Junction Box




Power Supply 24 V DC




Servo Drive Power




Output Valve 1-4




Output Valve 5-7




Digital Input_1




Digital Input_3




Pressure Sensor




Digital Output




Digital Output_1




Interface C-Box - J-Box




Control Panel





PLC





CPU





Digital Input 4K1 / 4K5




Digital Input 5K1 / 5K5




Digital Output 6K1 / 6K5



Digital Output 7K1 / 7K5




Q2.0	DQ0	+001/13.1 IO CUST OUT READY
Q2.1	DQ1	+001/13.2 IO CUST OUT STANDBY
Q2.2	DQ2	+001/13.3 IO CUST OUT INRELOAD
Q2.3	DQ3	+001/13.4 IO CUST OUT ALARM
Q2.4	DQ4	+001/13.5 IO CUST OUT ERR_BIT0
Q2.5	DQ5	+001/13.6 IO CUST OUT ERR_BIT1
Q2.6	DQ6	+001/13.7 IO CUST OUT ERR_BIT2
Q2.7	DQ7	+001/13.8 IO CUST OUT ERR_BIT3
1+	24VDC	/2.7
M	0VDC	/2.7



Q3.0	DQ0	+001/14.1 IO CUST OUT ERR_BIT4
Q3.1	DQ1	+001/14.2 IO CUST OUT INDISPENSE
Q3.2	DQ2	+001/14.3 IO CUST IN JOB
Q3.3	DQ3	+001/14.4 IO CUST RELOAD REQUEST
Q3.4	DQ4	+001/4.6 LW emergency stop button activated
Q3.5	DQ5	/10.6 SPARE
Q3.6	DQ6	/10.7 SPARE
Q3.7	DQ7	/10.8 SPARE
1+	24VDC	/2.7
M	0VDC	/2.8

Analog Input



Digital Input Spare

	1,3
DI2	
+400-K41	
/42	
10.2	
SPARE	

Digital Output Spare

SPARE
Q1.0
/6.6
+400-6K5
DQ0
1

SPARE
Q1.1
/6.6
+400-6K5
DQ1
2

SPARE
Q1.2
/6.6
+400-6K5
DQ2
3

SPARE
Q1.3
/6.6
+400-6K5
DQ3
4

SPARE
Q1.4
/6.6
+400-6K5
DQ4
5

SPARE
Q1.5
/6.6
+400-6K5
DQ5
6

SPARE
Q1.6
/6.6
+400-6K5
DQ6
7

SPARE
Q1.7
/6.6
+400-6K5
DQ7
8


SPARE
Q0.7
/6.2
+400-6K1
DQ7
8

SPARE
Q3.5
/7.6
+400-7K5
DQ5
6


SPARE
Q3.6
/7.6
+400-7K5
DQ6
7

SPARE
Q3.7
/7.6
+400-7K5
DQ7
8


Analog Input Spare




Interface C-Box - J-Box





Valves J-Box



Sensor J-Box



Pressure Sensor



Summarized Parts List

Quantity	Order number	Type number	Designation	Manufacturer	Pos.
1	65319	65319	Adapter, D-Sub, 37-polig, Buchse mit Platine	Delock	1
1	216537	M22-12	Aufbaugehäuse, 2-Taster	Eaton	2
1	216876	M22-IV	Emergency-stop pushbutton, non-illuminated	Eaton	3
2	216382	M22-KC01	Contact element, 1 N/C, base fixing, 6, contact, screw connection	Eaton	4
3	216380	M22-KC10	Contact element, 1N/O, base fixing, 6, contact, screw connection	Eaton	5
1	216931	M22-DL-B	Illuminated pushbutton actuator, flush, blue, momentary	Eaton	6
1	218058	M22-LEDC-B	Light element, LED, blue, base fixing, 12-30VAC/DC, screw connection	Eaton	7
1	MHDM3755	MHDM3755	D-Sub Buchsenleiste, 180°, 37-polig, numerisch, Lötkontakte	MH Connectors	8
1	MHHDS26-F-T-B-S	MHHDS26-F-T-B-S	D-Sub Buchsenleiste, 180°, 26-polig, numerisch, Lötkontakte	MH Connectors	9
3	EZE-X4MD1-M1	EZE-X4MD1-M1	Inductive sensors, Compact - cylindrical, EZE	OMRON ELECTRONICS GmbH	10
1	750103	PNQZ S3 24VDC2 1/0	Device for monitoring of safety-related circuits	Pipe GmbH & Co. KG	11
7	2966471	PLC-RSC- 24DC/21	Relay Module	Phoenix Contact	12
1	1338000	AX.1338000	Compact enclosure AX	Rittal	13
2	3237200	SK.3237200	Outlet filter	Rittal	14
1	3237124	SK.3237124	TopTherm fan-and-filter units	Rittal	15
2	5S76106-7	5S76106-7	CIRCUIT BREAKER 6KA, 1POL C6	Siemens AG	16
1	5S76104-7	5S76104-7	CIRCUIT BREAKER 6KA, 1POL C4	Siemens AG	17
1	5S73010	5S73010	AUXILIARY SWITCH 1S10E	Siemens AG	18
1	3RH2131-1BB40	3RH2131-1BB40	CONT.RELAY 3NO+1NC/DC24V	Siemens AG	19
1	3UD2103-0TK53	3UD2103-0TK53	EM, STOP SWITCH 25A/690V 400V/9,5KW	Siemens AG	20
1	3UD9286-1A	SIE.3UD9286-1A	extra rating plate, German/English, 47 mm x 17 mm	Siemens AG	21
1	6SL3210-5FB10-4UF1	6SL3210-5FB10-4UF1	SINAMICS V90, PROFINET, 1/3 AC 200V 0.4kW	Siemens AG	22
1	6EP1333-3BA10	6EP1333-3BA10	STOP PSU200M	Siemens AG	23
1	6AV2123-2DB03-0AX0	6AV2123-2DB03-0AX0	SIMATIC HMI KTP400 BASIC	Siemens AG	24
1	6ES7510-1D01-0A80	6ES7510-1D01-0A80	CPU 1510SP-1, PU, 100KB Prog./750KB Data	Siemens AG	25
1	6ES7954-8LC3-0AA0	6ES7954-8LC3-0AA0	SIMATIC S7 memory card, 4 MB	Siemens AG	26
1	6ES7193-6AR00-0AA0	6ES7193-6AR00-0AA0	BA 2XB45	Siemens AG	27
4	6ES7131-6BR01-0BA0	6ES7131-6BR01-0BA0	ET 200SP, DI 8x 24V DC ST, PU 1	Siemens AG	28

Summarized parts list

FD2_006-Graeco

Summarized Parts List_1

Summarized parts list

Quantity	Order number	Type number	Designation	Manufacturer	Pos.
5	6ES7193-6BP00-0DA0	6ES7193-6BP00-0DA0	BAGELUNIT TYPE A0, BU15-P16+A0+2D	Siemens AG	29
4	6ES7193-6BP00-0BA0	6ES7193-6BP00-0BA0	BAGELUNIT TYPE A0, BU15-P16+A0+2B	Siemens AG	30
4	6ES7132-6BF01-0BA0	6ES7132-6BF01-0BA0	ET 200SP, DQ 8x 24V DC/0,5A ST, PU 1	Siemens AG	31
1	6ES7134-6FF00-0AA1	6ES7134-6FF00-0AA1	ET 200SP, AI 8XU BASIC	Siemens AG	32
3	7V0500M5FG	7V0500M5FG		Stralbeil Automation GmbH	33
5	7V0510M5B050	7V0510M5B050		Stralbeil Automation GmbH	34
1	SF1612/S3-1	SF1612/S3-1	Buchsenstecker, 3-polig	WEIPU Connector	35
6	SF1612/S4-1	SF1612/S4-1	Buchsenstecker, 4-polig	WEIPU Connector	36
2	SF1612/S5-1	SF1612/S5-1	Buchsenstecker, 5-polig	WEIPU Connector	37
1	SF1612/S10-1	SF1612/S10-1	Buchsenstecker, 10-polig	WEIPU Connector	38
6	SF612B/S3	SF612B/S3	Buchsenstecker, 3-polig	WEIPU Connector	39

FD2_006-Graco


Cable diagram =C_Box+001-W201

Cable diagram

F09_001

Cable name =C_Box+001-W201		Cable type			No. of conductors		Cross-section		Cable length		Function text	
Function text	X-Ref	Target designation from	Connection point	Conductor	Target designation to	Connection point	X-Ref	5	Function text	Interface C-Box <-> J-Box		
	=]_Box+002/1.1		15	BK		24	=]_Box+002/1.7					
	=]_Box+002/1.1		16	BK/WH		26	=]_Box+002/1.7					
	=]_Box+002/1.7		1	BN		1	=]_Box+002/1.1					
	=]_Box+002/1.1		2	BN/BK		3	=]_Box+002/1.7					
	=]_Box+002/1.7		8	BU		17	=]_Box+002/1.1					
	=]_Box+002/1.7		12	BU/BK		18	=]_Box+002/1.1					
	=]_Box+002/1.1		13	GN		20	=]_Box+002/1.7					
	=]_Box+002/1.1		14	GN/BK		22	=]_Box+002/1.7					
	=]_Box+002/1.1		11	GV		16	=]_Box+002/1.7					
	=]_Box+002/1.1		12	GV/BK		18	=]_Box+002/1.7					
	=]_Box+002/1.1		19	LBU		36	=]_Box+002/1.7					
	=]_Box+002/1.1		20	LBU/BK		34	=]_Box+002/1.7					
	=]_Box+002/1.1		7	OG		13	=]_Box+002/1.7					
	=]_Box+002/1.7		2	OG/BK		8	=]_Box+002/1.1					
	=]_Box+002/1.1		25	PK		35	=]_Box+002/1.7					
	=]_Box+002/1.7		17	PK/BK		26	=]_Box+002/1.1					
	=]_Box+002/1.7		19	PK/BK		26	=]_Box+002/1.1					
	=]_Box+002/1.1		3	RD		5	=]_Box+002/1.7					
	=]_Box+002/1.1		4	RD/BK		7	=]_Box+002/1.7					
	=]_Box+002/1.1		21	TK		32	=]_Box+002/1.7					
	=]_Box+002/1.1		22	TK/BK		30	=]_Box+002/1.7					
	=]_Box+002/1.1		23	VT		28	=]_Box+002/1.7					
	=]_Box+002/1.1		24	VT/BK		27	=]_Box+002/1.7					
	=]_Box+002/1.1		5	WH		9	=]_Box+002/1.7					
	=]_Box+002/1.1		6	WH/BK		11	=]_Box+002/1.7					
	=]_Box+002/1.7		4	YE		9	=]_Box+002/1.1					
	=]_Box+002/1.1		10	YE/BK		15	=]_Box+002/1.7					

I/O signals



No.	Signal Style	I/O Pin No.	Mark	Color	Signal Name
1	Input	15	X32	Black	JOB_START
2		10	X20	Black Yellow	DISPENSE*
3		14	X22	Green Black	RELOAD
4		12	X21	Grey Black	PURGE
5		11	X30	Grey	E_STOP
6		13	X31	Green	REMOTE_RST
7		30	X26	Orange Blue	SYS_RELIEF
8		32	X27	Green Blue	SUPPLY_STOP
9		28	X25	Red Blue	MODE_SELECT
10		16	X23	Black White	STYLE BIT0
11		17	X33	Blue	STYLE BIT1
12		26	X24	Pink Black	STYLE BIT2
13		25	X34	Pink	STYLE BIT3
14		18	P24	Blue White	Input Common
15	Analog Input	33	V4+	Purple White	RATE_CMD+
16		34	V4-	Purple Blue	RATE_CMD-
17	Output	1	31	Brown	READY
18		2	32	Brown Black	STANDBY
19		3	33	Red	INRELOAD
20		4	34	Red Black	ALARM
21		5	35	White	ERR_BIT0
22		6	36	Brown White	ERR_BIT1
23		7	37	Orange	ERR_BIT2
24		8	38	Orange Black	ERR_BIT3
25		9	30	Yellow	Output Common
26		19	39	Light Blue	ERR_BIT4
27		20	40	Light Blue Black	INDISPENSE
28		21	41	Light Green	IN_JOB
29		22	42	Light Green Black	RELOAD_REQUEST

* The Start Signal Connection (BJ) is only connected to the "Start" signal, and its logic function is the same as the "Dispense" signal of the Remote I/O Connection (BC).

Profinet Map

Controller input from PLC output


Name	Units	In Byte	Description	
GATE_IN_CMD_BITS	0	JOB_START	1	Used to start job
	1	DISPENSE		Used to dispense in bead mode or shot mode
	2	RELOAD		Used to reload material
	3	PURGE		Used to purge
	4	REMOTE_RESET		Used to reset error
	5	MODE_SELECT		Used to set control mode in automatic 0 means shot mode 1 means bead mode
	6	SYS_RELIEF		Used to open dispense valve and relief pressure in metering system
	7	SUPPLY_STOP		Used to stop cartridge material supply
GATE_IN_NOTUSED		2	Not Used	
GATE_IN_STYLE_NO		3-4	0-15, used to select style	
GATE_IN_RATE_CMD		5-6	0-5000, used to control the dispense flowrate	

Controller output to PLC input


Name	Units	In Byte	Description	
GATE_OUT_STATUS_0	0	READY	1	
	1	INDISPENSE		
	2	COMPLETED		
	3	INRELOAD		
	4	PURGE_REQUEST		
	5	RELOAD_REQUEST		
	6	ALARM		
	7	STANDBY		
GATE_OUT_STATUS_1	0	INJOB	2	
	1	INPURGE		
GATE_OUT_ERR_CODE		3-4		
GATE_OUT_DISP_VOL		5-6	Integer, should multiply by 0.1, unit is cc	
GATE_OUT_JOB_VOL		7-8	Integer, should multiply by 0.1, unit is cc	
GATE_OUT_DISP_RATE		9-10	Integer, should multiply by 0.1, unit is cc	
GATE_OUT_PRESS_A		11-12	Integer, unit is psi	
GATE_OUT_PRESS_B		13-14	Integer, unit is psi	
GATE_OUT_MTR_TRQ		15-16	Integer, should multiply by 0.001, unit is NM	
GATE_OUT_DISP_RATIO		17-18	Integer, should multiply by 0.01	

Timing Chart

Reload after each job



Reload after multi job



Technical Specifications

PR-X System		
	US	Metric
Maximum Inlet Fluid Pressure	1200 psi	8.3 MPa, 83 bar
Maximum Working Fluid Pressure	1200 psi	8.3 MPa, 83 bar
Maximum Air Pressure	100 psi	0.7 MPa, 7 bar
Electrical Power	200 - 240 VAC, 50/60 Hz, 16 A	
Viscosity Range	20 - 1,000,000 cps	
Wetted Parts	303/304 Stainless Steel, Hard Chrome, Ceramic, UHMWPE, NBR, Carbon Steel, PTFE	
Shot Size Range	0.03 - 50 cc	
Shot Size Repeatability	1 %	
Flowrate	0.01 - 24.9 cc/s (Depend on material viscosity)	
Material Ratio	1:1 ⁽¹⁾	
Inlet / Outlet Sizes		
Air Inlet size	1/4 in.	6 mm
Fluid Inlet size	1/4 in. npt (f)	
Fluid Outlet size	7/8-9 bell outlet	
Weight		
Supply Pump Feed	35 lb	16 kg
Cartridge Feed	70 lb	32 kg
Maximum Operating Temperature		
UHMWPE Pistons	120 °F	50 °C
PEEK Bearings	300 °F	150 °C
Notes		
All trademarks or registered trademarks are the property of their respective owners.		

⁽¹⁾ All PR-X systems are 1:1 fixed ratio systems. If you want to order other ratio systems (1:1 - 2.4:1), please contact Graco sales representative for a custom solution.

California Proposition 65

CALIFORNIA RESIDENTS

 **WARNING:** Cancer and reproductive harm – www.P65warnings.ca.gov.

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

Sealant and Adhesive Dispensing Equipment

For the latest information about Graco products, visit www.graco.com.

For patent information, see www.graco.com/patents.

TO PLACE AN ORDER, contact your Graco distributor, go to www.graco.com, or call to identify the nearest distributor.

If calling from the USA: 1-800-746-1334

If calling from Asia Pacific: 00-86-512-6260-5711 or 00-86-21-2310-6198

If calling from Europe: 00-32-89-770-862

All written and visual data contained in this document reflects the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice.

Original instructions. This manual contains English. MM 333589A

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA
Copyright 2021, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com
Revision C, May 2022