

Active Surge Suppressor


‘Set and Forget’ Pulsation Minimization

Minimize pulsation on factory paint circulation lines with Graco’s active surge suppressor. Once you set it up, you can forget about manual adjustments.

- Active air pressure compensation makes periodic air pressure checks unnecessary.
- Automatic self-adjustment removes the need to manually adjust air pressure inside the surge suppressor when target fluid pressure changes.



17W739



- **Shop air compatibility:** Suppressor connects to compressed air lines already installed in most plants.
- **Good flush-ability:** Fluid section has an optimized flow path that flushes cleanly and thoroughly in between colors.
- **Improved failure mode:** Check valve prevents paint from leaking out if a diaphragm ruptures.

- Save space with easy installation.
- Mount directly onto pump, wall or floor.
- Install in down or up position.



Ordering Information

Part No.	Inlet/ Outlet	Maximum Charge Air Pressure psi	Maximum Inbound Fluid			Max. Delivery		Wetted Parts	Manual
			psi	bar	MPa	Single Pump	E-flo DC 2X		
17W739	1 1/2 sanitary	100	300	21	2.1	10 gpm 37.8 lpm	20 gpm 75.7 lpm	304 Stainless Steel, PTFE	3A6103

Part No.	Description
17X733	Repair Kit
18A983	Direct Pump Mount Kit
18A984	Floor / Wall Mount Kit
18A985	Floor Stand Adapter Kit
17X529	Breather Valve Kit

All written and visual data contained in this document are based on the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice.

Call today for product information or to request a demonstration.

877.84GRACO (1-877-844-7226) or visit us at www.graco.com/finishing