


PULSE FC


1

Software Quick Start




Open Starter Kit


1.




2.



Hook-up Card Reader & Install Software



Activate Software




System Settings

File View Settings Help

System

DISPENSES FLUID TOTALS



Create Pulse FC Disable Card

DISABLE PULSE FC A.

DISABLE PULSE FC


GRACO

REUSABLE

Pulse FC compatible devices set to Pulse FC mode can only be used with the PC that created the profile cards

To restore a device to preset mode or move the device to another Pulse FC system, a Disable Pulse FC card is required


Create a Disable Pulse FC Card and keep it somewhere safe with your software activation key!






Configure Fluids


Settings Help
System
Setup
PULS
System
Setup
Pluids
Meter Profiles
Calibration
FLUID TOTALS




Configure Meter Profile Cards



Configure Calibration Cards (optional)




Need 1 card per Meter



Create and Perform a Dispense





Actual Dispense Totals

A. Same as create a dispense.



WARNING

Do not discard, this key is required to use the Pulse FC Software.			
	,		- \
			- 1
			- i
	i		- 1
	1		- 1
	The second secon		- 1
	The second secon		- 1
	T. Control of the Con		-!
	I		- !
	!		- 1
			- 1
			- 1
			i
	X		. /
		Activation Key Sticke	r

DISCOVER THE PULSE DIFFERENCE









for more information visit GracoPulse.com

