# **Instructions–Parts List**

# Nickel-Plated Steel and Aluminum, PTFE Seals LOW-Pressure Ball Valves

500 psi (35 bar, 3.5 MPa) Maximum Fluid Working Pressure


NOTE: npsm threaded ends meet SAE J516 fitting recommendations.

#### Important Safety Instructions

Read all warnings and instructions in this manual. Save these instructions.

# **Table of Contents**

List of Models 1
Nickel–Plated Steel, PTFE Seals
Aluminum, PTFE Seals 1
Warnings 2
Graco Standard Warranty 4
Graco Information 4





# **List of Models**

#### Nickel-Plated Steel, PTFE Seals

Model No.	Series	Thread
208390	A	1/4 npt(m) x 1/4 npt(m)
208391	A	3/8 npt(m) x 3/8 npt(f)
208392	A	3/8 npt(f) x 1/4 npt(m)
208393	A	3/8 npt(m) x 3/8 npt(m)
208475	В	3/8 npt(f) x 1/4 npsm(m)
208476	В	3/8 npt(f) x 3/8 npsm(m)
208630	A	3/8 npt(f) x 1/2 npt(m)
218109	В	3/8 npt(m) x 3/8 npsm(m)

Canadian Registration Number (CRN): Alberta – 0C04874.52 Ontario – 0C4874.5R1

### Aluminum, PTFE Seals

Model No.	Series	Thread
224754	A	1/4 npsm(m) x 1/4 npsm(f) <i>left-hand thread</i>





ΕN

307068V

# Warnings

### Warning Symbol

Ŷ

### WARNING

This symbol alerts you to the possibility of serious injury or death if you do not follow the instructions.

### Caution Symbol

### 

This symbol alerts you to the possibility of damage to or destruction of equipment if you do not follow the instructions.

EQUIPMENT MISUSE HAZARD
Spray from the gun, hose leaks, or ruptured components can splash fluid in the eyes or on the skin and cause serious injury.
To reduce the risk of splashing follow the pressure relief procedure for your equipment before removing the valve.
Do not stop or deflect fluid leaks with your hand, body, glove, or rag.
Equipment misuse can cause the equipment to rupture, malfunction, or start unexpectedly and result in serious injury.
This equipment is for professional use only.
<ul> <li>Read all instruction manuals, warnings, tags, and labels before operating the equipment.</li> </ul>
<ul> <li>Use the equipment only for its intended purpose. If you are uncertain about usage, call your Graco distributor.</li> </ul>
<ul> <li>Do not alter or modify this equipment. Use only genuine Graco parts and accessories.</li> </ul>
Check the equipment daily. Repair or replace worn or damaged parts immediately.
• Never exceed the recommended working pressure of the lowest rated system component. This equipment has a maximum fluid working pressure of 35 bar, 3.5 MPa (500 psi).
• Use only fluids and solvents that are compatible with the equipment wetted parts. See the <b>Technical Data</b> sections of all the equipment manuals. Read the fluid manufacturer's warnings.
<ul> <li>Always wear protective eyewear, gloves, clothing, and respirator as recommended by the fluid and solvent manufacturers.</li> </ul>
• Comply with all applicable local, state and national fire, electrical and other safety regulations.


### **Graco Standard Warranty**

Graco warrants all equipment manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non–Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

#### THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

Graco makes no warranty, and disclaims all implied warranties of merchantability and fitness for a particular purpose in connection with accessories, equipment, materials or components sold but not manufactured by Graco. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

#### FOR GRACO CANADA CUSTOMERS

The parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés à la suite de ou en rapport, directement ou indirectement, avec les procedures concernées.

### **Graco Information**

For the latest information about Graco products, visit www.graco.com.

*TO PLACE AN ORDER*, contact your Graco distributor or call to identify the distributor closest to you: **Phone:** 612–623–6921 or **Toll Free:** 1–800–328–0211 **Fax:** 612–378–3505

All written and visual data contained in this document reflects the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice.

Original inltrultionl. This manual contains English. MM 3007068

Graco Headquarters: Minneapolis International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA

Copyright 1971, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com