

HTX 2030

313890L

- For Portable Airless and Air-Assisted Spraying of Water-Based Architectural Coatings with Base Coat Pump -

For Airless Spraying Architectural Coatings and Paints with Top Coat Pump -



IMPORTANT SAFETY INSTRUCTIONS

Read all warnings and instructions in this manual. Save these instructions.

Model Number: 257369 (HTX2030 FreeFlo Inline Gun)

Model Number: 18B024 (HTX2030 FreeFlo Inline Gun - China Only)

Model Number: 278675 (HTX2030 AirSpray Trigger Gun)
Model Number: 26C681 (HTX2030 STX Gun, 50 ft. Hose)
Model Number: 26C682 (HTX2030 STX Gun, 100 ft. Hose)
Model Number: 26C683 (HTX2030 Plus, STX Gun, 50 ft. Hose)
Model Number: 26C684 (HTX2030 Plus, STX Gun, 100 ft. Hose)
Model Number: 26C697 (HTX2030 w/ Air Manifold, Bare Unit)

Maximum Working Pressure:

Base Coat Pump: 1000 psi (69 bar, 6.9 MPa) **Top Coat Pump:** 3300 psi (228 bar, 22.8 MPa)

Related Manuals:

313888 - Operation (English)

313891 - Operation (French)

313893 - Operation (Spanish)

313889 - Repair (English)

313892 - Repair (French)

313894 - Repair (Spanish)

313895 - HTX 2030 Flex Head and Pole Spray Applicator (English)

313896 - HTX 2030 Flex Head and Pole Spray Applicator (French)

313897 - HTX 2030 Flex Head and Pole Spray Applicator (Spanish)

310894 - Displacement Pump (Top Coat)

308491 - Texture Airless Spray Gun

313537 - HTX 2030 Applicator (English)

313603 - HTX 2030 Applicator (Chinese)

313908 - HTX 2030 Applicator (French)

313911 - HTX 2030 Applicator (Spanish)

332160 - HTX2030 AirSpray Trigger Gun (English)


332227 - HTX2030 AirSpray Trigger Gun (French)

332228 - HTX2030 AirSpray Trigger Gun (Spanish)

332229 - HTX2030 AirSpray Trigger Gun (Chinese)


3A6746 - STX Air Spray Trigger Gun

3A6839 - Air Manifold






Parts



Parts List


			Qty				Qty
Ref.	Part	Description		Ref.	Part	Description	
1		FRAME, cart, HTX 2030	1	45	118444	SCREW, mach, slot hex wash hd	4
2		WASHER, flat	2	63		WASHER, lock	4
3		WHEEL, pneumatic	2	64	112599	SCREW, cap, socket head	4
4		CLIP, retaining	2	70	24B324	PRESSURE CONTROL BOX	1
8		SCREW, mach, pnh	4	75		LABEL, proconnect	1
10		HANDLE, assy	1	76	114678	BUSHING, strain relief	1
11		WIRE, ground assembly w/ clamp	1	83	114271	STRAP, retaining	1
12		SCREW, thread forming, hex hd	1	110	119677	SPRING, retaining	1
14		CAP, leg	2	114		PIN, pump	1
15		ENGINE, GAS, 6.5 hp, Honda	1	122		LABEL, identification	1
		ENGINE, GAS, 6.5 hp, Honda	1	126		LABEL, identification	1
		(China Only)				LABEL, warning	1
16	110837	SCREW, flange, hex	2	133		CLIP, retainer	1
17		NUT, lock	2	134		BUSHING, strain relief	2
18		KEY, parallel	1	146		WASHER, wave spring	2
19		HOUSING, clutch, mach	1	153		SHIELD, cable	1
20		SCREW, cap, hex hd	4	158	24B560	TRANSDUCER, handtight, 5000	1
21		WASHER, lock	4			psi	
22	193680	COLLAR, shaft	1	180		FLUID, TSL, 8 OZ (not shown)	1
23†		SCREW, hex, socket head	6	181		LABEL, Made in the USA	1
24†	105510	WASHER, lock, spring (hi-collar)	10	182		SCREW, flange, hex hd	4
25†		ARMATURE, clutch, 5 in.	1	183		BLOCK, mounting, transducer	1
26†		HUB, armature	1	184		COVER, block, mounting	1
27†		ROTOR, clutch, 5 in.	1			LABEL, caution	1
28†		SCREW, cap, sch	4			LABEL, warning, English	1
29		HOUSING, pinion	1			LABEL, warning, Spanish	1
30		WASHER, thrust	2			LABEL, warning, French	1
31		WASHER, thrust	1			LABEL, warning, Chinese	1
32		GEAR, combination	1	500		KIT, suction, 55 gal. (optional)	1
33		HOUSING, drive	1			GASKET, coupler	1
33a		WASHER, steel	1		187123		1
33b		WASHER, bronze	1	500C	18/119	STRAINER, 1/2 nps	1
35		SCREW, cap, flng hd	1	A D-		4 Danasay and Mayrina Islanta tana	
36	102962	SCREW, cap sch	4			t Danger and Warning labels, tags,	ana
37		WASHER, lock, spring	4	caras	are availa	able at no cost.	
38		SCREW, mach, hex wash hd	6	± 11		lutale Danila a mant Kit 044440	
40		HOUSING, bearing	1	† incli	uaea in C	lutch Replacement Kit 241113.	
43		ROD, connecting	1				
44	28/520	COVER, front	1				

Pressure Control Box 24B324



Ref.	Part	Description	Qty.
70		PRESSURE CONTROL BOX	1
		(includes all parts shown)	
70a	24B574	BOX, control, modified	1
70b	119545	BUSHING, strain, relief	3
70c	257431	CONTROL, board	1
70d	117317	SCREW, plastite, pan head	7
70g	287515	DISPLAY, LCD	1
70h	15E855	LABEL, SmartControl	1
70j	116752	SWITCH, rocker	1
70k	116167	KNOB, pump control	1
70m	15C973	GASKET	1
70n	198650	SPACER, shaft	1
70p	256219	POTENTIOMETR, assembly	1
71	116585	SCREW, pan, cross, recess, sst	2
120	15X746	GASKET, control cover	1
156	122207	HARNESS, switch/jack	1
157	120761	COVER, jack	1
185	113160	SCREW, mach, slot, hex, wash	4
186	15Y262	LABEL, prime switch	1
187	195428	BOOT, toggle	1


Bearing Housing 24B528



Ref.	Part	Description	Qty.
40		HOUSING, bearing	1
40a†	107251	SCREW, panhead	1
40b†	565361	CLAMP, cable	1
40c†		SENSOR, pump	1
40d†	15E625	PIN, housing, bearing	1
40e†	15G890	LATCH, housing, bearing	1
40f†	111040	NUT, lock, hex	2
40g†	15F503	SCREW, set, socket hd	1
40h†	15F498	SCREW, adjustment	1
40j†	15F116	LATCH	1
40k†	15G584	RECEIVER, latch	1
40m†	116942	SCREW, shoulder, sch	1


[†] Included in Bearing Housing 40.

Base Coat Pump




Ref.	Part	Description	Qty.
47	24B321	PUMP, displacement	1
82	15X762	STRAINER, 2 in. npt	1
102	24B572	VALVE, drain, assembly	1
102a	193710	SEAL, seat, valve	1
102b	193709	SEAT, valve	1
102c	107204	O-RING	1
102e	122287	SPRING, drain valve, knob	1
102f	15Y594	HANDLE, black, arrow, marked	1
102g	116424	NUT, cap	1
154	122602	COUPLER, cam, quick, 2 in.	1
155	15X088	EXTENSION, valve, inlet	1
158	24B560	TRANSDUCER, handtight, 5000 psi	1
158b	111710	SEAL, o-ring	1
		(included with transducer 158)	
158c	122500	PACKING, o-ring	1
159	15X943	FITTING, manifold, drain tube	1
160	16C053	MANIFOLD, pump	1
161	15T116	COUPLER, male, cam and groove	1
162	100020	WASHER, lock	4
163	104705	SCREW, cap, sch	4
164	115719	PACKING, o-ring, 015, FKM	1
165	123621	RING, cover, thread 1 npt	1
166	123602	NIPPLE, close 1/2 npt sst	1
167	123622	RING, cover, thread 1/2 npt	1
168	24C750	VALVE, ball, 1/2 npt	1
169	158683	ELBOW, street, 1/2 npt	1

Base Coat Pump 24B321




Ref.	Part	Description	Qty.	Ref.	Part	Description	Qty.		
201	15X090	PISTON ROD	1	217	187064	BALL GUIDE	1		
202	187068	PACKING NUT	1	218	188558*	U-CUP SEAL, poly/fluoroelastomer	1		
203	188560*	V-PACKING, poly	2	219	187072*	V-PACKING, polu	3		
204	187939*	GLAND, male	1	220	102972*	BALL, piston, 0.875 in. ID	1		
205	188557*	O-RING	2	221	187066	CYLINDER	1		
206	187934	PISTON HOUSING	1	223	115719	SEAT, o-ring, manifold	1		
207††	188559*	O-RING fluoroelastomer	1	225	187071*	V-PACKING, poly	3		
208	188434*	NUT	1	226	187070*	GLAND, female	1		
209	188432*	GLAND, male	1	227	15X089	HOUSING, pump	1		
210	188561*		2	232	235962	SEAL, foot valve	1		
211	188433*	GLAND, female	1	235	104705	,	4		
212	188627	BACKUP WASHER, nylon	1	236	100020	WASHER, lock	4		
213	235165	PISTON SEAT	1	*These parts are also included in Repair Kit 235186, which can					
214	187929	LUG NUT	1	be purchased separately.					
215	235963	INTAKE HOUSING	1						
216	102973*	BALL, intake, 1.25 in. ID	1	†† Not used in all revisions of pump.					

Texture Applicator and Hose



			Qty				Qty
Ref.	Part	Description		Ref.	Part	Description	
304	24B327	APPLICATOR, HTX (accessories),	1	320f†	16H087	NUT, switch	2
		Model 257369, see manual		320g	24B561	· • • • • • • • • • • • • • • • • • • •	1
		313537, 313603, 313908, 313911		320h	289874	,	1
306	119394		1	320j	15T116		1
307	112779	VALVE, air, needle	1	320k	. = > / = 0.0	HOSE, fluid, bare	
308	155570		1		15X539		1
309	121591	KNOB, valve	1	000	17S247	100 ft.	1
320		HOSE, texture		320m†		BOOT, switch	1
		(includes 320a-320k)		320n	125058	- - 3/	2
	24B300	50 ft.	1	330	287227	KIT, FineFinish	ı
	17S244	100 ft. (optional)	1	240	040054	(see manual 310617)	4
320a		SLEEVE, hose, shield	1	340	24R054	1 7 55	ı
	24X577	50 ft.	1			Model 278675, (see manual	
	17S245		1	0.4.4	0.40005	332160, 332227, 332228, 332229)	
320b		HARNESS, switch		341	248395	TOOL, cleaning, applicator	1
	15W716		1	342	248515	BALL, sponge, 30 mm (5 pk)	1
		100 ft.	1	343	M70613	BRUSH, cleaning	I
320c†		HOUSING, switch	1	+ Inclus	dad with a	nuitab 220a	
320d†	119236	SCREWS	2	Inclu	ueu wiin s	switch 320g.	
320e†	16H086	U-BOLT	1				

Top Coat Pump Kit 24B140 (Sold Separately)




Ref.	Part	Description	Qty.	Ref.	Part	Description	Qty.
401	100020	-		427	241705	TEXTURE SPRAY GUN (includes	1
_		WASHER, lock	4		211700	LTX531 Switch Tip and guard; see	•
402	104705	SCREW, cap, sch	4				
403	108833	PACKING, o-ring	1	400	0.40707	manual 308491 for parts)	_
404	189920	STRAINER, (1-11 1/2 npsm)	1	428	240797	HOSE, grounded, nylon; 3/8 in. ID;	1
406	115719	PACKING, o-ring, 015, viton	1			cpld 3/8 npsm(fbe); 50 ft (15 m);	
409	118444	SCREW, mach, slot, hex wash hd	1			spring guards both ends; 3300 psi	
410	159239	FITTING, nipple, pip, rdcg	1			(228 bar, 22.8 MPa)	
411	278204	CLIP, spring	1	429	238358	HOSE, whip 1/4 in. x 3 ft	1
413	15X083	MANIFOLD, pump	1	431	159841	BUSHING, 3/8 x 1/4 in. x 3 ft	1
414	15X085	EXTENSION, valve, inlet	1	432	LTX643	SWITCH TIP 643	1
418	241920	DEFLECTOR, threaded	1	433	206994	FLUID, throat seal liquid, 8 oz. (not	1
419	243993	HOSE, drain	1	.00	20000.	shown)	•
420	24B322	PUMP, displacement (see manual	1	434	307765	MSDS, throat seal liquid (not shown)	1
		310894)		404	307703	MODO, Illioat seal liquid (flot showil)	'
421	24B592	VALVE, drain (includes 421a - 421f)	1	▲ Re	nlacemen	nt Danger and Warning labels, tags, a	nd
		see manual 308961			•	able at no cost.	<i>iu</i>
421a	193709	SEAT, valve	1	Carus	are avail	able at 110 cost.	
421b	193710	SEAL, seat, valve	1				
421d	114708	SPRING, compression	1				
421e	15Y594	HANDLE, black	1				
1016	140404		:				

9 313890L

421f 116424

NUT, cap

Texture Applicator and Hose for Sprayers 26C681, 26C682, 26C683, and 26C684



Ref.	Part	Description	Qty.
500	17Y910	GUN	1
501	18A560	HOSE, coupled, 50 ft.	1
	18A558	HOSE, coupled, 100 ft.	1
502	17Z148	HOSE, air/signal, 50 ft.	1
	17Z151	HOSE, air/signal, 100 ft.	1
503	19A983	SPONGE, ball, 25mm, 5-pack	1

Notes	
	_

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

For the latest information about Graco products, visit www.graco.com.

TO PLACE AN ORDER, contact your Graco distributor or call 1-800-690-2894 to identify the nearest distributor.

All written and visual data contained in this document reflects the latest product information available at the time of publication.

Graco reserves the right to make changes at any time without notice.

For patent information, see www.graco.com/patents.

Original instructions. This manual contains English. MM 313890

Graco Headquarters: Minneapolis International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA

Copyright 2009, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.