

Hose Rack Kit for EcoQuip 2 Vapor Abrasive Blast Systems

3A3470B


EN

Kit 17G833



Important Safety Instructions

Read all warnings and instructions in the EcoQuip2 system manual. Save these instructions.



Ref.	Part	Description	Qty.
1	17G827	BRACKET, hose, rack, right	1
2	17G829	BRACKET, hose, rack, left	1
3	128702	PIN, spring, sst	2
4	111218	CAP, tube, square	2
5	C19834	SCREW, cap, socket, hd	8
6	111743	WASHER, flat	20
7	101566	NUT, hex, 3/8 in.	10
8	17G831	HANGER, hose, rack	2
10	C19846	SCREW, cap, socket, hd	2

- 1 Install spring pin (3) centered into hanger (8).
- 2 Lift up, push back, and hook pin (3) in notch on bracket (1) for use.
- 3 Lift up, pull out, and drop down when not in use.

Graco Information

For the latest information about Graco products, visit www.graco.com.

For patent information, see www.graco.com/patents.

**TO PLACE AN ORDER, contact your Graco distributor or call to identify the nearest distributor.
Phone: 612-623-6921 or Toll Free: 1-800-328-0211 Fax: 612-378-3505**

*All written and visual data contained in this document reflects the latest product information available at the time of publication.
Graco reserves the right to make changes at any time without notice.*

Original instructions. This manual contains English. MM 3A3470

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA
Copyright 2014, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com

Revision B, April 2020