

CSP Valve Weld Bracket Kit

3A6585A

EN

Installation support bracket used with CSP Valves for oil and grease lubrication only.




Important Safety Instructions

Read all warnings and instructions in this manual and in the CSP Valve, instruction manual before using the equipment. Save all instructions.

Part No. 25N730

Instructions


1. Weld the bracket (1) to a suitable surface to ensure a secure mounting.
2. Attach injector manifold using screws (2) and washers (3) provided in the kit. Torque screws to 140 in-lbs \pm 10% (16 N•m \pm 10%).



Parts

Ref	Description	Qty
1	BRACKET, weld, CSP	1
2	SCREW, cap, hex head	2
3	WASHER, lock, spring, M6	2

Dimensions



*All written and visual data contained in this document reflects the latest product information available at the time of publication.
Graco reserves the right to make changes at any time without notice.*

Original instructions. This manual contains English. MM 3A6585

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA
Copyright 2018, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com
Revision A, October 2018