

406860E

ΕN

## **XP Hopper Installation Kits**

## 7 and 10 gallon hoppers for gravity feeding material to XP plural component sprayers.



**Important Safety Instructions** Read all warnings and instructions in this manual before using the equipment. Save these instructions.


## 24F376, 7 Gallon Blue Hopper Kit 24F377, 7 Gallon Green Hopper Kit

Ref.	Part	Description	Qty.
1	262479	HOPPER, blue; 24F376	1
	262480	HOPPER, green; 24F377	1
2	124450	CLAMP, spring, constant-tension	1
3	16D376	FITTING, nipple, hex	1
4	24E872	BRACKET	1
5	111192	BOLT, carriage	2
6	100131	NUT, full hex	2
7	100133	WASHER, lock	2
8	16E791	STRAINER; not shown	1
9	110110	SEALANT, pipe, sst, 6 ml; not shown	1

Install clamp on hopper outlet tube before screwing in fitting (3).

A Use anaerobic pipe sealant on threads.


- A Press strainer (8) into the inside of the hopper so that the edge bands bend and form to the hopper walls.
- Adjust height as needed.



## 24Y389, 10 Gallon, Stainless Steel Hopper Kit

Ref.	Part	Description	Qty.
1	17E114	HOPPER, weldment, xtreme	1
2	17G705	BRACKET, hopper xp	1
3	17C692	FITTING, cam/groove, 1.5m, 1-1/2 npt	1
4	120308	FITTING, hose adapter, female	ə 1
5	126939	FITTING, elbow, 90", female, reducing	1
6	111192	SCREW, cap flang hd	2
7	100131	NUT, full hex	2
12	17H067	COVER, hopper, weldment	1
13	15R424	LABEL, a-b identification (not shown)	1

2 Use anaerobic pipe sealant on threads.



ti26735a

All written and visual data contained in this document reflects the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice.

Original instructions. This manual contains English. MM 406860

Graco Headquarters: Minneapolis International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA Copyright 2019, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

> www.graco.com Revision E, July 2019