

# PULSE™

FLUID MANAGEMENT

2

## Register Your Devices


[graco.com](http://graco.com)



Meter









TLM





PAC




# Extender






1. connect power  or 
2. press button 4x in rapid succession
3. solid green light
4. switch on Extender Discovery Mode
  - settings
  - device settings
  - device network
  - Extender Discovery
5. wait  for Discovery process to finish
6. ID of Extender found will be displayed at the end of Extender Discovery

# Remote Extender





1. connect ethernet to a customer network port on the same sub-network as the HUB
  2. power Remote Extender
  3. wait  for Remote Extender to start up and join network
  4. switch on Discovery Mode
    - settings
    - device network
    - Discovery
- NOTE: NOT Extender Discovery
5. wait  for Remote Extender to be found
  6. switch off Discovery Mode


# Switch on Discovery Mode





# Meter



# Tank Level Monitor



1. Press and HOLD  

2.  Pulse™ TLM

3. wait   Pulse™ TLM


4. configure settings in PULSE software (PULSE guide 3)

5. Press 

6. TLM processes a tank reading

  Pulse™ TLM

# Pump Air Control



1. connect power  or  red light on
2. wait  blue light on
3. press and HOLD  until green light comes on
4. release  wait 
5. press and HOLD   all lights on
6. wait  green light off, blue flashing
7. wait  blue light on
8. configure settings in PULSE software (PULSE guide 3)
9. wait  red light off when configured

# Notes

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

## DISCOVER THE PULSE DIFFERENCE



Transparency



Accountability



Integration



Simplicity